YK610XE-1

Arm length 610mm
Maximum payload 10kg

■ Ordering method

YK610XE - 10 -200

RCX340-4

■ Controller

RCX340

Specify various controller setting items. RCX340 ▶ P.566

Note. The return-to-origin method is provided only in the sensor specifications, but not in the stroke end specifications.

■ Specifi	ications					
			X-axis	Y-axis	Z-axis	R-axis
Axis	Arm length		335 mm	275 mm	200 mm	-
specifications	Rotation angle		+/-134 °	+/-152 °	-	+/-360 °
AC servo motor output			400 W	200 W	200 W	200 W
Deceleration mechanism	Transmission method	Motor to speed reducer	Direct-coupled Timir		ng belt	
		Speed reducer to output	Direct-coupled			Timing belt
Repeatability Note 1			+/-0.01 mm		+/-0.01 mm	+/-0.01 °
Maximum speed			8.6 m/sec		2 m/sec	2600 °/sec
Maximum payload			10 kg (Standard specification), 9 kg (Option specifications Note 4)			
Standard cycle time: with 2kg payload Note 2			0.39 sec			
R-axis tolerable moment of inertia Note 3			0.3 kgm²			
User wiring			0.2 sq × 20 wires			
User tubing (Outer diameter)			ф 6 × 3			
Travel limit			1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length			Standard: 3.5 m Option: 5 m, 10 m			
Weight			25 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)
Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions and performing the coarse positioning arch operation.
Note 3. The acceleration coefficient is set automatically in accordance with the tip weight and offset amount for R-axis moment of inertia settings.
Note 4. Maximum payload of option specifications (with user wiring/tubing through spline type) is 9kg.

Note. The movement range can be restricted by adding the X- and Y-axis mechanical stoppers. (The maximum movement range was set at shipment.)
See our robot manuals (installation manuals) for detailed information.

Note. To set the standard coordinates with high accuracy, use a standard coordinate with high accuracy.

Controller | Power capacity (VA) | Operation method

1700

standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below https://global.yamaha-motor.com/business/robot/

YK610XE-10
User wiring connector (Numbers 1 to 12 are usable.) J.S.T. Mfg. Co. Ltd. SM connector: SMR-12VB A-M3 × 0.5 through-hole (No phase relation to R-axis origin.) As this hole is intended for the wiring/tubing clamp, do not attach a large load to it. User tubing 1 (\$\phi\$ black) User tubing 1 (\$\phi\$ black) User tubing 1 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 1 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 1 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 1 (\$\phi\$ black) User tubing 1 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 3 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 1 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 2 (\$\phi\$ feed) User tubing 3 (\$\phi\$ black) User tubing 3 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 3 (\$\phi\$ black) User tubing 3 (\$\phi\$ black) User tubing 1 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 3 (\$\phi\$ black) User tubing 3 (\$\phi\$ black) User tubing 1 (\$\phi\$ black) User tubing 2 (\$\phi\$ feed) User tubing 3 (\$\phi\$ black) User tubing 2 (\$\phi\$ fer tubing 2 (\$\phi\$ fer to installation) Working envelope V-axis mechanical stopper position : 154°
SB ase installation Surface Option User wiring and tubing routed through spline shaft. Cross section A-A SWAMARA 582.5 100 100 100 100 100 100 100 1
20.8 8 20
Keep enough space for the maintenance work at the rear of the base. Option Tool flange mount type View of C

No entry: None F: With tool flange S: With hollow shaft

Standard type: Medium type **OLOW COST HIGH PERFORMANCE MODEL**

Programming / Remote command / Operation

using RS-232C communication