

YAMAHA  
**ROBOT**  
CATALOG 2016/2017

- YA
- LCM100
- TRANSERVO
- FLIP-X
- PHASER
- XY-X
- YK-X
- YP-X
- CLEAN
- CONTROLLER

# FULL LINEUP

## ARTICULATED ROBOTS

### YA Series

Features P. 6  
Specifications P.107

#### 6-axis

YA-RJ  
YA-R3F  
YA-R5F  
YA-R5LF  
YA-R6F



▶ P.109

#### 7-axis

YA-U5F  
YA-U10F  
YA-U20F



▶ P.114

Controller for use with  
the YA series  
YAC100



▶ P.117

## LINEAR CONVEYOR MODULES

### LCM100

Features P.8  
Specifications P.119

LCM100-4M/3M/2MT  
(Linear module)



▶ P.120

LCM100-4B/3B  
(Belt module)



▶ P.120

Controller LCC140 for Linear  
module



▶ P.126

## CLOSED LOOP STEPPING MOTOR SINGLE-AXIS ROBOTS

### TRANSERVO Series

Features P.14  
Specifications P.127

SS Type (Slider type)  
Straight model/Space-saving model

SS05H-S SS05H-R (L)  
SS05-S SS05-R (L)  
SS04-S SS04-R (L)



▶ P.130

SG Type (Slider type)

SG07



▶ P.136

SR Type (Rod type)  
Straight model/Space-saving model

SR05-S SR05-R (L)  
SR04-S SR04-R (L)  
SR03-S SR03-R (L)



▶ P.137

SR Type (Rod type with support guide)  
Straight model/Space-saving model

SRD05-S SRD05-U  
SRD04-S SRD04-U  
SRD03-S SRD03-U



▶ P.140

STH Type  
(Slide table type)  
Straight model/  
Space-saving model

STH04-S STH04-R (L)  
STH06-S STH06-R (L)



▶ P.150

RF Type  
(Rotary type)  
Standard model/  
High rigidity model

RF02  
RF03  
RF04



▶ P.154

BD Type  
(Belt type)  
Straight model

BD04  
BD05  
BD07



▶ P.166

## LINEAR MOTOR SINGLE-AXIS ROBOTS

### PHASER Series

Features P.30  
Specifications P.215

MF Type Long stroke & high-power using flat motor with core

■ Double Carriages Standard on all Modules

MF7/7D  
MF15/15D  
MF20/20D  
MF30/30D  
MF75/75D



MF15



MF20



MF30D



MF75

▶ P.218

MR Type Shaft motor drive is compact and lightweight

■ Double Carriages Standard on all Modules

MR12/12D



MR12

▶ P.236

## CARTESIAN ROBOTS

### XY-X Series


Features P.34  
Specifications P.239

PXYx



▶ P.250

FXYx



▶ P.252

FXYBx



▶ P.258

SXYx



▶ P.264

SXYBx



▶ P.282

MXYx



▶ P.300

NXY



▶ P.290

NXY-W



▶ P.296

HXYx



▶ P.310

HXYLx



▶ P.316

## SINGLE-AXIS ROBOTS

### FLIP-X Series

Features P.20  
Specifications P.169

T type Frame-less structure model

T4L/T4LH  
T5L/T5LH  
T6L  
T9/T9H



▶ P.174

F type / GF type  
High rigidity frame model

F8/F8L/F8LH/F10/F10H/F14/F14H/  
F17/F17L/F20/F20N  
GF14XL/GF17XL




F8

GF14XL ▶ P.181

N type Nut rotation type model

N15/N18  
N15D/N18D  
(Double carriage)



N15

▶ P.198

R type Rotation axis type model

R5  
R10  
R20



R5

▶ P.212

B type Timing belt drive model

B10  
B14/B14H



B10

▶ P.206



## SCARA ROBOTS

### YK-TW Series / YK-XG Series / YK-XR Series YK-XGS / YK-XGP

Features P.38

Specifications P.367

#### Orbit type (Omni directional) [YK-TW]

Arm length: 350mm/500mm  
Maximum payload: 5kg

YK350TW  
YK500TW



YK500TW

▶P.370

#### Tiny (ultra-small) type [YK-XG]

Arm length: 120mm to 220mm  
Maximum payload: 1kg

YK120XG  
YK150XG  
YK180XG  
YK180X  
YK220X



YK180XG

▶P.374

#### Small type [YK-XG]

Arm length: 250mm to 400mm  
Maximum payload: 5kg

YK250XG  
YK350XG  
YK400XG



YK400XG

▶P.379

#### Small type [YK-XR]

Arm length: 400mm  
Maximum payload: 3kg

YK400XR



YK400XR

▶P.385

#### Medium type [YK-XG]

Arm length: 500mm to 600mm  
Maximum payload: 5kg to 20kg

YK500XGL/XG  
YK600XGL/XG/XGH



YK500XGL

▶P.386

#### Large type [YK-XG/YK-X]

Arm length: 700mm to 1200mm  
Maximum payload: 20kg to 50kg

YK700XG/XGL  
YK800XG  
YK900XG  
YK1000XG  
YK1200X



YK1200X

▶P.393

#### Wall-mount / inverse type [YK-XGS]

Arm length: 300mm to 1000mm  
Maximum payload: 20kg



YK500XGS

▶P.399

#### Dust-proof & drip-proof type [YK-XGP]

Arm length: 250mm to 1000mm  
Maximum payload: 20kg



YK250XGP

▶P.409

## PICK & PLACE ROBOTS

### YP-X Series

Features P.46

Specifications P.427

#### 2 axes type

YP220BX  
YP320X



YP220BX

▶P.429

#### 3 axes type

YP220BXR  
YP320XR  
YP330X



YP220BXR

▶P.431

#### 4 axes type

YP340X



YP340X

▶P.434

## CLEAN ROBOTS

### CLEAN Type

Features P.48  
Specifications P.435

#### Single-axis robots

SSC04/05/05H  
C4L/C4LH/  
C5L/C5LH/C6L  
C8/C8L/C8LH  
C10/C14/C14H  
C17/C17L/C20



C14

▶P.439

#### Cartesian robots

SXYxC  
SXYxC (ZSC12)  
SXYxC (ZSC6)  
SXYxC (ZRSC12)  
SXYxC (ZRSC6)



SXYxC

▶P.456

#### SCARA robots

YX180XC/ YK700XC/  
YK220XC/ YK800XC/  
YK250XGC YK1000XC  
YK350XGC/  
YK400XGC/  
YK500XGLC  
YK500XC/  
YK600XGLC/  
YK600XC/



YK250XGC

▶P.462

## ROBOTS CONTROLLER

### Controllers

Features P.52  
Specifications P.479

#### Single axis Robot positioner



TS-S2  
TS-SH

TS-X  
TS-P

▶P.490

#### Single axis Robot driver

<pulse train input only>



TS-SD

RDV-X  
RDV-P

▶P.500

▶P.504

#### Single axis Robot controller

<small servo 24V · 30W>



ERCD

▶P.510

#### Single axis Robot controller



SR1-X  
SR1-P

▶P.516

#### 1 to 2 axis Robot controller



RCX221

RCX222

▶P.524

#### 1 to 4 axes Robot controller



RCX240  
RCX240S

RCX340

▶P.532

## ROBOT VISION Robot with image processing functions


### iVY System

Features P.72

### iVY2 System

Features P.78


A robot-integrated vision system



RCX240 + iVY  
iVY board

- Lighting control board
- Tracking board

▶P.572



RCX340 + iVY2

Tracking board iVY2 unit

▶P.576

## ELECTRIC GRIPPER

### YRG Series

Features P.86  
Specifications P.582



YRG-4225S

YRG-2810W

YRG-2840FS

YRG-2820T

▶P.583

# YAMAHA ROBOT

## History and approach

### 30 years of proven reliability.

YAMAHA's robot development started as it was introduced in our motorcycle production line more than 30 years ago.

Since then, YAMAHA's industrial robots have supported production equipment in a wide variety of industries, such as assembly of electronic products, transfer of in-vehicle components, and manufacture of large-scale LCD panels.

Over the years YAMAHA has striven to develop and improve the market and this is a testament to YAMAHA's reliability.



### Technical development based on the originally developed technologies and focusing on the needs of the market

"Motor control technology" absolutely necessary for precise and high-speed operation "Controller development technology" is based on the highest evaluation standards and Signal processing technology allowing stable operation even under extreme environmental conditions.

Rigidity, durability, and operability are features of YAMAHA's products base on "Coretechnologies"

\*Control boards, linear motors, and linear scales (position detectors), etc.



### Evaluation system provides high reliability

YAMAHA continues to evaluate technology to assure product reliability.

In the product development phase, the evaluation test at "anechoic chamber" (YAMAHA's equipment) was developed to ensure the high reliability and quality.

\*Anechoic chamber: This equipment is intended to synthetically develop the EMC (Electro-Magnetic Compatibility) technologies for YAMAHA Group products and to share the developed technologies. This equipment can evaluate the compliance with each country's regulation in conformity with the international standards.



### YAMAHA quality ensuring safety

Manufacturing, sales, and technology integrated system is utilized at its maximum level to establish a system that consistently performs a series of processes: inspection → manufacture → assembly → inspection → shipping. This can provide the customers with high quality, low price, and short delivery time.

Key components are manufactured through in-house processing and machining. YAMAHA as a robot manufacturer builds the components to the highest quality level.

Furthermore, the quality control based on the severe standards achieves the craftsmanship with high quality.



# ALL YOU

Only Yamaha can provide a  
We provide the best solution

#### Orbit type robots YK-TW


High-speed transfer processing

Ideal for narrow or limited space

#### Integrated robot vision iVY2 SYSTEM

Verify workpiece positioning

Unified control with only the robot program



#### Linear conveyor modules LCM100-4M/3M

Multi-step production lines

Shorten transport time and save space

#### Belt modules

#### LCM100-4B/3B

Slider return

Reduce facility cost

SPECUP

Major improvements

Linear conveyor module

#### LCM100



Repeat positioning accuracy

Width 100μm

±0.015mm

(single slider)

width 0.1mm

(mutual difference among all sliders)

Max. payload

5kg

15kg

Reduced slider no-stop zone

65mm

6mm

# ASSEMBLE

unified lineup from miniature actuators to articulated robots.  
for a wide range of automation.

**Cartesian robots (2-axis to 6-axis)**  
**XY-X Series**

Sealing work

High-rigidity guide ensures long life

**Single-axis AC servo motor robot**  
**FLIP-X Series**

Board inspection work

A wide range of general-purpose robots

**Linear motor single-axis robots**  
**PHASER Series**

For long-distance or high-mass transport

**Closed loop stepping motor single-axis robots**  
**TRANSERVO Series**

Low-cost positioning equipment

**Scara robots**  
**YK-XG Series**

Pick and place work

Completely beltless design for high rigidity and high precision

**Articulated robots (6-axis · 7-axis)**  
**YA Series**


Variable-orientation workpiece assembly work

Allows more complex work

**Circulation module**  
**LCM100-2MT**

"Insert" and "eject" sliders

Reduce the number of steps for design and execution



**NEW**

## New products

Articulated robots

**YA Series**



P.6

Belt modules

**LCM100-4B/3B**



P.8

Single-axis robots

**F10H**



P.186

Orbit type robots

**YK350TW**



P.370

Scara robots

**YK700XGL**



P.393

Robot driver



**RDV-X / RDV-P**



P.504


# ARTICULATED ROBOTS

Ideal for compact cell construction, transport and assembly of small parts, and inspection work.



## 6-axis robots

- S-axis:** Rotate the body horizontally
- L-axis:** Move the body forward/backward
- U-axis:** Move the arm up/down
- R-axis:** Rotate the arm
- B-axis:** Move the tip of the arm up/down
- T-axis:** Rotate the tip of the arm



## 7-axis robots


- S-axis:** Rotate the body horizontally
- L-axis:** Move the body forward/backward
- E-axis:** Twist the arm
- U-axis:** Move the arm up/down
- R-axis:** Rotate the arm
- B-axis:** Move the tip of the arm up/down
- T-axis:** Rotate the tip of the arm

# Reduce personnel, increase productivity

## 6-axis



## 7-axis



Type	Model	Application	Number of axes	Payload (kg)	Vertical reach (mm)	Horizontal reach (mm)	Page
6-axis	YA-RJ	Handling (general)	6-axis	1 kg (max. 2 kg <sup>Note</sup> )	909	545	P.109
	YA-R3F			3	804	532	P.110
	YA-R5F			5	1193	706	P.111
	YA-R5LF			5	1560	895	P.112
	YA-R6F			6	2486	1422	P.113
7-axis	YA-U5F	Assembly / Placement	7-axis	5	1007	559	P.114
	YA-U10F			10	1203	720	P.115
	YA-U20F			20	1498	910	P.116

Note. When a load is more than 1 kg, the motion range will be smaller. Use the robot within the recommended motion range.

### POINT

#### High-speed operation reduces cycle time

Thanks to high-speed, low-inertia AC servo motors, an arm designed for light weight, and the latest control technology, these robots achieve an operating speed that is best in their class. From supply, assembly, inspection, and packing to palletization, all applications can enjoy shorter cycle time and improved productivity.


#### Workpieces with a high wrist load are also supported

With a wrist section that has the highest allowable moment of inertia in its class, these robots can support jobs involving a high wrist load, or simultaneous handling of multiple workpieces.

#### Robot simulator dramatically reduces startup time

We provide software that lets you use 3D CAD data to construct a production facility in virtual space in a personal computer, and easily perform engineering tasks such creating programs and checking for robot interference. Teaching can be performed even before the actual production line is completed, dramatically reducing line startup time.

Note. Optional support



## Free arm movement further boosts productivity.

#### 7-axis Reduced space allows sophisticated system layouts


Since these robots can be installed close to workpieces or other equipment, you can reduce the space required for your production facility. By locating multiple robots close to each other, processing can be integrated and shortened.

#### 7-axis Access the workpiece from the opposite side or from below

Rotation of the seventh axis enables flexible movement with the same freedom of motion as a human arm, allowing the workpiece to be accessed from the opposite side or from below. This allows the robot to enter narrow locations that a person could not fit in, or to approach the workpiece in a way that avoids obstructions, giving you more freedom to design the layout for shorter cycle time and reduced space.

#### 7-axis "Elbow movement" unique to 7-axis models allows optimal posture to be maintained

The 7-axis U-type robots allow "elbow movement," changing only the elbow angle without affecting the position or posture of the tool. This permits operation to avoid nearby obstructions.




LCM100

Product Lineup

# LINEAR CONVEYOR MODULES

From "flow" to "move"

Efficient transfer processes for increased profitability



Linear conveyor module LCM100





Note. As the figure shown above illustrates CG images, they are different from the actual product.



# Linear Conveyor Module LCM100

## Constructing high-speed throughput lines.



### High-speed and high-accuracy transfer


- Max. speed: **3000mm/sec**
- Max. acceleration: **2G**
- Max. load mass: **15kg**
- Repeated positioning accuracy: **±0.015mm (standalone slider)** <sup>Note</sup>

Note. This is the repeated positioning accuracy for a standalone slider when positioning from one direction (single-side approach).  
 Note. The positioning accuracy for the single-side approach after correction by RFID is 0.1 mm including the mutual difference between sliders.

### POINT

## Increase productivity by shortening transport time

- Comparison between LCM100 and a conventional conveyor





# The length of the transfer line can be adjusted freely by adding modules.

**POINT**

## Save equipment space.


- Since the movement direction can be changed, the same processes are made common. This makes the equipment compact and results in cost reduction.
- Forward and backward movement at a high speed can be set freely.
- Flexible actions such as moving only some sliders backward is possible.



**POINT**

## Can be moved efficiently between processes with different tacts



- Narrow pitch movement is possible.
- Movement time can be reduced by combining the use of different movements, such as using pitch-feed for the same processes in short-time processes while transferring three workpieces at the same time at a high speed in long-time processes.



**POINT**

## Workpieces do not need to be retracted


- As the work moves down, you can assemble and process them on the transfer line.
- Eliminates having to retract the work from the pallet to the work table.
- Reduces costs.



**POINT**

**Significant reduction of start-up time**

- Just connect modules for easy construction of a transfer line.
- Lifting cylinders, sensors, stoppers, and other complex parts are not necessary.
- Operations can be performed by using only the LCC140 Controller.
- Economical as excess modules can be used for other lines or stored for maintenance.




**POINT**


**Construct branching lines, joint lines, and other lines in flexible configurations.**

- Layout examples by combining modules with circulation mechanisms


**Example of horizontal circulation**



**Example of horizontal branching**



**Example of vertical circulation**





Note. The customer needs to prepare the return unit and the circulation mechanism.  
Note. Modules convenient for the circulation are configured.


**POINT**

**Optimal for small batch production of various product types**

- No need for mechanical stoppers or sensors. Change layout easily.
- Reconstruction can be finished quickly by just changing the program to set a stop position.
- Frequent unit changes for different models can be handled flexibly.



**Flexible set-up of the slider's acceleration/deceleration, forward/backward movement, positioning, and other actions. The variety of possible line structures has been greatly expanded to supersede conventional models.**



**Optimum line length design**

Stroke variation [640 mm/480 mm]  
The optimum design can be achieved by combining multiple modules to reduce line length.

**Linear module**

**Belt module**

**Circulation modules are also available**

**Simpler design and fewer processing steps**

- LCM100-2MT, a module for circulation, is available to insert or eject a slider into or out of a line.
- Also can be used for a return mechanism.

We welcome consultations on proposals for customized design, design drawing presentation, etc., to create return units best fitting your request. For details, contact our sales representatives.

**Belt modules can be selected to your needs**

**Genuine new Yamaha belt modules are included in the lineup.**

- Low price.....Using modules only for return processes and interprocess transfer will help reduce the facility cost.
- Easy control without controllers and no need to create robot programs

**POINT**

**Quick recovery by replacing the slider when machine trouble occurs**

- Parts can be replaced easily.
- Parts can be kept for maintenance as they are standardized.
- Possible to minimize the downtime of a production line.



**POINT**

**Easy maintenance**

- Motors and scales do not make contact and are free from abrasion.
- As only the rails are sliding parts, dust generation is low.
- There are only a few consumable parts, which mean a long service life.



## System configuration diagram (when 3 sliders are connected)


The module is standardized and can also be stored for maintenance.

If a short line is used and modules are in excess, they can be diverted to another line or stored for maintenance.



Standardized slider

The slider is standardized and can be used for any line. It is also possible to share the slider on multiple lines. Production can be restored immediately by replacing a failed slider if trouble occurs.




Controller is replaceable

The connected controller and module combinations can be changed as needed. Note that initial setting is required when a combination is changed. Replacing just the controller or the module is also possible.



## Belt module



This interface allows the customer to supply 24V power and select just the necessary signals to use.<sup>Note</sup>  
 Note. The customer will need to prepare the wiring on the user side.

## Linear module controller LCC140

Program operation

The LCC140 controller can perform operations using registered programs and operations using remote commands from the PLC.

In addition to the control of input/output signals such as movement or positioning, processes related to the insertion/ejection of sliders can be performed.

Controller-linking function

You can use the link cables dedicated to LCC140 controllers to connect the controllers when two or more modules are connected. You can handle multiple controllers as if they were one controller.

SR1 controller base operation system

The same user interface as the SR1 controller is incorporated, and specifications and functions specific to the linear conveyor module have been added based on this user interface. A very user friendly operation system is provided.<sup>Note 1</sup>

Position correction function using RFID

When multiple sliders are each stopped at a position of your choice, actual stop positions has an error width (machine difference) of 500  $\mu\text{m}$ . This is because each slider has a different stopping accuracy. Link the RFID unit and LCC140 controller to suppress the machine difference of individual sliders to an error width of approximately 100  $\mu\text{m}$ .<sup>Note 2</sup>



Note 1. Please note that some Yamaha single-axis controller SR1 functions are not available with the linear conveyor controller.  
 Note 2. All sliders stop within the width of 100 $\mu\text{m}$  that includes a teaching point.

# TRANSERVO Series

Product Lineup

## CLOSED LOOP STEPPING MOTOR SINGLE-AXIS ROBOTS

Excellent characteristics of both stepping motor and servomotor were combined. Stepping motor single-axis robots "TRANSERVO" series breaking through existing conventions.



### Robot positioner TS-S2/TS-SH

P.490

This robot positioner is specialized for the I/O point trace input. The positioning or pushing operation can be performed using simple operation, only by specifying a point number from the host control unit and inputting the START signal.

Applicable models:



Note. SG07 is only applicable to TS-SH.



TS-S2 TS-SH

### Robot driver TS-SD

P.500

This robot driver omits the operation with robot languages and is dedicated to the pulse train input. This driver can be made applicable to the open collector method or line driver method using the parameter setting and signal wiring. So, you can match the robot driver to the host unit to be used.

Applicable models:



Note. Except for STH vertical specifications and RF sensor specifications.



TS-SD

# Newly developed vector control method provides functions and performance similar to servomotors.

## SS type (Slider type)

**Straight model** P.130



SS05H-S

**Space-saving model (Side mounted motor model)** P.131



SS05H-R (L)

## SG type (Slider type)

**Straight model** P.136



SG07

## SR type (Rod type standard)

**Straight model** P.137



SR05-S

SR04-S

SR03-S

**Space-saving model (Side mounted motor model)** P.138



SR05-R (L)

SR04-R (L)

SR03-R (L)

## SR type (Rod type with support guide)

**Straight model** P.140



SRD05-S

SRD04-S

SRD03-S

**Space-saving model (Side mounted motor model)** P.141



SRD05-U

SRD04-U

SRD03-U

Type	Model	Size (mm) <sup>Note 1</sup>	Lead (mm)	Maximum payload (kg) <sup>Note 2</sup>		Maximum speed (mm/sec.) <sup>Note 3</sup>	Stroke (mm)	Page
				Horizontal	Vertical			
SS type (Slider type) Straight model/ Space-saving model	SS04-S SS04-R (L)	W49 × H59	12	2	1	600	50 to 400	SS04-S: P.130 SS04-R (L): P.131
			6	4	2	300		
			2	6	4	100		
	SS05-S SS05-R (L)	W55 × H56	20	4	-	1000	50 to 800	SS05-S: P.132 SS05-R (L): P.133 SS05H-S: P.134
			12	6	1	600		
			6	10	2	300		
SS05H-S SS05H-R (L)	W55 × H56	20	6	-	1000	50 to 800	SS05H-S: P.134 SS05H-R (L): P.135	
		12	8	2	600 (Horizontal) 500 (Vertical)			
SG type (Slider type)	SG07	W65 × H64	20	36	4	1200	50 to 800	SG07: P.136
			12	43	12	800		
			6	46	20	350		
SR type (Rod type standard) Straight model/ Space-saving model	SR03-S SR03-R (L) SR03-U	W48 × H56.5	12	10	4	500	50 to 200	SR03-S: P.137 SR03-R (L): P.138 SR03-U: P.139
			6	20	8	250		
			12	25	5	500		
	SR04-S SR04-R (L)	W48 × H58	6	40	12	250	50 to 300	SR04-S: P.142 SR04-R (L): P.143
			2	45	25	80		
			12	50	10	500		
	SR05-S SR05-R (L)	W56.4 × H71	6	55	20	150	50 to 300	SR05-S: P.146 SR05-R (L): P.147
			2	60	30	50		
			12	10	3.5	500		
SR type (Rod type with support guide) Straight model/ Space-saving model	SRD03-S SRD03-U	W105 × H56.5	6	20	7.5	250	50 to 200	SRD03-S: P.140 SRD03-U: P.141
			12	25	4	500		
			6	40	11	250		
	SRD04-S SRD04-U	W135 × H58	2	45	24	80	50 to 300	SRD04-S: P.144 SRD04-U: P.145
			12	50	8.5	300		
			6	55	18.5	150		
	SRD05-S SRD05-U	W157 × H71	2	60	28.5	50	50 to 300	SRD05-S: P.148 SRD05-U: P.149
			12	60	28.5	50		

Note 1. The size shows approximate maximum cross sectional size.

Note 2. The payload may vary depending on the operation speed. For details, refer to the detailed page of relevant model.

Note 3. The maximum speed may vary depending on the transfer weight or stroke length. For details, refer to the detailed page of relevant model.

■ Allowable ambient temperature for robot installation

SS/SR type 0 to 40 °C

As the slide table type, rotary type, and belt type were added to the product lineup, the design flexibility was extended.

### STH type (Slide table type)

Straight model

P.150

Space-saving model

P.151



STH04-S  
STH06-S



STH04-R (L)  
STH06-R (L)

Type	Model	Size (mm) <sup>Note 1</sup>	Lead (mm)	Maximum payload (kg) <sup>Note 2</sup>		Maximum speed (mm/sec.) <sup>Note 3</sup>	Stroke (mm)	Page
				Horizontal	Vertical			
STH type (Slide table type) Straight model/ Space-saving model	STH04-S	W45 × H46	5	6	2	200	50 to 100	STH04-S: P.150
	STH04-R (L) <sup>Note 4</sup>	W73 × H51	10	4	1	400		STH04-R (L): P.151
	STH06	W61 × H65	8	9	2	150	50 to 150	STH06: P.152
	STH06-R (L)	W106 × H70	16	6	4	400		STH06-R (L): P.153

### RF type (Rotary type)

Standard model

P.154

High rigidity model

P.155



RF02  
RF03  
RF04

Type	Model	Height (mm)	Torque type	Rotation torque (N · m)	Maximum pushing torque (N · m)	Maximum speed (mm/sec.) <sup>Note 3</sup>	Rotation range (°)	Page
RF type (Rotary type) Standard/High rigidity	RF02-N	42 (Standard)	N: Standard	0.22	0.11	420	310 (RF02-N)	RF02-N: P.154
	RF02-S	49 (High rigidity)	H: High torque	0.32	0.16	280	360 (RF02-S)	RF02-S: P.157
	RF03-N	53 (Standard)	N: Standard	0.8	0.4	420	320 (RF03-N)	RF03-N: P.158
	RF03-S	62 (High rigidity)	H: High torque	1.2	0.6	280	360 (RF03-S)	RF03-S: P.161
	RF04-N	68 (Standard)	N: Standard	6.6	3.3	420	320 (RF04-N)	RF04-N: P.162
	RF04-S	78 (High rigidity)	H: High torque	10	5	280	360 (RF04-S)	RF04-S: P.165

### BD type (Belt type)

Straight model

P.166



BD04  
BD05  
BD07

Type	Model	Size (mm) <sup>Note 1</sup>	Lead (mm)	Maximum payload (kg) <sup>Note 2</sup>		Maximum speed (mm/sec.) <sup>Note 3</sup>	Stroke (mm)	Page
				Horizontal	Vertical			
BD type (Belt type)	BD04	W40 × H40	48	1	-	1100	300 to 1000	BD04: P.166
	BD05	W58 × H48	48	5	-	1400	300 to 2000	BD05: P.167
	BD07	W70 × H60	48	14	-	1500	300 to 2000	BD07: P.168

Note 1. The size shows approximate maximum cross sectional size.

Note 2. The payload may vary depending on the operation speed. For details, refer to the detailed page of relevant model.

Note 3. The maximum speed may vary depending on the transfer weight or stroke length. For details, refer to the detailed page of relevant model.

Note 4. STH04-R (L) with 50-stroke and brake is not supported.

■ Allowable ambient temperature for robot installation

STH/RF/BD type 5 to 40 °C




# Common features of TRANSRVO Series

## POINT 1

### New control method combining the advantages of both the servomotor and stepping motor

The stepping motor provides features that its price is less expensive and hunting (minute vibration) does not occur during stopping. However, this motor has disadvantages that the positional deviation due to step-out occurs (in the open loop mode), the torque decreases greatly in the high speed area, and the power consumption is large during stopping. As YAMAHA's TRANSERVO uses the closed loop control, this ensures complete "no step-out". Furthermore, use of a newly developed vector control method ensures less torque decrease in the high speed area, energy saving, and low noise. The function and performance equivalent to the servomotor are achieved at a low cost even using the stepping motor.



### Energy saving

As the basic control is the same as the servomotor, waste power consumption is suppressed. This greatly contributes to the energy saving and CO<sub>2</sub> reduction.

### No hunting during stopping

Stop mode without hunting can be set in the same manner as the general stepping motor. So, select this mode as required.

## POINT 2


### Closed loop control using excellent environment resistant resolver

A resolver with excellent reliability is used to detect the motor position in the same manner as YAMAHA's upper model. The stable position detection can be made even in a poor environment where fine particle dusts or oil mists exist. Additionally, a high resolution of 20480 pulses per revolution is provided.



This resolver is a magnetic position detector. The resolver features a simple structure without using electronic components and optical elements, and less potential failure factors when compared to general optical encoders.


The resolver has **high environment resistance and low failure ratio**, and is used in a wide variety of fields aiming at reliability such as automobile or aircraft industry.



## POINT 3

### High resolution (4096, 20480 pulse/rev)

Use of a high resolution makes it possible to maintain excellent controllability. Variations in speed are small and settling time during deceleration stop can be shortened.



## POINT 4

### Return-to-origin is not needed to shorten the start-up time.

New type robot positioner TS-SH applicable to the high power was newly developed.

This robot positioner is applicable to the absolute position system and does not need any return-to-origin.

The work can be started quickly to shorten the start-up time.



TS-SH

**SS type (Slider type) Straight model/Space-saving model**

**POINT**

**4-row circular arc groove type 2-point contact guide applicable to even large moment load**



A newly developed module guide is employed with a 4-row circular arc groove type 2-point contact guide built into a very compact body similar to the conventional model. This guide maintains a satisfactory rolling movement with less ball differential slip due to its structure even if a large moment load is applied or the installation surface precision is poor, and has characteristics that are difficult to malfunction, such as unusual wear.

**Conventional model**

■ 2-row gothic arch groove type 4-point contact guide

If a large moment load is applied or the installation surface precision is poor, a large differential slip may occur easily.

**TRANSERVO (SS type)**

■ 4-row circular arc groove type 2-point contact guide



Differential slip is small due to its structure and service life is long.

**POINT**

**Tact is shortened by high-speed movement.**

As advantages of the vector control method are utilized at maximum level, the TRANSERVO maintains a constant payload even in a high-speed range. This greatly contributes to shortening of the tact time. Additionally, by combining this feature with high-lead ball screws, the TRANSERVO has achieved a maximum speed of 1 m/sec.<sup>Note</sup> which is faster than any single-axis servo motor.

Note. SS05-S/SS05H-S with 20 mm-lead specifications



**SG type (Slider type)**

**POINT**

**Maximum payload is 46 kg. A maximum payload of 20 kg is supported even with the vertical specifications.**

As rigid table slide and 56 □ motor are adopted, the payload is increased greatly. A maximum payload of 46 kg is achieved. Up to 20 kg can be transferred even with the vertical specifications.

**SS05H**

Maximum payload 12 kg

**SG07**


Maximum payload 46 kg

Payload is increased about 4 times.

**POINT**

**Maximum speed is 1200 mm/sec.**

The maximum speed is made 1.2 times faster than that of the current model SS05H. The tact-up of the equipment can be achieved.



**SR type (Rod type) Standard model/Model with support guide**

**POINT**

**Long-term maintenance free is achieved.**

A lubricator used in the ball screw and a contact scraper installed at the rod inlet and outlet provide maintenance-free operation.

**Maintenance interval is greatly extended.**

Normal grease lubrication on the ball screw loses a very small amount of oil as the ball screw moves. The SR type has a lubricator that supplies grease lost over long periods to greatly extend the maintenance interval and ensure near maintenance-free operation<sup>Note</sup>.

Note. The maintenance-free period is within the running life of the robot.

**Highly reliable resolver is used.**


A resolver with excellent environment resistance is used for the position detector. All models can select brake specifications.

**Ball screw lubricator**

A lubricator with high density fiber net impregnated with grease supplies an adequate amount of oil to appropriate locations.

**Laminated type contact scraper**

A dual-layer scraper removes fine foreign objects sticking to the rod to prevent them from entering the inside and troubles caused by foreign objects. Rod rattle is suppressed effectively.



## Environment-friendly lubrication system

The lubrication system is environment-friendly as it uses a high density fiber net and supplies an adequate amount of oil to appropriate locations to eliminate waste lubrication.

## Prevention of foreign object entry


The dual-layer scraper is in contact with the front of the rod to ensure excellent fine contaminant particle removal performance. The scraper removes fine contaminant particles sticking to the rod through multi steps to prevent them from entering the inside and troubles caused by foreign objects. Additionally, oleo-synthetic foam rubber with a self-lubricating function ensures low-friction resistance.

### ■ Tip nozzle for grease application

When applying the grease to the ball screw of the SR type space-saving model SR03-UB or SRD03-UB, use a grease gun with the tip bent.

Model	KCU-M3861-00
-------	--------------

Note: YAMAHA's recommended product. This tip nozzle can be attached to a generally available grease gun.




## STH type (Slide table type) Straight model/Space-saving model

### POINT

### Use of a circulation type linear guide achieves the high rigidity and high accuracy.

- Guide rail is integrated with the table.
- Table deflection amount is small.
- Use of a circulation type linear guide achieves the high rigidity and high accuracy.
- STH06 provides an allowable overhang exceeding that of FLIP-X series T9.
- Space-saving model with the motor built-into the body is also added to the product lineup.
- Suitable for precision assembly.




## RF type (Rotary type) Standard model/High rigidity model

### POINT

### Rotation axis model, first in TRANSERVO series

- Rotation axis model, first in TRANSERVO series
- Thin and compact
- Can be secured from the top or bottom surface.
- Hollow hole, through which the tool wiring is passed, is prepared.
- Workpiece can be attached easily.
- Motor is built-into the body to achieve the space-saving.
- Standard model or high rigidity model can be selected.



## BD type (Belt type) Straight model

### POINT

### Belt type applicable to long stroke

- Applicable to up to 2000 mm-stroke.
- High speed movement at a speed of up to 1500 mm/sec. can be made.
- Maximum payload 14 kg
- Main body can be installed without disassembling the robot.
- Shutter is provided as standard equipment. This prevents grease scattering or entry of foreign object.



# FLIP-X Series

Product Lineup

## SINGLE-AXIS ROBOTS

General-purpose single-axis robots can be used for various applications, such as assembly and inspection work.

6 types and 29 models ranging from compact size to long-stroke robots are available.



**Various custom specifications are also supported.**

Various custom specifications, such as double-slider and wide slider are also supported.  
For details, please consult YAMAHA.


# Six types with high reliability and durability

## T type Frame-less structure model P.174



- Double appeal of compact body and low price.
- Ideal in applications as an actuator directly installed on an installation base.

## F type Model with high rigidity frame P.181




- Tolerable load moment is large and highly resistant to the offset load.
- Suitable for Cartesian robots needing rigid arm or moving arms that move the entire axis.

## R type Rotation axis model P.212



- Repeated positioning accuracy +/- 30 sec. (0.0083 °)
- The robot can be used as the rotation axis when combined with other robots or utilized for a wide variety of applications, such as index tables.
- High rigidity and high accuracy by harmonic drive.




## GF type Long stroke model with high rigidity frame P.190



- Movable at 1200 mm/sec. in the whole area without critical speed.
- Suitable for long distance transfer.


## N type Nut rotation type model P.198

- Repeated positioning accuracy +/- 0.01 mm
- Maximum payload 80 kg
- Double-carrier available as a standard




Critical speed is not restricted and high-speed transfer is possible.  
Stroke: 2500 mm  
Maximum speed: 1200 mm/sec.

In this structure, the hollow motor is connected to the nut of the ball screw and the nut is rotated with the screw shaft secured to perform the movement.



## B type Timing belt drive model P.206



- Maximum stroke is 3050 mm. Long-distance transfer between the processes is possible.

POINT 1


**4-row circular arc groove type 2-point contact guide that is resistant to large moment load is adopted.** <sup>Note 1</sup>



4-row circular arc groove type 2-point contact guide with less differential slip is used for the linear guide. This guide has less ball differential slip due to its structure when compared to the 2-row Gothic arch type 4-point contact guide and maintains a satisfactory rolling movement even if a large moment load is applied or the installation surface precision is poor. The guide has characteristics that are difficult to malfunction, such as unusual wear and provides excellent reliability.

Note 1. Except for T4L/T4LH and T5L/T5LH


**2-row gothic arch groove type 4-point contact guide**



**Friction resistance is large and differential slip is large.**

- Easy to receive adverse effects of installation surface accuracy, friction, and elastic deformation.
- Breakage may occur before expiration of calculation service life.

**4-row circular arc groove type 2-point contact guide**




**Differential slip is small and self-centering function is high.**

- Resistant to alignment changes and moment loads.
- Difficult to break.

**F/N/B type** <sup>Note 2</sup>

For the F type, N type, and B type, two guide frames are laid out on the high rigidity aluminum extruded material frame. Two bearing units per rail, four bearing units in total, support a large load firmly. As a large moment load is mainly converted into vertical force, the moment applied to one bearing unit becomes small to ensure excellent durability.




(F14)

Note 2. Except for F8 series/F10/B10.

**F8 series**


The F8 series uses a newly developed module guide to greatly reduce the cross-sectional area (70 % when compared to F10). The rail is laid out in the full width of the frame to ensure the high rigidity even with compact design. Of course, this series also uses the 4-row circular arc groove type 2-point contact guide.



(F8)

POINT 2

**Resolver with excellent environment resistance is used for the position detector.**



**Position detector**  
Device intended to read-out the position or speed.

**Optical encoder**



- Optical type
- Electronic components are required and structure is complicated.
- Damaged easily by electronic component breakdown, dew condensation on or oil sticking to the disk.

**Detection failure**

**Resolver**



- Magnetic type
- Simple structure only with iron core and winding has less potential failure factors.
- Immune to shock and electric noise.

**High reliability**


A resolver is used for the position detector. The resolver has a simple and rigid structure without using electronic components and optical elements. Detection problems due to electronic component breakdown, dew condensation on or oil sticking to the disk that may occur in optical encoders do not occur in the resolver. The resolver provides excellent durability. Additionally, as the absolute specifications and incremental specifications use the same mechanical specifications and common controller, desired specifications can be selected only by setting parameters. Furthermore, even when the absolute battery is consumed completely, the robot can still operate as the incremental specifications. So, even if a trouble occurs, the line stop is not needed to ensure the safe production line. Furthermore, the backup circuit has been completely renovated and now has a backup period of one year in the non-energizing state.

### POINT 3

## Long service life greatly reduces the maintenance cost.

As the acceleration is determined by the weight parameter, the service life can be assured when the weight and position of center of gravity are known.

**Allowable overhang** Note




Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				Vertical installation (Unit: mm)			
	A	B	C		A	B	C		A	C	
Lead 30	5kg	864	501	383	5kg	348	384	776	1kg	600	600
	15kg	491	156	140	15kg	87	40	306	2kg	1098	1098
Lead 20	5kg	1292	505	462	5kg	416	388	1186	4kg	545	545
	15kg	572	158	151	15kg	92	42	386	4kg	594	594
Lead 10	30kg	455	73	75	30kg	0	0	61	8kg	280	280
	20kg	617	119	127	10kg	193	132	910	10kg	217	217
Lead 5	40kg	422	53	59	20kg	53	0	400	10kg	221	221
	55kg	420	36	40	30kg	0	0	109	15kg	135	135
Lead 5	50kg	722	42	47	10kg	197	133	2360	20kg	92	92
	60kg	657	33	37	20kg	54	0	985			
	80kg	577	23	25	30kg	0	0	427			

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

As YAMAHA's robot uses high rigidity ball screw or guide, it provides excellent durability. This greatly contributes to reduction of the customer's maintenance cost.







### Cost reduction by high durability



### POINT 4

## Controllers suitable for applications are prepared.

In addition to the robot program operation and pulse train control, a positioner that is operated by specifying a point number was added to the product lineup. Additionally, multi specifications that control multiple robots using one controller are also supported. You can select an optimal controller suitable for your application.

Program				I/O point trace (Positioner)	Pulse-train control
SR1-X	RCX222	RCX240/ RCX240S	RCX340	TS-X	RDV-X
					
P.516	P.524	P.532	P.542	P.490	P.504

### POINT 5

## Various custom specifications are supported.

YAMAHA supports custom orders flexibility to meet the customers' various needs.

<b>Addition of free slider</b>	Free slider is added. Various applications, such as rigidity increase or use of two heads are supported.
<b>Wide slider</b>	To increase the slider rigidity, the standard slider is processed to the wide slider.
<b>Specified stroke</b>	A stroke smaller than the minimum stroke may be supported. For details, please consult YAMAHA.
<b>Lead beyond catalog</b>	The lead may be changed to that not stated in the catalog. For details, please consult YAMAHA.
<b>Origin non-motor specifications</b>	Even when not stated in the catalog, the origin may be changed to the non-motor side. For details, please consult YAMAHA.

YAMAHA has a wide variety of custom order results other than those shown above. If you have any requirement or request, please feel free to contact YAMAHA.

Type	Size (mm) <sup>Note 1</sup>	Model	Lead (mm)	Maximum payload (kg)		Maximum speed (mm/sec.)	Stroke (mm)	Page
				Horizontal	Vertical			
T type Frame-less structure model	W45 × H53	T4L/T4LH	12	4.5	1.2	720	50 to 400	T4L: P.174
			6	6	2.4	360		T4LH: P.175
			2	6	7.2	120		
	W55 × H52	T5L/T5LH	20	3	-	1200	50 to 800	T5L: P.176
			12	5	1.2	800		T5LH: P.177
			6	9	2.4	400		
	W65 × H56	T6L	20	10	-	1333	50 to 800	P.178
			12	12	4	800		
			6	30	8	400		
	W94 × H98	T9 (Standard)	30	15	-	1800	150 to 1050	P.179
			20	30	4	1200		
			10	55	10	600		
			5	80	20	300		
		T9H (High thrust)	30	25	-	1800	150 to 1050	P.180
			20	40	8	1200		
10			80	20	600			
5			100	30	300			
F type Model with high rigidity frame	W80 × H65	F8	20	12	-	1200	150 to 800	P.181
			12	20	4	720		
			6	40	8	360		
	W80 × H65	F8L	30	7	-	1800	150 to 1050	P.182
			20	20	4	1200		
			10	40	8	600		
			5	50	16	300		
	W80 × H65	F8LH	20	30	-	1200	150 to 1050	P.184
			10	60	-	600		
			5	80	-	300		
	W110 × H71	F10 (Standard)	30	15	-	1800	150 to 1050	P.185
			20	20	4	1200		
			10	40	10	600		
		F10H (High thrust)	30	25	-	1800	150 to 1000	P.186
			20	40	8	1200		
			10	80	20	600		
			5	100	30	300		
	W136 × H83	F14 (Standard)	30	15	-	1800	150 to 1050	P.188
			20	30	4	1200		
			10	55	10	600		
			5	80	20	300		
		F14H (High thrust)	30	25	-	1800		P.189
			20	40	8	1200		
			10	80	20	600		
	W168 × H100	F17L	50	50	10	2200	1100 to 2050	P.193
			40	40	-	2400	200 to 1450	P.191
		F17	20	80	15	1200	200 to 1250	
10			120	35	600			
W202 × H115	F20	40	60	-	2400	200 to 1450	P.195	
		20	120	25	1200			
		10	-	45	600			
W202 × H120	F20N	20	80	-	1200	1150 to 2050	P.197	
GF type	W140 × H91.5	GF14XL	20	45	-	1200	750 to 2000	P.190
	W168 × H105.5	GF17XL	20	90	-	1200	850 to 2500	P.194
N type Nut rotation type model	W145 × H120	N15 (Single-carrier)	20	50	-	1200	500 to 2000	P.198
		N15D (Double-carrier)					250 to 1750	P.200
	W180 × H115	N18 (Single-carrier)		80	-		500 to 2500	P.202
		N18D (Double-carrier)					250 to 2250	P.204
B type Timing belt drive model	W100 × H81	B10	Belt drive	10	-	1875	150 to 2550	P.206
	W146 × H94	B14 (Standard)	Belt drive	20	-	1875	150 to 3050	B14: P.208
		B14H (High thrust)	Belt drive	30	-	1875		B14H: P.210
R type Rotation axis model	-	R5	-	0.12 kgm <sup>2</sup>	-	360 °/sec	360 °	P.212
		R10		0.36 kgm <sup>2</sup>	-			P.213
		R20		1.83 kgm <sup>2</sup>	-			P.214

Note 1. The size shows approximate maximum cross sectional size.



# Multi-robot


MULTI-FLIP/MULTI-PHASER

This robot has multi specifications that control multiple robots using one controller.

## Advantages of control with multi-axis controller

- Sequence control is easy. System upgrades are easy at less expensive price.
- Compact and space saving when compared to the operation with multiple single-axis controllers.
- More advanced control is possible.
- RCX221, RCX240, RCX240S, and RCX340 provide mixed control of the FLIP-X series and PHASER series (linear single-axis).

## Multi-robot ordering method



Note 1. When ordering a multi-robot, prefix "MLTX" to the top of the order model.  
 Note 2. Select either MULTI-FLIP or MULTI-PHASER shown below.  
 Note 3. For details about the controller and controller option models, please refer to relevant page of each controller.

### MULTI-FLIP

Type	Model	Lead (mm)	Stroke (mm)				
T type Frame-less structure model	T4L/T4LH	12	50 to 400				
		6					
		2					
	T5L/T5LH	20	50 to 800				
		12					
		6					
	T6L	20	50 to 800				
		12					
		6					
	T9 (Standard)	T9	30	150 to 1050			
			20				
			10				
5							
T9H (High thrust)	T9H	30	150 to 1050				
		20					
		10					
		5					
F type Model with high rigidity frame	F8	20	150 to 800				
		12					
		6					
	F8L	F8L	30	150 to 1050			
			20				
			10				
			5				
	F8LH	F8LH	20	150 to 1050			
			10				
			5				
	F10 (Standard)	F10	30	150 to 1050			
			20				
			10				
			5				
	NEW F10H (High thrust)	F10H	30	150 to 1000			
			20				
			10				
			5				
	F14 (Standard)	F14	30	150 to 1050			
			20				
			10				
			5				
			F14H (High thrust)		F14H	30	150 to 1050
						20	
10							
F17L	F17L	50	1100 to 2050				
		40					
		200 to 1450					
F17	F17	20	200 to 1250				
		10					
		40					
F20	F20	20	200 to 1450				
		10					
		200 to 1250					
F20N	F20N	20	1150 to 2050				
		20					
		750 to 2000					
GF type	GF14XL	20	850 to 2500				
	GF17XL	20	850 to 2500				
N type Nut rotation type model	N15 (Single-carrier)	20	500 to 2000				
	N15D (Double-carrier)		250 to 1750				
	N18 (Single-carrier)		500 to 2500				
	N18D (Double-carrier)		250 to 2250				
B type Timing belt drive model	B10	Belt drive	150 to 2550				
	B14 (Standard)	Belt drive	150 to 3050				
	B14H (High thrust)	Belt drive					
R type Rotation axis model	R5	-	360 °				
	R10						
	R20						

### MULTI-PHASER

Type	Model	Carrier	Stroke (mm)
MF type Flat type with core Linear motor specifications	MF7	Single	100 to 4000
	MF7D	Double	100 to 3800
	MF15	Single	300 to 4000
	MF15D	Double	100 to 3800
	MF20	Single	150 to 4050
	MF20D	Double	150 to 3850
	MF30	Single	100 to 4000
	MF30D	Double	150 to 3750
	MF75	Single	1000 to 4000
	MF75D	Double	680 to 3680
MR type Shaft type Linear motor specifications	MR12	Single	50 to 1050
	MR12D	Double	50 to 1050


## Robot settings

### 2-robot settings

Use of 2-robot settings and multi-task program makes it possible to perform asynchronous independent operation. As the auxiliary axis setting is used together, more free axis assignment can be made.

### Double-carrier

In robot types that the motor runs separately, such as linear motor single-axis PHASER series or N type (nut rotation type) of FLIP-X series, two motors can be added to one axis.




### Main auxiliary axis setting





This auxiliary axis setting is used when it is inconvenient that two axes move simultaneously by the MOVE command. The axis set for the main auxiliary axis does not operate by the MOVE command and it operates only by the DRIVE command (movement command in axis units). This setting is recommended for the axis that needs to be operated asynchronously from the main robot.

### Dual setting

This setting is used when performing the dual drive (2-axis synchronous control). This setting is used when the gantry type Cartesian robot with a long Y-axis stroke stabilizes the high acceleration/deceleration or when a high load or high thrust is needed.




## Applicable controllers

Name	1 to 2 axes controller		1 to 4 axes controller	1 to 4 axes controller
	RCX221	RCX222	RCX240/RCX240S	RCX340
Appearance	 P.524	 P.524	 P.532	 P.542
Position detection	Incremental	Absolute	Incremental/Absolute	Incremental/Absolute
Control model	FLIP-X and PHASER can be mixed.	FLIP-X	FLIP-X and PHASER can be mixed.	FLIP-X and PHASER can be mixed.
Maximum number of programs	100 programs		100 programs	100 programs
Maximum number of points	10,000 points		10,000 points	30,000 points
Number of input/output points	Standard	Dedicated input 10 points/ dedicated output 12 points General-purpose input 16 points/ general-purpose output 8 points	Dedicated input 10 points/ dedicated output 11 points General-purpose input 16 points/ general-purpose output 8 points	Dedicated input 8 points/ dedicated output 9 points General-purpose input 16 points/ general-purpose output 8 points
	Expansion	General-purpose input 24 points/ general-purpose output 16 points	General-purpose input 24 points/ general-purpose output 16 points	General-purpose input 24 points/ general-purpose output 16 points
Network option	CC-Link, DeviceNet™, Ethernet, PROFIBUS		CC-Link, DeviceNet™, EtherNet/IP™, Ethernet, PROFIBUS	CC-Link, DeviceNet™, EtherNet/IP™, Ethernet, PROFIBUS, PROFINET

## Examples of multi-robot ordering methods


### Separate single axes

<Example> F14H and F10 are installed separately.



### 2 axes + 1 axis


<Example> T6 is installed on the base for the 1st axis, C6 is secured to the upper portion for the 2nd axis, and CH4 is secured to the upper portion for the 3rd axis to assemble the C6 and C4H to the XZ. (Either 2 axes + 1 axis or 3 axes simultaneous control can be made by the setting.)



Note. When the customer combines each axis, it is recommended to use the cable terminal (relay cable) for the wiring among axes. For details about cable terminal, please contact YAMAHA.

### 3 axes combination


<Example> C17L, C14H, and C14H are used for the X-axis, Y-axis, and Z-axis, respectively to form a 3-axis XYZ combination.



### Double-carrier

#### Example of 4-axis control

<Example> Two T6 are assembled to the double-carrier of the MF20A, and they are used as XZ type and controlled using one controller.




Note. For the double-carrier, since one robot occupies two axes of the controller, the number of robots may differ from the number of controllable axes.

### Double-carrier/dual drive (2-axis simultaneous control)

#### Example of 8-axis control

<Example> Two double-carriers of the MF30 are arranged in parallel and two MF20 installed on the top are moved by the dual-drive. T6 is attached to each tip of the MF20 and the robots are controlled using two controllers.



Note. For this specification, when writing one controller model, two controller will be arranged automatically.

## CAUTION

### Conditions needing regenerative unit on multi-robot

- The total motor capacity exceeds 450 W.
- The total motor capacity of the vertical axis exceeds 240 W.
- The B14H performs the operation at a maximum speed of more than 1250 mm/s.
- When the vertical axis is 240 W or less, the conditions shown below are satisfied.
  - There is a 200 W-vertical axis.
  - A 100 W-vertical axis has a stroke of 700 mm or more.
  - There are two 100 W-vertical axes with a 5 mm-lead.

## FLIP-X terminology

### High lead

This term indicates models supporting ball screw leads that exceed the standard lead (12 mm or 20 mm). (The standard lead of the F17L and C17L is 50.)

### Origin on non-motor side

This term indicates models that are applicable to the origin non-motor specifications as standard. The origin on the non-motor side in the standard state is not supported with a lead not stated in the catalog. If special specifications are needed, please consult YAMAHA.

### Maximum speed

This term indicates the maximum transfer speed. YAMAHA's single-axis robots can transfer a workpiece at this speed regardless of the transfer weight as long as it is within the maximum payload. However, as the workpiece is heavier, the acceleration/deceleration curve becomes gentle. If the movement distance is short, the speed does not reach the maximum speed stated in the catalog.

#### CAUTION

When the stroke of the ball screw drive type is long, noise or vibration is produced due to resonance of the ball screw if moved at the maximum speed. If this happens, lower the speed to that stated in the note column. (It is also possible to lower the transfer speed of the entire program using the SPEED setting or make the adjustment for each movement command.)

### Maximum payload


This term indicates the maximum weight that can be loaded on the slider and transferred. Select an appropriate model so that the total weight of the customer's tools (air cylinder or chuck) and workpiece is less than this data. When the center of gravity of the tool or workpiece is offset from the center of the slider, the allowable overhang needs to be taken into consideration. Additionally, when entering the total weight of the tool and workpiece for the payload parameter of the controller, optimal acceleration/deceleration and servo parameter are automatically set.

### Rated thrust

This term indicates the force to be applied in the slider advancing direction in the slider stationary (hold) state. When using vertically, the weight of the loaded workpiece is subtracted from this value (when the force is applied downward from the top). The slider can move only at a low speed (approximately 10 % of the maximum speed), but this value becomes lower than the specification value. Additionally, the type B of the timing belt drive cannot be used for applications, in which thrust is applied.

### Allowable overhang


This term indicates an allowable overhang of an object to be transferred. In the specification data, this indicates the distance from the center of the top face of the slider to the center of gravity of an object to be transferred by the weight. This value is determined according to the service life of the linear guide. Under normal operation conditions<sup>Note</sup>, the 90 %-service life of the linear guide is 10,000 km or more if gravity centers of the workpiece and tool are kept within the allowable overhang. When using with an overhang amount exceeding the specification data, it is necessary to install a separate support guide or restrict operating conditions (speed, acceleration) so that a load is not applied to the linear guide of the single-axis robot. For detail, please consult YAMAHA.



Note. Speed, acceleration 100 % (It is preconditioned that the weight parameters are set correctly.)  
There shall be no impact load or excessive vibration during operation.  
Additionally, the alignment is correct.

### Static tolerance moment

This term indicates the load moment applied to the slider in the robot stationary state.



### Critical speed

When the stroke of the ball screw drive type is long, noise or vibration is produced due to resonance of the ball screw if moved at the maximum speed. If this happens, lower the speed to that stated in the note column. (It is also possible to lower the transfer speed of the entire program using the SPEED setting or make the adjustment for each movement command.)



# PHASER Series

Product Lineup

## LINEAR MOTOR SINGLE-AXIS ROBOTS

No limit on critical speed even when using a long stroke of 4 m.  
"PHASER" series delivers superb performance  
during long distance transfer.




# Critical speed is not restricted and high-speed long-stroke transfer is possible.

## MF type

High-power and long-stroke using flat motor with core

P.218

- Maximum stroke: 4050 mm
- Maximum speed: 2500 mm/s
- Repeated positioning accuracy: +/-5 μm
- Maximum payload: 7 to 160 kg





## MR type

Lightweight, compact, and low cogging by shaft motor drive

P.236

- Maximum stroke: 1050 mm
- Maximum speed: 2500 mm/s
- Repeated positioning accuracy: +/-5 μm
- Maximum payload: 5 kg



Type	Size (mm) <sup>Note 1</sup>	Model	Carrier	Maximum payload (kg)	Maximum speed (mm/sec.)	Stroke (mm)	Page
MF type Flat type with core Linear motor specifications	W85 × H80	MF7	Single	10 (7) <sup>Note 2</sup>	2500	100 to 4000	P.218
		MF7D	Double			100 to 3800	
	W100 × H80	MF15	Single	30 (15) <sup>Note 2</sup>		100 to 4000	P.224
		MF15D	Double			100 to 3800	
	W150 × H80	MF20	Single	40 (20) <sup>Note 2</sup>		150 to 4050	P.228
		MF20D	Double			150 to 3850	
		MF30	Single	60 (30) <sup>Note 2</sup>		100 to 4000	
		MF30D	Double			150 to 3750	
W210 × H100	MF75	Single	160 (75) <sup>Note 2</sup>	1000 to 4000	P.234		
	MF75D	Double		680 to 3680			
MR type Shaft type Linear motor specifications	W60 × H90	MR12	Single	5	50 to 1050	P.236	
		MR12D	Double		50 to 1050		

Note 1. The size shows approximate maximum cross sectional size.


Note 2. When using at the maximum speed, the maximum payload becomes the value in ( ).

POINT 1

**Maximum speed 2.5 m/sec. and no critical speed limit**

The ultimate appeal of the linear motor single-axis robot is that there are restrictions on critical speed like ball screw. The maximum speed does not decrease even with long-distance transfer. Additionally, the maximum stroke of the MR type is set to up to 1050 mm and that of the MF type is set to up to 4000 mm with standard settings. In particular, the cycle time of the long-distance transfer is greatly improved.

**Movement time comparison between linear single-axis robot PHASER and single-axis robot FLIP-X**




POINT 4


**In-house manufacturing of major parts achieves low costs.**

Magnetic scales are developed and manufactured at YAMAHA. In-house manufacturing of other major parts achieves large cost reduction. Nowadays, the linear motor is not a special mechanism. The customer can select the linear motor or ball screw in the similar way according to the customer's needs. In particular, when performing a high-speed and long-distance transfer of a light workpiece, selecting linear motor robots may reduce the cost.


MF7: Linear motor



F17: Ball screw



B10: Belt type



■ Comparison of single-axis robot models

Model name	Main body price <sup>Note 1</sup>	Maximum speed (mm/sec.)	Maximum payload (kg)	Repeated positioning accuracy (μm)	Maximum stroke (mm)	Maximum cross-sectional dimension <sup>Note 2</sup> (mm)
MF7-1500		2500	10 (7) <sup>Note 3</sup>	+/- 5	4000	W85 × H80
F17-40-1450		720 <sup>Note 4</sup>	40	+/- 10	1450	W168 × H100
B10-1450		1850	10	+/- 40	2550	W100 × H81

Note 1: The prices are compared with the strokes shown above.

Note 2: Cable carriers are not included.

Note 3: The payload is 7 kg when the maximum speed is 2500 mm/s. (10 kg-payload: 2100 mm/s)


Note 4: This value is obtained by considering the critical speed with a stroke of 1450 mm.

POINT 5


**Double-carrier available as standard**

Double-carrier specifications that operate two carriers on one robot are available as standard. High effects, such as space saving, cost reduction, and tact improvement are obtained when compared to two single-axis robots. Furthermore, no axis alignment is needed and tools are commonly used to shorten the setup time. (When using the RCX series controller, an anti-collision function can be used.)

■ Layout using two ball screw single-axis robots



■ Space saving using double-carrier



POINT 2


**Suitable for heavy object transfer. Maximum payload 160 kg**

The maximum payload of the MF type using a flat magnet is 160 kg. The robot can transfer a heavy object, such as large LCD panel at a high speed with high accuracy. (In the payload range of some MF types, the maximum speed may be restricted. For details, refer to the specification page of each model.)

POINT 3

**Effective use of stroke**

As the linear motor single-axis robot incorporates a coil that is the drive part inside the table, dead spaces are eliminated to maximize the stroke. Additionally, as the main body is symmetrical, the flexibility of the layout is improved.





## POINT 6

### Linear scale developed by YAMAHA

YAMAHA originally developed a new linear scale based on its excellent magnetic signal detection technology.



#### Magnetic scale provides high environment resistance.

YAMAHA's magnetic scale is resistant to dirt and can be used in an environment where grease or cutting fluid sometimes splashes.

#### Semi-absolute specifications

The current position is obtained by reading the signal recorded in the linear scale. So, it is not necessary to perform a large return-to-origin movement before starting the operation after turning on the power (the slider moves up to 76 mm when reading the signals).

#### Cost reduction

In-house linear scale development and manufacturing achieves large cost reduction.


#### High resolution 1 $\mu\text{m}$

Magnetic signals recorded in the magnetic scale are detected and interpolated to achieve a highly accurate resolution of 1  $\mu\text{m}$ .

#### Repeated positioning accuracy: $\pm 5 \mu\text{m}$

A fully-closed control that always feeds back the table position provides high accuracy steadily.

Additionally, there are no mechanical backlashes, such as ball screws or timing belts.



## POINT 7

### Silence and long service life

Unlike ball screw type robots, there are few sliding and rotating parts. So, the operation is very quiet. Moreover, as the coil is not in contact with the magnet, they are not worn out and can be used for an extended period of time.

## POINT 8

### Dust-proof structure


All YAMAHA's linear motor robots use a stainless steel shutter. This prevents entry of foreign objects. Additionally, these shutters are made of tough stainless steel with an extremely high fatigue strength to support high-speed and long-stroke operation.

## POINT 9


### Flat type without cable carrier protrusion

For the MF7, as the main body is made compact, a flat type that the cable carrier becomes flat on the top surface of the table is prepared as standard. Please select this type according to the tool or workpiece shape, or installation method.

#### Standard type



#### Flat type




As the cable carrier does not protrude from the table upper surface in the flat type, a large tool can be installed easily.




#### Applicable to multi-carrier operation

The PHASER series also supports "multi-carrier" operation that allows using three or more carriers on one robot. This "multi-carrier" operation drastically extends applications due to its high effect in improving tact time and saving space.



#### Applicable to dual-drive

As a dual-drive that simultaneously drives two axes, high-speed transfer and heavy object transfer are possible in a wide area. YAMAHA can propose an optimal control method according to the robot linkage rigidity.



# XY-X Series

Product Lineup

## CARTESIAN ROBOTS

Offering a full lineup of Cartesian robots that come with exact performances and sizes supports a wide variety of applications.



### Fulfilling product lineups

Fulfilling product lineups are provided, such as compact and low price PXYx type, HXYLx allowing long-distance transfer with a maximum payload of 50kg, and NXY with hollow servomotor used for the X-axis applicable to double-arm. Fulfilling arm and performance variations support the customers' various requests.


Additionally, various custom-order products other than models stated in the catalog are also supported. For detail, please feel free to consult YAMAHA.

# Fulfilling product lineups support a wide variety of applications.

## Various variations

P.240

Models with 3 or more axes can be selected from: ■ Z-axis clamped base and moving table type  
 ■ Z-axis clamped table and moving base type



Model	Applicable arm variations					Number of axes	Maximum payload (kg)	Maximum stroke (mm)	
	Arm	Gantry	Moving arm	Pole	XZ			X-axis	Y-axis
PXYx	●	-	-	-	-	2 axes	4.5	150 to 650	50 to 300
FXYx	●	-	-	-	-	2 axes/3 axes	12	150 to 1050	150 to 550
FXYBx	●	-	-	-	-	2 axes	7	150 to 2450	150 to 550
SXYx	●	-	●	●	●	2 axes/3 axes/4 axes	20	150 to 1050	150 to 650
SXYBx	●	-	-	-	●	2 axes/3 axes/4 axes	14	150 to 3050	150 to 550
MXYx	●	●	●	●	●	2 axes/3 axes/4 axes	30	250 to 1250	150 to 650
NXY	●	-	-	-	-	2 axes/3 axes	25	500 to 2000	150 to 650
NXY-W	●	-	-	-	-	4 axes/6 axes	25	250 to 1750	150 to 650
HXYx	●	●	●	●	●	2 axes/3 axes/4 axes	40	250 to 1250	250 to 650
HXYLx	●	●	-	-	-	2 axes	40	1150 to 2050	250 to 650

Note. The maximum payloads and maximum strokes shown above are values when using arm type/cable carrier specifications.


### POINT 1

#### Use of 4-row circular arc groove type 2-point contact achieves high durability.



4-row circular arc groove type 2-point contact guide with less differential slip is adopted. When compared to the 2-row Gothic arch type 4-point contact guide, the robot provides features that it does not stop due to catching or overload and is difficult to malfunction even under poor conditions with low installation surface accuracy or large overhang amount. Guide rail type suitable for Cartesian robots, to which moment is always applied.


#### 2-row gothic arch groove type 4-point contact guide



Differential slip is large and friction resistance is large.

- Easy to receive effects of poor installation surface accuracy, friction, and elastic deformation.
- Breakage may occur even within the calculated service life.

#### 4-row circular arc groove type 2-point contact guide



Differential slip is small and self-centering function is high.

- Resistant to alignment changes and moment loads.
- Difficult to break.

### POINT 2

#### Highly reliable resolver is used.



A resolver is used for the position detector. As the resolver uses a simple and rigid structure without using electronic components and optical elements, it features high environment resistance and low failure ratio. Detection problems due to electronic component breakdown, dew condensation on or oil sticking to the disk that may occur in optical encoders do not occur in the resolver due to its structure. Additionally, as the absolute specifications and incremental specifications use the same mechanical specifications and common controller, desired specifications can be selected only by setting parameters. Furthermore, even when the absolute battery is consumed completely, the robot can still operate as the incremental specifications. So, even if a trouble occurs, the line stop is not needed to ensure the safe production line. Furthermore, the backup circuit has been completely renovated and now has a backup period of one year in the non-energizing state.

### POINT 3

#### Easy maintenance

Even when the built-in structure is used, the motor or ball screw can be replaced individually to ensure smooth maintenance work.

POINT 4


Low price

It was succeeded to reduce the number of parts while improving the basic performance. So, further cost reduction was achieved. Additionally, the resolver was used to eliminate the existing image "absolute specifications are expensive". Additionally, both the absolute specifications and incremental specifications use exactly same mechanical parts.

POINT 5

Lightweight and compact

The ball screw drive motor is renovated to a couplingless built-in structure to make dead spaces small and contribute to space saving.




POINT 6

Double Y-axis available as standard

The NXY with nut rotation type structure supports a double Y-axis with two carriers arranged on the same axis. Two Cartesian robots can be made compact to improve the work efficiency at a low cost and ensures the space saving.

- Layout using two conventional Cartesian robots
- Space saving and process integration using NXY-W



Arm & cable variations

Cable variations

Two kinds of cable specifications, cable carrier and whipover (separate cable), are available. (PXYx uses only the cable carrier.)

● Cable carrier (C)

[User cable is provided as standard equipment.]  
When adding cables into a cable carrier, carefully check the space factor (30 % or less), etc.  
Note. User cable: 10-core, 0.3 sq



● Whipover (S)

[User cable and air tubing are provided as standard equipment.]  
Be aware that sagging or faulty wiring may occur if a load is applied to the whipover. Additionally, sagging may also occur when using a long-stroke.  
Note. User cable: 7-core, 0.2 sq  
Note. User tubing: φ 4-air tube, 2 pcs.




Arm variations

2 axes combination

● Arm type

Type with Y-axis slider movement



● Moving arm type

Type with entire Y-axis arm movement



● Gantry type

Type with support guide attached to the Y-axis tip of the arm type



● Pole type

Type with Y-axis slider vertical movement



● XZ type

Type with combination of X-axis for horizontal movement and Z-axis for vertical movement


Clamped table/moving base

Clamped base/moving table



● Dual-robot (2 axes)

Type with synchronous drive between two axes  
Note. The dual-robot is supported as a custom order.




### 3 axes combinations


- Z-axis clamped base and moving table type  
ZR-axis model: ZT / ZF / ZFL / ZL




- Z-axis clamped table and moving base type  
ZR-axis model: ZFH / ZH




- Shaft up/down type  
ZR-axis model: ZS




- X-Y Gantry + Z-axis  
(Clamped base/moving table)



- X-Y Gantry + Z-axis  
(Clamped table/moving base)




- Dual-robot (3 axes)  
Note. The dual-robot is supported as a custom order.



### 4 axes combinations


- Z-axis clamped base and moving table type + rotation axis  
ZR-axis model: ZRF / ZRFL / ZRL




- Z-axis clamped table and moving base type + rotation axis  
ZR-axis model: ZRFH / ZRH




- ZR-axis integrated type  
ZR-axis model: ZRS



- X-Y Gantry + Z-axis  
(Clamped base/moving table) + rotation axis



- X-Y Gantry + Z-axis  
(Clamped table/moving base) + rotation axis



- Dual-robot (4 axes)  
Note. The dual-robot is supported as a custom order.




- Double Y-axis specifications  
Robot model: NXY-W




### 6 axes combination

- Double Y-axis specifications/ Z-axis clamped base and moving table type  
Robot model: NXY-W-ZFL



- Double Y-axis specifications/ Z-axis clamped table and moving base type  
Robot model: NXY-W-ZFH



#### Special orders

YAMAHA supports models with strokes and payloads other than the standards as special orders. For detail, please feel free to consult YAMAHA.

Contact Us ☎ 81-53-460-6103 E-mail: robotn@yamaha-motor.co.jp

## YK-X Series

Product Lineup

YK-TW	Omni directional model
YK-XG/YK-X	Completely beltless model <sup>Note</sup>
YK-XR	Low cost high performance model
YK-XGS	Wall mount/inverse model
YK-XGP	Dust-proof & drip-proof model

Note. Except for YK1200X

# SCARA ROBOTS

Arm length of 120 mm to 1200 mm, full-selection of lineup is top in the world. Completely beltless structure pursues the features of SCARA robots to their utmost limits.



Low cost high performance model  
YK400XR

### History of 30 years

The first YAMAHA robots were SCARA robots. Since the first SCARA robot called "CAME" was produced in 1979, some 30 years of SCARA robot innovations have continually appeared. These SCARA robots have undergone countless modifications in an ever changing marketplace and amassed a hefty record of successful products making them an essential part of the YAMAHA robot lineup.



# Comprehensive line of YAMAHA SCARA robots

## Orbit type

P.370

- Arm length 350 mm / 500 mm
- Maximum payload 4 kg



## Extra small type

P.374

- Arm length 120 mm to 220 mm
- Maximum payload 1 kg



## Small type

P.379

- Arm length 250 mm to 400 mm
- Maximum payload 5 kg

Low cost high performance model  
YK400XR



## Medium type

P.386


- Arm length 500 mm to 600 mm
- Maximum payload 5 kg to 20 kg



## Large type

P.393

- Arm length 700 mm to 1200 mm
- Maximum payload 20 kg to 50 kg



## Wall mount/inverse model

P.399

YK300XGS to YK1000XGS



- Wall mount type

Type where the robot body is installed in the wall.

- Inverse type

Type where the wall-mount type is installed upside down.

## Dust-proof & drip-proof model

P.409



Plays active part in the working environment with a large amount of water or dust (protection class equivalent to IP65).

- Please consult YAMAHA for anti-droplet protection for fluids other than water.

## YK-TW Orbit type


### YK-TW POINT 1

#### Layout design freedom

User: We want a smaller equipment footprint.

**YK-TW can move anywhere through the full  $\phi$  1000 mm <sup>Note 2</sup> work envelope.**

Featuring a ceiling-mount configuration with a wide arm rotation angle, the YK-TW can access any point within the full  $\phi$  1000 mm downward range. This eliminates all motion-related restrictions with regard to pallet and conveyor placement operations, while dramatically reducing the equipment footprint.



Orbit type SCARA robot

Standard type SCARA robot


### YK-TW POINT 2

#### Higher productivity

User: We need to reduce cycle time.

**Standard cycle time of 0.29 secs. <sup>Note 2</sup>**

Y-axis (arm 2) passes beneath the X-axis (arm 1) and it has a horizontal articulated structure, allowing it to move along the optimal path between points. Moreover, the optimized weight balance of the internal components reduces the cycle time by 36 % as compared to previous models.



The standard cycle time for moving a 1-kg load horizontally 300 mm and up/down 25 mm is shortened by approximately 36 % compared to existing YAMAHA models.


### YK-TW POINT 3

#### High quality

User: We want a high precision assembly system.

**YK-TW offers a repeated positioning accuracy of  $\pm 0.01$  mm <sup>Note 1</sup> (XY axes).**

Higher repeated positioning accuracy than that offered by a parallel-link robot. This was accomplished by optimizing the robot's weight balance through an extensive re-design of its internal construction. The lightweight yet highly rigid arm has also been fitted with optimally tuned motors to enable high accuracy positioning.



#### Hollow construction

Y-motor and reduction gear feature a hollow construction which allows them to be housed inside the harness arm.

**360° Rotation.**

#### Optimized rotation center of gravity moment

Weight balance was optimized by placing the R-motor and Z-motor at the left and right sides respectively.

**Reduced inertia enables high-speed motion.**

### YK-TW POINT 4

#### Suitable for a wide range of applications

User: We need to move heavy workpieces at high speeds.

**YK-TW handles payloads up to 5 kg.**

Handles loads up to 5 kg. Also accommodates arm-end tools which tend to be heavy, making it highly adaptable to various applications.


### YK-TW POINT 5

#### Smaller equipment footprint

User: We want to reduce the height of our equipment.

**YK-TW offers both a lower height and a smaller footprint.**

YK-TW height is only 392 mm. This compact size enables more freedom in the equipment layout design.



Note 1. Applies to the YK350TW Note 2. Applies to the YK500TW




## YK-TW POINT 6

### Easy installation

User: Parallel-link robots require large frames which complicates installation...

YK-TW has a total height of only 392 mm, and weighs only 27 kg <sup>Note 2</sup>.

Lower inertia = Lighter frame



## YK-TW POINT 7


### Reduce the number of steps

User: Preparing the frame is extra work.

We can optionally provide a dedicated frame for the YK-TW.

With no need for complex calculations of strength, startup steps can be reduced.

Note. For details on dimensions and price, please contact Yamaha.




## YK-TW POINT 8

### Ideal for narrow space applications

User: We need to install in limited space, such as between equipment.


Minimum installation width 492mm <sup>Note 1</sup>



## YK-XG Completely beltless type

### Integral structure designed for optimal operation


Note. The following shows an example of YK500XG.



## YK-XG POINT 1

### Completely beltless structure


A completely beltless structure was achieved using a ZR-axis direct coupling structure. This completely beltless structure greatly reduces waste motion. This structure also maintains high accuracy for an extended period of time. Additionally, this structure ensures maintenance-free operation for an extended period of time without worrying about belt breakage, elongation, or secular deterioration (except for Orbit type and large type).



## YK-XG POINT 2

### High speed

The standard cycle time is fast. Additionally, YAMAHA also places special emphasis on the tact time in the practical working area. The speed reduction ratio or maximum motor RPM was reviewed to greatly improve the maximum speed. This contributes to improvement of the tact time.



YK-XG POINT 3

### Resolver is used for position detector.



As the resolver uses a simple and rigid structure without using electronic components and optical elements, it features high environment resistance and low failure ratio. Detection problems due to electronic component breakdown, dew condensation on or oil sticking to the disk that may occur in optical encoders do not occur in the resolver due to its structure. Additionally, as **the absolute specifications and incremental specifications use the same mechanical specifications and common controller**, the specifications can be changed only by setting parameters. Furthermore, even when the absolute battery is consumed completely, the robot can still operate as the incremental specifications. So, even if a trouble occurs, the line stop is not needed to ensure the safe production line. The backup circuit has been completely renovated and now has a backup period of one year in the non-energizing state.

Note. The resolver has a simple structure without using electronic components. So, the resolver is highly resistant to low and high temperatures, impacts, electrical noise, dust particles, and oil, etc., and is used in automobiles, trains, and aircrafts that particularly require the reliability.

**Optical encoder**




- Optical type
- Electronic components are required and structure is complicated.
- Electronic component malfunction, or dew condensation on or oily content sticking to disk may occur easily.

▼

**Detection failure**

**Resolver**



- Magnetic type
- Simple structure only with iron core and winding has less potential failure factors.
- Immune to shock and electric noise.

▼

**High reliability**

YK-XG POINT 4

### Excellent maintenance ability

The covers of YAMAHA SCARA robot YK-XG series can be removed forward or upward. The cover is separated from the cable, so the maintenance work is easy. Additionally, the grease replacement of the harmonic gear needs many steps to disassemble the gear and may cause positional deviation. However, since the harmonic gear of the YAMAHA SCARA robot uses long-life grease, the grease replacement is not needed.


YK-XG POINT 5

### Surprising R-axis tolerable moment of inertia

The SCARA robot performance cannot be expressed only by the standard cycle time. In actual operating environments, there are various workpieces, such as heavy workpiece or workpiece with large offset. At this time, since the robot with low R-axis tolerable moment of inertia needs to decrease the speed during operation, the cycle time decreases greatly. All YAMAHA SCARA robot YK-XG types have the tip rotation axis directly coupled to the speed reducer. Since the R-axis tolerable moment of inertia is very high when compared to a general structure in which the moment of inertia is transmitted by a belt after decelerating, the robot can operate at a high speed even with workpieces that have been offset.

R-axis tolerable moment of inertia: Comparison between YK120XG and other company's model


When the offset from the R-axis to the center of gravity of the load is large, the inertia becomes large and the acceleration during operation is restricted. The R-axis tolerable moment of inertia of YAMAHA XG series is exceedingly large when compared to other company's SCARA robots in the similar class, so it can operate at a high speed even in the offset state.



**YK120XG**

(R-axis tolerable moment of inertia: 0.1 kgfcm<sup>2</sup>)

When the tip load weight is 1 kg, it is possible to operate at **approx. 100 mm** offset.



When the load weight is 1 kg (refer to the right in the figure.)

Offset (mm)	Inertia (kgfcm <sup>2</sup> )	Operation	
		YK120XG	Company A
0	0.0039	○	○
45	0.025	○	×
97	0.1	○	×


○: Operable    ×: Out of catalog value tolerance range

◆ R-axis tolerable moment of inertia: YK120XG..... 0.1 kgfcm<sup>2</sup>  
 Company A..... 0.0039 kgfcm<sup>2</sup>

## YK-XG POINT 6

### Compact

As the cable layout is changed, the cable height becomes lower than the main body cover. Additionally, use of extruded material base and motor with low overall height achieves the lowest overall height in the same class.



## YK-XG POINT 7

### Hollow shaft and tool flange options are selectable.

Hollow shaft that allows easy wiring to the tip tool and tool flange for tool mounting are provided as options.



Hollow shaft option convenient for routing of air tubes and harness wires

Note. YK250XG to YK400XG  
YK500XGL/YK600XGL



Tool flange option for easy mounting of a tool to the tip

Note. YK250XG to YK1000XG

## YK-XG POINT 8

### Zone control (= Optimal acceleration/deceleration automatic setting) function

In the SCARA robot, the load applied to the motor and speed reducer in the arm folded state greatly differs from that in the arm extended state. YAMAHA SCARA robot **automatically selects** optimal acceleration and deceleration from the arm postures at operation start and operation end. Therefore, the robot does not exceed the tolerance value of **the motor peak torque** or **speed reducer allowable peak torque** only by entering the initial payload. So, full power can be extracted from the motor whenever needed and high acceleration/deceleration are maintained.

#### For X-axis of YK500XG

The torque in the arm folded state is 5 or more times different from that in the arm extended state.


**This may greatly affect the service life, vibration during operation, and controllability.**

If the motor torque exceeds the peak value

→ **This may adversely affect the controllability and mechanical vibration, etc.**

If the torque exceeds the tolerable peak torque value of the speed reducer


→ **This may cause early breakage or shorten the service life extremely.**



## YK-XG POINT 9

### Low price models with the arm length 500 mm/600 mm specifications are also added to the product lineup.

The customers require to use SCARA robots at a more affordable price. Models YK500XGL/YK600XGL were developed to meet these customer's requests. About 30 %-cost reduction was achieved when compared to the conventional models YK500XG/600XG.



## YK-XR Low cost high performance model YK400XR

### YK-XR POINT 1

#### Shortest cycle time in this class

A standard cycle time of 0.45 sec. is achieved by drawing out the robot performance to its maximum level.

### YK-XR POINT 2

#### Superior cost performance

Most economical price in YAMAHA's similar robot class without sacrificing its existing features.

### YK-XR POINT 3

#### With versatile and high performance controller RCX340.

Combination of YK400XR robot and new RCX340 controller enable operation up to 16 axes with simple easy networking.

## YK-XGS Wall mount/inverse model

#### Hanging type is renewed. Completely beltless structure and high rigidity

As the conventional hanging type is changed to the wall mount type, the flexibility of the system design is improved. The production equipment can be downsized. Additionally, as an inverse type that allows upward operation is also added to the product lineup, the flexibility of the working direction is widened. Furthermore, use of a completely beltless structure achieves a maximum payload of 20 kg and a R-axis tolerable moment of inertia of 1 kgm<sup>2</sup>Note that are the top in the class. A large hand can also be installed. So, this robot is suitable for heavy load work.

Note. YK700XGS to YK1000XGS



## YK-XGP Dust-proof & drip-proof model

#### Up/down bellows structure improves the dust-proof and drip-proof performance.

The dust-proof and drip-proof type that can be operated even in a work environment where water or particle dust scatters was renewed to a completely beltless structure. The belt does not deteriorate and poor environment resistance is improved. Additionally, an up/down bellows structure is used to improve the dust-proof and drip-proof performance.

Note. YK250XGP to YK600XGLP



### Protection class equivalent to IP65 (IEC60529)

Seals are added to the joints to maintain the dust-proof and drip-proof performance without air purging. The robot conforms to the protection class equivalent to IP65 (IEC60529).

**IP 65** - Class of protection against invasion of water: 5  
 Water injected from any direction does not affect adversely.  
 The standard pressure of the injected water is 30 KPa (30 KN/m<sup>2</sup>, 0.3 kgf/cm).  
 The injection speed is 12.5 liters/min. and the injection time is 3 min.  
 Note. The water injected under conditions exceeding those shown above may enter the unit.  
**Class of protection against solid objects: 6**  
 No invasion of particle dust.

### Dust-proof and drip-proof connector for user wiring is provided as standard.



YK250XGP to 600XGLP (arm part)



YK250XGP to 600XGLP (base part)

Model/Type		Model	Arm length (mm)	Maximum payload (kg)	Standard cycle time (sec.)	Page
Omni directional model		YK350TW	350	5.0	0.32 (RCX340) 0.38 (RCX240)	P.370
		YK500TW	500	4.0 (3.0) <sup>Note 2</sup>	0.29	P.372
Completely beltless model	Micro-mini type (Tiny)	YK120XG	120	1.0	0.33	P.374
		YK150XG	150			P.375
		YK180XG	180			P.376
		YK180X	180			P.377
		YK220X	220			P.378
	Small type	YK250XG	250	5.0 (4.0) <sup>Note 2</sup>	0.49	P.379
		YK350XG	350			P.381
		YK400XG	400			P.383
Low cost high performance model		YK400XR	400	3.0 (2.0) <sup>Note 2</sup>	0.45	P.385
Completely beltless model	Medium type	YK500XGL	500	5.0 (4.0) <sup>Note 2</sup>	0.59	P.386
		YK500XG	500	10.0	0.45	P.388
		YK600XGL	600	5.0 (4.0) <sup>Note 2</sup>	0.63	P.389
		YK600XG	600	10.0	0.46	P.391
		YK600XGH	600	20.0 (19.0)	0.47	P.392
	Large type	YK700XGL	700	10.0 (9.0)	0.50	P.393
		YK700XG	700	20.0 (19.0)	0.42	P.394
		YK800XG	800		0.48	P.395
		YK900XG	900		0.49	P.396
		YK1000XG	1000		0.49	P.397
–		YK1200X	1200		50	0.91
Wall mount/inverse model		YK300XGS <sup>Note 1</sup>	300	5.0 (4.0) <sup>Note 2</sup>	0.49	P.399
		YK400XGS <sup>Note 1</sup>	400			P.401
		YK500XGS	500	10.0	0.45	P.403
		YK600XGS	600		0.46	P.404
		YK700XGS	700	20.0	0.42	P.405
		YK800XGS	800		0.48	P.406
		YK900XGS	900		0.49	P.407
		YK1000XGS	1000		0.6	P.408
Dust-proof & drip-proof model		YK250XGP	250		5.0	0.49
		YK350XGP	350	P.411		
		YK400XGP	400	P.413		
		YK500XGLP	500	4.0	0.74	P.415
		YK500XGP	500	8.0	0.55	P.417
		YK600XGLP	600	4.0	0.74	P.418
		YK600XGP	600	8.0	0.56	P.420
		YK600XGHP	600	18.0	0.57	P.421
		YK700XGP	700		0.52	P.422
		YK800XGP	800		0.58	P.423
		YK900XGP	900		0.59	P.424
		YK1000XGP	1000		0.59	P.425

Note 1. The YK300XGS and YK400XGS are custom-order products. For details about the delivery time, please contact YAMAHA.

Note 2. For the option specifications (tool flange mount type and user wiring/tubing through spline type), the maximum payload becomes the value in ( ).

# YP-X Series

Product Lineup

## PICK & PLACE ROBOTS

Ideal for small components high-speed pick & place work.  
Positioning is made by servo control, so no complex mechanical  
adjustments are needed.



# Full lineup of 6 models in all from 2 axes to 4 axes

2 axes type

P.429

3 axes type


P.431

4 axes type

P.434



YP220BX/YP320X



YP220BXR/YP320XR/YP330X




YP340X

Model	Axis	Structure				Maximum payload (kg)	Cycle time (sec.)	Page
		X-axis	Y-axis	Z-axis	R-axis			
YP220BX	2 axes	Belt	-	Belt	-	3	0.45	P.429
YP320X		Ball screw	-	Belt	-	3	0.57	P.430
YP220BXR	3 axes	Belt	-	Belt	Rotation axis	1	0.62	P.431
YP320XR		Ball screw	-	Belt	Rotation axis	1	0.67	P.432
YP330X		Ball screw	Ball screw	Belt	-	3	0.57	P.433
YP340X	4 axes	Ball screw	Ball screw	Belt	Rotation axis	1	0.67	P.434

## POINT 1

### High speed

Super high-speed pick & place operation with a standard cycle time of 0.45 sec. (YP220BX with up/down 50 mm, back/forth 150 mm, arch amount 50, load 1 kg) greatly contributes to improvement of the productivity. Since it is possible to output a signal to turn on/off any external equipment from any position while the axis is moving, the actual production cycle time is further improved.



## POINT 2

### Compact

Use of a compact size with an overall width of 109 mm (YP220BX) makes it possible to make the production line compact and simple. The moving arm structure with less interference with surroundings contributes to space saving.




#### Reference examples of robot layout comparisons

■ Line using pick & place utilizing space saving

■ Line using YAMAHA's compact Cartesian robot PXYx  
X-axis stroke: 250 mm  
Y-axis stroke: 250 mm

■ Line using YAMAHA's compact SCARA robot YK250X

The compactness can be checked by comparing the occupied spaces when the YP-X series and YAMAHA's Cartesian/SCARA robots are laid out.



## POINT 3

### High accuracy

Both extremely high-speed performance and high repeated positioning accuracy of +/- 0.02 mm (YP320X, YP320XR, YP330X, YP340X) are assured.

## POINT 4

### Complete absolute position system

As the complete absolute position system is used, no return-to-origin operation is needed.

## POINT 5

### Versatility

Use of YAMAHA's unique servo system makes it possible to freely program the stop point and operation pattern settings. This robot is applicable to production of many models in small quantities that cannot be supported by the cam type robot.

# CLEAN Type

Product Lineup

## CLEAN ROBOTS

Suitable for electronics component, food, and medical unit related work in clean room.

High sealing structure, dust generation prevention, and improvement of suction efficiency are achieved.

Both the high cleanliness degree and high performance are established.

Clean robots contribute to automation and labor saving of production systems in clean rooms.





# Both high cleanliness degree and high performance were achieved. Clean single-axis, Cartesian, and SCARA robots were added to the product lineup.

## Clean SCARA robots

### YK-XGC/XC type

The Z-axis spline is covered with bellows made of materials with low dust generation and other sliding parts are sealed completely. Harnesses are also incorporated completely and the inside of the robot is sucked from the rear of the base to prevent dust generation.

- Arm length: 180 mm to 1000 mm
- Suction amount: 30 to 60 Nℓ/min.
- Cleanliness degree: CLASS ISO3 (ISO14644-1)  
CLASS10 (FED-STD-209D)
- Maximum payload: 20 kg



### POINT 1

#### Vertical bellows structure improves the reliability of the clean performance.

As a beltless structure is used, no dust generation caused by the belt occurs. Furthermore, as the YK-XGC type was renewed to a structure, in which the bellows are installed on the Z-axis vertically, the reliability of the clean performance was further improved.

Note. Except for YK500XC to YK1000XC



### POINT 2

#### High durability

As a beltless structure is used, the robot can be operated without worry about belt elongation and secular change <sup>Note</sup>. Additionally, the bellows installed on the Z-axis use material with high durability to ensure the durability performance.


Note. Except for YK500XC to YK1000XC

### POINT 3

#### Completely beltless structure improves the rigidity.

A completely beltless structure was achieved using a ZR-axis direct coupling structure. As a speed reducer is coupled to the tip rotation axis, the R-axis tolerable moment of inertia is very high and the high-speed movement is possible even with a heavy workpiece or largely offset workpiece.

Note. Except for YK500XC to YK1000XC



Type	Model	Arm length (mm)	Maximum payload (kg)	Standard cycle time (sec.)	Beltless structure	Page
Micro-mini type	YK180XC	180	1	0.42	○	P.462
	YK220XC	220	1	0.45	○	P.463
Small type	YK250XGC	250	4	0.57	○	P.464
	YK350XGC	350	4	0.57	○	P.466
	YK400XGC	400	4	0.57	○	P.468
Medium type	YK500XC	500	10	0.53	-	P.472
	YK500XGLC	500	4	0.74	○	P.470
	YK600XC	600	10	0.56	-	P.475
	YK600XGLC	600	4	0.74	○	P.473
Large type	YK700XC	700	20	0.57	-	P.476
	YK800XC	800	20	0.57	-	P.477
	YK1000XC	1000	20	0.60	-	P.478

Clean single-axis robots

FLIP-XC type

P.442

The FLIP-XC type robots are single-axis robots "FLIP-X series" with clean room specifications. According to the applications, an optimal robot can be selected from 14 models from a lightweight and compact model to a large model with a maximum payload of 120 kg. As an air joint for suction is provided as standard equipment, grease with low dust generative characteristics is used, and stainless sheets with an excellent durability are used for the slide table surface, high cleanliness degree is achieved.

- Stroke: 50 to 2050 mm
- Suction amount: 15 to 90 Nℓ/min.
- Cleanliness degree: CLASS10<sup>Note</sup>
- Maximum payload: 120 kg (When installed horizontally)


Note. C4L/C4LH, C5L/C5LH, and C6L are CLASS ISO3 (ISO14644-1).



POINT

Excellent maintenance ability

For C4L to C6L models, removing the screws from the side panel of the slider will allow replacement of the inner roller without detaching the tool. For C8 to C20 models, even when the direct coupling structure is used, the motor or ball screw can be replaced individually.



Model	Size (mm) <sup>Note</sup>	Lead (mm)	Maximum payload (kg)		Maximum speed (mm/sec.)	Stroke (mm)	Page
			Horizontal	Vertical			
C4L C4LH	W45 × H55	12	4.5	1.2	720	50 to 400	C4L : P.442 C4LH : P.443
		6	6	2.4	360		
		2	6	7.2	120		
C5L C5LH	W55 × H65	20	3	-	1000	50 to 800	C5L : P.444 C5LH : P.445
		12	5	1.2	800		
		6	9	2.4	400		
C6L	W65 × H65	20	10	-	1000	50 to 800	P.446
		12	12	4	800		
		6	30	8	400		
C8	W80 × H75	20	12	-	1000	150 to 800	P.447
		12	20	4	720		
		6	40	8	360		
C8L	W80 × H75	20	20	4	1000	150 to 1050	P.448
		10	40	8	600		
		5	50	16	300		
C8LH	W80 × H75	20	30	-	1000	150 to 1050	P.449
		10	60	-	600		
		5	80	-	300		
C10	W104 × H85	20	20	4	1000	150 to 1050	P.450
		10	40	10	500		
		5	60	20	250		
C14	W136 × H96	20	30	4	1000	150 to 1050	P.451
		10	55	10	500		
		5	80	20	250		
C14H	W136 × H96	20	40	8	1000	150 to 1050	P.452
		10	80	20	500		
		5	100	30	250		
C17	W168 × H114	20	80	15	1000	250 to 1250	P.453
		10	120	35	600		
C17L	W168 × H114	50	50	10	1000	1150 to 2050	P.454
C20	W202 × H117	20	120	25	1000	250 to 1250	P.455
		10	-	45	500		

Note 1. The size shows approximate maximum cross sectional size.

## Clean single-axis robots

### SSC type (TRANSERVO)

P.439

The SSC type robots are stepping motor single-axis robots "TRANSERVO series" with clean room specifications. Use of a newly developed vector control method achieves the function and performance equivalent to the servomotor at a low cost even using the stepping motor. As an air joint for suction is provided as standard equipment, grease with low dust generative characteristics is used and stainless sheets with an excellent durability are used for the slide table surface, the high cleanliness degree is achieved.

- Stroke: 50 to 800 mm
- Suction amount: 15 to 80 Nℓ/min.
- Cleanliness degree: CLASS10
- Maximum payload: 12 kg (When installed horizontally)



Model	Size (mm) <sup>Note 1</sup>	Lead (mm)	Maximum payload (kg)		Maximum speed (mm/sec.)	Stroke (mm)	Page
			Horizontal	Vertical			
SSC04	W49 × H59	12	2	1	600	50 to 400	P.439
		6	4	2	300		
		2	6	4	100		
SSC05	W55 × H56	20	4	-	1000	50 to 800	P.440
		12	6	1	600		
		6	10	2	300		
SSC05H	W55 × H56	20	6	-	1000	50 to 800	P.441
		12	8	2	600 (horizontal) / 500 (vertical)		
		6	12	4	300 (horizontal) / 250 (vertical)		

Note 1. The size shows approximate maximum cross sectional size.

## Clean Cartesian robots

### XY-XC type

P.456

This Cartesian robot XY-XC type is applicable to clean rooms. As stainless sheets with excellent durability are used, the opening can be designed to be its minimum level and the robots area applicable to CLASS10 with less suction amount. Furthermore, as the ZR-axis of the SXYxC uses a super high speed unit of the SCARA robot, this achieves great reduction of the cycle time.

- Suction amount: 60 to 90 Nℓ/min.
- Cleanliness degree: CLASS10 <sup>Note</sup>
- Maximum payload: 20 kg
- Maximum speed: 1000 mm/sec.

Note. User wiring: D-Sub 25-pin connector (Numbers 1 to 24 are already wired and number 25 is frame ground.)  
Note. User tubing: φ 6-air tube, 3 pcs.



Type	Model	Axis	Movement range	Maximum speed (mm/sec.)	Maximum payload (kg)	Page
2 axes	SXYxC	X	150 to 1050 mm	1000	20	P.456
		Y	150 to 650 mm	1000		
3 axes	SXYxC (ZSC12)	X	150 to 1050 mm	1000	3	P.458
		Y	150 to 650 mm	1000		
		Z	150 mm	1000		
3 axes	SXYxC (ZSC6)	X	150 to 1050 mm	1000	5	P.459
		Y	150 to 650 mm	1000		
		Z	150 mm	500		
4 axes	SXYxC (ZRSC12)	X	150 to 1050 mm	1000	3	P.460
		Y	150 to 650 mm	1000		
		Z	150 mm	1000		
		R	360 °	1020 °/sec		
4 axes	SXYxC (ZRSC6)	X	150 to 1050 mm	1000	5	P.461
		Y	150 to 650 mm	1000		
		Z	150 mm	500		
		R	360 °	1020 °/sec		

## CONTROLLERS

An optimal controller can be selected from various command input formats.

As servo parameters and deceleration patterns suitable for robots are pre-registered, robots can be operated quickly without complex settings.



# High performance controllers supporting YAMAHA robots

		TRANSERVO	FLIP-X		PHASER	
		Stepping motor	[T4L/T5L] Small type servomotor (24 V · 30 W)	General-purpose servomotor (30 to 600 W)	Linear motor	
1 axis	<ul style="list-style-type: none"> <li>I/O point trace</li> <li>Remote command</li> <li>Online command</li> </ul>	 TS-S2 TS-SH		 TS-X	 TS-P	TS-S2/ TS-SH/ TS-X/TS-P  P.490
	<ul style="list-style-type: none"> <li>Pulse train</li> </ul>	 TS-SD	 ERCD	 RDV-X	 RDV-P	TS-SD P.500  RDV-X/ RDV-P P.504  ERCD P.510
	<ul style="list-style-type: none"> <li>Program (YAMAHA SRC language)</li> <li>I/O point trace</li> <li>Remote command</li> <li>Online command</li> </ul>			 SR1-X	 SR1-P	SR1-X/ SR1-P  P.516
2 axes	<ul style="list-style-type: none"> <li>Program (YAMAHA BASIC language)</li> <li>I/O command</li> <li>Remote command</li> <li>Online command</li> </ul>			 RCX222	 RCX221	RCX221/ RCX222  P.524
3, 4 axes	<ul style="list-style-type: none"> <li>Program (YAMAHA BASIC language) <sup>Note 1</sup></li> <li>I/O command <sup>Note 2</sup></li> <li>Remote command</li> <li>Online command</li> </ul>			 RCX240 RCX240S	 RCX340	RCX240/ RCX240S  P.532  RCX340 P.542

## Five or more axes can also be supported

5 to 8 axes	<b>RCX240</b> <b>YC-LINK couples single-axis controllers to a 4-axis controller</b> Note : Up to four SR1 series controllers can be connected to the RCX series controller.	
	<b>RCX340</b> <b>YC-Link/E</b> Up to four RCX340 controllers (up to 16 controllable axes) can be connected.	

Note 1. The RCX340 uses YAMAHA BASIC2 language.  
 Note 2. The I/O command is not applicable to the RCX340.

**P** : Robot positioner      **D** : Robot driver      **C** : Robot controller

POINT 1

Selectable from various control methods

Program input

A variety of operation settings, calculations, and conditional branching is possible

The single-axis robot controllers use the YAMAHA SRC language <sup>Note</sup> which is simple yet contains all required functions, such as I/O outputs and conditional branching, etc. The multi-axis controller RCX series uses the YAMAHA BASIC language capable of more sophisticated programming and includes all types of arithmetic operations, flexible variable settings, and various conditional branching, etc. Both are easy to use robot language conforming to the BASIC. These languages support various needs from simple operations to expert user's sophisticated work.


Note. The 2-axis controller DRCX also uses YAMAHA SRC language.

Single-axis robot controller	YAMAHA SRC language <Example>	MOVA 1, 100	Moves to point number 1 at 100 %-speed.
		DO 1, 1	Turns on general-purpose output number 1.
		WAIT 2, 1	Waits until general-purpose input number 2 turns on.
Multi-axis robot controller	YAMAHA BASIC language <Example>	IF DO(10)=1 THEN *END	Jumps to *END if general-purpose input number 10 turns on. Otherwise, moves to the next line.
		MOVE P, P2, STOPON DI(1)=1	Moves to point number 2. Stops when general-purpose input number 1 turns on during movement.
		WAIT ARM	Waits until the robot arm operation ends.
		P3=WHERE	Writes the current position into point number 3.
		*END:	Defines the label named "END".
HOLD	Pauses the program.		

I/O point trace

Program-less means easy

The host unit specifies a point number in binary format and the robot moves to the specified point when the start signal is input. The controller can operate only by teaching the point data without programs.




Remote command

Ideal for unified data management

The word function of the CC-Link or DeviceNet™ is used to issue various commands or data to the robot. The expandability of the word function from simple operation instructions to point data writing is fully utilized to freely use the robot controller functions from the host unit.


Note. This function is enabled when selecting an option network board.



Pulse train

Acceleration/deceleration curves can be created freely

The robot is controlled using pulse trains sent from the positioning unit. The controller does not need to have programs or point data. This pulse train is convenient when the control is centralized to the host unit.



Online command

Execute everything from a PC

The PC can issue various commands or data to the controller or receive the data or status through the RS-232C or Ethernet <sup>Note</sup>. All executable operations from the teaching pendant can be executed from the PC.


Note. Ethernet is enabled when selecting an option network board. (For the RCX340, Ethernet is provided as standard function.)



## Easy optimal setup

### Complicated parameter settings are unnecessary


Robot controllers are specially designed for YAMAHA robots. Optimal values for servo parameters required for robot operation, such as gain are already registered beforehand. **Start operating immediately without any need for complicated settings or tuning, even if you don't have knowledge or experience about control.**




### Easy acceleration/deceleration settings

The acceleration/deceleration is an important factor that affects the service life of the machine. **If too high acceleration is set, this may cause the service life of the machine to shorten. If the acceleration is too low, the motor power cannot be used effectively, causing the fact time to lower.** The acceleration/deceleration setting of YAMAHA robot controller is determined finely by load weight. Setting only payload parameters will automatically set optimal acceleration/deceleration by taking the service life of the machine and motor capability into consideration. Detailed robot knowledge from YAMAHA is what makes this possible. (Note: For the pulse train input, the customer may need to set the acceleration/deceleration.)

### Concept of speed and acceleration



### Acceleration calculation algorithm




### Zone control (= Optimal acceleration/deceleration automatic setting) function

The SCARA robot also incorporates a zone control function that always operates the robot at its maximum performance level by considering changes in inertia due to the arm posture. Therefore, the robot does not exceed the tolerance value of the motor peak torque or speed reducer allowable peak torque only by entering the initial payload to bring out the full power of the motor and keep the high acceleration/deceleration.

#### For X-axis of YK500XG

The torque in the arm folded state is 5 or more times different from that in the arm extended state.



**This may greatly affect the service life, vibration during operation, and controllability.**

If the motor torque exceeds the peak value

→ **This may adversely affect the controllability and mechanical vibration, etc.**

If the torque exceeds the tolerable peak torque value of the speed reducer

→ **This may cause early breakage or shorten the service life extremely.**

POINT 3

### Multi-function and expandability

■ Multi-axis controllers support up to 30,000 points (10,000 points for the RCX2 series, 1,000 points for the single-axis controller (255 points for the TS series)). Up to 100 programs can be created on each controller.

■ Various field networks, CC-Link, DeviceNet™, PROFIBUS, and EtherNet/IP™ are supported.

Note. Some models do not support all networks.

■ The TS series, RD series, SR1 series, and RCX series use a dual-power supply system with separate control power supply and power supply.

■ As the controllers conform to the CE marking that is safety standards in EU (Europe), they can be used safely even overseas.

The TS series (except for TS-S), SR1 series, and RCX series conform to up to safety category 4.

For details about functions of each controller, refer to controller details pages from P.479.

Name	Type	Number of points	Number of programs	Applicable network						Compliance with CE
				CC-Link	DeviceNet™	Ethernet	EtherNet/IP™	PROFIBUS	PROFINET	
TS-S2/TS-SH	1 axis robot positioner	255	-	○	○	-	○	-	○	○
TS-X/TS-P		255	-	○	○	-	○	-	○	○
TS-SD	1 axis robot driver	-	-	-	-	-	-	-	-	○
RDV-X/RDV-P		-	-	-	-	-	-	-	-	○
ERCD	1 axis robot controller	1,000	100	-	-	-	-	-	-	-
SR1-X/SR1-P		1,000	100	○	○	○	-	○	-	○
RCX221/RCX222	1 to 2 axes controller	10,000	100	○	○	○	-	○	-	○
RCX240	1 to 4 axes controller	10,000	100	○	○	○	○	○	-	○
RCX340		30,000	100	○	○	○	○	○	○	○

## RDV-X/RDV-P

P.504

FLIP-X

PHASER

### [Robot driver]



Operation method	Pulse train
Input power	Main power Single-phase/3-phase AC 200 V to 230 V Control power Single-phase AC 200 V to 230 V
Origin search method	Incremental

#### Dedicated pulse train control

The dedicated pulse train control has achieved a compact body and a low price.

#### Position setting time reduced by 40%

The response frequency is enhanced about two times in comparison with former models. The position setting time of uniaxial robots is reduced by about 40%.<sup>Note 1</sup>

#### Large cost reduction possible

It is easy to assemble them in automated machinery. You can save much labor in designing, parts selection, setting and more. A large cost reduction is possible.

#### Contributing to saving space for the whole control board

The compact design has reduced the width up to a maximum of 38% in comparison with former models. In addition, the improvement of radiation efficiency makes it possible to arrange the devices with less space in between. Multiple units can be installed side by side in a neat arrangement.

#### Easy replacement

The parameter settings and fastening-hole pitches are the same as those of former models. It is easy to replace the software and the hardware as well.

#### Command input: Line driver (2 Mpps)

#### Command output: ABZ-phase output (with a divider function)

#### Real-time operation status monitoring

You can have analog outputs for speed, amperage, and more information to know the operation status in real time. RDV-Manager, the dedicated support software, is also available for a graphical view of the status.

#### Main power: Single and three phases supported (200V)


The full-specification operation is available with a single-phase power supply.

Note 1. With a 400W servomotor, 20mm ball screw lead, and portability of 40kg.



# TS-S2/TS-SH/TS-SD POINT

## Usable for all TRANSERVO series models



Note 1. The STH type vertical specifications and RF type sensor specifications do not support the TS-SD.  
 Note 2. SG07 is only applicable to TS-SH.

## TS-SD P.500 TRANSERVO

### [Robot driver]



Operation method	Pulse train	
Input power	Main power	DC 24 V +/- 10 %
	Control power	DC 24 V +/- 10 %
Origin search method	Incremental	

### Pulse train input driver dedicated to "TRANSERVO"

A robot driver dedicated to the pulse train input for "TRANSERVO".

### Torque decrease in high-speed area is suppressed

As a vector control method is used, the torque decrease in high-speed area is small and high-speed operation even with high payload can be performed. This greatly contributes to shortening of the tact time.

### Excellent silence

High-pitched operation sounds unique to the stepping motor are suppressed to achieve silent operation sounds similar to the AC servo.

### Easy operation with support software TS-Manager

In the same manner as the robot positioner TS series, the operation can be performed with the TS-Manager (Ver.1.3.0 or later) having various convenient functions, such as robot parameter setting, backup, and real-time trace (The handy terminal "HT1" cannot use this TS Manager).

### Applicable to a wide variety of pulse train command inputs

This robot driver can be made applicable to the open collector method or line driver method using the parameter setting and signal wiring. In the open collector method, a wide voltage range from 5 V to 24 V is supported. So, the robot driver can be matched to the specifications of the host unit to be used.


### TS-Manager: Real-time trace function

The current position, speed, load factor, current value, and voltage value, etc. can be traced at real-time. Additionally, as trigger conditions are set, the data when the conditions are satisfied can be automatically acquired. Furthermore, as a range is specified from the monitor results, the maximum value, minimum value, and average value can be calculated. So, this is useful for the analysis if a trouble occurs.

Real-time traceable items (up to four items)		
• Voltage type	• Command position	• Current position
• Command speed	• Current speed	• Internal temperature
• Command current value	• Current current value	• Motor load factor
• Input/output I/O state	• Input pulse count <sup>Note 1</sup>	• Movement pulse count <sup>Note 1</sup>
• Word input/output state <sup>Note 2</sup>	Note. 1: TS-SD only Note. 2: TS controller only	

### Daisy chain function

As multiple TS series controllers and drivers are connected in a daisy chain, the data of a desired unit can be edited from the personal computer (up to 16 units).



**TS-S2/TS-SH** P.490 **TRANSERVO**

**TS-X/TS-P** P.490 **FLIP-X PHASER**

[Robot positioner]



<b>Operation method</b>	Point trace Remote command Online command
<b>Number of points</b>	255 points
<b>Input power</b>	Main power DC 24 V +/- 10 % Control power DC 24 V +/- 10 %
<b>Origin search method</b>	TS-S2 Incremental TS-SH Absolute Incremental




<b>Operation method</b>	Point trace Remote command Online command
<b>Number of points</b>	255 points
<b>Input power</b>	AC 100 V / AC 200 V
<b>Origin search method</b>	TS-X Absolute Incremental TS-P Incremental Semi-absolute

**Design that allows a clean installation**

**Unified installation sizes**

Height and installation pitch are unified throughout the series. Units can be installed neatly within the control board.



**Selectable I/O interfaces**

**Two RS-232C ports provided**

● **Connect support tools**

Intuitive operation supports controller design and maintenance.

● **Daisy-chaining**

Two ports can be used to daisy-chain up to 16 units.

● **Communication commands**

Easily understood ASCII text strings can be used to perform robot operations.



**Selectable 100V/200V**

- The TS-X/P let you select AC100/200V as the power input. (The 20A model is 200V only.)
- The TS-S2/SH is DC24V input.

**A variety of I/O interfaces**

In addition to NPN and PNP, you can choose CC-Link, DeviceNet™, EtherNet/IP™, and PROFINET field networks.



● **Positioner interface**

Functionality has been condensed into an I/O interface with 16 inputs and 16 outputs. In addition to easy positioning, this also includes functionality that enhances interoperability with the control device.

● **Remote commands**

Numerical data can be directly manipulated by using the four-word input and four-word output areas. You can add new direct positioning commands to further unify the data at the control device.


● **Gateway function**

New types of connection are provided to reduce network costs. (CC-Link, EtherNet/IP™, and PROFINET are supported.)

# Positional interface

## "Positioner function" for easy positioning


You can easily perform positioning operations by specifying the number of a point that is registered in the data, and entering a start command.



Number	Operation type	Position (mm)	Speed (%)	Acceleration (%)	Deceleration (%)	Branch	Timer (ms)
P1	ABS	100.00	100	100	100	0	0
P2	ABS	200.00	80	100	100	0	0

## A variety of output functions

The TS controller provides a variety of status outputs that are linked with positioning operations. By selecting and using an output appropriate for the scene, this can contribute to cost-saving measures such as making the steps of the control device's program more efficient or by reducing the peripheral equipment.




List of outputs	
• Zone output .....	Output ON when between the two specified points
• Near position output .....	Output ON when entering the specified region from the goal position
• In movement output .....	Output ON when above the specified speed
• Pressing status .....	Output ON when specified pressing strength is reached

Also provided are return-to-origin completed status, manual mode status, warning output, and alarm number output, etc.

## Consecutive operation, linked operation


By specifying a branch destination, it is possible to execute positioning operations consecutively. Additionally, by specifying linked operation, operation with the branch destination can be executed while changing the speed without positioning stops; this allows control programming to be simplified and takt to be shortened.



Number	Operation type	Position (mm)	Speed (%)	Acceleration (%)	Deceleration (%)	Branch	Timer (ms)
P1	ABS	100.00	100	100	100	2	500
P2	ABS	200.00	80	100	100	3	800
P3	ABS linked	300.00	100	100	100	4	0
P4	ABS	350.00	30	100	100	0	0

## Jog and point teaching functions are provided as standard

Jog movement and point teaching functions are provided as standard for input signals. By linking these with buttons of a touch panel etc., a simple teaching system can be constructed.




TS-S2/TS-SH/TS-X/TS-P

Remote commands

Ideal for unifying data management

Remote commands are functions by which the control device can directly handle data such as points and parameters using the word area of the field network.

Numerical data can be operated directly by using the word area. This promotes unification of data management.



**New function** Direct positioning commands that directly specify position and speed data

As remote commands, "direct positioning commands" are provided, allowing the position and speed data to be specified directly and then positioning operations to be performed. In addition to unifying the positioning data on the control device, this allows it to be done with a single command, simplifying programming of the control device.

Consecutive queries for realtime update of various status information

Normally, remote commands only update data when responding, but if a consecutive query is issued, the data continues to be updated at a fixed interval until permission is given to stop. This is useful in various cases such as when it is desirable to obtain positioning data during operation for interoperation with peripheral devices, or to obtain current values in order to monitor the status of a robot.


Parallel processing of "positioner interface" and "remote commands"

Since positioner interface and remote commands operate independently of each other, parallel processing is possible.

- < Usage examples >
- Obtain the current position during positioning operation
  - Obtain the current position during jog movement
  - Change the target position during linked operation

		Positioner interface		Remote command
		Positioning operation	Jog movement	Positioning operation
Remote commands	Data write	○	○	—
	Data read	○	○	—
	Consecutive query	○	○	○

○ : Parallel processing possible





"Gateway function" -- a new way to connect

New function

Decrease network cost

One controller equipped with a field network board can provide unified management of up to four I/O interfaces via a daisy-chain connection. This allows network cost to be decreased while enabling the same type of I/O control as when one board is installed for each unit. (CC-Link and EtherNet/IP™ are supported)




Note. Daisy chain connection cable is required.

## Daisy chain connection


### No need to connect or disconnect cables during operation (up to 16 units)

From a single PC, handy terminal, or touch-panel display, it is possible to specify point data and parameters, perform operations, and monitor the status for up to 16 axes on daisy-chained controllers. For everything from design to maintenance, a connection to only the first controller is sufficient; any desired controller can be accessed simply by switching the station number, without having to connect or disconnect cables.



### Communication commands

An easily handled command protocol using ASCII text strings supports a wide range of needs from data editing to operation and status monitoring. By daisy-chaining multiple devices, simple multi-axis control can be performed.



## "KEYENCE PROTOCOL STUDIO Lite" serial communication settings software

By loading a TS settings file into PROTOCOL STUDIO Lite, communication settings and main communication commands can be registered automatically. Ladder-less data editing and daisy-chaining can be easily accomplished.

Contact for questions regarding PROTOCOL STUDIO Lite  
Keyence Corporation, [www.keyence.co.jp/red/kv01/](http://www.keyence.co.jp/red/kv01/)

### Daisy-chain connections (up to 16 axes)

Communication with the KV-L21V uses a Yamaha-made communication cable (D-sub type). By using daisy-chain connections, up to 16 axes can be managed together.



### Automatic device assignment for each communication command

If the communication type is specified as cyclic, the desired information to be obtained is automatically stored in data memory.

No.	名前	通信先	通信方法	通信速度	方向	データ	データ	コメント	実行
1	位置位置	サイクル毎	設定	1	DM1000 - DM1000	位置位置	NC200		
2	位置速度	サイクル毎	設定	1	DM1000 - DM1000	位置速度	NC200		
3	位置加速度	サイクル毎	設定	1	DM1000 - DM1000	位置加速度	NC200		
4	位置位置	サイクル毎	設定	1	DM1000 - DM1000	位置位置	NC200		
5	位置速度	サイクル毎	設定	1	DM1000 - DM1000	位置速度	NC200		
6	位置加速度	サイクル毎	設定	1	DM1000 - DM1000	位置加速度	NC200		

## Touch operator interface "Pro-Face" GP4000 Series

Connecting GP4000 Series made by Pro-face to Robot Positioner, TS-S2, TS-SH, TS-X, TS-P enables you to use a lot of functions as well as basic operations on Touch Operator Interface.


Free download of the program file from the Pro-face home page  
<http://www.proface.com>

### Can easily check a state and change settings.

- Check the status (the current position, speed etc)
- Basic operations such as Jog operation, inching operation, return to origin, error reset etc.
- Set, edit, or back up point data and parameters
- Check triggered alarms and detailed descriptions of alarm history

### Supports 3 languages

- Supports Japanese, English, and Chinese (simplified, traditional)



# SR1-X/SR1-P

P.516

FLIP-X

PHASER

## [Single-axis robot controller]



SR1-X

SR1-P

<b>Operation method</b>	Program Point trace Remote command Online command
<b>Number of points</b>	1000 points
<b>Input power</b>	AC 100 V AC 200 V
<b>Origin search method</b>	SR1-X Absolute Incremental SR1-P Incremental Semi-absolute

### Various command methods

An optimal method can be selected from various command methods, such as program, point trace, remote command, and online command. The program uses the YAMAHA SRC language that is similar to the BASIC. Various operations, such as I/O output and conditional branching, etc. can be executed using simple operations.

### Applicable to complete absolute position system

The SR1-X is applicable to complete absolute position system. No return-to-origin is needed. (The backup period is one year in the non-energizing state.)

### I/O assignment function

As the I/O assignment is changed, the point trace operation, point teaching, and trace operation by specifying coordinate values can be selected in addition to the normal program operation. Since the JOG movement through the I/O is possible in the point teaching mode, the point teaching can be performed from the host unit without the HPB.

### Current position output function

The position data is output as feedback pulse or binary data. This allows the host unit to understand the current robot position at real-time. Furthermore, functions, zone output or point zone output to output near point number are incorporated.

### Torque limiting

As this function limits the maximum torque command value at desired timing, it is effective in operations such as pushing and workpiece gripping operations. Furthermore, in addition to the torque limiting by the parameter data value, the torque limiting by the analog input voltage can be performed.

# ERCD

P.510

T4L/T5L

## [Single-axis robot controller]



ERCD

<b>Operation method</b>	Program Point trace Online command Pulse train
<b>Number of points</b>	1000 points
<b>Input power</b>	DC 24 V
<b>Origin search method</b>	Incremental


### Four command formats

A desired command format can be selected from four command formats, program operation using various commands, point trace operation only by instructing a point number, online command, and pulse train input.

### Compact design

Compact box size of W 44 × H 142 × D 117mm is achieved with the functions improved.

The volume ratio of the robot controller is downsized to approximately 62 % when compared to YAMAHA's conventional model ERCX. The flexibility of the installation space is improved.



### Various input/output functions

As a feedback pulse output function is provided, the host control unit can easily manage the current position. Additionally, as the movement point number can be output in binary format during point trace, the operation can be checked easily. As a teaching function using the I/O is added, the flexibility and usability of the system configuration are further improved.

This output is enabled in the program or point trace operation and the number of outputs can be changed to a desired level using the division setting.

### Various monitor functions

The controller status can be checked using the input/output status monitor, duty monitor, and LED status display.

### Error history and alarm history


The error or alarm history that occurred in the past can be displayed and checked on the HPB or personal computer screen.

### Robot number management

As the controller is initialized by the robot number of the robot to be controlled, parameters suitable for each robot model are automatically registered and no complicated servo adjustment is needed.


### Torque limiting control

The torque limiting control can be performed using the program command. The axis can be stopped with the torque applied. This torque limiting control can be used for continuous positioning of workpieces with different sizes, press-fitting work, and workpiece holding operation.



### Zone output function

The general-purpose output on/off setting between desired points can be performed using the parameter setting. The positive logic/negative logic setting can be made and the axis position can be easily judged by an external unit. Up to four patterns can be set.




# SR1-X/SR1-P/ERCD Various functions

## Position data output function

### Zone output


Outputs whether or not the robot position is within the specified range.



It is possible to reverse the output logic.

### Point zone output


Outputs the point number near the robot position in binary format.



It is also possible to limit to only the moving point.

### Binary output


Outputs the current robot position in 16-bit binary format. (This function is available only in the SR1.)



It is possible to adjust the unit of the output position data to be output using parameters.

### Feedback pulse output

Outputs the current position counter value of the robot through the A/B-phase line driver.




It is possible to perform the monitoring by host unit at real-time. A frequency division function is built-in.

## Point teaching

The JOG movement of the robot and the point reaching can be performed from the host unit.

### Concept


- The robot is moved to the teaching position using the JOG+/JOG- command.
- The current position is registered into the point number specified by the PSET input.



## Torque limiting function

As the torque limiting is performed during operation, the operation, such as pushing and workpiece gripping can be performed.

### Concept



### Features

#### SR1

- Host unit manages the limiting time using the TLM input.
- Limiting status is understood using the torque limiting status output (TLON).
- Torque limit value is changed (up to 4 patterns) using the input.
- Torque can be limited using the program command.
- Torque can be limited using the analog input (0 to +10 V / 12 bit).


#### ERCD

- Torque can be limited using the T program command.

## Movement data change function

The movement speed or target position can be changed during movement. (This function is available only in the SR1.)

### Concept




### Features

- Host unit manages the limiting time using the movement command input.
- Movement command is ABS-PT (absolute movement command) or ABS-BN (binary specified movement command).
- Change speed can be specified in a range of 1 to 100 % (up to 4 patterns).
- Changing is disabled in the deceleration zone.

# YAMAHA SRC language convenient functions


## Multi-task function

This function can execute multi tasks, such as robot peripheral units in parallel at the same time. Up to four tasks can be executed. With the multi-task function combined with JMPP command, the I/O signals can be output when the robot passes through the specified point during movement.



## Conditional stop function during movement

The arm can be decelerated and stopped using I/O conditions of the MOVF command while it is moving. This function is useful when searching for the target position with the sensor.




# RCX2 series RCX221/222

P.524


# RCX240/240S

P.532


## [Multi-axis robot controller]

	<b>Operation method</b>	Program Remote command Online command
	<b>Number of points</b>	10000 points
	<b>Input power</b>	AC 200 V
	<b>Origin search method</b>	Incremental Semi-absolute

RCX221

	<b>Operation method</b>	Program Remote command Online command
	<b>Number of points</b>	10000 points
	<b>Input power</b>	AC 200 V
	<b>Origin search method</b>	Absolute Incremental

RCX222

	<b>Operation method</b>	Program Remote command Online command
	<b>Number of points</b>	10000 points
	<b>Input power</b>	Single phase : AC200V to 230V +/-10% maximum
	<b>Origin search method</b>	Absolute Incremental

RCX240

### Applicable to all YAMAHA robot models

The RCX series is applicable to all YAMAHA robot models, such as PHASER, FLIP-X, and XY-X, etc. As the single-axis robot (FLIP-X/ PHASER) can be combined with the Cartesian robot freely, various applications can be supported (except for some compact single-axis robots).

### Complete absolute position system


The RCX uses complete absolute specifications that need no return-to-origin when the power turns on. The completely same system can be applicable to the incremental specifications. (When the PHASER series uses the magnetic scale, it is applicable to the semi-absolute or incremental specifications.)

### Extension of absolute data backup time

As the backup circuit is improved to the energy saving, the absolute position data retention period in the non-energizing state is greatly extended. The maximum one month of the conventional model is extended to approximately one year. The current position information is monitored during long vacations, equipment storage, or even during transportation, and no return-to-origin is needed when energized again. This allows quick production start.

### Area check output function

This function can output the I/O signals when the robot enters a set area during operation. Up to eight check areas can be set.




### Applicable to dual-drive

A dual-drive function is incorporated that controls two axes synchronously. This function is effective for heavy workpiece transfer or Y-axis long stroke of the Cartesian robot. The function can perform the operation using the high-speed and high acceleration/ deceleration of YAMAHA robots.


Note. The dual-drive is supported as a custom order. For detail, please consult YAMAHA.

#### Example of dual-drive



### Applicable to robot vision "iVY System"

The RCX series also supports the YAMAHA robot vision "iVY System" that is capable of easy setup and applicable to a wide variety of applications. As the vision board is incorporated into the controller main body, the calibration work requiring a long time and labor is then greatly simplified. As the position is corrected by the image recognition, the versatility and applicability of the equipment is widened greatly (only supported by the RCX240).




### Double-carrier anti-collision function

When using the double-carrier, collisions between both carriers can be prevented by the control in the controller. Collision preventions by the zone judgments or external sensors are no longer needed to make the double-carrier easier to use.

### 3D linear/circular interpolation control

2D and 3D linear and circular interpolation controls are possible. This ensures the smooth and highly accurate operations suitable for the sealing work. (The 3D interpolation is not available in the RCX221/222.)






## Palletizing function


This function can easily define up to 20 kinds of pallets only by entering four corner positions on the pallet as the teaching points. When entering the teaching point in the height direction, even three-dimensional pallets are supported.

When specifying the defined pallet number and executing the movement command, the palletizing work is then performed. Various operations, one point → pellet, pallet → one point, and pallet → pallet, can be performed using the programs.




## Hand definition

This function operates the robot based on coordinates of the offset tool tip when the tool is attached to the tip of the robot axis in the offset state. Particularly, this function is effective during tool rotation of SCARA robots or robots including the rotation axis.




## Shift coordinates

A deviation may occur in the coordinate system when re-installing or replacing the robot during maintenance work. In this case, the coordinate system can be corrected using the shift coordinate function. So, the point data can be used as it is. No re-teaching is needed.




## Passing point output control

The general-purpose output on/off can be controlled by specified points without stopping the axis operation during interpolation operation. The dispense can be turned on or off with the axis operated during sealing to allow smooth and stable dispensing.



## Torque limiting function


The motor torque can be limited during gripping or press-fitting.



## Multi-task function

This function can execute multi tasks (up to eight tasks), such as robot peripheral units in parallel at the same time. When there are multiple tasks, the task can be changed by means of the time sharing method and a priority can be put on the task. Additionally, the priority can also be changed while the task is running. The multi-task function simplifies the control configuration of the entire system to improve the operation efficiency.

### Task scheduling




## Sequence program

In addition to the normal task, a task to individually control the input/output (parallel, serial, memory, timer) can be executed. As the sequence program can be enabled even in the manual mode, this is effective to construct a safety system linked with peripheral units.

**2-robot control**

Two robots that are assigned to the main and sub robots can be simultaneously controlled using one controller. As this function is used together with the multi-task, advanced and smooth linking of two robots can be performed using one controller.



**Applicable to auxiliary axis addition function "YC-Link system"**


This YC-Link is a system that controls the single-axis robot controller SR1 from the multi-axis controller RCX series through the serial communication.

By installing the YC-Link system, the RCX series can be easily linked with the SR1 series. As multiple controllers can be linked as required, up to eight axes (up to six axes for simultaneous control) can be controlled.




**Powerful support software: VIP+ (plus)**

This application software allows you to easily and visually operate the robot, create and edit programs, and teach points. The user interface is greatly improved and made easier to use when compared to the conventional support software VIP.



**Applicable to electric gripper "YRG series"**

All grippers can be controlled using one RCX240 controller. Data exchanging with the host unit, such as PLC is not needed. The setup or startup is very easy.




**RCX240/RCX340 POINT**

**RCX240 and RCX340 are applicable to all single-axis, Cartesian, SCARA, and P&P robots** Note

The 4-axis robot controller RCX240 and RCX340 are applicable to all robot models including single-axis, Cartesian, SCARA, and Pick & Place robots.

As the mixed control of the ball screw type FLIP-X series and linear motor type PHASER series can be performed, the robots can be combined freely according to the applications. Additionally, when preparing the robot controllers for the maintenance work of multiple robots, it is enough to prepare only one robot controller. This robot controller can be used for any model only by changing the setting.

Note. Except for 24 V specification models.



# RCX3 series RCX340

P.542

## [Multi-axis robot controller]



RCX340



<b>Operation method</b>	Program Remote command Online command
<b>Number of points</b>	30000 points
<b>Input power</b>	Single phase : AC200V to 230V +/-10% maximum
<b>Origin search method</b>	Absolute Incremental Semi-absolute

## Advanced functionality allowing construction of high-level equipment

Multiple robots can be operated synchronously through the high-speed communication. Use of linking among controllers makes it possible to store programs into only one controller. Use of a newly developed algorithm achieves shortening of the positioning time and improvement of the tracking accuracy.



### The control of multiple robots can be managed using one master controller

The RCX340 controller allows high-speed communication among the controllers. As the operation command can be sent to the controller of each slave from the master controller, the programs or points can be managed only using the host master controller. Additionally, as this controller supports multi tasks flexibly, data exchanging with the PLC can be simplified. Simultaneous start and simultaneous arrival of each robot can be controlled freely. Complicated and precision robot system using many axes can be constructed at a low cost.



### Arch motion can be specified more intuitively

As the arch motion route designation method is changed and the designation method is simplified, the arch motion can be specified more intuitively.




### RCX340

## Smooth movement is achieved by greatly improving motion functions

As a new servo motion engine is incorporated, various operations can be merged. Use of a newly developed algorithm achieves shortening of the positioning time and improvement of the tracking accuracy.



### Expansion of CONT option function

Different type operations, such as PTP, interpolation operation, and conveyor tracking, etc. are merged to improve the speed.





### Improvement of operation speed <sup>Note</sup>

All operations can be merged as much as possible using the merge PTP. As even operations with different acceleration or deceleration time are merged at maximum level with priority put on the operation time, the movement time is shortened greatly.



### Proper use according to application <sup>Note</sup>

When performing the continuous operation, an optimal operation can be selected according to the application, like traditional PATH is used for constant-speed operation, such as sealing and merge PTP is used for operation with priority put on the movement time.






Note. It is necessary to upgrade the firmware to its latest version.

## Improvement of tracking accuracy

Use of visualization with servo analyze function and high responsiveness with new servo function makes it possible to increase the follow-up ability and improve the tracking accuracy when compared to the conventional models.

15 mm/sec.  
500 mm/sec.



## Improved basic performance


Functions, such as robot language, multi-task, sequence function, communication, and field bus are improved and made easier to use.

### Motion optimization

The optimization of the motion to meet the operation pattern is further strengthened to bring out the robot performance at its maximum level. Higher quality robot operations, such as shortening of the operation time and suppression of vibrations during stopping are achieved.


### Optimal acceleration/deceleration motion

Acceleration/deceleration motion is generated that can perform the high-speed operation while suppressing vibrations.



### Compact design

The outside dimensions are approximately 355 mm (W) × 195 mm (H) × 130 mm (D). The volume ratio is reduced to approximately 85 % and the body size is made compact when compared to the conventional 4-axis controllers so as to make the installation inside the control panel easy.




## Improvement of cycle time

The speed-up of the YK-XG series is achieved.


### Example: YK400XG

- Standard cycle time operation  
0.49 sec → 0.45 sec



## User memory capacity increase

- Number of points is greatly increased.
- Total capacity of program and point



## Built-in regenerative unit

As the regenerative unit (equivalent to RGU3) is built-in, no additional regenerative unit is needed when connecting to the existing robot.


## Support tool with visibility and operability improved New support software RCX-Studio Pro

The program debug function is strengthened to support the multi-task. Use of convenient operability and program input support function makes it possible to perform the quick setup.

- YAMAHA robot becomes easier to use, faster setup, efficient maintenance



### Evaluation

- Emulator function provided
- Cycle time calculator




### Design

- Easy-to-use operating controls
- Inter-operation with other manufacturer's line simulators
- iVY2 editor provided




### After installation

- Realtime trace
- Application debugging function



### Maintenance

- Data comparison tool



### Programing box PBX

This programming box is applicable to three languages, "Japanese", "English", and "Chinese". Use of a color display makes it possible to improve the visibility. Work to add or edit functions becomes easy, allowing even personnel without programming skill to operate this programming box. A function to save the controller data into the USB memory is incorporated.



RCX340

Enhanced expandability

RS-232C and Ethernet ports are provided as standard equipment. A wide variety of high-speed and large capacity field networks, such as CC-Link, DeviceNet™, and EtherNet/IP™ are supported as options. Connections with general-purpose servo amplifier or other company's VISION are easy. So, the RCX340 is called "connectable controller".

Communication between controllers <b>YC-Link/E</b>	<b>Up to four RCX340 controllers (up to 16 controllable axes) can be connected.</b>	
	More flexible robot configuration Easy programming	Centralized control of multiple robots Cost reduction


Applicable to various field buses/centralized control of robots through connections of up to four controllers

RS-232C and Ethernet ports are provided as standard equipment. Additionally, fulfilling field buses, such as CC-Link, EtherNet/IP™, DeviceNet™, PROFIBUS, and PROFINET <sup>Note 1</sup> can be supported to connect and control a wide variety of devices. For 5 or more axes, use of YC-Link/E makes it possible to connect up to four RCX340 controllers so as to perform the centralized control of multiple robots. Additionally, when using YC-Link/E <sup>Note 2</sup>, multiple robots can be handled as if they are operated using one controller. This ensures very easy robot programming and management.

Therefore, this robot controller contributes to reduction of unseen costs, such as labor cost necessary for the setup work.

Note 1. Supports PROFINET Ver. 2.2

Note 2. When ordering YC-Link/E, please specify what robot is connected to what number controller.





# iVY System

Product Lineup

## ROBOT VISION iVY RCX240

Easy to use and reduction of work steps.

"Finds and Picks up" and "Pursues and Picks up" without teaching.

Many robot users might think, "We tried vision recognition, but it seemed to take a lot of work" or "we tried it before, but making adjustments was a tough job".

But YAMAHA iVY system solves these problems.





Anyone can make the setup easily to contribute to reduction of work steps.





# iVY system layout

A robot controller with an image processing function is completed only by setting the iVY board in the 4-axis controller RCX240 or RCX240S. As "eye" is put in the robot, the robot finds and takes workpiece, checks deviations in workpiece position, and makes correction if the workpiece deviates largely. This expands the range of applications.



POINT 1

### Easy for anyone to use, applicable to a wide variety of applications

When the system was upgraded by combining the robot with a generally available image processing unit, it took a long time conventionally to adjust the robot controller and image processing unit, and perform the correction calculation. In YAMAHA "iVY system", the vision board is integrated into the robot controller and the functions are limited to the positioning and position correction so as to greatly simplify the operability. This makes the system incredibly easy to use when compared to conventional vision systems. YAMAHA aimed at "a vision system that anyone can easily use". Please try to use YAMAHA's new robot vision.

#### Conventional robot vision

- ① Alignment with robot coordinates is difficult.
- ② Correction calculation is needed when the camera moves.
- ③ Operation deviation between the camera and robot due to communication time.
- ④ Adjustment of communication format is needed.

Image processing unit  
Camera cable  
Camera  
Light  
Power supply for lighting  
RS-232C communication  
RCX240  
Robot

- ✕ • Difficult to handle.
- ✕ • Hard to actually operate.
- ✕ • Installation and setup costs are high.
- ✕ • Difficult to know emergency contact address.

**Special skills are required and many work steps are needed.**  
Connecting an external camera to the robot controller requires tasks such as coordinate alignment (calibration), and correction programs are needed, so the startup work is difficult. When using for simple applications, many work steps are needed. So, possible applications are limited.

#### iVY system

- ① Simple calibration function is incorporated.
- ② Coordinates are corrected automatically even when the camera moves.
- ③ High-speed connections through dedicated bus line.
- ④ Controller is incorporated to provide the central operation.
- ⑤ Applicable to all models of YAMAHA robot lineup.

Point

Camera cable  
Camera  
Light  
RCX240  
+  
iVY board  
+  
Lighting control board  
Robot

- • Easy to use
- • Various applications are supported using easy operation.
- • Cost reduction by reducing work steps.
- • YAMAHA gives you total support.

**Easy operation extends applications**  
YAMAHA iVY system can be calibrated very simply  
Furthermore, the coordinates are corrected automatically when a camera is installed on the robot. As iVY system can be used, it can be applied to various applications.

POINT 2

### Easy workpiece registration only with 3 steps

YAMAHA aimed at "a vision system that anyone can easily use". But, image recognition itself has been around for a long time. However, conventional image recognition required complex tasks such as coordinate matching (calibration) or coordinate correction during camera movement, and it never became very popular. YAMAHA vision iVY System can be operated by anyone including machine designers or actual machine operators.

#### STEP. 1

##### Capture images.

Put the workpiece within the camera field-of-view and specify an image capturing range.

#### STEP. 2

##### Set the contour.

Contour is automatically extracted. Paint the necessary contour with a pen tool.

#### STEP. 3

##### Register the detection position.

Specify the detection position with the mouse. Desired positions can be set.


#### Search results

**POINT 3**

**Dedicated software "iVY Studio" included**

The iVY system includes dedicated software "iVY Studio". All operations related to the vision, such as registration of fiducial marks used for the calibration or workpieces (edge setting, various parameter setting, and image capturing range setting, etc.), backup, restore, and operation monitor can be performed only with this software.

**Support software iVY Studio**




- Search trial-run, part type registration
- Reference mark registration (for calibration)
- Up to 40 workpiece types can be registered.
- Workpiece can also be added easily.
- Up to 40 workpieces can be detected at once.
- Data backup
- This software functions as a monitor during program operation.

**POINT 4**

**Simple calibration function (coordinate matching alignment work) incorporated**

Conventional equipment combining "image processing unit + robot" requires many steps in "calibration" that aligns the camera coordinates with the robot coordinates. In the iVY system, the operation is completed easily in a short time only by following interactive instructions using the programming box. Additionally, the coordinate values are corrected automatically even when the robot installation position is changed, such as upward clamping, downward clamping, robot Z-axis clamping, or SCARA robot Y-arm clamping.




Just follow instructions on Wizards

**POINT 5**

**Setup time reduced greatly**

When using a general vision, a coordinate conversion program needs to be created in the robot controller since the robot coordinate data differs from the vision format. Since the robot controller is integrated into the iVY system, the robot coordinate data can be stored into the robot point data using single process. This ensures very simple operation. Additionally, the unified control of the camera control and light control can be performed using the robot program. The control becomes easy and the number of start-up steps can also be reduced.

**Comparison of setup time**



**POINT 6**

**Free selection from YAMAHA robot lineup**

This robot vision is applicable to all YAMAHA robots that can be operated by the RCX controller. According to the applications, an appropriate robot can be selected from the single-axis robots FLIP-X series, linear single-axis robots PHASER series, Cartesian robots XY-X, and SCARA robots YK-XG. A low-cost and easy-to-use robot vision system can be constructed with an optimal model suitable for applications.

■ Cartesian robots XY-X

■ SCARA robots YK-XG

■ Linear motor single-axis robots PHASER

■ Single-axis robots FLIP-X



## POINT 7

**Workpiece handling without teaching**

When the robot handles a workpiece, the teaching work to the correct position is absolutely required. If the workpiece position deviates, the correct handling cannot be performed.

Use of iVY system makes it possible to detect the correct position through the image recognition after coarse positioning. The workpiece can be transferred without teaching, so the start-up steps are reduced and workpiece can be changed or added flexibly.




## POINT 8


**Edge search engine with excellent stability**

The gray search (normalized correlation search) that was frequently used for conventional visions is vulnerable to adverse effects, such as lighting conditions, or workpiece chipping or contamination. The environments and applications are restricted.

The iVY system incorporates an "edge search engine" that performs the search process using information on contour shape. This contour search is resistant to effects on external environment and the range of applications is extended.



Search is made with good lighting.




Search is correct even with insufficient lightning.

## POINT 9

**High-speed connections through dedicated bus line**

By directly connecting the robot controller and CPU board through the bus, a data communication speed approximately 5,000 times higher than that of the serial communication speed with general vision is achieved.

Programming also becomes easy since the time lag due to communication does not need to be considered. Additionally, this robot vision supports the conveyor tracking that requires high-speed processing.




## POINT 10

**Applicable to conveyor tracking**

The iVY system is applicable to the conveyor tracking only by adding the tracking board. As the pulses (AB-phase) are taken from the encoder installed on the conveyor, the workpiece that is flowing can be picked up without stopping the conveyor.

As up to two encoders for the camera, lighting, and conveyor can be connected, the iVY system is applicable to movement between the conveyors.





## Vision is also controlled easily with robot programs.

The robot program executes all vision controls including camera switching, image capturing, and workpiece search. Program creation is simple when compared to general vision systems since the operations from the robot movement to the camera control are performed consistently. Furthermore, the debug work can be performed efficiently to greatly reduce the total number of work steps.

### Example of robot vision language

Command name	Function
VCAPTURE	Captures images from the camera.
VSEARCH	Searches for the specified part type.
VMONITOR	Switches the monitor mode between on and off.
VGETCNT	Acquires the number of parts that were found.
VGETPOS	Acquires the position data.
VGETTIME	Acquires a period of time used for the search command that was executed.
VGETSCR	Acquires judgment values for the detected workpiece.
VSAVEIMG	Saves images in BMP format.



## So, the iVY system can solve such problems.

### Number of teaching steps needs to be reduced.

Robot teaching work requires a lot of labor and time. The iVY system acts as "robot eye". The final fine positioning can be automated to greatly reduce the teaching time that was required for the conventional models.

### Positioning mechanism needs to be simplified.

In the current trend toward small-lot production of multiple models, a larger number of models means that positioning and other aspects of setup will require more time and trouble. Use of the iVY system makes it possible to greatly reduce costs necessary for manufacture, management, and replacement of positioning jigs.

### Random workpieces need to be handled.

Use of a position detection function of the iVY system makes it possible to simply construct operations, such as "workpiece is directly placed from the parts feeder" and "workpiece in the pallet is gripped and transferred".

### Workpiece flowing on the conveyor is picked up.

The iVY system is applicable to conveyor tracking. The position of the flowing workpiece is continuously recognized according to the signals from the encoder. The workpiece can be picked up without stopping the conveyor.

### Consultation destination is not found if a trouble occurs.

When a generally available image processing unit is combined with the robot, various problems such as being unable to capture images, unable to write data, or position deviation occur. YAMAHA iVY system will solve such troubles. The iVY system delivers total support for tasks ranging from capturing of images from the camera to operating the robot.

# iVY2 System

Product Lineup

## ROBOT VISION iVY2 RCX340

Integrated Robot Vision System with "plug-and-play" simplicity  
Basic specifications have been dramatically enhanced while retaining the current iVY system's ease of use.



### Simplicity

Setup is completed as little as eight minutes after power-on.  
**Auto-calibration** makes setup easy.

### Sophistication

**With up to five million pixels, a variety of workpieces can be supported.**  
Improve throughput to 100 CPM with conveyor tracking.


### Assurance

**Comprehensive support** covers everything from camera image acquisition to the operation of the gripper and robot.  
With support that only the robot manufacturer can provide, you can relax.

# Basic specifications have been dramatically enhanced while retaining the current iVY system's ease of use.

<b>Camera</b> Supports from 300,000 to <b>5</b> million pixels Megapixel camera support	<b>Number of registered types</b> Increased to <b>254</b> types Previously 40 types	<b>Shorter search time</b> Approximately <b>50</b> % less With capture: 30–40% less Search only: approximately 50% less <small>Note. Time depends on the workpiece.</small>	<b>Longer cables usable</b> Cables can be as long as <b>20</b> m Previously 9.5 m	<b>Monitoring</b> <b>Monitor output is provided</b> Enables operating status to be monitored without a PC
--	--	--	--	---


## iVY2 System configuration illustration



### POINT 1

## Various application examples

- **Labeling device** (affixing labels to food packages)
- **Sealant touch-up** (engine block sealant)
- **Screw attachment position detection** (television panel screw attachment)
- **Position compensation with upward-facing camera** (installing irregularly-shaped parts on a circuit board)




■ Industry: food  
 ■ Robot used: YK500TW omnidirectional robot

Even if the incoming workpieces are irregularly spaced or positioned, labels can be affixed at the same position.




■ Industry: automotive  
 ■ Robot used: SXYX Cartesian robot

Even if the workpiece is skewed from its correct position, the skew and angle are detected, and the application path is automatically compensated.



■ Industry: electronics  
 ■ Robot used: NXY Cartesian robot

Hole position is detected, and screws are fastened accurately.



■ Industry: electronics  
 ■ Robot used: YK150XG SCARA robot

The roughly-positioned circuit board connector is picked up, the upward-facing camera is used to apply position compensation, and the part is mounted directly on the circuit board.

POINT 2

Auto-calibration

Easily complete high-precision calibration just by following a wizard! Even if equipment becomes misaligned, execute auto-calibration and resume operation.

Requires as little as 5 minutes


STEP 1

Register the desired fiducial mark



STEP 2

Select the camera mounting method




POINT 3

Easy workpiece registration

From image acquisition, registration takes just three steps.

Requires as little as 3 minutes


STEP 1



Capture images.

Put the workpiece within the camera field-of-view and specify an image capturing range.


STEP 2



Set the contour.

Contour is automatically extracted. Paint the necessary contour with a pen tool.


STEP 3



Register the detection position.

Specify the detection position with the mouse. Desired positions can be set.

Search results




POINT 4

No need to make time-consuming connection settings. Dramatic reduction in setup time.

From image acquisition, registration takes just three steps.

Comparison of setup time







### STEP 3

#### Align fiducial mark position


If camera is movable, move the robot



If camera is fixed, attach fiducial mark to robot, and move it



### Execute auto-calibration



### POINT 5

## No need to create a coordinate conversion program.

Dedicated robot language for vision is provided.

#### General robot vision

```

MOVE P, P9
OFF LINE
SEND (* *) TO CMU
SEND CMU TO P10
ON LINE
MOVE P, P10
    
```

Communication with image processing unit

RS-232C

Program of image processing unit

Program of host PLC

Camera and robot have separate programs

#### iVY2 system

```

MOVE P, P9
VSEARCH 1,2,0
P10=VGETPOS(0)
MOVE P, P10
    
```

Searches for workpiece.  
Reads the point.  
Moves to this point.



**MERITS**


- No communication time lag
- Needs only few command lines.
- Simple and easy to understand

Centralized control using only the robot program

### POINT 6

## Easy inter-operation with peripheral equipment


The same controller provides unified control of robot, gripper, and lighting.



### POINT 7

## Also supports moving camera

Even if the camera is mounted on the robot, coordinates are automatically converted according to the robot's movement.



Conveyor tracking reaches **100** CPM per unit

POINT 8

### Conveyor tracking

Ideal for high-speed packaging arrangement high-speed transport of multiple types of items such as pharmaceuticals, cosmetics, and food products.

The vision camera detects the position and orientation of parts moving on the conveyor, and the robot picks them up.

Previous RCX240 controller		New RCX340 controller	
Example program (RCX240)			
① PTP command	MOVE P,P1	Executed using multiple operation commands	Unify movement commands →
② CTMOVE	CTMOVE (1)		
③ CTDRIIVE	CTDRIIVE(10.0)		
Multiple operating takt required		Example program (RCX340)	
		① New CTMOVE CTMOVE (1),Z=0.0,CTZ=10.0	
		Can be executed with a single command	
		Unify the move up command, follow workpiece command, move down command	

Reduce operating takt →

Seamless movement from move up to move down

Reduce movement distance

Operating conditions: YK500XG / payload 1 kg (total of workpiece and tool) / horizontal movement 250 mm / vertical movement 1 mm / conveyor speed 100 mm/sec

POINT 9

### Control multiple robots for even more improvement in production efficiency.

Shortened cycle time  
Improve throughput

RCX340 + iVY2

RCX340

Tracking board

YC-Link/E

Connect up to four units  
100 CPM/unit x 4 units (maximum 400 CPM)

Program allows differentiation by model for even more improvement in production efficiency

Information from a single camera can be shared by multiple robots

Control two robots to let downstream robot handle missed items


Conveyor direction

## POINT 10

### Approximately double the search speed (compared to previous model)


Even a large number of workpieces can be detected at high speed. The search speed is approximately double that of the previous model. This can be used for a wide variety of applications, including molded plastic parts or food items.

Sample workpiece ① Connector-shaped workpiece




**RCX240 + iVY** 158.7 ms → **RCX340 + iVY2** 83.8 ms

Sample workpiece ② Washer-shaped workpiece



**RCX240 + iVY** 200.2 ms → **RCX340 + iVY2** 91.7 ms

Sample workpiece ③ Food item workpiece



**RCX240 + iVY** 149.8 ms → **RCX340 + iVY2** 91.1 ms

## POINT 11

### Support for five-megapixel cameras

(Choose from 300,000 pixel, 1.3 megapixel, and 2 megapixel, and 5 megapixel)


- Stable workpiece detection
- Decreased number of search detections

Detailed edge detection is possible even if workpieces are touching each other or have a complex shape.

- Previous: 300,000 pixel camera
- New: 1.3 megapixel camera





(partial detail illustration)



(partial detail illustration)

A single search allows detection even for a large workpiece, improving takt.

- Previous: 300,000 pixel camera
- New: two-megapixel camera



Field of vision

## POINT 12

### 254 types can be registered

Setup changes require only that part numbers be changed. Setup changes are easy.



## POINT 13

### Monitor output is provided

- Monitor the operating status

Monitor the search status while making calibration settings or during automatic operation.

#### Contents of output

- Selected type / Captured image
- Search result (position, score, scale)
- Executed command
- Time required by command

#### Output method

- DVI-I (supports digital monitor or analog monitor)




## POINT 14


### High-precision search even under low light

- Edge search engine is built-in

Supports a variety of applications while being minimally affected by the external environment.



When lighting is sufficient




Accurate search even if lighting is insufficient

POINT 15

### Preparatory evaluation and advice give you peace of mind

We borrow the workpiece from you, evaluate it, and submit an evaluation report.

In addition, we draw on our wealth of experience and evaluation results to provide advice and training regarding selection and installation of robots and peripheral equipment.



POINT 16

### Choose freely from Yamaha's lineup of robots

A low-cost and convenient robot vision system can be constructed using the models that are optimal for the customer's application.

■ XY-X Cartesian robots



■ YK-XG SCARA robots



■ YK-TW orbit type robots



■ FLIP-X single-axis robots



Note. The YA series is not supported.



# YRG Series

Product Lineup

## ELECTRIC GRIPPERS

Electric grippers dedicated to the RCX240/RCX340 controller. Easy operation is achieved as YAMAHA robot language gives unified control.



### Gripping force control

Gripping force can be set in 1 % steps from 30 to 100 %.

### Measuring

Workpiece can be measured using position detection function.

### Speed control

Speed can be set in 1 % steps from 20 to 100 % and acceleration can be set in 1 % steps from 1 to 100 %.

### Multi-point position control

Up to 10,000 positioning points can be set.

### Workpiece check function

Workpiece gripping mistake or workpiece drop can be checked by the HOLD output signal without using sensor.

# Plenty of lightweight and compact model variations

## S type Single cam type

P.583

Lightweight, compact, high-speed



**Single cam structure**  
Use of a unique cam structure achieves the simple and compact design. As the self-lock is not activated, the fingers can be operated using an external force.

## W type Double cam type

P.585

High gripping force



**Double cam structure**  
Unique double cam structure with gear. Use of a simple structure achieves high gripping force with compact body.

## Screw type Straight shape

P.586

High accuracy, long stroke



## Screw type "T" shape

P.587



**Ball screw structure**  
As the ground ball screw is driven by the belt, the long stroke with high efficiency and high accuracy is achieved.

## Three fingers type

P.588

Compact, high rigidity, long stroke



**Compact ball guide structure**  
Use of a special cam provides lightweight and compact electric grippers. These electric grippers are suitable for transfer of round workpieces made of glass or similar materials.

Type	Model	Gripping force(N)	Open/close stroke (mm)	Maximum speed (mm/sec.)	Repeated positioning accuracy (mm)	Main body weight (g)	Page
Compact single cam	YRG-2005SS	5	3.2	100	+/- 0.02	90	P.583
Single cam	YRG-2010S	6	7.6	100	+/- 0.02	160	P.584
	YRG-2815S	22	14.3	100	+/- 0.02	300	
	YRG-4225S	40	23.5	100	+/- 0.02	580	
	YRG-2005W	50	5	60	+/- 0.03	200	
Double cam	YRG-2810W	150	10	60	+/- 0.03	350	P.585
	YRG-4220W	250	19.3	45	+/- 0.03	800	
	YRG-2020FS	50	19	50	+/- 0.01	420	
Screw type Straight shape	YRG-2840FS	150	38	50	+/- 0.01	880	
Screw type "T" shape	YRG-2020FT	50	19	50	+/- 0.01	420	P.587
	YRG-2840FT	150	38	50	+/- 0.01	890	
Three fingers type	YRG-2004T	2.5	3.5	100	+/- 0.03	90	P.588
	YRG-2013T	2	13	100	+/- 0.03	190	P.589
	YRG-2820T	10	20	100	+/- 0.03	340	
	YRG-4230T	20	30	100	+/- 0.03	640	

- Gripping force control: 30 to 100 % (1 % steps)
- Speed control: 20 to 100 % (1 % steps)
- Acceleration control: 1 to 100 % (1 % steps)
- Multi-point position control: Maximum 10,000 points
- Workpiece size judgment: 0.01 mm steps (by ZON signal)


## POINT 1

## Electric grippers achieve highly accurate gripping force, and position, and speed controls.

The YRG series provides the gripping force control, speed and acceleration controls, multi-point control, and workpiece measurement that were difficult by conventional air-driven devices. The YRG series flexibly supports various applications.


### Gripping force control

The gripping force can be set in 1 % steps. Workpieces that are easy to break or deform, such as glass or spring can be gripped. The gripping force is constant even when the finger position changes.



### Workpiece presence check function

The electric gripper outputs the HOLD signal. Workpiece gripping mistake or workpiece drop during transfer can be checked. No external sensors are needed.



### Speed control

The speed and acceleration can be set in a range of 20 to 100 mm/sec. in 1 % steps (single cam and three fingers type). The gripper can gently touch workpieces that are vulnerable to impact, such as lenses or electronic components.


## POINT 2

## Gripper can be controlled with controller commands.

The gripper controls can be performed with one multi-axis controller RCX240/RCX340. Data exchanging with the host unit, such as PLC is not needed. The setup or startup can be made easily.


### Multi-point position control

The finger can be set to a desired position according to the workpiece size. This contributes to efficiency improvement of lines with different workpiece sizes and materials mixed and lines with many setup steps.




### Measuring function

The gripped workpiece can be measured using the position detection. Use of this function makes it possible to correctly judge what portion of the workpiece is gripped.



### Zone range function

Use of this zone range function makes it possible to judge the size OK/NG and check for slant insertion.



### List of robot languages (example)


Language name	Function
<b>GDRIVE</b>	Absolute position movement
<b>GDRIVEI</b>	Relative position movement
<b>GHOLD</b>	Absolute position gripping movement
<b>GHOLDI</b>	Relative position gripping movement
<b>GOPEN</b>	Constant speed gripping movement (open)
<b>GCLOSE</b>	Constant speed gripping movement (close)
<b>GORIGIN</b>	Gripper axis return-to-origin
<b>GSTATUS</b>	Status acquisition
<b>ORIGIN</b>	Return-to-origin
<b>WHERE</b>	Main group current position acquisition (joint coordinate: pulse)
<b>WHERE2</b>	Sub group current position acquisition (joint coordinate: pulse)
<b>WHRXY</b>	Main group current position acquisition (Cartesian coordinate: mm, degree)
<b>WHRXY2</b>	Sub group current position acquisition (Cartesian coordinate: mm, degree)




## POINT 3

### Combination with a vision system supports a wide variety of applications.

As the YRG series is combined with controller integrated robot vision "iVY System", the operations from the positioning using the camera to workpiece handling can be controlled in the batch mode using the RCX240/RCX340 controller. Sophisticated systems can be easily configured.





## Gripping force comparison of electric gripper models





## Application examples

### Deformation prevention transfer of resin rings, etc.





- Measuring function
  - Gripping force control
  - Speed control
  - Multi-point position control
- (Maintains workpiece shape.)  
(Maintains workpiece shape and prevents scratches.)  
(Maintains workpiece shape and prevents scratches.)  
(Applicable to many part types of workpieces.)

### Chip assembly transfer Deformation prevention and lead protrusion dimension check



- Measuring function
  - Gripping force control
  - Speed control
  - Multi-point position control
- (Checks lead protrusion dimensions.)  
(Maintains workpiece shape and prevents scratches.)  
(Maintains workpiece shape and prevents scratches.)  
(Applicable to many part types of workpieces.)

### Transfer and dimension check of flexible workpieces with different sizes



- Measuring function
  - Gripping force control
  - Speed control
  - Multi-point position control
  - Reduction of setup work
- (Checks lead protrusion dimensions.)  
(Prevents workpiece deformation.)  
(Prevents scratches.)  
(Applicable to many part types of workpieces.)  
(Improves productivity.)

Note. Air unit cannot control the gripping force and speed, causing workpiece to be scratched or tact time not to be shortened.



# APPLICATION

## CONTENTS

### STEPPING MOTOR SINGLE-AXIS ROBOTS TRANSERVO

Pressing and cutter machines	92
Pressing and pitch feed	92

### SINGLE-AXIS ROBOTS FLIP-X

Clean, dustproof / dripproof, high-speed conveying unit	92
Contact stopper height change unit	92
Screw tightening device	93
Device to shift workpiece in width direction	93
Press-fitting device	93
O-ring fitting device	93
Carrying and transferring equipment	93
Jig and tool positioning mechanism	93
Painting by combining multiple single-axis robots	94
Tape affixing to circular workpieces	94

### LINEAR MOTOR SINGLE-AXIS ROBOTS PHASER

Check camera moving unit	94
Ink jet printer	94
Chip mounter	95
Check device	95
Open / close device	95
High-speed screw tightening unit	95
High-speed applicator (1)	95
High-speed applicator (2)	95
High-speed pick & place unit	96
High-speed loading / unloading robot	96

### CARTESIAN ROBOTS XY-X

Conveyor (2 parts simultaneously)	96
Application of adhesive agent	96
IC palletizing within the unit	97
Tester (2 Cartesian robots controlled simultaneously)	97
Sealing	97

Transfer and stacking device within the unit	97
Dispenser	97
Insertion unit (Tare weight cancellation using moving Z + air balancer)	97
Assembler & tester base machine (Simultaneous operation at upper and lower levels)	98
Part assembly machine	98
Part pick and place	98
Dual-drive transport between processes	98
Application example of combination with auxiliary single-axis	98
Application example of long-stroke and dual-drive	98

### SCARA ROBOT YK-X

Finished product inspection, touch-panel type evaluation machine	99
Conveying masks for wafers	99
Tall work pieces conveying and stacking machine	99
Assembly cell (independent cell)	99
Assembly cell (line cell)	99
Assembly cell (Handling unit for special purpose tester)	100
Inter-process transport	100
Inter-process transport with inverse specifications applied	100

### PICK & PLACE ROBOTS YP-X

Precision part assembler (1)	100
Precision part assembler (2)	100

### ROBOT VISION iVY/iVY2

Small part palletizing	101
Loading parts into assembler machine	101
Screw tightening work with SCARA robot	101
Pick & place work	101
Sealing correction	101
Labeling device	102
Screw attachment position detection	102
Position compensation with upward-facing camera	102

## YAMAHA STEPPING MOTOR SINGLE-AXIS ROBOTS


# TRANSERVO Series



P.127

## Pressing and cutter machines

- Cuts plastic lens material
- Pressing function applications




### POINT

- Cutting tasks using the TRANSERVO (TS-S, TS-X, TS-P) pressing function
- Pressing torque is adjustable, and time-out time and operation after reaching specified torque can be selected as desired (continuous pressing, position hold).
- Host control can be simplified by setting multiple continuous operation points.

## Pressing and pitch feed

- Positioning for bread loaf slicing
- Pressing function and pitch feed applications



### POINT

- Measures bread thickness with robot and identifies bread type. (TS positioner can send feedback on current position.)
- Varies the pitch feed quantity to match workpiece type.
- Pressing torque is adjustable to match the workpiece type.

## YAMAHA SINGLE-AXIS ROBOTS

# FLIP - X Series



P.169

## Clean, dustproof / dripproof, high-speed conveying unit

- Transfer and conveyance in the clean environment.
- Transfer and conveyance in the harsh environment.




### POINT

- Belt drive type robot complying with cleanliness requirement.
- With a large payload, it is optimum for conveying panels.
- Provided with specifications for cleanliness and applicable to long stroke.
- With the payload and moment permissible value at high level, it is applicable to the Cartesian combination.
- Equivalent to B10 (YAMAHA model) .

## Contact stopper height change unit

- Change of stopper height in multiple number of steps.




### POINT

- The stop position for the stopper block is positioned by the cylinder type robot.
- It is possible to make set-up done by single touch operation or automatically.

### Screw tightening device

- Tightening screws arranged on a straight line.




#### POINT

1. High rigidity with a support axis added.
2. Pitch selectable freely in the moving axis direction.

### Device to shift workpiece in width direction

- Positioning of workpieces flowing on the conveyor.




#### POINT

1. Arrangement of multiple number of compact robots.
2. Pulse string control from the upper controller.

### Press-fitting device

- Workpieces are press-fitted in holes arranged on a straight line.




#### POINT

1. Highly rigid frame.
2. Applicable to work positions arranged linearly.

### O-ring fitting device

- Handling workpieces to assembly units arranged on a straight line.




#### POINT

1. Assembly jigs arranged on a straight line under the single axis robot.

### Carrying and transferring equipment

- Handling parts




#### POINT

1. Space saving layout using double carrier. (N15 / N18)

### Jig and tool positioning mechanism

- Adjustment of cutting fluid nozzle position of machining center
- Positioning under harsh working environments



#### POINT

1. The adoption of a magnetic accuracy detection resolver allows use even under adverse conditions.

## Painting by combining multiple single-axis robots

- Interpolation control of multiple single-axis robots is performed for painting work.




### POINT

- As single-axis robots are controlled with the multi-axis controller, such as RCX240, the linear or circular interpolation operation can be performed with combined coordinates.
- A layout, such as desktop type that is different from the normal Cartesian robot can be configured.
- Optimal specifications can be selected from the versatile single-axis robot lineup and they can be combined.

## Tape affixing to circular workpieces

- Interpolation control of multiple single-axis robots is performed for tape affixing to circular workpieces



### POINT

- Multiple single-axis robots are controlled with one multi-axis controller (multi-robot).
- Use of an interpolation function of the multi-axis controller makes it possible to synchronize each axis.
- As each axis is synchronized, a tension applied to the tape is kept constant to provide tape affixing without elongation or sagging.

## YAMAHA LINEAR MOTOR SINGLE-AXIS ROBOTS


# PHASER Series



P.215

## Check camera moving unit

- Checking with moving camera.
- Multi-point check with a camera.
- Drawing created with line sensor and moving axes.




### POINT

- Allows movement with minimal speed fluctuations.
- Compact size.

## Ink jet printer

- Ink jet feeding mechanism.




### POINT

- Allows movement with minimal speed fluctuations.
- Capable of coping with a request for high speed. (Max. 2,500mm/sec)
- Allows setting long constant-speed sections, with large acceleration.

## Chip mounter

- Bonding and chip mounting on circuit board.
- Electronic part mounting process.




### POINT

1. Double carrier structure enabled compact size.
2. Layout designing is easy as different workpieces can be carried onto the same axis.
3. Clean specification requirement can be coped with easily.

## Check device

- Handling to multiple number of check devices.




### POINT

1. 2 heads can be installed to the same axis compactly.
2. High speed operation.

## Open / close device

- Wide open/close of shutter.




### POINT

1. It is possible to drive a work with a large width (shutter) using the dual drive method.
2. Various advantages (such as center layout, higher open / close speed, sharing of effective stroke) are available due to adoption of the double carrier mechanism.
3. Drives with the dual drive mechanism with 2 units of double carrier PHASER in parallel and fixing them with sliders respectively.
4. RCX240 can control 4 axes in all.

## High-speed screw tightening unit

- Positioning 2 nut runners at the same time for a large work piece.
- 2 screws at opposite locations tightened at the same time.




### POINT

1. Performs high-speed, high-accuracy screw tightening on large work pieces such as large construction materials.

## High-speed applicator (1)

- Application to a large size workpiece such as liquid crystal circuit board and the like.




### POINT

1. Capable of applying to a large size work such as a flat panel display.

## High-speed applicator (2)

- Application to a large size workpiece such as liquid crystal circuit board and the like.



### POINT

1. Capable of applying to a large size work such as a flat panel display.
2. It is possible to drive a work with a large width using the dual drive method.

## High-speed pick & place unit

- Pick & place operation from the rack for large size parts.




### POINT

1. Capable of carrying over a long distance between processes in various production facilities.

## High-speed loading / unloading robot

- The loading unit and unloading unit are mounted on the same axis.



### POINT

1. Utilizing double-carriers allows building systems that are highly efficient in saving space.

## YAMAHA CARTESIAN ROBOTS


### XY-X Series



P.239

## Conveyor (2 parts simultaneously)

- Conveyance with high efficiency using double arms.




### POINT

1. Setting 2 units on the Z-axis intersecting XZ drastically cuts the total tact time and reduces the required installation space.
2. Customization only possible because a highly rigid frame and guide are used.

## Application of adhesive agent

- Application of adhesive agent within a large size liquid crystal surface processing unit.




### POINT

1. Capable of handling large size workpieces.
2. Also applicable to cutting work with a cutter, surface check with a camera, etc.



## IC palletizing within the unit

- ICs are taken out of the pallet and parts are transferred to the specified place by the XYZ Cartesian robot.
- Application as a part of the machine used in the process where a die is attached to the circuit board using thermocompression bonding in the manufacture of semi-conductors.




### POINT

1. By using the RCX controller, it is possible to use the result of the operation based on variables during palletizing.

## Tester (2 Cartesian robots controlled simultaneously)

- Use as a tester in the post-process of manufacturing electronic parts.




### POINT

1. 2 units of SXYx are operated using 1 unit of RCX240 with settings for 2 robots.
2. The vertical traveling accuracy of XY axes of both 2 units of SXYx is within +/- 0.05mm.

## Sealing

- Spreading sealant to mating faces of the cases.




### POINT

1. Three dimensional application using 3 axes Cartesian robot. Cartesian robot incorporated with special purpose machine.

## Transfer and stacking device within the unit

- Used in the sheet metal processing unit.




### POINT

1. X1 and X2 axes are superposed for space efficiency.
2. The unit layout is easy even for the doubled stroke.

## Dispenser

- Spreading adhesive agent to drums.




### POINT

1. Boosting the R axis strength allows 3-dimensional interpolation + R operation.
2. Each axis has high rigidity and so can easily withstand harsh conditions such as on the moving arm (handles 100mm/sec).

## Insertion unit

(Tare weight cancellation using moving Z + air balancer)

- Heavy workpiece inserted in the pallet, etc.
- Heavy workpiece before processing set in the processing machine.




### POINT

1. Z axis moving type: The heavy workpiece is cancelled by the air balancer and moved up and down.

## Assembler & tester base machine (Simultaneous operation at upper and lower levels)

- Tester (upper and lower probes, camera with lighting) .
- Precision spot welding machine.
- Simultaneous assembly at upper and lower levels (caulking parts, screw tightening) .




### POINT

1. Simultaneous control of 2 Cartesian robots.
2. Levelness of upper and lower robots assured (custom specification) .

## Part assembly machine

- Automotive clutch assembly
- Efficient alternate assembly of two different parts




### POINT

1. Double-arm ensures a short tact time along with a space-saving footprint.
2. Double-arm specifications selectable as standard feature.
3. Y axis and Z axis strokes are selectable separately for left and right. (Special orders available)
4. Nut rotation type X axis supports long stroke and also maintains maximum speed.

## Part pick and place

- Pick and place of parts from index




### POINT

1. Vision system recognizes parts on index, and robot extracts and sorts the parts.
2. Vision system identifies the type and position and directs robot to operating position.
3. Robot shifts not only to pre-instructed teaching position but also to any position based on data sent from external device.
4. Fieldbus to communicate with controller is selectable from RS-232C, Ethernet or CC-Link.

## Dual-drive transport between processes

- Uses dual-drive to convey large and heavy workpieces




### POINT

1. Dual-drive allows synchronized operation of two single-axis robots of the same type.
2. Using dual-drive even allows conveying heavy items or large size parts and products.
3. Enhanced acceleration also helps cut tact time.

## Application example of combination with auxiliary single-axis

- Cartesian robot and single-axis robot are controlled with one controller.



### POINT

1. Multiple robots can be controlled simultaneously with one controller. Up to 8 axes of maximum 2 groups can be expanded.
2. As multiple robots are controlled with one controller, the linking can be performed without using the I/O of the PLC or between the controllers. Therefore, there are merits that the number of control program creation steps is reduced to shorten the equipment startup time and reduce the labor cost.

## Application example of long-stroke and dual-drive

- Long-stroke axis is combined with Cartesian axis using the dual-drive control.



### POINT

1. As the dual drive (simultaneous 2 axes) control is applied, a Y-axis long-stroke of up to 2m can be supported. This is applicable to long-distance transfer and heavy workpiece transfer specifications.
2. As the vertical axis is combined, this can be applied to the inspection with large LCD glass panels arranged vertically.
3. According to required repeated accuracy, YAMAHA proposes optimal combination mechanism and control method.

YAMAHA SCARA ROBOT


YK - X Series



P.367

Finished product inspection, touch-panel type evaluation machine

- Finished product function test.
- Developed software evaluation.
- Push-button type quality check.




POINT

1. Supports a variety of systems in a product lineup that is top class in its field with arm lengths from 120mm to 1200mm.
2. Space saving.
3. Using SCARA, judgment is made through image processing by pushing each button.

Conveying masks for wafers

- Replacing wafer mask from the stocker.




POINT

1. Drive section installed beneath work pieces has clean specs + inverted structure.
2. If the cylindrical coordinate type robot is used, a running axis is necessary for this application. However, if SCARA with the interpolation function is used, the fixed type is usable.

Tall work pieces conveying and stacking machine

- Tall workpieces stacked by utilizing long Z axis.




POINT

1. Z-axis long stroke is also accepted as special order. If a stroke longer than the standard stroke shown below is needed, consult YAMAHA.  

Standard Z-axis stroke	
[YK120XG to YK180XG]..... 50mm	[YK180X to YK220X]..... 100mm
[YK250XG to YK600XGL].... 150mm	[YK500XG to YK600XG].. 200mm/300mm
[YK600XGH to YK1000XG].. 200mm/400mm	[YK1200X]..... 400mm
2. SCARA robot is used by utilizing its advantages, such as X/Y-axis speed and space saving installation.

Assembly cell (independent cell)

- Base machine of independent type assembly cell.




POINT

1. Optimum for multi type variable quantity production.
2. Setting up reception places forms a construction of multiple number of cells.

Assembly cell (line cell)

- Base machine of line type assembly cell.




POINT

1. Utilization of advantages of SCARA with a wide operation range.
2. Form a line to any length by coupling these cells together.

## Assembly cell (Handling unit for special purpose tester)

- When placed between 2 turn tables, handling of both tables is possible.

Special purpose tester



### POINT


- Utilization of advantages of SCARA which has a wide operation range.

## Inter-process transport

- Conveys large and heavy workpieces



Web site



### POINT


- Built-in structure with no timing belt achieves high allowable moment-of-inertia on R axis.
- High allowable moment-of-inertia on R axis permits using large hand on robot. So more workpieces can be conveyed per one time which makes operation more efficient.
- R axis can be driven at high acceleration during low moment-of-inertia. This shortens the tact time.
- Uses a harmonic gear as XYR axis speed reducers. No periodic greasing is required due to sealed grease.  
Note: Available for YK500XG to YK1000XG.

## Inter-process transport with inverse specifications applied

- Workpiece inter-process transport with inverse specifications applied



Web site



### POINT

- As the inverse specifications are applied, the workpieces can be held from the lower portion to prevent foreign objects from dropping onto workpieces being transported.
- The performance of the robot mechanical section is similar to the standard specifications. The high performance of the YK-XG series can be utilized.
- YAMAHA SCARA robot can select three installation patterns, standard floor installation, wall-mount, inverse specifications<sup>(Note)</sup>. YAMAHA proposes various ideas about equipment design.

Note. If the robot with the standard specifications, normal ceiling-mount specifications, or wall-mount specifications is installed upside down, this may cause a malfunction. When considering the installation like this, be sure to use the robot with the dedicated inverse specifications (YK-XS-U).

## YAMAHA PICK & PLACE ROBOTS


### Y P - X Series



P.427

## Precision part assembler (1)

- Assembly of small size precision parts.




### POINT

- High speed assembly.
- Narrow machine width, and settable with a tiny pitch.

## Precision part assembler (2)

- Assembly of small size precision parts.



### POINT

- Speed increased even more when used in combination with a rotary table.


# iVY/iVY2 System



iVY P.572 / iVY2 P.576

## Small part palletizing


- Assemble a sorting pallet for the automated machine in the next process.



### POINT

## Loading parts into assembler machine

- Loads unsorted parts or components into automated equipment.



### POINT

## Screw tightening work with SCARA robot

- Screw tightening work with the SCARA robot is improved using the iVY system.



### POINT

- As the position detection function using the iVY system is added, the robot is applicable to various conditions. For example, if the screw hole position varies, the workpiece position on the conveyor is not constant, or various workpieces are supplied, the robot can be installed easily.
- Use of iVY system makes it possible to perform the calibration using system operation. As the teaching steps can be reduced, the equipment startup time is shortened and labor cost can be reduced.

## Pick & place work

- Component pick & place work is improved using iVY system.




### POINT

- As the position detection function using the iVY system is added, components on soft pallets or pallets with low accuracy can be gripped correctly.
- Therefore, merits are provided that the pallet manufacture cost is reduced, positioning mechanism is simplified, and equipment cost is reduced.
- Two camera input channels are provided on one controller.
- The camera can be incorporated into the robot or secured outside the robot. Simple calibration work can be performed under either of the conditions.

## Sealing correction

- Sealing tasks for placing gaskets or applying adhesives in parts
- Coating trajectory correction using iVY system




### POINT

- Use of iVY system makes corrections to Cartesian robot sealing tasks.
- iVY system detects deviations and tilting even if workpiece strayed from its main position, and automatically corrects the coating trajectory.
- Maintains high coating quality even during low positioning accuracy on component side.

## Labeling device

- Affixing labels to food packages




### POINT

1. Even if the incoming workpieces are irregularly spaced or positioned, labels can be affixed at the same position.

## Screw attachment position detection

- Television panel screw attachment




### POINT

1. Hole position is detected, and screws are fastened accurately.

## Position compensation with upward-facing camera

- Installing irregularly-shaped parts on a circuit board



### POINT

1. The roughly-positioned circuit board connector is picked up, the upward-facing camera is used to apply position compensation, and the part is mounted directly on the circuit board.

# Officially discontinued models and service period

Models listed in the current model column are equivalent items. Since these might not be compatible in some cases, please contact Yamaha if you are considering replacement.  
E-MAIL [robotn@yamaha-motor.co.jp](mailto:robotn@yamaha-motor.co.jp)

Single-axis robots				
Series	Model	Sale discontinued time	Service period	Current model (equivalent)
FLIP-X	YMS45	Dec. 2013	Dec. 2020	-
	YMS55			
	T4	Dec. 2012	Dec. 2019	T4L
	T4H			T4LH
	T5			T5L
	T5H			T5LH
	T6			T6L
	C4			C4L
	C4H			C4LH
	C5			C5L
	C5H			C5LH
	C6			C6L
	T7	Dec. 2009	Dec. 2016	-
	F17 (Former model)	Sep. 2002	Sep. 2009	F17 (Latter model)
	F17 (Latter model)	-	-	On sale
	F20 (Former model)	Sep. 2002	Sep. 2009	F20 (Latter model)
	F20 (Latter model)	-	-	On sale
	T9 (Former model)	Oct. 2001	Oct. 2008	T9 (Latter model)
	T9 (Latter model)	-	-	On sale
	T9H (Former model)	Oct. 2001	Oct. 2008	T9H (Latter model)
T9H (Latter model)	-	-	On sale	
F10 (Former model)	Oct. 2001	Oct. 2008	F10 (Latter model)	
F10 (Latter model)	-	-	On sale	
F14 (Former model)	Oct. 2001	Oct. 2008	F14 (Latter model)	
F14 (Latter model)	-	-	On sale	
F14H (Former model)	Oct. 2001	Oct. 2008	F14H (Latter model)	
F14H (Latter model)	-	-	On sale	
PHASER	MR16/16D	Dec. 2011	Dec. 2018	MF15/15D
	MR16H/16HD			MF20/20D
	MR20/20D			MF30/30D
	MR25/25D	Mar. 2011	Mar. 2018	MF75
	MF50/50D			
MF100/100D				
Pico	T4P	Dec. 2009	Dec. 2016	-
	T5P			
FLIPt	FSt	Jan. 2002	Jan. 2009	F10
	BFSSt			B10
	LTt			T9
	LSt			F14
	BLSt			B14
	LRt			-
	LTHt			T9H
	LSHt			F14H
	BLSHt			B14H
	MSt			F17
	HSt			F20
	HSLt			F20N
	BHS			-
	FROP-Ft			R5
	FROP-St			R10
	FROP-Mt			R20
	TR			-
FTt	-			
Economy Type	BPS	Jan. 2002	Jan. 2009	-
	PS			
	BSt			
FLIP AC	BFSA	Jul. 1998	Jul. 2005	B10
	BLSA			B14
	BSA			-
	FROP-FA			R5
	FROP-HA			-
	FROP-MA			R20
	FSA			F10
	FTA			-
	HSA			F20
	HSC			C20
HSLA	F20N			

OFFICIALLY DISCONTINUED MODELS AND SERVICE PERIOD

Continues on next page ▶

## Single-axis robots (continued)

Series	Model	Sale discontinued time	Service period	Current model (equivalent)
FLIP AC	LRA	Jul. 1998	Jul. 2005	-
	LSA			F14
	LTA			T9
	MS			-
	MSA			F17
	MTA			T9H
FLIP DC	BFS	Jul. 1998	Jul. 2005	B10
	BLSII			B14
	BS			-
	FROP-F			R5
	FROP-M			R20
	FROP-H			-
	FS			F10
	FT			-
	FTB			-
	HS			-
	HSL			-
	LR			-
	LS/LSII/LSB/LSI			F14
	LT/LTB/LTI			T9
	MS			F17
MT	T9H			

## Cartesian robots

Series	Model	Sale discontinued time	Service period	Current model (equivalent)
XY-X	MXYY 3 axis ZF	Jan. 2005	Jan. 2012	MXYY 3 axis ZFL/ZFH
	MXYY 4 axis ZRF			MXYY 4 axis ZRFL/ZRFH
	MXYY pole type ZPM			MXYY pole type
	TXYY	Mar. 2004	Mar. 2011	PXYX
	SXYX (Former model)	Oct. 2001	Oct. 2008	SXYX (Latter model)
	SXYX (Latter model)	-	-	On sale
	MXYY (Former model)	Oct. 2001	Oct. 2008	MXYY (Latter model)
	MXYY (Latter model)	-	-	On sale
	HXYX (Former model)	Sep. 2002	Sep. 2009	HXYX (Latter model)
HXYX (Latter model)	-	-	On sale	
XYt	FXyt	Jan. 2002	Jan. 2009	FXYBX
	SXYt-C			SXYX
	SXYt-S			SXYBX
	SXYLt			-
	MXyt-C			MXYY
	MXyt-S			-
	HXYt-C			HXYX
HXYt-S	-			
HXYLt	HXYLX			
XY AC	SXYA	Jan. 1999	Jan. 2006	SXYX
	SXYLA			SXYBX
	MXYA			MXYY
	HXYA			HXYX
	HXYLA			HXYLX
XY DC	FXy	Jan. 1999	Jan. 2006	-
	FXyL			-
	SXY			SXYX
	SXYI			-
	SXYL			-
	MXy			-
MXyL	Oct. 1995	Oct. 2002	-	

## Pick & place robots

Series	Model	Sale discontinued time	Service period	Current model (equivalent)
YP	YPX220	Apr. 2001	Apr. 2008	YP220BX
YP AC	YP320A	Apr. 2001	Apr. 2008	YP320X
	YP340A			YP340X
	YP330A			YP330X
YP DC	YPS21	Jul. 1998	Jul. 2005	-
	YP340	May 1996	May 2003	YP340X
	YP330			-
	YP320			YP320X



## SCARA robots

Series	Model	Sale discontinued time	Service period	Current model (equivalent)
YK-XP	YK500XP	Dec. 2013	Dec. 2020	YK500XGP
	YK600XP			YK600XGP
	YK700XP			YK700XGP
	YK800XP			YK800XGP
	YK1000XP			YK1000XGP
	YK250XP	Dec. 2012	Dec. 2019	YK250XGP
	YK350XP			YK350XGP
YK400XP	YK400XGP			
YK-XC	YK250XC(H)	Dec. 2012	Dec. 2019	YK250XGC
	YK350XC(H)			YK350XGC
	YK400XC(H)			YK400XGC
YK-XS	YK300XHS	Dec. 2012	Dec. 2019	YK300XGS
	YK400XHS			YK400XGS
	YK500XS			YK500XGS
	YK600XS			YK600XGS
	YK700XS			YK700XGS
	YK800XS			YK800XGS
	YK1000XS			YK1000XGS
YK-X	YK250X(H)	Dec. 2012	Dec. 2019	YK250XG
	YK350X(H)			YK350XG
	YK400XH			YK400XG
	YK550X(H)	Dec. 2009	Dec. 2016	-
	YK120X	Dec. 2008	Dec. 2015	YK120XG
	YK150X			YK150XG
	YK400X			YK400XG
	YK500X			YK500XG
	YK600X			YK600XG
	YK700X			YK700XG
	YK800X			YK800XG
	YK1000X			YK1000XG
	YK AC (SANYO motor model)	YK550H	Mar. 2003	Mar. 2010
YK420A-I/420ALZ-I/440A-I		Mar. 2001	Mar. 2008	YK400XG
YK540A-I/541A-I				YK500XG
YK520A-I				YK600XG
YK640A-I/641A-I				YK700XG
YK620A-I				YK800XG
YK740A-I/741A-I				YK1000XG
YK720A-I				-
YK840A-I/841A-I				YK1200X
YK820A-I				-
YK1041A-I				-
YK1043A-I	-			
YK1243A-1	-			
YK AC (YASUKAWA motor model)	YK420A/420ALZ/440A	Dec. 1995	Dec. 2002	YK400XG
	YK520A/540A/541A			YK500XG
	YK620A/640A/641A			YK600XG
	YK720A/740A/741A			YK700XG
	YK820A/840A/841A			YK800XG
	YK1041A			YK1000XG
	YK1043A			-
	YK1243A			YK1200X
YK DC	YK5020/5021	May 1997	May 2004	Replacement unavailable
	YK7011/7012/7022			YK400XG
	YK4000/4000LZ/4040			YK500XG
	YK420/420LZ/440			YK600XG
	YK520/540/541			YK700XG
	YK620/640/641			YK800XG
	YK720/740/741			YK1000XG
	YK820/840/841			-
	YK1041			YK1200X
YK1200	-			
CAME	YK5012	Mar. 1990	Mar. 1997	-
	YK8050			-
	YK8080			-

OFFICIALLY DISCONTINUED MODELS AND SERVICE PERIOD

## Software

Model	Usage	Sale discontinued time	Current model (equivalent)
POPCOM	ERC series / SRC series / DRC series / SR1 series	Jul. 2013	POPCOM+
VIP	For multi-axis controller	Dec. 2009	VIP+
YPB-Win	Pico series	Dec. 2009	-

Controllers					
Model	Sale discontinued time	Service period	Service availability	Replacing models for maintenance	Current model (equivalent)
RDX/RDP	Aug. 2015	Aug. 2022	Being continued	RDV-X/RDV-P	RDV-X/RDV-P
TS-S	Sep. 2013	Sep. 2020	Being continued	TS-S2	TS-S2
DRCX	Dec. 2012	Dec. 2019	Being continued	-	-
ERCX	Jul. 2011	Jul. 2018	Being continued	-	-
SRCP30	Mar. 2011	Mar. 2018	Being continued	-	-
PRC	Dec. 2009	Dec. 2016	Being continued	Replacement unavailable	No current model
RCX141	Dec. 2008	Dec. 2015	Already discontinued	RCX240	RCX240
RCX142				Replacement unavailable	No current model
RCX142-T					
SRCX	Apr. 2008	Apr. 2015	Already discontinued	SR1-X	SR1-X
SRCP05/10/20				SR1-P RDP	SR1-P RDP
SRCD				SR1-X RDX	SR1-X RDX
TRCX				RCX240	RCX240 <sup>Note. 2</sup>
RCX40				RCX240	RCX240
QRCX	Mar. 2002	Mar. 2009	Already discontinued	RCX240	RCX240
QRCX-E					RCX240-E
SRCH	Jan. 2002	Jan. 2009	Already discontinued	Replacement unavailable	SR1-X
DRCH					RCX222
TRCH3					RCX240
TRCH4					
DRC-R	Apr. 2001	Apr. 2008	Already discontinued	Replacement unavailable	No current model
QRCH	Mar. 2001	Mar. 2008	Already discontinued	Replacement unavailable	RCX240
QRCH-E					No current model <sup>Note. 1</sup>
QRCH-P					No current model <sup>Note. 1</sup>
MRCH					
MRCH-E					
SRCA (Latter model)	Oct. 1999	Oct. 2006	Already discontinued	Replacement unavailable	SR1-X
DRCA (Latter model)					RCX222
ERC					SR1-X
MRCA	Nov. 1997	Nov. 2004	Already discontinued	Replacement unavailable	No current model <sup>Note. 1</sup>
DRC	Sep. 1997	Sep. 2004	Already discontinued	Replacement unavailable	RCX222
SRC-1					SR1-X
SRC-2					
QRC	May 1997	May 2004	Already discontinued	Replacement unavailable	RCX240
QRCA					
SRC-3	Dec. 1995	Dec. 2002	Already discontinued	Replacement unavailable	SR1-X
SRC-4					
SRCA (Former model)					
DRCA (Former model)					RCX222
MRCA					RCX240
MRC					
RCH20	Mar. 1994	Mar. 2001	Already discontinued	Replacement unavailable	RCX240
SRC2A					SR1-X
SRC4A					
RCH40	Mar. 1992	Mar. 1999	Already discontinued	Replacement unavailable	RCX240
RCH41					
RCS40					
RCS41	Mar. 1990	Mar. 1997	Already discontinued	Replacement unavailable	RCX240
LP					SR1-X

If a replacing model for maintenance is available, it can be used as a set including the controller and the cable for conversion.


When replacing with the current model, it is necessary to replace the robot and the controller as a set.

Note 1. Replacement with the current model is possible under certain conditions.

Note 2. Depending on specifications, replacement with the current model may not be possible.

Programming box				
Model	Sale discontinued time	Service period	Service availability	Current model (equivalent)
TP-2	Dec. 2009	Dec. 2016	Being continued	-
MPB	Jan. 2009	Jan. 2016	Already discontinued	RPB <sup>Note</sup>
TP-1	Oct. 2005	Oct. 2012	Already discontinued	TP-2
TPB	Jun. 2005	Jun. 2012	Already discontinued	HPB
DPB	Jan. 1999	Jan. 2006	Already discontinued	HPB
YPU20	Mar. 1994	Mar. 2001	Already discontinued	-
SPB-2	Aug. 1992	Aug. 1999	Already discontinued	-
YPU1	Mar. 1992	Mar. 1999	Already discontinued	-
YPU2				-
YPU3				-
SPB	Jan. 1990	Jan. 1997	Already discontinued	-

Note. Customers using the RCX40/RCX141/RCX142 controllers will use a connector adaptor cable.



## ARTICULATED ROBOTS

# YA SERIES

## CONTENTS

### ■ YA SERIES MANIPULATOR SPECIFICATIONS ..... 108

#### 6-axis

YA-RJ .....	109
YA-R3F .....	110
YA-R5F .....	111
YA-R5LF .....	112
YA-R6F .....	113

#### 7-axis

YA-U5F .....	114
YA-U10F .....	115
YA-U20F .....	116

### ■ YAC100 Specifications .....117

### ■ Accessories and part options...118


# YA SERIES MANIPULATOR SPECIFICATIONS

		6-axis					7-axis		
Applications		Handling (general)					Assembly / Placement		
Number of axes		6	6	6	6	6	7	7	7
Payload		1 kg (max. 2 kg <sup>Note 2</sup> )	3 kg	5 kg	5 kg	6 kg	5 kg	10 kg	20 kg
Vertical reach		909 mm	804 mm	1193 mm	1560 mm	2486 mm	1007 mm	1203 mm	1498 mm
Horizontal reach		545 mm	532 mm	706 mm	895 mm	1422 mm	559 mm	720 mm	910 mm
Repeatability		±0.03 mm	±0.03 mm	±0.02 mm	±0.03 mm	±0.08 mm	±0.06 mm	±0.1 mm	±0.1 mm
Range of Motion	S-axis (turning)	-160° to +160°	-160° to +160°	-170° to +170°	-170° to +170°	-170° to +170°	-180° to +180°	-180° to +180°	-180° to +180°
	L-axis (lower Arm)	-90° to +110°	-85° to +90°	-65° to +150°	-65° to +150°	-90° to +155°	-110° to +110°	-110° to +110°	-110° to +110°
	E-axis (elbow twist)	-	-	-	-	-	-170° to +170°	-170° to +170°	-170° to +170°
	U-axis (upper arm)	-290° to +105°	-105° to +260°	-136° to +255°	-138° to +255°	-175° to +250°	-90° to +115°	-135° to +135°	-130° to +130°
	R-axis (wrist roll)	-180° to +180°	-170° to +170°	-190° to +190°	-190° to +190°	-180° to +180°	-180° to +180°	-180° to +180°	-180° to +180°
	B-axis (wrist pitch/yaw)	-130° to +130°	-120° to +120°	-135° to +135°	-135° to +135°	-45° to +225°	-110° to +110°	-110° to +110°	-110° to +110°
	T-axis (wrist twist)	-360° to +360°	-360° to +360°	-360° to +360°	-360° to +360°	-360° to +360°	-180° to +180°	-180° to +180°	-180° to +180°
Maximum Speed	S-axis (turning)	160°/s	200°/s	376°/s	270°/s	220°/s	200°/s	170°/s	130°/s
	L-axis (lower Arm)	130°/s	150°/s	350°/s	280°/s	200°/s	200°/s	170°/s	130°/s
	E-axis (elbow twist)	-	-	-	-	-	200°/s	170°/s	170°/s
	U-axis (upper arm)	200°/s	190°/s	400°/s	300°/s	220°/s	200°/s	170°/s	170°/s
	R-axis (wrist roll)	300°/s	300°/s	450°/s	450°/s	410°/s	200°/s	200°/s	200°/s
	B-axis (wrist pitch/yaw)	400°/s	300°/s	450°/s	450°/s	410°/s	230°/s	200°/s	200°/s
	T-axis (wrist twist)	500°/s	420°/s	720°/s	720°/s	610°/s	350°/s	400°/s	400°/s
Allowable Moment	R-axis (wrist roll)	3.33 N·m	5.39 N·m	12 N·m	12 N·m	11.8 N·m	14.7 N·m	31.4 N·m	58.8 N·m
	B-axis (wrist pitch/yaw)	3.33 N·m	5.39 N·m	12 N·m	12 N·m	9.8 N·m	14.7 N·m	31.4 N·m	58.8 N·m
	T-axis (wrist twist)	0.98 N·m	2.94 N·m	7 N·m	7 N·m	5.9 N·m	7.35 N·m	19.6 N·m	29.4 N·m
Allowable Inertia (GD <sup>2</sup> /4)	R-axis (wrist roll)	0.058 kg·m <sup>2</sup>	0.1 kg·m <sup>2</sup>	0.30 kg·m <sup>2</sup>	0.30 kg·m <sup>2</sup>	0.27 kg·m <sup>2</sup>	0.45 kg·m <sup>2</sup>	1.0 kg·m <sup>2</sup>	4.0 kg·m <sup>2</sup>
	B-axis (wrist pitch/yaw)	0.058 kg·m <sup>2</sup>	0.1 kg·m <sup>2</sup>	0.30 kg·m <sup>2</sup>	0.30 kg·m <sup>2</sup>	0.27 kg·m <sup>2</sup>	0.45 kg·m <sup>2</sup>	1.0 kg·m <sup>2</sup>	4.0 kg·m <sup>2</sup>
	T-axis (wrist twist)	0.005 kg·m <sup>2</sup>	0.03 kg·m <sup>2</sup>	0.1 kg·m <sup>2</sup>	0.1 kg·m <sup>2</sup>	0.06 kg·m <sup>2</sup>	0.11 kg·m <sup>2</sup>	0.4 kg·m <sup>2</sup>	2.0 kg·m <sup>2</sup>
Mass		15 kg	27 kg	27 kg	29 kg	130 kg	30 kg	60 kg	120 kg
Power Requirements <sup>Note 1</sup>		0.5 kVA	0.5 kVA	1.0 kVA	1.0 kVA	1.0 kVA	1.0 kVA	1.0 kVA	1.5 kVA
Detailed info page		<a href="#">P.109</a>	<a href="#">P.110</a>	<a href="#">P.111</a>	<a href="#">P.112</a>	<a href="#">P.113</a>	<a href="#">P.114</a>	<a href="#">P.115</a>	<a href="#">P.116</a>

Note 1. Varies in accordance with applications and motion patterns.

Note 2. When a load is more than 1 kg, the motion range will be smaller. Use the robot within the recommended motion range. For details, refer to the dimensional diagram on P.109.

## YA series basic system contents



\*1. Differs by model. For details, refer to the page for each model.

\*2. YAP-E (English) or YAP-C (Chinese) can also be selected.

\*3. PNP model is an option. Take care not to mix NPN and PNP for DIO.

# YA-RJ

6-axis

● Maximum payload 2 kg

● Longest Reach R545 mm



## Ordering method


<b>YA-RJ</b>	<b>4L</b>	<b>YAC100</b>				
<b>Model</b>	<b>Power cable length</b> 4L: 4m	<b>Controller</b>	<b>Safety standard</b> N: Normal E: CE marking	<b>Language setting</b> JE: Japanese/English JC: Japanese/Chinese EJ: English/Japanese EC: English/Chinese	<b>Option I/O</b> N, P: Standard I/O 28/28 N1, P1: 56/56 points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	<b>Network option</b> No entry: None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave

Note. This unit is ideal for small tabletop devices or for education.  
 Note. The ultra-light, compact YA-RJ features portability and easy installation for simplified system integration.  
 Note. Each axis uses a motor of 80 W or less.  
 Note. This unit can also be used in combination with a travel axis or other external axis. Please contact us.

## Specifications

<b>Controlled Axis</b>	6	
<b>Payload</b>	1 kg (max. 2 kg <sup>Note 1</sup> )	
<b>Repeatability</b>	±0.03 mm	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-160° to +160°
	<b>L-axis (lower Arm)</b>	-90° to +110°
	<b>U-axis (upper arm)</b>	-290° to +105°
	<b>R-axis (wrist roll)</b>	-180° to +180°
	<b>B-axis (wrist pitch/yaw)</b>	-130° to +130°
	<b>T-axis (wrist twist)</b>	-360° to +360°
<b>Axis with brake<sup>Note 2</sup></b>	L-axis, U-axis	
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	2.79 rad/s, 160°/s
	<b>L-axis (lower Arm)</b>	2.27 rad/s, 130°/s
	<b>U-axis (upper arm)</b>	3.49 rad/s, 200°/s
	<b>R-axis (wrist roll)</b>	5.23 rad/s, 300°/s
	<b>B-axis (wrist pitch/yaw)</b>	6.98 rad/s, 400°/s
	<b>T-axis (wrist twist)</b>	8.72 rad/s, 500°/s
<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	3.33 N·m
	<b>B-axis (wrist pitch/yaw)</b>	3.33 N·m
<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>R-axis (wrist roll)</b>	0.058 kg·m <sup>2</sup>
	<b>B-axis (wrist pitch/yaw)</b>	0.058 kg·m <sup>2</sup>
<b>Mass</b>	<b>R-axis (wrist roll)</b>	0.98 N·m
	<b>T-axis (wrist twist)</b>	0.005 kg·m <sup>2</sup>
<b>Ambient Conditions</b>	<b>Ambient Temperature</b>	During operation: 0 to +40°C, During storage: -10 to +60°C
	<b>Relative Humidity</b>	90% max. (non-condensing)
	<b>Vibration Acceleration</b>	4.9 m/s <sup>2</sup> or less
	<b>Others</b>	<ul style="list-style-type: none"> <li>Free from corrosive gasses or liquids, or explosive gasses</li> <li>Free from exposure to water, oil, or dust</li> <li>Free from excessive electrical noise (plasma)</li> </ul>
<b>Power Requirements<sup>Note 3</sup></b>		0.5 kVA

Note 1. When a load is more than 1 kg, the motion range will be smaller. Use the robot within the recommended motion range. (See diagrams below)  
 Note 2. The S-, R-, B-, and T-axes do not have any brakes. Make sure that the operation does not require brakes.  
 Note 3. Varies in accordance with applications and motion patterns.  
 Note. SI units are used for specifications.



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

# YA-R3F

6-axis



- Maximum payload 3 kg
- Longest Reach R532 mm

## Ordering method

<b>YA-R3F</b>	<b>4L</b>	<b>YAC100</b>				
<b>Model</b>	<b>Power cable length</b> 4L: 4m	<b>Controller</b>	<b>Safety standard</b> N: Normal E: CE marking	<b>Language setting</b> JE: Japanese/English JC: Japanese/Chinese EJ: English/Japanese EC: English/Chinese	<b>Option I/O</b> N, P: Standard I/O 28/28 N1, P1: 56/56 points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	<b>Network option</b> No entry: None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave

Note. The YA-R3F, a compact manipulator with a motor of 80 W or less mounted on all axes, requires minimal space (baseplate: 240 mm × 170 mm). No fence is required for robot's working area. The robot can be used in applications such as automated guided vehicles (AGVs), testing equipment, and educational tools.

Note. Standard models include four air hoses (diameter: 4 mm), and an internal user I/O wiring harness (0.2 mm<sup>2</sup> × 10) running through the U-arm. This structure simplifies wiring and tubing for easier system construction.

Note. Floor-mounted, wall-mounted, and ceiling-mounted types are available. Please contact us separately regarding wall-mounted or ceiling-mounted installations.

Note. This unit can also be used in combination with a travel axis or other external axis. Please contact us.

## Specifications

<b>Controlled Axis</b>	6	
<b>Payload</b>	3 kg	
<b>Repeatability</b>	±0.03 mm	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-160° to +160° <sup>Note 1</sup>
	<b>L-axis (lower Arm)</b>	-85° to +90°
	<b>U-axis (upper arm)</b>	-105° to +260°
	<b>R-axis (wrist roll)</b>	-170° to +170°
	<b>B-axis (wrist pitch/yaw)</b>	-120° to +120°
	<b>T-axis (wrist twist)</b>	-360° to +360°
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	3.49 rad/s, 200°/s
	<b>L-axis (lower Arm)</b>	2.62 rad/s, 150°/s
	<b>U-axis (upper arm)</b>	3.32 rad/s, 190°/s
	<b>R-axis (wrist roll)</b>	5.24 rad/s, 300°/s
	<b>B-axis (wrist pitch/yaw)</b>	5.24 rad/s, 300°/s
<b>T-axis (wrist twist)</b>	7.33 rad/s, 420°/s	

<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	5.39 N·m
	<b>B-axis (wrist pitch/yaw)</b>	5.39 N·m
	<b>T-axis (wrist twist)</b>	2.94 N·m
<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>R-axis (wrist roll)</b>	0.1 kg·m <sup>2</sup>
	<b>B-axis (wrist pitch/yaw)</b>	0.1 kg·m <sup>2</sup>
	<b>T-axis (wrist twist)</b>	0.03 kg·m <sup>2</sup>
<b>Mass</b>		27 kg
<b>Ambient Conditions</b>	<b>Temperature</b>	0 to +40°C
	<b>Humidity</b>	20 to 80%RH (non-condensing)
	<b>Vibration</b>	4.9 m/s <sup>2</sup> or less
	<b>Others</b>	<ul style="list-style-type: none"> <li>• Free from corrosive gasses or liquids, or explosive gasses</li> <li>• Free from exposure to water, oil, or dust</li> <li>• Free from excessive electrical noise (plasma)</li> </ul>
<b>Power Requirements</b> <sup>Note 2</sup>		0.5 kVA


Note 1. For wall-mounted installation, the S-axis operating range is ±25°.

Note 2. Varies in accordance with applications and motion patterns.

Note. SI units are used for specifications.

## YA-R3F

Units: mm : P-point Maximum Envelop



Note 1. Motion range of point P when the S-axis is between -40° to +40°.

Note 2. Motion range of point P when the S-axis is between -125° to -160° or +125° to +160°.

# YA-R5F 6-axis

● Maximum payload 5 kg ● Longest Reach R706 mm



## Ordering method

<b>YA-R5F</b>	<b>4L</b>	<b>YAC100</b>				
<b>Model</b>	<b>Power cable length</b>	<b>Controller</b>	<b>Safety standard</b>	<b>Language setting</b>	<b>Option I/O</b>	<b>Network option</b>
	4L: 4m		N: Normal E: CE marking	JE: Japanese/English JC: Japanese/Chinese EJ: English/Japanese EC: English/Chinese	N, P: Standard I/O 28/28 N1, P1: 56/56 points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	No entry : None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave


Note. Thanks to the higher control rate of the YAC100 controller and vibration-damping control of the arm, we have reduced the residual vibration when the arm stops moving, while shortening the cycle time and achieving the fastest speed in this class.  
 Note. Longest reach in a respective class (706 mm)  
 Note. Floor-mounted, wall-mounted, and ceiling-mounted types are available. Please contact us separately regarding wall-mounted or ceiling-mounted installations.  
 Note. This unit can also be used in combination with a travel axis or other external axis. Please contact us.

## Specifications

<b>Controlled Axis</b>	6	<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	12 N·m	
<b>Payload</b>	5 kg	<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>B-axis (wrist pitch/yaw)</b>	12 N·m	
<b>Repeatability</b>	±0.02 mm		<b>T-axis (wrist twist)</b>	7 N·m	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-170° to +170° <sup>Note 1</sup>	<b>R-axis (wrist roll)</b>	0.3 kg·m <sup>2</sup>	
	<b>L-axis (lower Arm)</b>	-65° to +150°	<b>B-axis (wrist pitch/yaw)</b>	0.3 kg·m <sup>2</sup>	
	<b>U-axis (upper arm)</b>	-136° to +255°	<b>T-axis (wrist twist)</b>	0.1 kg·m <sup>2</sup>	
	<b>R-axis (wrist roll)</b>	-190° to +190°	<b>Mass</b>	27 kg	
	<b>B-axis (wrist pitch/yaw)</b>	-135° to +135°	<b>Ambient Conditions</b>	<b>Temperature</b>	0 to +45°C
	<b>T-axis (wrist twist)</b>	-360° to +360°		<b>Humidity</b>	20 to 80%RH (non-condensing)
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	6.56 rad/s, 376°/s	<b>Vibration</b>	4.9 m/s <sup>2</sup> or less	
	<b>L-axis (lower Arm)</b>	6.11 rad/s, 350°/s	<b>Others</b>	<ul style="list-style-type: none"> <li>Free from corrosive gasses or liquids, or explosive gasses</li> <li>Free from exposure to water, oil, or dust</li> <li>Free from excessive electrical noise (plasma)</li> </ul>	
	<b>U-axis (upper arm)</b>	6.98 rad/s, 400°/s			
	<b>R-axis (wrist roll)</b>	7.85 rad/s, 450°/s			
	<b>B-axis (wrist pitch/yaw)</b>	7.85 rad/s, 450°/s	<b>Power Requirements</b> <sup>Note 2</sup>	1.0 kVA	
<b>T-axis (wrist twist)</b>	12.57 rad/s, 720°/s				

Note 1. For wall-mounted installation, the S-axis operating range is ±30°.  
 Note 2. Varies in accordance with applications and motion patterns.  
 Note. SI units are used for specifications.

## YA-R5F



# YA-R5LF

6-axis

- Maximum payload 5 kg
- Longest Reach R895 mm

## Ordering method

<b>YA-R5LF</b>	<b>4L</b>	<b>YAC100</b>				
<b>Model</b>	<b>Power cable length</b> 4L: 4m	<b>Controller</b>	<b>Safety standard</b> N: Normal E: CE marking	<b>Language setting</b> JE: Japanese/English JC: Japanese/Chinese EJ: English/Japanese EC: English/Chinese	<b>Option I/O</b> N, P: Standard I/O 28/28 N1, P1: 56/56 points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	<b>Network option</b> No entry: None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave



Note. Thanks to the higher control rate of the YAC100 controller and vibration-damping control of the arm, we have reduced the residual vibration when the arm stops moving, while shortening the cycle time and achieving the fastest speed in this class.  
 Note. Longest reach in a respective class (895 mm)  
 Note. Floor-mounted, wall-mounted, and ceiling-mounted types are available. Please contact us separately regarding wall-mounted or ceiling-mounted installations.  
 Note. This unit can also be used in combination with a travel axis or other external axis. Please contact us.

## Specifications


<b>Controlled Axis</b>	6	
<b>Payload</b>	5 kg	
<b>Repeatability</b>	±0.03 mm	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-170° to +170° <sup>Note 1</sup>
	<b>L-axis (lower Arm)</b>	-65° to +150°
	<b>U-axis (upper arm)</b>	-138° to +255°
	<b>R-axis (wrist roll)</b>	-190° to +190°
	<b>B-axis (wrist pitch/yaw)</b>	-135° to +135°
	<b>T-axis (wrist twist)</b>	-360° to +360°
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	4.71 rad/s, 270°/s
	<b>L-axis (lower Arm)</b>	4.89 rad/s, 280°/s
	<b>U-axis (upper arm)</b>	5.24 rad/s, 300°/s
	<b>R-axis (wrist roll)</b>	7.85 rad/s, 450°/s
	<b>B-axis (wrist pitch/yaw)</b>	7.85 rad/s, 450°/s
<b>T-axis (wrist twist)</b>	12.57 rad/s, 720°/s	

<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	12 N·m
	<b>B-axis (wrist pitch/yaw)</b>	12 N·m
	<b>T-axis (wrist twist)</b>	7 N·m
<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>R-axis (wrist roll)</b>	0.3 kg·m <sup>2</sup>
	<b>B-axis (wrist pitch/yaw)</b>	0.3 kg·m <sup>2</sup>
	<b>T-axis (wrist twist)</b>	0.1 kg·m <sup>2</sup>
<b>Mass</b>		29 kg
<b>Ambient Conditions</b>	<b>Temperature</b>	0 to +45°C
	<b>Humidity</b>	20 to 80%RH (non-condensing)
	<b>Vibration</b>	4.9 m/s <sup>2</sup> or less
	<b>Others</b>	<ul style="list-style-type: none"> <li>Free from corrosive gasses or liquids, or explosive gasses</li> <li>Free from exposure to water, oil, or dust</li> <li>Free from excessive electrical noise (plasma)</li> </ul>
<b>Power Requirements</b> <sup>Note 2</sup>		1.0 kVA

Note 1. For wall-mounted installation, the S-axis operating range is ±30°.  
 Note 2. Varies in accordance with applications and motion patterns.  
 Note. SI units are used for specifications.

## YA-R5LF

Units: mm : P-point Maximum Envelop






# YA-R6F

6-axis

- Maximum payload 6 kg
- Longest Reach R1422 mm



## Ordering method

**YA-R6F** - **4L** - **YAC100**

Model	Power cable length	Controller	Safety standard	Language setting	Option I/O	Network option
	4L: 4m		N: Normal E: CE marking	JE: Japanese/English JC: Japanese/Chinese EJ: English/Japanese EC: English/Chinese	N, P: Standard I/O 28/28 N1, P1: 56/56 points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	No entry : None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave


Note. Thanks to the higher control rate of the YAC100 controller and vibration-damping control of the arm, we have reduced the residual vibration when the arm stops moving, while shortening the cycle time and achieving the fastest speed in this class.  
 Note. Longest reach in its class (1422 mm) and increased moment capacity of the wrist.  
 Note. Floor-mounted, wall-mounted, and ceiling-mounted types are available. Please contact us separately regarding wall-mounted or ceiling-mounted installations.  
 Note. This unit can also be used in combination with a travel axis or other external axis. Please contact us.

## Specifications

<b>Controlled Axis</b>	6	<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	11.8 N-m	
<b>Payload</b>	6 kg	<b>Allowable Moment</b>	<b>B-axis (wrist pitch/yaw)</b>	9.8 N-m	
<b>Repeatability</b>	±0.08 mm	<b>Allowable Moment</b>	<b>T-axis (wrist twist)</b>	5.9 N-m	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-170° to +170° <sup>Note 1</sup>	<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>R-axis (wrist roll)</b>	0.27 kg-m <sup>2</sup>
	<b>L-axis (lower Arm)</b>	-90° to +155°	<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>B-axis (wrist pitch/yaw)</b>	0.27 kg-m <sup>2</sup>
	<b>U-axis (upper arm)</b>	-175° to +250°	<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>T-axis (wrist twist)</b>	0.06 kg-m <sup>2</sup>
	<b>R-axis (wrist roll)</b>	-180° to +180°	<b>Mass</b>		130 kg
	<b>B-axis (wrist pitch/yaw)</b>	-45° to +225°	<b>Ambient Conditions</b>	<b>Temperature</b>	0 to +45°C
	<b>T-axis (wrist twist)</b>	-360° to +360°		<b>Humidity</b>	20 to 80%RH (non-condensing)
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	3.84 rad/s, 220°/s	<b>Vibration</b>	4.9 m/s <sup>2</sup> or less	
	<b>L-axis (lower Arm)</b>	3.49 rad/s, 200°/s	<b>Others</b>	<ul style="list-style-type: none"> <li>Free from corrosive gasses or liquids, or explosive gasses</li> <li>Free from exposure to water, oil, or dust</li> <li>Free from excessive electrical noise (plasma)</li> </ul>	
	<b>U-axis (upper arm)</b>	3.84 rad/s, 220°/s			
	<b>R-axis (wrist roll)</b>	7.16 rad/s, 410°/s			
	<b>B-axis (wrist pitch/yaw)</b>	7.16 rad/s, 410°/s			
	<b>T-axis (wrist twist)</b>	10.65 rad/s, 610°/s	<b>Power Requirements<sup>Note 2</sup></b>	1.0 kVA	

Note 1. For wall-mounted installation, the S-axis operating range is ±30°.  
 Note 2. Varies in accordance with applications and motion patterns.  
 Note. SI units are used for specifications.

## YA-R6F



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

# YA-U5F

7-axis



● Maximum payload 5 kg

## Ordering method

<b>YA-U5F</b>	<b>4L</b>	<b>YAC100</b>				
<b>Model</b>	<b>Power cable length</b> 4L: 4m	<b>Controller</b>	<b>Safety standard</b> N: Normal E: CE marking	<b>Language setting</b> J/E: Japanese/English J/C: Japanese/Chinese E/J: English/Japanese E/C: English/Chinese	<b>Option I/O</b> N, P: Standard I/O 28/28 N1, P1: 56/56 points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	<b>Network option</b> No entry: None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave

Note. High degree of motion like a human arm with its 7-axis arm.

Note. The arm has been slimmed by employing a newly developed miniaturized actuator for the wrist section, greatly reducing the interference of the arm with the workpiece. Note. The narrowing of the motion range that usually results when downsizing a robot is avoided by an ingenious mechanism used for the arm joints, so maximum range is maintained.

Note. Light and weighs only 30 kg, so many installation choices are available: floor, ceiling, or wall. Please contact us separately regarding wall-mounted or ceiling-mounted installations. Note. By utilizing internal user I/O wiring harness and air lines integrated in the arm, layout can be planned offline without worrying about peripheral interference. (Internal user I/O wiring harness and air lines specifications: two air lines and eight-core cables) External axis specification for a hand can be accommodated. Contact YAMAHA regarding your requirements.

## Specifications


<b>Controlled Axis</b>	7	
<b>Payload</b>	5 kg	
<b>Repeatability</b>	±0.06 mm	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-180° to +180°
	<b>L-axis (lower Arm)</b>	-110° to +110°
	<b>E-axis (elbow twist)</b>	-170° to +170°
	<b>U-axis (upper arm)</b>	-90° to +115°
	<b>R-axis (wrist roll)</b>	-180° to +180°
	<b>B-axis (wrist pitch/yaw)</b>	-110° to +110°
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	3.49 rad/s, 200°/s
	<b>L-axis (lower Arm)</b>	3.49 rad/s, 200°/s
	<b>E-axis (elbow twist)</b>	3.49 rad/s, 200°/s
	<b>U-axis (upper arm)</b>	3.49 rad/s, 200°/s
	<b>R-axis (wrist roll)</b>	3.49 rad/s, 200°/s
	<b>B-axis (wrist pitch/yaw)</b>	4.01 rad/s, 230°/s
	<b>T-axis (wrist twist)</b>	6.11 rad/s, 350°/s

<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	14.7 N·m
	<b>B-axis (wrist pitch/yaw)</b>	14.7 N·m
	<b>T-axis (wrist twist)</b>	7.35 N·m
<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>R-axis (wrist roll)</b>	0.45 kg·m <sup>2</sup>
	<b>B-axis (wrist pitch/yaw)</b>	0.45 kg·m <sup>2</sup>
	<b>T-axis (wrist twist)</b>	0.11 kg·m <sup>2</sup>
<b>Mass</b>		30 kg
<b>Power Requirements</b> <sup>Note 1</sup>	<b>Temperature</b>	0 to +40°C
	<b>Humidity</b>	20 to 80%RH (non-condensing)
	<b>Vibration</b>	4.9 m/s <sup>2</sup> or less
<b>Ambient Conditions</b>	<b>Others</b>	<ul style="list-style-type: none"> <li>Free from corrosive gasses or liquids, or explosive gasses</li> <li>Free from exposure to water, oil, or dust</li> <li>Free from excessive electrical noise (plasma)</li> </ul>

Note 1. Varies in accordance with applications and motion patterns. Note. SI units are used for specifications.

## YA-U5F

Units: mm : P-point Maximum Envelop



Note 1. The flange is equipped with a cable through hole. When mounting equipment such as an attachment, ensure that no foreign liquid, oil, or dust go into hole.  
Note 2. A bolt is mounted for T-axis grease replenished. When attaching an attachment to 80 dia. -0.035/0 part of the T-axis, enough space for the grease zerk (A-MT6X1) is required to the shape of the attachment.

# YA-U10F

7-axis

Maximum payload 10 kg

## Ordering method

<b>YA-U10F</b>	<b>4L</b>	<b>YAC100</b>				
<b>Model</b>	<b>Power cable length</b>	<b>Controller</b>	<b>Safety standard</b>	<b>Language setting</b>	<b>Option I/O</b>	<b>Network option</b>
	4L: 4m		N: Normal E: CE marking	JE: Japanese/English JC: Japanese/Chinese EJ: English/Japanese EC: English/Chinese	N, P: Standard I/O 28/28 N1, P1: 56/56 points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	No entry : None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave


Note. High degree of motion like a human arm with its 7-axis arm.  
 Note. The high flexibility of motion makes operation possible even in narrow spaces inaccessible to humans.  
 Note. Folds to compact size when not in use.  
 Note. Many installation options: on the floor, on the wall or on the ceiling. Please contact us separately regarding wall-mounted or ceiling-mounted installations.  
 Note. Optimal for handling small objects.  
 Note. By utilizing internal user I/O wiring harness and air lines integrated in the arm, layout can be planned offline without worrying about peripheral interference.  
 (Internal user I/O wiring harness and air lines specifications: two air hoses and twelve-core cables)  
 External axis specification for a hand can be accommodated. Contact YAMAHA regarding your requirements.

## Specifications

<b>Controlled Axis</b>	7	<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	31.4 N-m	
<b>Payload</b>	10 kg		<b>B-axis (wrist pitch/yaw)</b>	31.4 N-m	
<b>Repeatability</b>	±0.1 mm		<b>T-axis (wrist twist)</b>	19.6 N-m	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-180° to +180°	<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>R-axis (wrist roll)</b>	1.0 kg-m <sup>2</sup>
	<b>L-axis (lower Arm)</b>	-110° to +110°		<b>B-axis (wrist pitch/yaw)</b>	1.0 kg-m <sup>2</sup>
	<b>E-axis (elbow twist)</b>	-170° to +170°		<b>T-axis (wrist twist)</b>	0.4 kg-m <sup>2</sup>
	<b>U-axis (upper arm)</b>	-135° to +135°		<b>Mass</b>	60 kg
	<b>R-axis (wrist roll)</b>	-180° to +180°		<b>Power Requirements</b> <sup>Note 1</sup>	1.0 kVA
	<b>B-axis (wrist pitch/yaw)</b>	-110° to +110°		<b>Temperature</b>	0 to +40°C
	<b>T-axis (wrist twist)</b>	-180° to +180°		<b>Humidity</b>	20 to 80%RH (non-condensing)
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	2.97 rad/s, 170°/s	<b>Ambient Conditions</b>	<b>Vibration</b>	4.9 m/s <sup>2</sup> or less
	<b>L-axis (lower Arm)</b>	2.97 rad/s, 170°/s		<b>Others</b>	<ul style="list-style-type: none"> <li>Free from corrosive gasses or liquids, or explosive gasses</li> <li>Free from exposure to water, oil, or dust</li> <li>Free from excessive electrical noise (plasma)</li> </ul>
	<b>E-axis (elbow twist)</b>	2.97 rad/s, 170°/s			
	<b>U-axis (upper arm)</b>	2.97 rad/s, 170°/s			
	<b>R-axis (wrist roll)</b>	3.49 rad/s, 200°/s			
	<b>B-axis (wrist pitch/yaw)</b>	3.49 rad/s, 200°/s			
	<b>T-axis (wrist twist)</b>	6.98 rad/s, 400°/s			

Note 1. Varies in accordance with applications and motion patterns.  
 Note. SI units are used for specifications.

## YA-U10F



Note 1. The flange is equipped with a cable through hole. When mounting equipment such as an attachment, ensure that no foreign liquid, oil, or dust go into hole.  
 Note 2. A bolt is mounted for T-axis grease replenished. When attaching an attachment to 80 dia. -0.035/0 part of the T-axis, enough space for the grease zerk (A-MT6X1) is required to the shape of the attachment.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION



# YA-U20F

7-axis

● Maximum payload 20 kg

## Ordering method

<b>YA-U20F</b>	<b>4L</b>	<b>YAC100</b>				
<b>Model</b>	<b>Power cable length</b> 4L: 4m	<b>Controller</b>	<b>Safety standard</b> N: Normal E: CE marking	<b>Language setting</b> JE: Japanese/English JC: Japanese/Chinese EJ: English/Japanese EC: English/Chinese	<b>Option I/O</b> N, P: Standard I/O 28/28 N1, P1: 56/56points N2, P2: 84/84 points N3, P3: 112/112 points N4, P4: 140/140 points	<b>Network option</b> No entry: None CC: CC-Link DM: DeviceNet master DS: DeviceNet slave PB: PROFIBUS EP: EtherNet/IP™ PM: Profinet master PT: Profinet slave ES: EtherCAT slave



Note. High degree of motion like a human arm with its 7-axis arm.  
 Note. The high flexibility of motion makes operation possible even in narrow spaces inaccessible to humans.  
 Note. Folds to compact size when not in use.  
 Note. Many installation options: on the floor, on the wall or on the ceiling. Please contact us separately regarding wall-mounted or ceiling-mounted installations.  
 Note. Assembles and handles heavy objects up to 20 kg.  
 Note. By utilizing internal user I/O wiring harness and air lines integrated in the arm, layout can be planned offline without worrying about peripheral interference.  
 (Internal user I/O wiring harness and air lines specifications: two air hoses and sixteen-core cables)  
 External axis specification for a hand can be accommodated. Contact YAMAHA regarding your requirements.

## Specifications


<b>Controlled Axis</b>	7	
<b>Payload</b>	20 kg	
<b>Repeatability</b>	±0.1 mm	
<b>Range of Motion</b>	<b>S-axis (turning)</b>	-180° to +180°
	<b>L-axis (lower Arm)</b>	-110° to +110°
	<b>E-axis (elbow twist)</b>	-170° to +170°
	<b>U-axis (upper arm)</b>	-130° to +130°
	<b>R-axis (wrist roll)</b>	-180° to +180°
	<b>B-axis (wrist pitch/yaw)</b>	-110° to +110°
	<b>T-axis (wrist twist)</b>	-180° to +180°
<b>Maximum Speed</b>	<b>S-axis (turning)</b>	2.27 rad/s, 130°/s
	<b>L-axis (lower Arm)</b>	2.27 rad/s, 130°/s
	<b>E-axis (elbow twist)</b>	2.97 rad/s, 170°/s
	<b>U-axis (upper arm)</b>	2.97 rad/s, 170°/s
	<b>R-axis (wrist roll)</b>	3.49 rad/s, 200°/s
	<b>B-axis (wrist pitch/yaw)</b>	3.49 rad/s, 200°/s
	<b>T-axis (wrist twist)</b>	6.98 rad/s, 400°/s

<b>Allowable Moment</b>	<b>R-axis (wrist roll)</b>	58.8 N·m
	<b>B-axis (wrist pitch/yaw)</b>	58.8 N·m
	<b>T-axis (wrist twist)</b>	29.4 N·m
<b>Allowable Inertia (GD<sup>2</sup>/4)</b>	<b>R-axis (wrist roll)</b>	4.0 kg·m <sup>2</sup>
	<b>B-axis (wrist pitch/yaw)</b>	4.0 kg·m <sup>2</sup>
	<b>T-axis (wrist twist)</b>	2.0 kg·m <sup>2</sup>
<b>Mass</b>		120 kg
<b>Power Requirements<sup>Note 1</sup></b>		1.5 kVA
<b>Ambient Conditions</b>	<b>Temperature</b>	0 to +40°C
	<b>Humidity</b>	20 to 80%RH (non-condensing)
	<b>Vibration</b>	4.9 m/s <sup>2</sup> or less
	<b>Others</b>	<ul style="list-style-type: none"> <li>Free from corrosive gasses or liquids, or explosive gasses</li> <li>Free from exposure to water, oil, or dust</li> <li>Free from excessive electrical noise (plasma)</li> </ul>

Note 1. Varies in accordance with applications and motion patterns.  
 Note. SI units are used for specifications.

## YA-U20F

Units: mm : P-point Maximum Envelop



Note 1. The flange is equipped with a cable through hole. When mounting equipment such as an attachment, ensure that no foreign liquid, oil, or dust go into hole.  
 Note 2. A bolt is mounted for T-axis grease replenished. When attaching an attachment to 80 dia. -0.035/0 part of the T-axis, enough space for the grease zerk (A-MT6X1) is required to the shape of the attachment.

# YAC100 Specifications

## ■ YAC100 controller specifications

<b>Configuration</b>	Standard: IP20 (open structure)
<b>Dimensions</b>	470 mm (W) × 420 mm (D) × 200 mm (H) (Protrusions are not included.)
<b>Mass</b>	20 kg
<b>Cooling System</b>	Direct cooling
<b>Ambient Temperature</b>	During operation: 0°C to +40°C During storage : -10°C to +60°C
<b>Relative Humidity</b>	90% max. (non-condensing)
<b>Power Supply</b> <sup>Note</sup>	Single-phase 200/230 VAC (+10% to -15%), 50/60 Hz Three-phase 200/220 VAC (+10% to -15%), 50/60 Hz
<b>Grounding</b>	Grounding resistance: 100 Ω or less
<b>Digital I/Os</b>	Specialized signals: 8 inputs and 11 output General signals : 16 inputs and 16 outputs Max. I/O (optional) : 1,024 inputs and 1,024 outputs
<b>Positioning System</b>	By serial encoder
<b>Programming Capacity</b>	JOB: 10,000 steps, 1,000 instructions C/O ladder: 1,500 steps
<b>Expansion Slots</b>	MP2000 bus × 5 slots
<b>LAN (Connection to Host)</b>	1 (10BASE-T/100BASE-TX)
<b>Interface</b>	RS-232C: 1ch
<b>Control Method</b>	Software servo control
<b>Drive Units</b>	Six axes for robots. Two more axes can be added as external axes. (Can be installed in the controller.)
<b>Painting Color</b>	Munsell notation 5Y7/1 (reference value)

Note. YA-R6F: Three-phase only.

## ■ Optimum controller for handling and assembly

The YAC100 is a compact controller with improved performance and functions optimized for handling and assembly.

- Fits in a 19-inch rack and can be installed under conveyors.
- Commands specifically designed for workpiece handling with synchronized conveyors.



### Hardware Options

- External axis (max.: 2 axes)
- I/O module (28 points, NPN or PNP)
- Major fieldbus interface boards DeviceNet™ (master/slave), CC-Link (slave), PROFIBUS (slave), EtherNet/IP™ (slave, I/O communications), EtherCAT (slave)

### Optional Functions

- Conveyor synchronization
- Vision function
- External reference point control
- Software pendant

## ■ Regarding the concurrent I/O ladder program

The YAC100 controller is equipped with an NPN (or PNP) for standard I/O. Dedicated input/output is assigned to this standard I/O board. For this reason, if dedicated input/output is to be assigned to various types of field bus, concurrent I/O ladder program settings must be made.

Sample programs can be downloaded from our website.<sup>Note</sup>

<http://global.yamaha-motor.com/business/robot/>

Note. The member site requires registration.

A robot simulator that implements the same functionality as the actual controller

## MotoSim EG-VRG for YAMAHA

Virtual programming before the actual line is completed allows major reduction in line startup time.

### ■ Modeling layout

Models of workers and workpieces can be easily laid out.

### ■ Intuitive control of models

Models can be moved intuitively, simply by using the mouse.

### ■ Programming and debugging

Automatic generation of robot operating programs, job editing, and job analysis can be performed easily.

### ■ Intuitive robot operation

The robot's posture can be operated intuitively, allowing more efficient teaching.

### ■ Robot simulation

The robot can be watched as it operates, allowing visual verification.

## ■ YAP programming pendant specifications



<b>Dimensions</b>	169 mm (W) × 314.5 mm (H) × 50 mm (D)
<b>Mass</b>	0.990 kg
<b>Material</b>	Reinforced plastics
<b>Operation Device</b>	Select keys, axis keys (8 axes), numerical/application keys, Mode switch with key (mode: teach, play, and remote), emergency stop button, enable switch, compact flash card interface device (compact flash is optional.), USB port (1 port)
<b>Display</b>	640 × 480 pixels color LCD, touch panel (Alphanumeric characters, Chinese characters, Japanese letters, Others)
<b>IEC Protection Class</b>	IP65
<b>Cable Length</b>	Standard: 8 m, 4 m / 8 m / 12 m extension cable (maximum 20 m)

## Accessories and part options

### YA Series

#### Standard accessories

##### YAP programming box (with 8m cable)

Name	Model	Language
YAP-J	KEN-M5110-0J	Japanese
YAP-E	KEN-M5110-0E	English
YAP-C	KEN-M5110-0C	Chinese

##### Parts for the YAC100 controller

Name	Model
Power supply connector	KEN-M4871-00
Power supply cable clamp	KEN-M4836-00
Dummy connector for shorting safety signal	KEN-M5370-00
Power supply protection fuse	KEN-M5853-00
Standard I/O connector (STD.IO)	KBH-M4420-00
	KEN-M4420-00

##### Power cable (robot cable)

Manipulator name	Model	Cable length	Cable diameter		Bending radius
			Signal wire	Power wire	
YA-RJ	KEM-M4710-40	4 m	Signal wire	φ8.5 mm	85.0 mm
			Power wire	φ13.5 mm	140.0 mm
YA-R3F	KEM-M4711-40	4 m	Signal wire	φ17.5 mm	180.0 mm
			Power wire	φ19.5 mm	200.0 mm
YA-R5F/R5LF/R6F	KEM-M4712-40	4 m	Signal wire	φ17.5 mm	180.0 mm
			Power wire	φ19.5 mm	180.0 mm
YA-U5F/U10F	KEM-M4713-40	4 m	Signal wire	φ17.5 mm	180.0 mm
			Power wire	φ16.1 mm	180.0 mm
YA-U20F	KEM-M4714-40	4 m	Signal wire	φ17.5 mm	180.0 mm
			Power wire	φ26.0 mm	260.0 mm

#### Options

##### Power cable (robot cable)

Manipulator name	Model			Cable diameter		Bending radius
	Cable length (10 m)	Cable length (15 m)	Cable length (20 m)	Signal wire	Power wire	
YA-RJ	KEM-M4710-A0	KEM-M4710-F0	KEM-M4710-L0	Signal wire	φ8.5 mm	85.0 mm
				Power wire	φ13.5 mm	140.0 mm
YA-R3F	KEM-M4711-A0	KEM-M4711-F0	KEM-M4711-L0	Signal wire	φ17.5 mm	180.0 mm
				Power wire	φ19.5 mm	200.0 mm
YA-R5F/R5LF/R6F	KEM-M4712-A0	KEM-M4712-F0	KEM-M4712-L0	Signal wire	φ17.5 mm	180.0 mm
				Power wire	φ19.5 mm	180.0 mm
YA-U5F/U10F	KEM-M4713-A0	KEM-M4713-F0	KEM-M4713-L0	Signal wire	φ17.5 mm	180.0 mm
				Power wire	φ16.1 mm	180.0 mm
YA-U20F	KEM-M4714-A0	KEM-M4714-F0	KEM-M4714-L0	Signal wire	φ17.5 mm	180.0 mm
				Power wire	φ26.0 mm	260.0 mm

##### Device cable connector (connector for user wiring)

Manipulator name	Part position	Model	Remarks
YA-RJ	Base side	KEM-M4870-00	
	Arm side	KEM-M4870-10	
YA-R3F	Base side	KEM-M4873-00	
	Arm side	KEM-M4874-00	
YA-R5F/R5LF	Base side	KEM-M4873-10	Two connectors
	Arm side	KEM-M4874-10	Two connectors
YA-R6F	Base side	KEM-M4870-20	
	Arm side	KEM-M4870-30	
YA-U5F	Base side	KEM-M4873-30	
	Arm side	KEM-M4870-40	
YA-U10F	Base side	KEM-M4873-30	
	Arm side	KEM-M4870-50	
YA-U20F	Base side	KEM-M4870-60	
	Arm side	KEM-M4870-40	

##### Extension cable for YAP (extension cable for programming box)

Name	Model	Cable length
Extension cable for YAP	KEN-M531F-10	4 m
	KEN-M531F-20	8 m
	KEN-M531F-30	12 m

##### Dummy connector for YAP

Name	Model
YAP dummy connector	KEN-M5163-00

#### Maintenance parts

Name	Model
Battery unit for YA-RJ/R3F	KEM-M53G3-10
YA-R5F/R5LF/R6F	KEM-M53G3-00
Battery unit for YA-U5F/U10F/U20F	
Battery unit for YAC100 controller	KEN-M53G3-00
AC fan motor	KEN-M6175-00



# LINEAR CONVEYOR MODULES

# LCM100

## CONTENTS

- LCM100 basic specifications... 120
- Static tolerable load of slider... 120
- Allowable overhang..... 120
- Ordering method ..... 120
- External view of LCM100 .... 121
- Accessory parts ..... 124
- Controller for linear module  
LCC140 basic specifications... 126
- External view of LCC140 ..... 126

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

# LCM100 basic specifications



## Basic specifications of linear conveyor module

Model	LCM100-4M / 3M / 2MT
Drive method	Moving magnet type, Linear motor with flat core
Repeat positioning accuracy	+/-0.015mm (single slider) <sup>Note 1</sup> / width 0.1mm (mutual difference among all sliders) <sup>Note 2</sup>
Scale	Electromagnetic type / resolution 5µm
Max. speed	3000mm/sec
Max. acceleration	2G
Max. payload	15kg <sup>Note 3 Note 4</sup>
Rated thrust	48N
Total module length	640mm (4M) / 480mm (3M) / 400mm (for 2MT circulation)
Max. number of combined modules	16 (total length: 10240 mm)
Max. number of sliders	16 (when 16 modules are combined)
Min. pitch between sliders	420mm
Mutual height difference between sliders	0.08mm
Max. external size of body cross-section	W136.5mm x H155mm (including slider)
Bearing method	1 guide rail / 2 blocks (with retainer)
Module weight	12.5kg (4M) / 9.4kg (3M) / 7.6kg (2MT)
Slider weight	2.4kg / 3.4kg (when the belt module is used.)
Cable length	3m / 5m
Controller	LCC140

## Basic specifications of belt module


Model	LCM100-4B / 3B
Drive method	Belt back surface pressing force drive <sup>Note 5</sup>
Bearing method	1 guide rail / 2 blocks (with retainer)
Max. speed	560mm/sec
Max. payload	14kg
Module length	640mm (4B) / 480mm (3B)
Max. number of sliders	1 slider / 1 module
Main unit maximum cross-section outside dimensions	W173.8mm×H155mm (including slider)
Cable length	None
Controller	Dedicated driver (Included)
Power supply	DC24V 5A
Communication I/F	Dedicated input/output 16 points
Module weight	11.2kg (4B) / 8.8kg (3B)

Note 5. Because the belt module works on the principle of using the friction of the belt to move the slider, the belt will be abraded and generate dust, making it unsuitable for environments that require a degree of cleanliness.

Note 1. Repeated positioning accuracy when positioning in the same direction (pulsating).  
 Note 2. Positioning accuracy in the pulsating when using the position correction function with the RFID.  
 Note 3. Weight per single slider.  
 Note 4. When used together with the belt module, the max. payload becomes 14kg since the parts dedicated to the belt are attached to the slider.


## Static tolerable load of slider

Static loads shown below are tolerable as references when performing the screw tightening, part assembly, or light press-fitting on the slider.




A (mm)	Payload		
	5 kg	10 kg	15 kg
0	2550	1560	1270
10	1790	1280	1170
20	1380	780	630
30	1130	520	420
40	900	390	310
50	720	310	250
60	600	260	210

Note. The loads shown above are tolerable loads at a position 'A' mm away from the center of the guide rail.



Payload		
5 kg	10 kg	15 kg
38		



C (mm)	Payload		
	5 kg	10 kg	15 kg
0	1190	850	780
10	970	710	650
20	760	610	560
30	630	530	490
40	540	480	430
50	470	430	390
60	410	390	360

Note. The loads shown above are tolerable loads at a position 'C' mm away from the slider upper surface.

## Allowable overhang

Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000 km.

	(Unit: mm)		
	A	B	C
5kg	677	325	325
10kg	533	146	146
15kg	468	90	90

## Ordering method

### Linear module

LCM100 - [ ] - [ ] - LCC140 - 10 - [ ]				
Model	Cable length <sup>Note 1</sup>	Controller	Current sensor	Network option <sup>Note 2</sup>
4M: 640mm 3M: 480mm 2MT: Module for circulation	3L: 3m 5L: 5m 3K: 3m (Flexible cable) 5K: 5m (Flexible cable)		10: 10A	No entry: None CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™

The above shows "one module + one controller" ordering method. When connecting modules, please separately inform the number of necessary modules.

Note 1. The cable for 2MT has flexible specifications.  
 Note 2. For 2MT, be sure to select an appropriate network option.


### Belt module

LCM100 - [ ] - [ ]	
Model	Termination module for belt module <sup>Note 1</sup>
4B: 640mm 3B: 480mm	No entry: None R: Linear module is connected to the right. L: Linear module is connected to the left. RL: Linear module is connected to both sides.

Note 1. Parts necessary to connect the belt module and linear module. Parts are incorporated into the belt module.



LCM100-4M/3M Linear conveyor module (640mm/ 480mm)




- Note 1. All sliders and modules have the same dimensions.
- Note 2. Use M6 hex socket head bolts to install the main body.
- Note 3. An area of +/-6mm from both ends of each connected module and an area of 150mm from the line end become slider stop inhibited areas. (These dimensions are obtained when the slider is located at its center position.)
- Note 4. Select an appropriate rail length of the insertion/ejection rail option from the "Insertion/ejection rail length selection table" shown on the left.
- Note 5. The LCM100 is installed only in the horizontal direction.
- Note 6. Module variations can be combined freely within the same line. (This figure shows that 3M on the left is combined with 4M on the right.)
- Note 7. It is recommended to install rail support parts on the insertion/ejection rail. When no support parts are installed, the rail may be deflected by the slider's own weight, leading to poor rail accuracy or short service life of the guide.
- Note. No mechanical stoppers are provided due to product characteristics. When necessary, the customer installs appropriate mechanical stoppers.

Insertion/ejection rail length selection table

Stroke variations	Insertion/ejection rail length selection table			L
	B	C	D	
4M	640	120	253	44
3M	480	40	93	100
				340


LCM100-2MT Module for circulation




- Note 1. Use M6 hex socket head bolts to install the main body.
- Note 2. For the stop point when the slider enters, specify a point 190mm or more away from the module end face. When ejecting the slider, eject the slider after it has been stopped at a point 190mm or more away from the end face of the module on the ejection side. Otherwise, the slider may not be stopped or ejected correctly.
- Note 3. The movement range above the module is 140mm around the center.
- Note. No mechanical stoppers are provided due to product characteristics. When necessary, the customer installs appropriate mechanical stoppers.



Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION

## LCM100-4B Belt module (640mm)



## LCM100-3B Belt module (480mm)






**Belt module outline diagram of input/output signal wiring**

**Connector on front panel**

Pin No.	Signal name	Function
A1	+24V	Power supply connection DC24V (+/-10%)
A2	GND	
A3	(Blank)	
A4	Option sensor L	Detection output
A5	Option sensor C	Detection output
A6	Option sensor R	Detection output
A7	ALARM	Alarm output
A8	SPEED	Speed output
B1	ALARM-RESET	Alarm reset input ON [L]: Reset      OFF [H]: Normal
B2	INT.VR/EXT	Speed setting unit change-over input ON [L]: Internal    OFF [H]: External
B3	CW/CCW	Rotation direction change-over input ON [L]: CW          OFF [H]: CCW
B4	RUN/BRAKE	Brake input ON [L]: Run          OFF [H]: Instantaneous stop
B5	START/STOP	Start/stop input ON [L]: Start        OFF [H]: Stop
B6	VRH	(When using the dedicated speed setting unit)
B7	VRM	Minus (-) side    DC power supply for speed setting
B8	VRL	Plus (+) side      DC0 to 5V, 1mA or more

Note. For each input, a side to be connected to GND by the external switch is ON (L level).  
 Note. When both the START/STOP and RUN/BRAKE signals are turned ON (L level), the motor starts rotating. In this case, when the CW/CCW signal is turned ON (L level), the slider moves to the left as viewed from the connector side.  
 Conversely, when this signal is turned OFF (H level), the slider moves to the right.  
 Note. When the START/STOP signal is turned OFF (H level) in the RUN/BRAKE signal ON (L level) state, the motor stops naturally.  
 According to the operation speed, the slider may overrun several tens to hundreds of millimeters.  
 Note. When the RUN/BRAKE signal is turned OFF (H level) in the START/STOP signal ON (L level) state, the motor stops instantaneously to suppress the slider overrun to its minimal level.


**Pin assignment drawing**



When investigating the linear conveyor module LCM100 actually, it is necessary to discuss the specifications and restrictions in detail. So, please contact YAMAHA or your dealer to hold hearings regarding your requests.

# LCM100

## LCM100/LCC140 Accessory parts



- ① Module
- ② Robot cable
- ③ Slider
- ④ Termination module (R side)
- ⑤ Termination module (L side)
- ⑥ Insertion/ejection rail
- ⑦ Module connection block (with fastening bolts)
- ⑧ Module connection cable

### LCM100 main body

#### LCM100 module

Linear module



①

Belt module

#### Linear module

Model	LCM100-4M
	KDJ-M2020-40 (640mm)
	LCM100-3M
	KDJ-M2020-30 (480mm)
	LCM100-2MT (for circulation)
	KDJ-M2022-20 (400mm)

#### Belt module

Model	LCM100-4B
	KDJ-4K111-40 (640mm)
	LCM100-3B
	KDJ-4K111-30 (480mm)

#### Robot cable for linear module

Robot cables for the number of modules are required.



②

Model	For LCM100-4M/3M
	KDJ-M4710-30 (3m×2 pcs.)
	KDJ-M4710-50 (5m×2 pcs.)
	For LCM100-2MT
	KDJ-M4721-30 (3m×1 pc.)
	KDJ-M4721-50 (5m×1 pc.)

#### Slider

For linear module

For belt module



③

#### Linear module

Model	KDJ-M2264-00
-------	--------------

#### Belt module

Model	KDJ-M2264-10
-------	--------------

### Parts for LCM100

#### Termination module for linear module (R side)

This part is attached to the right end of the module. One termination module per line is required. <sup>Note 1</sup> Additionally, even when using only one module without connections, one termination module is required.



④

Model	KDJ-M2021-R0
-------	--------------

#### Termination module for linear module (L side)

This part is attached to the left end of the module. One termination module per line is required. <sup>Note 1</sup> Additionally, even when using only one module without connections, one termination module is required.




⑤

Model	KDJ-M2021-L0
-------	--------------

#### Insertion/ejection rail

Tapered rail.

Up to two rails per line can be installed. <sup>Note 1</sup>



⑥

Model	44mm : KDJ-M6200-00 (With a dedicated 44mm connection block)
	100mm : KDJ-M2222-10
	160mm : KDJ-M2222-20 <sup>Note</sup>
	220mm : KDJ-M2222-30 <sup>Note</sup>
	280mm : KDJ-M2222-40 <sup>Note</sup>
	340mm : KDJ-M2222-50

Note. Not in stock. We require some lead time for delivery.

#### Module connection block (with fastening bolts)

This block connects modules. ([Number of modules making up the line <sup>Note 1</sup>] - 1) blocks are required. Additionally, when installing insertion/ejection rails, one block per rail is required.



⑦

Model	KDJ-M6100-00
-------	--------------

#### Module connection cable

This cable connects modules. ([Number of modules] - 1) cables per line are required. <sup>Note 1</sup>



⑧


Model	KDJ-M4811-00
-------	--------------

Note 1. A state, in which multiple modules are connected, is called "line".

Parts for LCC140 controller

**Power connector + connection lever**


One set of parts per LCC140 is required.



Model	KAS-M5382-00
-------	--------------

**HPB dummy connector**


When performing the operation with the programming box HPB removed, connect this dummy connector to the HPB connector. One connector per LCC140 is required.



Model	KDK-M5163-00
-------	--------------

**SAFETY connector**

One connector per LCC140 is required.




Model	Not wired : KDK-M5370-10 Wired <sup>Note</sup> : KDK-M5370-00
-------	--

Note. The wired connector is that the wiring for the emergency stop cancel was performed inside the connector. Select this model when performing the operation check or debugging with single linear conveyor.

Parts for line configuration

**LINK cable**


[(Number of modules) - 1] cables per line are required.



Model	1m : KDK-M5361-10 3m : KDK-M5361-30 5m : KDK-M5361-50
-------	---

**Terminator connector**

When connecting modules, two connectors per line are required.



Model	KDK-M5361-00
-------	--------------

**Dust cover (for LINK connector)**

This dust cover is attached to the insertion port, into which the the LINK cable terminator connector is not inserted. When using only one module without connections, two dust covers are required.


Note. The dust cover is essential for the 2MT.



Model	KDK-M658K-00 (for MDR20 pin)
-------	------------------------------

Selection parts

**Proximity sensor for belt module**



Model	L (Left): KDJ-M2205-L0 C (Center): KDJ-M2205-C0 R (Right): KDJ-M2205-R0
-------	---

**Programming box HPB/HPB-D**

All operations, such as robot manual operation, program input or edit, teaching, and parameter setting can be performed with this programming box. As an interactive interface with the screen display is used, even personnel who use this programming box for the first time can easily understand how to operate it.

Model	HPB: KBB-M5110-01 HPB-D: KBB-M5110-21 (CE specifications / with 3-position enable switch)
-------	---



Support software POPCOM+

● PC supporting software POPCOM+



POPCOM+ software model	KBG-M4966-00
------------------------	--------------

● POPCOM+ environment

OS	Microsoft Windows XP / Vista (32bit / 64Bit) / 7 (32bit / 64Bit) / 8, 8.1 (32bit/64bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	50MB of available space required on installation drive.
Disk operation	RS-232C
Applicable controllers	SRCX/ERCX/DRCX/TRCX/SRCP/SRCD/ERCD/SR1/LCC140 <sup>Note 1</sup>

Note 1. LCC140 is applicable to Ver. 2.1.1 or later.  
Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

● Data cables (5m)

Communication cable for POPCOM+. Select from USB cable or D-sub cable.



Model	USB type (5m)	KBG-M538F-00
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10

Note. This USB cable supports Windows 2000/XP or later.  
Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.  
Note. USB driver for communication cable can also be downloaded from our website.

# LCM100

## RFID

RFID (manufactured by BALLUFF GmbH)

Reader/writer cable



Model KDK-M6300-00

RFID (manufactured by OMRON)

Antenna amplifier controller cable



Model KDK-M6300-A0

Dust cover (for RFID)

This cover is attached to the insertion port if RFID is not used. (Included as standard)



Model KDK-M658K-10(for MDR26 pin)

Whether or not the RFID system can be used may vary depending on the destination place (country). Before selecting a RFID system, please contact YAMAHA.

## Maintenance parts

Robot cable for LCM100



Model	KDJ-M4751-30 (3m×1 pc.)
	KDJ-M4751-50 (5m×1 pc.)
	KDJ-M4755-30 (Flexible cable 3m×1 pc.)
	KDJ-M4755-50 (Flexible cable 5m×1 pc.)

Lithium battery for system backup



Model KDK-M4252-00

Replacement filter for LCC140 (5 pcs. in package)



Model KDK-M427G-00

## Controller for linear module


# LCC140 basic specifications


### Basic specifications of LCC140 controller

<b>Controllable robot</b>	Linear conveyor module LCM series
<b>Outside dimensions</b>	W402.5×H229×D106.5mm
<b>Main body weight</b>	4.8kg
<b>Input power voltage</b>	Single-phase AC200 to 230V +/-10% or less (50/60Hz)
<b>Maximum power consumption</b>	350VA (LCM100-4M 1 slider is driven.)
<b>External input/output</b>	SAFETY
	RS-232C (dedicated to RFID)
	RS-232C (for HPB / doubles as POPCOM+)
<b>Network option</b>	CC-Link Ver. 1.10 compatible, Remote device station (2 stations)
	DeviceNet™ Slave 1 node
	EtherNet/IP™ adapter 2 ports
<b>Programming box</b>	HPB, HPB-D (Software version 24.01 or later)



### External view of LCC140





## CLOSED LOOP STEPPING MOTOR SINGLE-AXIS ROBOTS

# TRANSERVO SERIES

### CONTENTS

■ <b>TRANSERVO SPECIFICATION SHEET</b> .....	128	RF02-N .....	154
■ <b>Robot ordering method description</b> .....	129	RF02-S .....	156
■ <b>Rod type: Bracket plates</b> .....	129	RF03-N .....	158
■ <b>Rod type: Grease gun nozzle tube for space-saving models</b> .....	129	RF03-S .....	160
■ <b>Rod type: Running life distance to life time conversion example</b> .....	129	RF04-N .....	162
		RF04-S .....	164
		BD04 .....	166
		BD05 .....	167
		BD07 .....	168

#### TRANSERVO

SS04 .....	130
SS05 .....	132
SS05H .....	134
SG07 .....	136
SR03 .....	137
SRD03 .....	140
SR04 .....	142
SRD04 .....	144
SR05 .....	146
SRD05 .....	148
STH04 .....	150
STH06 .....	152





# Robot ordering method description

In the order format for the YAMAHA single-axis robots TRANSERVO series, the notation (letters/numbers) for the mechanical section is shown linked to the controller section notation.

## [Example]

### ● Mechanical ▶ SS05

- Lead ▷ 6mm
- Model ▷ Straight
- Brake ▷ Yes
- Origin position ▷ Standard
- Grease ▷ Standard
- Stroke ▷ 600mm
- Cable length ▷ 1m

### ● Controller ▶ TS-S2

- Input /Output selection ▷ NPN

### ● Ordering Method

**SS05-06SB-NN-600-1K-S2NP**

Mechanical section

Controller section

To find detailed controller information see the controller page.

TS-S2 ▶ **P.490**, TS-SH ▶ **P.490**, TS-SD ▶ **P.500**

#### ● SS type / SG type (Slider type)

Model	Lead	Model	Brake	Origin position	Grease option	Stroke	Cable length
SS04	02 2mm	S Straight model	N With no brake	N Standard	N Standard grease		1K 1m
SS05	06 6mm	R Space-saving model (motor installed on right)	B With brake	Z No-motor side	C Clean room grease		3K 3m
SS05H	12 12mm						5K 5m
SG07	20 20mm	L Space-saving model (motor installed on left)					10K 10m

#### ● SR type (Rod type)

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
SR03	02 2mm	S Straight model	N With no brake	N Standard	N No plate		1K 1m
SRD03	06 6mm	R Space-saving model (motor installed on right)	B With brake	Z No-motor side	H With plate		3K 3m
SR04	12 12mm				V With flange		5K 5m
SRD04		L Space-saving model (motor installed on left)					10K 10m
SR05							
SRD05		U Space-saving model (motor installed on top)					

#### ● STH Type (Slide table type)

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
STH04	05 5mm	S Straight model	N With no brake	N Standard	N No plate		1K 1m
STH06	08 8mm	R Space-saving model (motor installed on right)	B With brake	Z No-motor side	H With plate		3K 3m
	10 10mm						5K 5m
	16 16mm	L Space-saving model (motor installed on left)					10K 10m

#### ● RF Type (Rotary type / Limit rotation specification, Rotary type / Sensor specification)

Model	Return-to-origin method	Bearing	Torque	Cable entry location	Rotation direction	Cable length
RF02-N	N Stroke end (Limit rotation)	N Standard	N Standard torque	R From the right	N CCW	1K 1m
RF02-S	S Sensor (Limitless rotation)	R High rigidity	R High torque	L From the left	Z CW	3K 3m
RF03-N						5K 5m
RF03-S						10K 10m
RF04-N						
RF04-S						

#### ● BD Type (Belt type)

Model	Lead	Brake	Origin position	Stroke	Cable length
BD04	48 48mm	N With no brake	N Standard		1K 1m
BD05					3K 3m
BD07					5K 5m
					10K 10m

## ■ Rod type: Bracket plates

### SR03/SRD03 bracket plates



Feet (horizontal mount) Flange (vertical mount)

Type	Model No.
Feet (2 plates per set)	KCU-M223F-00
Flange (1 piece)	KCU-M224F-00

### SR04/SRD04 bracket plates



Feet (horizontal mount) Flange (vertical mount)

Type	Model No.
Feet (2 plates per set)*	KCV-M223F-00
Flange (1 piece)	KCV-M224F-00

\* Comes with 12 mounting nuts for feet.

### SR05/SRD05 bracket plates



Feet (horizontal mount) Flange (vertical mount)


Type	Model No.
Feet (2 plates per set)*	KCW-M223F-00
Flange (1 piece)	KCW-M224F-00

\* Comes with 8 mounting nuts for feet.

## ■ Rod type: Grease gun nozzle tube for space-saving models

When greasing the ball screw in the SR03-UB or SRD03-UB (motor installed on top / with brake), use a grease gun with a bent nozzle tube as shown below.

### ■ Grease gun nozzle tube (YAMAHA recommended nozzle tube)




Model KCU-M3861-00

Note. This nozzle tube can be attached to a commercially available ordinary grease gun.

This nozzle tube is even usable when there is little space around the grease port.

For example, when the SR04 or SR05 space-saving model is used with the motor facing up, the grease port is positioned on the side of the robot body. This may make it difficult to refill grease depending on the positions of other robots or peripheral units.



## ■ Rod type: Running life distance to life time conversion example


This is an example of life time converted from the running life distance listed on each model page for the SR type.

Model	SR04-02SB, Vertical mount, 25 kg payload
Life distance	500 km → Life time : Approx. 3 years
Operating conditions	100mm back-and-forth movement, shuttle time 16 seconds (duty: 20%)
Work conditions	16 hours per day
Work days	240 days per year

Note. Make sure that the rod is not subjected to a radical load.

# SS04 Slider type

- CE compliance
- Origin on the non-motor side is selectable



## Ordering method

### SS04

Model	Lead	Model	Brake	Origin position	Grease option	Stroke	Cable length <sup>Note 2</sup>
	12: 12mm 06: 6mm 02: 2mm	S: Straight model R: Space-saving model (motor installed on right) L: Space-saving model (motor installed on left)	N: With no brake B: With brake	N: Standard <sup>Note 1</sup> Z: Non-motor side	N: Standard grease C: Clean room grease	50 to 400 (50mm pitch)	1K: 1m 3K: 3m 5K: 5m 10K: 10m

### S2

Robot positioner	I/O
S2: TS-S2 <sup>Note 3</sup>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 4</sup>

### SH

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 4</sup>	B: With battery (Absolute) N: None (Incremental)

### SD

Robot driver	I/O cable
SD: TS-SD	1: 1m


Note 1. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 2. The robot cable is flexible and resists bending.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>Motor</b>	42 □ Step motor	
<b>Resolution (Pulse/rotation)</b>	20480	
<b>Repeatability <sup>Note 1</sup> (mm)</b>	±0.02	
<b>Deceleration mechanism</b>	Ball screw φ8 (Class C10)	
<b>Maximum motor torque (N·m)</b>	0.27	
<b>Ball screw lead (mm)</b>	12	6
<b>Maximum speed (mm/sec)</b>	600	300
<b>Maximum payload (kg)</b>	Horizontal: 2 Vertical: 1	4 2
<b>Max. pressing force (N)</b>	45	90
<b>Stroke (mm)</b>	50 to 400 (50mm pitch)	
<b>Overall length (mm)</b>	Horizontal: Stroke+216 Vertical: Stroke+261	
<b>Maximum outside dimension of body cross-section (mm)</b>	W49 × H59	
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10	


Note 1. Positioning repeatability in one direction.

## Allowable overhang <sup>Note</sup>




Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				Vertical installation (Unit: mm)			
	A	B	C		A	B	C	Lead 12	A	C	
Lead 12	1kg	807	218	292	1kg	274	204	776	0.5kg	407	408
	2kg	667	107	152	2kg	133	93	611	1kg	204	204
Lead 6	2kg	687	116	169	2kg	149	102	656	1kg	223	223
	3kg	556	76	112	3kg	92	62	516	2kg	107	107
Lead 2	4kg	567	56	84	4kg	63	43	507	2kg	118	118
	4kg	869	61	92	4kg	72	48	829	4kg	53	53
Lead 2	6kg	863	40	60	6kg	39	29	789			

## Static loading moment




(Unit: N·m)		
MY	MP	MR
16	19	17

## Motor installation (Space-saving model)




## SS04 Straight model S



Effective stroke	50	100	150	200	250	300	350	400
L	266	316	366	416	466	516	566	616
A	2	3	4	5	6	7	8	9
B	3	4	5	6	7	8	9	10
C	50	100	150	200	250	300	350	400
Weight (kg) <sup>Note 4</sup>	1.5	1.6	1.7	1.8	2.0	2.1	2.2	2.3

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 3. The cable's minimum bend radius is R30.  
 Note 4. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.

SS04 Space-saving model **R** **L**



Effective stroke	50	100	150	200	250	300	350	400
<b>L</b>	187	237	287	337	387	437	487	537
<b>A</b>	2	3	4	5	6	7	8	9
<b>B</b>	3	4	5	6	7	8	9	10
<b>C</b>	100	150	200	250	300	350	400	450
<b>Weight (kg)</b> <sup>Note 4</sup>	1.2	1.4	1.5	1.6	1.7	1.8	1.9	2.1

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Secure the cable with a tie-band 80mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 3. The cable's minimum bend radius is R30.  
 Note 4. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.  
 Note 5. The belt cover's left and right sides are asymmetrical. Therefore, if the motor mounting orientation is changed, the cover cannot be attached.

# SS05

## Slider type

- High lead: Lead 20
- CE compliance
- Origin on the non-motor side is selectable



### Ordering method

## SS05

Model	Lead	Model	Brake	Origin position	Grease option	Stroke	Cable length
	20: 20mm 12: 12mm 06: 6mm	S: Straight model R: Space-saving model (motor installed on right) L: Space-saving model (motor installed on left)	Note 1 N: With no brake B: With brake	Note 2 N: Standard Z: Non-motor side	N: Standard grease C: Clean room grease	50 to 800 (50mm pitch)	Note 3 1K: 1m 3K: 3m 5K: 5m 10K: 10m


Note 1. Brake-equipped models can be selected only when the lead is 12mm or 6mm.  
 Note 2. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 3. The robot cable is flexible and resists bending.  
 Note 4. See P.498 for DIN rail mounting bracket.  
 Note 5. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications


Motor	42 Step motor		
Resolution (Pulse/rotation)	20480		
Repeatability (mm)	±0.02		
Deceleration mechanism	Ball screw φ12 (Class C10)		
Maximum motor torque (N·m)	0.27		
Ball screw lead (mm)	20	12	6
Maximum speed (mm/sec)	1000	600	300
Maximum payload (kg)	Horizontal	Vertical	
	4	6	10
Max. pressing force (N)	27	45	90
Stroke (mm)	50 to 800 (50mm pitch)		
Overall length (mm)	Horizontal	Stroke+230	
	Vertical	Stroke+270	
Maximum outside dimension of body cross-section (mm)	W55 × H56		
Cable length (m)	Standard: 1 / Option: 3, 5, 10		

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.

### Motor installation (Space-saving model)



### Allowable overhang



Lead	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)					
	A	B	C	A	B	C	A	C				
Lead 20	2kg	413	139	218	2kg	192	123	372	Lead 12	0.5kg	578	579
	4kg	334	67	120	4kg	92	51	265		1kg	286	286
Lead 12	4kg	347	72	139	4kg	109	57	300	Lead 6	1kg	312	312
	6kg	335	47	95	6kg	63	31	263		2kg	148	148
Lead 6	4kg	503	78	165	4kg	134	63	496				
	8kg	332	37	79	6kg	76	35	377				
10kg	344	29	62	8kg	47	22	355					

Note. Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000 km (Service life is calculated for 600mm stroke models).


### Static loading moment

Static loading moment (Unit: N·m)		
MY	MP	MR
25	33	30

### Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control


### SS05 Straight model



Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	280	330	380	430	480	530	580	630	680	730	780	830	880	930	980	1030
A	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
B	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
C	100	150	200	250	300	350	400	450	500	500	500	500	500	500	500	500
Weight (kg)	2.1	2.3	2.5	2.7	2.8	3.0	3.2	3.4	3.6	3.8	4.0	4.2	4.4	4.6	4.8	5.0
Maximum speed for each stroke (mm/sec)	Lead 20	1000										933	833	733	633	
	Lead 12	600										560	500	440	380	
Speed setting	Lead 6	300										280	250	220	190	
	Speed setting	-										93%	83%	73%	63%	

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 3. The cable's minimum bend radius is R30.  
 Note 4. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.  
 Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

SS05 Space-saving model **R** **L**



Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	
<b>L</b>	196.5	246.5	296.5	346.5	396.5	446.5	496.5	546.5	596.5	646.5	696.5	746.5	796.5	846.5	896.5	946.5	
<b>A</b>	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	
<b>B</b>	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	
<b>C</b>	100	150	200	250	300	350	400	450	500	500	500	500	500	500	500	500	
<b>Weight (kg)</b> <sup>Note 4</sup>	1.6	1.8	2.0	2.2	2.4	2.6	2.8	3.0	3.2	3.4	3.6	3.8	4.0	4.1	4.3	4.5	
<b>Maximum speed for each stroke</b> <sup>Note 5</sup> (mm/sec)	<b>Lead20</b>											1000	933	833	733	633	
	<b>Lead12</b>											600	560	500	440	380	
	<b>Lead6</b>											300	280	250	220	190	
<b>Speed setting</b>											-	93%	83%	73%	63%		

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Secure the cable with a tie-band 80mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 3. The cable's minimum bend radius is R30.  
 Note 4. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.  
 Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.  
 Note 6. The belt cover's left and right sides are asymmetrical. Therefore, if the motor mounting orientation is changed, the cover cannot be attached.

# SS05H

Slider type



- High lead: Lead 20
- CE compliance
- Origin on the non-motor side is selectable

## Ordering method

<b>SS05H</b>							
<b>Model</b>	<b>Lead</b>	<b>Model</b>	<b>Brake</b> <sup>Note 1</sup>	<b>Origin position</b>	<b>Grease option</b>	<b>Stroke</b>	<b>Cable length</b> <sup>Note 3</sup>
	20: 20mm 12: 12mm 06: 6mm	S: Straight model R: Space-saving model (motor installed on right) L: Space-saving model (motor installed on left)	N: With no brake B: With brake	N: Standard <sup>Note 2</sup> Z: Non-motor side	N: Standard grease C: Clean room grease	50 to 800 (50mm pitch)	1K: 1m 3K: 3m 5K: 5m 10K: 10m

<b>S2</b>		
<b>Robot positioner</b>	<b>I/O</b>	
S2: TS-S2 <sup>Note 4</sup>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>	
<b>SH</b>		
<b>Robot positioner</b>	<b>I/O</b>	<b>Battery</b>
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>	B: With battery (Absolute) N: None (Incremental)
<b>SD</b>	<b>1</b>	
<b>Robot driver</b>	<b>I/O cable</b>	
SD: TS-SD	1: 1m	


Note 1. Brake-equipped models can be selected only when the lead is 12mm or 6mm.  
 Note 2. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 3. The robot cable is flexible and resists bending.  
 Note 4. See P.498 for DIN rail mounting bracket.  
 Note 5. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications


<b>Motor</b>	42 □ Step motor
<b>Resolution (Pulse/rotation)</b>	20480
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.02
<b>Deceleration mechanism</b>	Ball screw φ12 (Class C10)
<b>Maximum motor torque (N·m)</b>	0.47
<b>Ball screw lead (mm)</b>	20    12    6
<b>Maximum speed</b> <sup>Note 2</sup> (mm/sec)	<b>Horizontal</b> 1000    600    300 <b>Vertical</b> -    500    250
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 6    8    12 <b>Vertical</b> -    2    4
<b>Max. pressing force (N)</b>	36    60    120
<b>Stroke (mm)</b>	50 to 800 (50pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+286 <b>Vertical</b> Stroke+306
<b>Maximum outside dimension of body cross-section (mm)</b>	W55 × H56
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.

## Motor installation (Space-saving model)



## Allowable overhang <sup>Note</sup>



Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				Vertical installation (Unit: mm)				
	A	B	C		A	B	C		A	C		
Lead 20	2kg	599	225	291	2kg	262	203	554	Lead 12	1kg	458	459
	4kg	366	109	148	4kg	118	88	309		2kg	224	224
	6kg	352	71	104	6kg	71	49	262		2kg	244	245
Lead 12	4kg	500	118	179	4kg	146	96	449	Lead 6	2kg	244	245
	6kg	399	79	118	6kg	85	55	334		4kg	113	113
	8kg	403	56	88	8kg	55	34	305				
Lead 6	6kg	573	83	136	6kg	101	62	519				
	8kg	480	61	100	8kg	64	39	413				
	10kg	442	47	78	10kg	43	26	355				
	12kg	465	39	64	12kg	28	17	338				

Note. Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000 km (Service life is calculated for 600mm stroke models).


## Static loading moment

(Unit: N·m)		
MY	MP	MR
32	38	34

## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control


## SS05H Straight model **S**



Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
	L	336	386	436	486	536	586	636	686	736	786	836	886	936	986	1036
A	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
B	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
C	100	150	200	250	300	350	400	450	500	500	500	500	500	500	500	500
<b>Weight (kg)</b> <sup>Note 4</sup>	2.4	2.6	2.8	3.0	3.2	3.4	3.6	3.8	4.0	4.2	4.4	4.5	4.7	4.9	5.1	5.3
<b>Maximum speed for each stroke</b> <sup>Note 5</sup> (mm/sec)	Lead20	1000														
	Lead12 (Horizontal)	600														
	Lead12 (Vertical)	500														
	Lead6 (Horizontal)	300														
	Lead6 (Vertical)	250														
<b>Speed setting</b>	-															
													93%	83%	73%	63%

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 3. The cable's minimum bend radius is R30.  
 Note 4. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.  
 Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

## SS05H Space-saving model R L



Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	212.5	262.5	312.5	362.5	412.5	462.5	512.5	562.5	612.5	662.5	712.5	762.5	812.5	862.5	912.5	962.5
A	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
B	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
C	100	150	200	250	300	350	400	450	500	500	500	500	500	500	500	500
Weight (kg) <sup>Note 4</sup>	1.7	1.9	2.1	2.3	2.5	2.7	2.8	3.0	3.2	3.4	3.6	3.8	4.0	4.2	4.4	4.6
Maximum speed for each stroke <sup>Note 5</sup> (mm/sec)																
Lead20	1000															
Lead12 (Horizontal)	600															
Lead12 (Vertical)	500															
Lead6 (Horizontal)	300															
Lead6 (Vertical)	250															
Speed setting	-															
													93%	83%	73%	63%

- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. Secure the cable with a tie-band 80mm or less from unit's end face to prevent the cable from being subjected to excessive loads.
- Note 3. The cable's minimum bend radius is R30.
- Note 4. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.
- Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.
- Note 6. The belt cover's left and right sides are asymmetrical. Therefore, if the motor mounting orientation is changed, the cover cannot be attached.





# SR03 Rod type

- CE compliance
- Origin on the non-motor side is selectable



## Ordering method

### SR03

<b>Model</b>	<b>Lead</b>	<b>Model</b>	<b>Brake</b>	<b>Origin position</b>	<b>Bracket plate</b>	<b>Stroke</b>	<b>Cable length</b> <sup>Note 3</sup>
	12: 12mm 06: 6mm	S: Straight model R: Space-saving model <sup>Note 1</sup> (motor installed on right) L: Space-saving model <sup>Note 1</sup> (motor installed on left) U: Space-saving model <sup>Note 1</sup> (motor installed on top)	N: With no brake B: With brake	N: Standard <sup>Note 2</sup> Z: Non-motor side	N: No plate H: With plate V: With flange	50 to 200 (50mm pitch)	1K: 1m 3K: 3m 5K: 5m 10K: 10m

Note 1. See P.129 for grease gun nozzles.  
Note 2. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.

Note 3. The robot cable is flexible and resists bending.  
Note 4. See P.498 for DIN rail mounting bracket.  
Note 5. Select this selection when using the gateway function. For details, see P.60.


<b>S2</b>	<b>SH</b>	<b>SD</b>
<b>Robot positioner</b>	<b>Robot positioner</b>	<b>Robot driver</b>
S2: TS-S2 <sup>Note 4</sup>	SH: TS-SH	SD: TS-SD
<b>I/O</b>	<b>I/O</b>	<b>I/O cable</b>
NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>	t: 1m
	<b>Battery</b>	
	B: With battery (Absolute) N: None (Incremental)	

## Basic specifications

<b>Motor</b>	42 □ Step motor
<b>Resolution (Pulse/rotation)</b>	20480
<b>Repeatability (mm)</b>	+/-0.02
<b>Deceleration mechanism</b>	Ball screw φ8 (Class C10)
<b>Ball screw lead (mm)</b>	12
<b>Maximum speed</b> <sup>Note 1</sup> (mm/sec)	500    250
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 10    20 <b>Vertical</b> 4    8
<b>Max. pressing force (N)</b>	75    100
<b>Stroke (mm)</b>	50 to 200 (50pitch)
<b>Lost motion</b>	0.1mm or less
<b>Rotating backlash (°)</b>	+/-1.0
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+236.5 <b>Vertical</b> Stroke+276.5
<b>Maximum outside dimension of body cross-section (mm)</b>	W48 × H56.5
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10


Note 1. The maximum speed needs to be changed in accordance with the payload.  
See the "Speed vs. payload" graph shown on the right.  
For details, see P. 128.

## Speed vs. payload




## Running life

5000 km on models other than shown below.  
Running life of only the model shown below becomes shorter than 5000 km depending on the payload, so check the running life curve.



Note. See P.129 for running life distance to life time conversion example.


## Motor installation (Space-saving model)



## Controller


Controller	Operation method	Controller	Operation method
TS-S2	I/O point trace / Remote command	TS-SD	Pulse train control
TS-SH			

## SR03 Straight model S




**Option: Horizontal installation plate (foot)**

\* Contents of option: Plate, 2 pcs.  
See our robot manuals for additional settings.



**Option: Vertical installation plate (flange)**



Effective stroke	50	100	150	200
L1	161	211	261	311
L	249	299	349	399
H	2	3	4	5
K	6	8	10	12
<b>Weight (kg)</b> <sup>Note 7</sup>	1.1	1.3	1.4	1.6

Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.

## SR03 Space-saving model (motor installed on right) **R**

**Dimensions of attached nut**

Effective stroke	50	100	150	200
L1	161	211	261	311
L	204	254	304	354
H	2	3	4	5
K	6	8	10	12
<b>Weight (kg)</b> <sup>Note 7</sup>	1.3	1.5	1.6	1.8

**Option: Horizontal installation plate (foot)**

\* Contents of option: Plate, 2 pcs.  
See our robot manuals for additional settings.

Hex. socket head cap bolt (M3×0.5), Length under head 10  
\* Two bolts are required for one plate.

**Option: Vertical installation plate (flange)**

Hex. socket head cap bolt (M3×0.5), Length under head 14

Note 1. It is possible to apply only the axial load. Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.

## SR03 Space-saving model (motor installed on left) **L**

**Dimensions of attached nut**

Effective stroke	50	100	150	200
L1	161	211	261	311
L	204	254	304	354
H	2	3	4	5
K	6	8	10	12
<b>Weight (kg)</b> <sup>Note 7</sup>	1.3	1.5	1.6	1.8

**Option: Horizontal installation plate (foot)**

\* Contents of option: Plate, 2 pcs.  
See our robot manuals for additional settings.

Hex. socket head cap bolt (M3×0.5), Length under head 10  
\* Two bolts are required for one plate.

**Option: Vertical installation plate (flange)**

Hex. socket head cap bolt (M3×0.5), Length under head 14

Note 1. It is possible to apply only the axial load. Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.

SR03 Space-saving model (motor installed on top) **U**

**Option: Horizontal installation plate (foot)**

\* Contents of option: Plate, 2 pcs.  
See our robot manuals for additional settings.

**Option: Vertical installation plate (flange)**

Hex. socket head cap bolt (M3×0.5), Length under head 10  
\* Two bolts are required for one plate.

Hex. socket head cap bolt (M3×0.5), Length under head 14

**Dimensions of attached nut**


Effective stroke	50	100	150	200
L1	161	211	261	311
L	204	254	304	354
H	2	3	4	5
K	6	8	10	12
<b>Weight (kg)</b> <sup>Note 7</sup>	1.3	1.5	1.6	1.8

Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables.  
(Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.

# SRD03

## Rod type (With support guide)

- CE compliance
- Origin on the non-motor side is selectable: Lead 6, 12



### Ordering method

#### SRD03

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length <sup>Note 3</sup>
	12: 12mm 06: 6mm	S: Straight model U: Space-saving model <sup>Note 1</sup> (motor installed on top)	N: With no brake B: With brake	N: Standard <sup>Note 2</sup> Z: Non-motor side	N: No plate H: With plate	50 to 200 (60mm pitch)	1K: 1m 3K: 3m 5K: 5m 10K: 10m

#### S2

Robot positioner	I/O
S2: TS-S2 <sup>Note 4</sup>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>

#### SH

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>	B: With battery (Absolute) N: None (Incremental)

#### SD 1

Robot driver	I/O cable
SD: TS-SD	1: 1m

Note 1. See P.129 for grease gun nozzles.  
Note 2. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.


Note 3. The robot cable is flexible and resists bending.  
Note 4. See P.498 for DIN rail mounting bracket.  
Note 5. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications

<b>Motor</b>	42 □ Step motor
<b>Resolution (Pulse/rotation)</b>	20480
<b>Repeatability (mm)</b>	+/-0.02
<b>Deceleration mechanism</b>	Ball screw φ8 (Class C10)
<b>Ball screw lead (mm)</b>	12      6
<b>Maximum speed <sup>Note 1</sup> (mm/sec)</b>	500      250
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 10      20 <b>Vertical</b> 3.5      7.5
<b>Max. pressing force (N)</b>	75      100
<b>Stroke (mm)</b>	50 to 200 (50pitch)
<b>Lost motion</b>	0.1mm or less
<b>Rotating backlash (°)</b>	+/-0.05
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+236.5 <b>Vertical</b> Stroke+276.5
<b>Maximum outside dimension of body cross-section (mm)</b>	W48 × H56.5
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10


Note 1. The maximum speed needs to be changed in accordance with the payload.  
See the "Speed vs. payload" graph shown on the right.  
For details, see P. 128.

### Speed vs. payload



### Running life

5000 km on models other than shown below.  
Running life of only the model shown below becomes shorter than 5000 km depending on the payload, so check the running life curve.




Note. See P.129 for running life distance to life time conversion example.

### Controller


Controller	Operation method	Controller	Operation method
TS-S2	I/O point trace / Remote command	TS-SD	Pulse train control

### SRD03 Straight model S



#### Option: Horizontal installation plate (foot)


\* Contents of option: Plate, 2 pcs.  
See our robot manuals for additional settings.



Effective stroke	50	100	150	200
L1	161	211	261	311
L	249	299	349	399
H	2	3	4	5
K	6	8	10	12
<b>Weight (kg) <sup>Note 5</sup></b>	1.5	1.7	1.9	2.1

Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. When running the cables, secure cables so that any load is not applied to them.  
Note 3. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 4. The cable's minimum bend radius is R30.  
Note 5. Models with a brake will be 0.2kg heavier.  
Note 6. Distance to mechanical stopper.

SRD03 Space-saving model (motor installed on top) **U**



# SR04 Rod type

- CE compliance
- Origin on the non-motor side is selectable: Lead 6, 12



## Ordering method

### SR04

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
	12: 12mm 06: 6mm 02: 2mm	S: Straight model R: Space-saving model (motor installed on right) L: Space-saving model (motor installed on left)	N: With no brake B: With brake	N: Standard Z: Non-motor side	N: No plate H: With plate V: With flange	50 to 300 (50mm pitch)	1K: 1m 3K: 3m 5K: 5m 10K: 10m

- Note 1. See P.129 for grease gun nozzles.  
 Note 2. When "2mm lead" is selected, the origin position cannot be changed (to non-motor side).  
 Note 3. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 4. The robot cable is flexible and resists bending.  
 Note 5. See P.498 for DIN rail mounting bracket.  
 Note 6. Select this selection when using the gateway function. For details, see P.60.

### S2

Robot positioner	I/O
S2: TS-S2	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board

### SH

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	B: With battery (Absolute) N: None (Incremental)

### SD


Robot driver	I/O cable
SD: TS-SD	1: 1m

## Basic specifications

Motor	42 Step motor	
Resolution (Pulse/rotation)	20480	
Repeatability (mm)	±0.02	
Deceleration mechanism	Ball screw φ8 (Class C10)	Ball screw φ10 (Class C10)
Ball screw lead (mm)	12	6
Maximum speed (mm/sec)	500	250
Maximum payload (kg)	Horizontal: 25 Vertical: 5	Horizontal: 40 Vertical: 12
Max. pressing force (N)	150	300
Stroke (mm)	50 to 300 (50pitch)	
Lost motion	0.1mm or less	
Rotating backlash (°)	±1.0	
Overall length (mm)	Stroke+263	
Maximum outside dimension of body cross-section (mm)	W48 × H58	
Cable length (m)	Standard: 1 / Option: 3, 5, 10	


Note 1. The maximum speed needs to be changed in accordance with the payload. See the "Speed vs. payload" graph shown on the right. For details, see P. 128. Additionally, when the stroke is long, the maximum speed is decreased due to the critical speed of the ball screw. See the maximum speed table shown at the lower portion of the drawing.

## Speed vs. payload




## Running life

5000 km on models other than shown below. Running life of only the model shown below becomes shorter than 5000 km depending on the payload, so check the running life curve.



Note. See P.129 for running life distance to life time conversion example.


## Motor installation (Space-saving model)



## Controller


Controller	Operation method	Controller	Operation method
TS-S2	I/O point trace / Remote command	TS-SD	Pulse train control
TS-SH			

## SR04 Straight model S





### Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 12 pcs. See our robot manuals for additional settings.



### Option: Vertical installation plate (flange)

Hex. socket head cap bolt (M4x0.7), Length under head 14



Effective stroke	Stroke					
	50	100	150	200	250	300
L1	162.5	212.5	262.5	312.5	362.5	412.5
L	270.5	320.5	370.5	420.5	470.5	520.5
Maximum speed for each stroke (mm/sec)	Lead 12	500		440	320	
	Lead 6	250		220	160	
	Lead 2	80		72	53	

- Note 1. It is possible to apply only the axial load.  
 Note 2. Use the external guide together so that any radial load is not applied to the rod.  
 Note 3. The orientation of the width across flat part is undefined to the base surface.  
 Note 4. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
 Note 5. When running the cables, secure cables so that any load is not applied to them.  
 Note 6. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth is)  
 Note 7. The cable's minimum bend radius is R30.  
 Note 8. Models with a brake will be 0.2kg heavier.  
 Note 9. Distance to mechanical stopper.

SR04 Space-saving model (motor installed on right) **R**

Approx. 245 (Cable length)

Effective stroke (5)(Note 8)

42.5<sup>+2</sup> (7)(Note 8)

152 (with brake)  
112

Origin on motor side

Origin on non-motor side (Note 9)

5.8  
3.3  
1.5

M10x1.25  
17  
6

Detail of section B

Dimensions of attached nut

67.5

Ball screw greasing port (φ6.5)

L1(T-slot range)

9.5

16.5

M4×0.7 Depth 5 (For securing cable)

9.5

M10×1.25  
φ20

8.5

9 22 (Width across flat part)

14

45

25

45

48

4-M4×0.7 Depth 10 (90°-equal division)

102.5

Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 12 pcs.  
See our robot manuals for additional settings.

2-φ6.6 drill-through

20

10

Installed within the T-slot range of the main unit.  
(Hex. socket head cap bolt (M3×0.5), Length under head 10)  
\* Six bolts are required for one plate.

Option: Vertical installation plate (flange)

Hex. socket head cap bolt (M4×0.7), Length under head 14

73

4-φ6.6 drill-through

60

Dimensions of attached square nut for T-slot (6 pcs.)

Effective stroke	50	100	150	200	250	300
L1	162.5	212.5	262.5	312.5	362.5	412.5
L	209.5	259.5	309.5	359.5	409.5	459.5
Weight (kg) <sup>Note 7</sup>	1.6	1.9	2.1	2.4	2.6	2.9
Maximum speed for each stroke (mm/sec)	Lead 12	500		440		320
	Lead 6	250		220		160
	Lead 2	80		72		53

Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.  
Note 9. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
Note 10. This unit can be installed with the motor facing up (turned 90 degrees from the position in this drawing).

SR04 Space-saving model (motor installed on left) **L**

Approx. 245 (Cable length)

Effective stroke (5)(Note 8)

42.5<sup>+2</sup> (7)(Note 8)

Origin on motor side

Origin on non-motor side (Note 9)

5.8  
3.3  
1.5

M10x1.25  
17  
6

Detail of section B

Dimensions of attached nut

67.5

Ball screw greasing port (φ6.5)

L1(T-slot range)

9.5

16.5

M4×0.7 Depth 5 (For securing cable)

9.5

M10×1.25  
φ20

8.5

9 22 (Width across flat part)

14

45

25

45

48

4-M4×0.7 Depth 10 (90°-equal division)

102.5

Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 12 pcs.  
See our robot manuals for additional settings.

2-φ6.6 drill-through

20

10

Installed within the T-slot range of the main unit.  
(Hex. socket head cap bolt (M3×0.5), Length under head 10)  
\* Six bolts are required for one plate.

Option: Vertical installation plate (flange)

Hex. socket head cap bolt (M4×0.7), Length under head 14

73

4-φ6.6 drill-through

60

Dimensions of attached square nut for T-slot (6 pcs.)

Effective stroke	50	100	150	200	250	300
L1	162.5	212.5	262.5	312.5	362.5	412.5
L	209.5	259.5	309.5	359.5	409.5	459.5
Weight (kg) <sup>Note 7</sup>	1.6	1.9	2.1	2.4	2.6	2.9
Maximum speed for each stroke (mm/sec)	Lead 12	500		440		320
	Lead 6	250		220		160
	Lead 2	80		72		53

Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.  
Note 9. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
Note 10. This unit can be installed with the motor facing up (turned 90 degrees from the position in this drawing).

# SRD04

## Rod type (With support guide)



- CE compliance
- Origin on the non-motor side is selectable: Lead 6, 12

### Ordering method

#### SRD04

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
	12: 12mm 06: 6mm 02: 2mm	S: Straight model J: Space-saving model (motor installed on top)	N: With no brake B: With brake	N: Standard Z: Non-motor side	N: No plate H: With plate	50 to 300 (50mm pitch)	Note 4 1K: 1m 3K: 3m 5K: 5m 10K: 10m

#### S2

Robot positioner	I/O
S2: TS-S2	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board

#### SH

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	B: With battery (Absolute) N: None (Incremental)

#### SD

Robot driver	I/O cable
SD: TS-SD	f: 1m

Note 1. See P.129 for grease gun nozzles.  
 Note 2. When "2mm lead" is selected, the origin position cannot be changed (to non-motor side).  
 Note 3. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.



Note 4. The robot cable is flexible and resists bending.  
 Note 5. See P.498 for DIN rail mounting bracket.  
 Note 6. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications

<b>Motor</b>	42 □ Step motor	
<b>Resolution (Pulse/rotation)</b>	20480	
<b>Repeatability (mm)</b>	+/-0.02	
<b>Deceleration mechanism</b>	Ball screw φ8 (Class C10)	Ball screw φ10 (Class C10)
<b>Ball screw lead (mm)</b>	12	6
<b>Maximum speed (mm/sec)</b>	500	250
<b>Maximum payload (kg)</b>	Horizontal: 25 Vertical: 4	Horizontal: 40 Vertical: 11
<b>Max. pressing force (N)</b>	150	300
<b>Stroke (mm)</b>	50 to 300 (50pitch)	
<b>Lost motion</b>	0.1mm or less	
<b>Rotating backlash (°)</b>	+/-0.05	
<b>Overall length (mm)</b>	Horizontal: Stroke+263	Vertical: Stroke+303
<b>Maximum outside dimension of body cross-section (mm)</b>	W48 × H58	
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10	


Note 1. The maximum speed needs to be changed in accordance with the payload. See the "Speed vs. payload" graph shown on the right. For details, see P. 128. Additionally, when the stroke is long, the maximum speed is decreased due to the critical speed of the ball screw. See the maximum speed table shown at the lower portion of the drawing.

### Speed vs. payload



### Running life

5000 km on models other than shown below. Running life of only the model shown below becomes shorter than 5000 km depending on the payload, so check the running life curve.




Note. See P.129 for running life distance to life time conversion example.

### Controller


Controller	Operation method	Controller	Operation method
TS-S2	I/O point trace / Remote command	TS-SD	Pulse train control

### SRD04 Straight model S



#### Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 12 pcs. See our robot manuals for additional settings.



Effective stroke	50	100	150	200	250	300
	L1	162.5	212.5	262.5	312.5	362.5
L	270.5	320.5	370.5	420.5	470.5	520.5
Weight (kg)	2.0	2.4	2.7	3.0	3.3	3.7
Maximum speed for each stroke (mm/sec)	Lead 12	500		440	320	
	Lead 6	250		220	160	
	Lead 2	80		72	53	


Note 1. It is possible to apply only the axial load. Use the external guide together so that any radial load is not applied to the rod.  
 Note 2. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
 Note 3. When running the cables, secure cables so that any load is not applied to them.  
 Note 4. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
 Note 5. The cable's minimum bend radius is R30.  
 Note 6. Models with a brake will be 0.2kg heavier.  
 Note 7. Distance to mechanical stopper.



## SRD04 Space-saving model (motor installed on top) U

Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 12 pcs.  
See our robot manuals for additional settings.



Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.

Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.  
Note 9. For lead 2mm specifications, the origin on the non-motor side cannot be set.

# SR05 Rod type

- CE compliance
- Origin on the non-motor side is selectable: Lead 6, 12



## Ordering method

### SR05

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
	12: 12mm 06: 6mm 02: 2mm	S: Straight model R: Space-saving model (motor installed on right) L: Space-saving model (motor installed on left)	N: With no brake B: With brake	N: Standard Z: Non-motor side	N: No plate H: With plate V: With flange	50 to 300 (50mm pitch)	1K: 1m 3K: 3m 5K: 5m 10K: 10m

- Note 1. See P.129 for grease gun nozzles.  
 Note 2. When "2mm lead" is selected, the origin position cannot be changed (to non-motor side).  
 Note 3. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 4. The robot cable is flexible and resists bending.  
 Note 5. See P.498 for DIN rail mounting bracket.  
 Note 6. Select this selection when using the gateway function. For details, see P.60.

### S2

Robot positioner	I/O
S2: TS-S2	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board

### SH

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	B: With battery (Absolute) N: None (Incremental)

### SD



Robot driver	I/O cable
SD: TS-SD	1: 1m

## Basic specifications

Motor	56 Step motor
Resolution (Pulse/rotation)	20480
Repeatability (mm)	+/-0.02
Deceleration mechanism	Ball screw $\phi$ 12 (Class C10)
Ball screw lead (mm)	12    6    2
Maximum speed (mm/sec)	300    150    50
Maximum payload (kg)	Horizontal: 50    55    60 Vertical: 10    20    30
Max. pressing force (N)	250    550    900
Stroke (mm)	50 to 300 (50pitch)
Lost motion	0.1mm or less
Rotating backlash (°)	+/-1.0
Overall length (mm)	Horizontal: Stroke+276 Vertical: Stroke+316
Maximum outside dimension of body cross-section (mm)	W56.4 × H71
Cable length (m)	Standard: 1 / Option: 3, 5, 10


- Note 1. The maximum speed needs to be changed in accordance with the payload.  
 See the "Speed vs. payload" graph shown on the right.  
 For details, see P. 128.

## Speed vs. payload




## Running life

5000 km on models other than shown below.  
 Running life of only the model shown below becomes shorter than 5000 km depending on the payload, so check the running life curve.



- Note. See P.129 for running life distance to life time conversion example.


## Motor installation (Space-saving model)



## Controller


Controller	Operation method	Controller	Operation method
TS-S2	I/O point trace / Remote command	TS-SD	Pulse train control

## SR05 Straight model S




### Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 8 pcs.  
 See our robot manuals for additional settings.



### Option: Vertical installation plate (flange)

Hex. socket head cap bolt (M5x0.8), Length under head 14



Dimensions of attached square nut for T-slot (6 pcs.)

Effective stroke	50	100	150	200	250	300
L1	183	233	283	333	383	433
L	280.5	330.5	380.5	430.5	480.5	530.5
Weight (kg)	2.2	2.6	3.0	3.3	3.7	4.1

- Note 1. It is possible to apply only the axial load.  
 Note 2. Use the external guide together so that any radial load is not applied to the rod.  
 Note 3. The orientation of the width across flat part is undefined to the base surface.  
 Note 4. Use the support guide together to maintain the straightness.  
 Note 5. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
 Note 6. When the lead is 2mm, this dimension is 27mm.  
 Note 7. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
 Note 8. The cable's minimum bend radius is R30.  
 Note 9. Take great care as the outer case of the motor projects from the bottom of the main unit.  
 Note 10. Models with a brake will be 0.2kg heavier.  
 Note 11. Distance to mechanical stopper.

SR05 Space-saving model (motor installed on right) **R**

Approx. 245 (Cable length)

146 (with brake)  
106

45.5<sup>+/-2</sup> Effective stroke (5)(Note 8, Note 12)  
(7)(Note 8)

Ball screw greasing port (φ6.5)

Origin on motor side

Origin on non-motor side (Note 9)

M4x0.7 (9.9)

Dimensions of attached square nut for T-slot (6 pcs.)

7.3  
4.3  
1.5  
6

M12x1.25 19 7  
(21.9)

Dimensions of attached nut

Detail of section B

28.5 70  
T-slot for M4 (8 locations)

17 (Width across flat)

30 55  
56.5 71

9.5  
10 24 17  
(Width across flat)

30 55

56.4

4-M5x0.8 Depth 10 (90°-equal division)

10 24 17  
(Width across flat)

(10) 35.5

Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 8 pcs. See our robot manuals for additional settings.

127.5 56.5

Option: Vertical installation plate (flange)

Hex. socket head cap bolt (M5x0.8), Length under head 14

4-φ6.6 drill-through

2-φ6.6 drill-through

Installed within the T-slot range of the main unit. (Hex. socket head cap bolt (M4x0.7), Length under head 12)

\* Four bolts are required for one plate.

20 10 30 68 80

12 (27.5)

Table:

Effective stroke	50	100	150	200	250	300
L1	183	233	283	333	383	433
L	227.5	277.5	327.5	377.5	427.5	477.5
Weight (kg) <sup>Note 7</sup>	2.4	2.8	3.2	3.5	3.9	4.3

Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.  
Note 9. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
Note 10. This unit can be installed with the motor facing up (turned 90 degrees from the position in this drawing).  
Note 11. Take great care as the outer case of the motor and cover belt projects from the bottom of the main unit.  
Note 12. When the lead is 2mm, this dimension is 27mm.

SR05 Space-saving model (motor installed on left) **L**

Approx. 245 (Cable length)

106  
146 (with brake)

45.5<sup>+/-2</sup> Effective stroke (5)(Note 8, Note 12)  
(7)(Note 8)

Ball screw greasing port (φ6.5)

Origin on motor side

Origin on non-motor side (Note 9)

M4x0.7 (9.9)

Dimensions of attached square nut for T-slot (6 pcs.)

7.3  
4.3  
1.5  
6

M12x1.25 19 7  
(21.9)

Dimensions of attached nut

Detail of section B

28.5 70  
T-slot for M4 (8 locations)

17 (Width across flat)

30 55  
56.5 71

9.5  
10 24 17  
(Width across flat)

30 55

56.4

4-M5x0.8 Depth 10 (90°-equal division)

10 24 17  
(Width across flat)

(10) 35.5

Option: Horizontal installation plate (foot)

\* Contents of option: Plate, 2 pcs., Nut, 8 pcs. See our robot manuals for additional settings.

127.5 56.5

Option: Vertical installation plate (flange)

Hex. socket head cap bolt (M5x0.8), Length under head 14

4-φ6.6 drill-through

2-φ6.6 drill-through

Installed within the T-slot range of the main unit. (Hex. socket head cap bolt (M4x0.7), Length under head 12)

\* Four bolts are required for one plate.

20 10 30 68 80

12 (27.5)

Table:

Effective stroke	50	100	150	200	250	300
L1	183	233	283	333	383	433
L	227.5	277.5	327.5	377.5	427.5	477.5
Weight (kg) <sup>Note 7</sup>	2.4	2.8	3.2	3.5	3.9	4.3

Note 1. It is possible to apply only the axial load.  
Use the external guide together so that any radial load is not applied to the rod.  
Note 2. The orientation of the width across flat part is undefined to the base surface.  
Note 3. Use the support guide together to maintain the straightness.  
Note 4. When running the cables, secure cables so that any load is not applied to them.  
Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
Note 6. The cable's minimum bend radius is R30.  
Note 7. Models with a brake will be 0.2kg heavier.  
Note 8. Distance to mechanical stopper.  
Note 9. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
Note 10. This unit can be installed with the motor facing up (turned 90 degrees from the position in this drawing).  
Note 11. Take great care as the outer case of the motor and cover belt projects from the bottom of the main unit.  
Note 12. When the lead is 2mm, this dimension is 27mm.

# SRD05

## Rod type (With support guide)



- CE compliance
- Origin on the non-motor side is selectable: Lead 6, 12

### Ordering method

#### SRD05

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
	12: 12mm 06: 6mm 02: 2mm	S: Straight model J: Space-saving model (motor installed on top)	N: With no brake B: With brake	N: Standard Z: Non-motor side	N: No plate H: With plate	50 to 300 (50mm pitch)	1K: 1m 3K: 3m 5K: 5m 10K: 10m

#### S2

Robot positioner	I/O
S2: TS-S2	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board

#### SH

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	B: With battery (Absolute) N: None (Incremental)

#### SD

Robot driver	I/O cable
SD: TS-SD	f: 1m

Note 1. See P.129 for grease gun nozzles.  
 Note 2. When "2mm lead" is selected, the origin position cannot be changed (to non-motor side).  
 Note 3. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.


Note 4. The robot cable is flexible and resists bending.  
 Note 5. See P.498 for DIN rail mounting bracket.  
 Note 6. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications

<b>Motor</b>	56 □ Step motor
<b>Resolution (Pulse/rotation)</b>	20480
<b>Repeatability (mm)</b>	+/-0.02
<b>Deceleration mechanism</b>	Ball screw φ12 (Class C10)
<b>Ball screw lead (mm)</b>	12    6    2
<b>Maximum speed<sup>Note 1</sup> (mm/sec)</b>	300    150    50
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 50    55    60 <b>Vertical</b> 8.5    18.5    28.5
<b>Max. pressing force (N)</b>	250    550    900
<b>Stroke (mm)</b>	50 to 300 (50pitch)
<b>Lost motion</b>	0.1mm or less
<b>Rotating backlash (°)</b>	+/-0.05
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+276 <b>Vertical</b> Stroke+316
<b>Maximum outside dimension of body cross-section (mm)</b>	W56.4 × H71
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10


Note 1. The maximum speed needs to be changed in accordance with the payload.  
 See the "Speed vs. payload" graph shown on the right.  
 For details, see P. 128.

### Speed vs. payload



### Running life

5000 km on models other than shown below.  
 Running life of only the model shown below becomes shorter than 5000 km depending on the payload, so check the running life curve.




Note. See P.129 for running life distance to life time conversion example.

### Controller



Controller	Operation method	Controller	Operation method
TS-S2	I/O point trace / Remote command	TS-SD	Pulse train control

### SRD05 Straight model S



#### Option: Horizontal installation plate (foot)


\* Contents of option: Plate, 2 pcs., Nut, 8 pcs.  
 See our robot manuals for additional settings.



Note 1. It is possible to apply only the axial load.  
 Note 2. Use the external guide together so that any radial load is not applied to the rod.  
 Note 3. For lead 2mm specifications, the origin on the non-motor side cannot be set.  
 Note 4. When running the cables, secure cables so that any load is not applied to them.  
 Note 5. Remove the M4 hex. socket head cap set bolts and use them to secure the cables. (Effective screw thread depth 5)  
 Note 6. The cable's minimum bend radius is R30.  
 Note 7. Take great care as the outer case of the motor projects from the bottom of the main unit.  
 Note 8. Models with a brake will be 0.2kg heavier.  
 Note 9. Distance to mechanical stopper.

Effective stroke	50	100	150	200	250	300
<b>L1</b>	183	233	283	333	383	433
<b>L</b>	280.5	330.5	380.5	430.5	480.5	530.5
<b>Weight (kg)</b> <sup>Note 8</sup>	3.1	3.6	4.1	4.5	5.0	5.5

**SRD05 Space-saving model (motor installed on top) U**



# STH04

Slide table type

- CE compliance
- Origin on the non-motor side is selectable

## Ordering method

**STH04**

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
	05: 5mm 10: 10mm	S: Straight model R: Space-saving model (motor installed on right) L: Space-saving model (motor installed on left)	N: With no brake B: With brake	N: Standard Z: Non-motor side	N: No plate H: With plate	50: 50mm 100: 100mm	1K: 1m 3K: 3m 5K: 5m 10K: 10m

**S2**

Robot positioner	I/O
S2: TS-S2	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board

**SH**

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	B: With battery (Absolute) N: None (Incremental)

**SD**

Robot driver	I/O cable
SD: TS-SD	1: 1m

Note 1. For the space saving models (R and L), the specifications with brake are applicable to only 100mm strokes.  
 Note 2. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 3. Space-saving models (R and L) with the plate cannot be selected.  
 Note 4. The robot cable is flexible and resists bending.  
 Note 5. See P.498 for DIN rail mounting bracket.  
 Note 6. The robot with the brake cannot use the TS-SD.  
 Note 7. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

Motor	28 □ Step motor	
Resolution (Pulse/rotation)	4096	
Repeatability (mm)	+/-0.05	
Drive method	Straight	Slide screw
	Space-saving	Slide screw + belt
Ball screw lead (mm)	5 10	
Maximum speed (mm/sec)	200 400	
Maximum payload (kg)	Horizontal	6 4
	Vertical	2 1
Max. pressing force (N)	55 30	
Stroke (mm)	50/100	
Maximum outside dimension of body cross-section (mm)	Straight	W45 × H46
	Space-saving	W74.5 × H51
Cable length (m)	Standard: 1 / Option: 3, 5, 10	

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed needs to be changed in accordance with the payload.  
 See the "Speed vs. payload" graph shown on the right. For details, see P. 128.

## Allowable overhang

Horizontal installation (Unit: mm)	Note		
	A	B	C
Lead 10	2kg 1534	611	415
Lead 5	3kg 949	374	255
Lead 10	4kg 656	255	175
Lead 5	2kg 1534	611	415
Lead 10	4kg 656	255	175
Lead 5	6kg 364	137	95

Wall installation (Unit: mm)	Note		
	A	B	C
Lead 10	2kg 435	595	1504
Lead 5	3kg 263	359	920
Lead 10	4kg 177	241	629
Lead 5	2kg 435	595	1504
Lead 10	4kg 177	241	629
Lead 5	6kg 91	123	337


Vertical installation (Unit: mm)	Note	
	A	C
Lead 10	0.5kg 2000	2000
Lead 5	0.75kg 1558	1558
Lead 10	1kg 1165	1164
Lead 5	1kg 1165	1164
Lead 10	1.5kg 771	771
Lead 5	2kg 574	574

Note. Overhang at travelling service life of 3000km.  
 (Service life is calculated for 75mm stroke models.)


## Static loading moment

Stroke	Note		
	MY	MP	MR
50mm	26	26	48
100mm	43	43	

## Motor installation (Space-saving model)



## Speed vs. payload



## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control

Note. The robot with the brake cannot use the TS-SD.

## STH04 Straight model S

Effective stroke	50	100
B	40	44
C	6	8
D	116.5	191.5
E	65	85
G	39.5	88.5
L	122	191
Weight (kg)	1.25	1.7

**Option: Installation plate**  
 Contents of option: Plate, 4 pcs.  
 \* For additional settings, contact your distributor.

Note 1. Return-to-origin position.  
 Note 2. Table movable range during return-to-origin operation. The values in [ ] show those when the return-to-origin direction is changed.  
 Note 3. The minimum bending radius of the motor cable is R30.  
 Note 4. When installing the mechanical main unit using the back facing holes, use the hex socket head cap M5 bolts.  
 Note 5. The installation hole positions of the main unit with the specifications with the brake are common to those shown above.  
 Note 6. Models with a brake will be 0.11kg heavier.

STH04 Space-saving model (motor installed on right) **R**

Approx. 160 (Cable length without brake)  
Approx. 120 (Cable length with brake)

(C/2-1)xB 19

5<sup>+0.03</sup>/<sub>-0.01</sub> Depth 5

6

B

24

C-M5x0.8 Depth 7.5

φ5<sup>+0.03</sup>/<sub>-0.01</sub> Depth 5

2.5 45 3-M5x0.8 Depth 8

29 17.2 35 0.3

13 5.5

72.5 (2)

1+/-0.5 (Note 2)

13

Origin on motor side (Note 1)

Effective stroke

1+/-0.5 (Note 2)

Origin on non-motor side (Note 1)

Effective stroke	50	100
B	40	44
C	6	8
D	45	44
E	2	4
F	45	88
G	116.5	191.5
L	106	181
Weight (kg) <sup>Note 7</sup>	1.15	1.6

φ10.5 (Note 4)

φ9.5

φ5.3 (M6)

9 35.5

**Cross-sectional drawing A-A**  
Detailed drawing of installation hole

E-M6x1.0 Depth 12  
See the cross-sectional drawing of A-A.

(E-1)xD 18

D

A

(25)

40

4H9<sup>+0.030</sup>/<sub>0</sub> Depth 4

5

F

φ4H9<sup>+0.030</sup>/<sub>0</sub> Depth 4

4

Note 1. Return-to-origin position.  
Note 2. Table movable range during return-to-origin operation. The values in [ ] show those when the return-to-origin direction is changed.  
Note 3. The minimum bending radius of the motor cable is R30.  
Note 4. When installing the mechanical main unit using the back facing holes, push the slider toward the origin position on the motor side and insert the hex socket head cap (M5) bolt.  
Note 5. The dimensions of the specifications with the brake are common to those shown above.  
Note 6. The specifications with the brake are applicable to only 100 strokes.  
Note 7. Models with a brake will be 0.11kg heavier.

STH04 Space-saving model (motor installed on left) **L**

Approx. 160 (Cable length without brake)  
Approx. 120 (Cable length with brake)

(C/2-1)xB 19

5<sup>+0.03</sup>/<sub>-0.01</sub> Depth 5

6

B

24

C-M5x0.8 Depth 7.5

φ5<sup>+0.03</sup>/<sub>-0.01</sub> Depth 5

2.5 45 3-M5x0.8 Depth 8

29 17.2 35 0.3

13 5.5

72.5 (2)

1+/-0.5 (Note 2)

13

Origin on motor side (Note 1)

Effective stroke

1+/-0.5 (Note 2)

Origin on non-motor side (Note 1)

Effective stroke	50	100
B	40	44
C	6	8
D	45	44
E	2	4
F	45	88
G	116.5	191.5
L	106	181
Weight (kg) <sup>Note 7</sup>	1.15	1.6

φ10.5 (Note 4)

φ9.5

φ5.3 (M6)

9 35.5

**Cross-sectional drawing A-A**  
Detailed drawing of installation hole

E-M6x1.0 Depth 12  
See the cross-sectional drawing of A-A.

(E-1)xD 18

D

A

(25)

40

4H9<sup>+0.030</sup>/<sub>0</sub> Depth 4

5

F

φ4H9<sup>+0.030</sup>/<sub>0</sub> Depth 4

4

Note 1. Return-to-origin position.  
Note 2. Table movable range during return-to-origin operation. The values in [ ] show those when the return-to-origin direction is changed.  
Note 3. The minimum bending radius of the motor cable is R30.  
Note 4. When installing the mechanical main unit using the back facing holes, push the slider toward the origin position on the motor side and insert the hex socket head cap (M5) bolt.  
Note 5. The dimensions of the specifications with the brake are common to those shown above.  
Note 6. The specifications with the brake are applicable to only 100 strokes.  
Note 7. Models with a brake will be 0.11kg heavier.

# STH06

Slide table type



- CE compliance
- Origin on the non-motor side is selectable

## Ordering method

### STH06

Model	Lead	Model	Brake	Origin position	Bracket plate	Stroke	Cable length
	08: 8mm 16: 16mm	S: Straight model R: Space-saving model (motor installed on right) L: Space-saving model (motor installed on left)	N: With no brake B: With brake	N: Standard Z: Non-motor side	N: No plate H: With plate	50: 50mm 100: 100mm 150: 150mm	1K: 1m 3K: 3m 5K: 5m 10K: 10m

### S2

Robot positioner	I/O
S2: TS-S2	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board

### SH

Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	B: With battery (Absolute) N: None (Incremental)

### SD

Robot driver	I/O cable
SD: TS-SD	1: 1m

- Note 1. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.
- Note 2. Space-saving models (R and L) with the plate cannot be selected.
- Note 3. The robot cable is flexible and resists bending.
- Note 4. See P.498 for DIN rail mounting bracket.
- Note 5. The robot with the brake cannot use the TS-SD.
- Note 6. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

Motor	42 □ Step motor	
Resolution (Pulse/rotation)	20480	
Repeatability (mm)	+/- 0.05	
Drive method	Straight	Slide screw
	Space-saving	Slide screw + belt
Ball screw lead (mm)	8 16	
Maximum speed (mm/sec)	150 400	
Maximum payload (kg)	Horizontal	9 6
	Vertical	4 2
Max. pressing force (N)	180 100	
Stroke (mm)	50/100/150	
Maximum outside dimension of body cross-section (mm)	Straight	W61 × H65
	Space-saving	W108 × H70
Cable length (m)	Standard: 1 / Option: 3, 5, 10	

- Note 1. Positioning repeatability in one direction.
- Note 2. The maximum speed needs to be changed in accordance with the payload.
- See the "Speed vs. payload" graph shown on the right. For details, see P. 128.

## Allowable overhang


Lead	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C	A	B	C
Lead 16	2kg 3000	2123	1436	2kg 1500	2091	3000	1kg 3000	3000	3000
Lead 8	4kg 2493	1001	680	4kg 710	975	2443	1.5kg 2458	2457	2457
	6kg 1571	627	428	6kg 440	603	1524	2kg 1837	1837	1837
Lead 8	3kg 3000	1375	932	3kg 979	1347	3000	2kg 1837	1837	1837
	6kg 1571	627	428	6kg 440	603	1524	3kg 1217	1216	1216
Lead 8	9kg 956	378	260	9kg 260	355	912	4kg 907	906	906

- Note. Overhang at travelling service life of 3000km. (Service life is calculated for 100mm stroke models.)


## Static loading moment

Stroke	MY	MP	MR
50mm	77	77	146
100mm	112	112	177
150mm	155	155	152

## Motor installation (Space-saving model)



## Speed vs. payload




## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control


- Note. The robot with the brake cannot use the TS-SD.

## STH06 Straight model S






STH06 Space-saving model (motor installed on right) **R**



STH06 Space-saving model (motor installed on left) **L**



# RF02-N

## Rotary type / Limit rotation specification

- CE compliance
- Rotation range : 310°

### Ordering method

<b>RF02</b>	<b>N</b>			<b>L</b>			<b>S2</b>	
<b>Model</b>	<b>Return-to-origin method</b> N: Stroke end (Limit rotation)	<b>Bearing</b> N: Standard H: High rigidity	<b>Torque</b> N: Standard torque H: High torque	<b>Cable entry location</b> L: From the left	<b>Rotation direction</b> N: CCW Z: CW	<b>Cable length</b> <small>Note 1</small> 1K: 1m 3K: 3m 5K: 5m 10K: 10m	<b>Robot positioner</b> S2: TS-S2 <small>Note 2</small>	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <small>Note 3</small>
							<b>SH</b>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>SD</b>	<b>1</b>
							<b>Robot driver</b> SD: TS-SD	<b>I/O cable</b> t: 1m


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications


<b>Motor</b>	20 □ Step motor	
<b>Resolution (Pulse/rotation)</b>	4096	
<b>Repeatability</b> <small>Note 1</small> (°)	±0.05	
<b>Drive method</b>	Special warm gear + belt	
<b>Torque type</b>	Standard	High torque
<b>Maximum speed</b> <small>Note 2</small> (°/sec)	420	280
<b>Rotating torque (N·m)</b>	0.22	0.32
<b>Max. pushing torque (N·m)</b>	0.11	0.16
<b>Backlash (°)</b>	±0.5	
<b>Max. moment of inertia</b> <small>Note 3</small> (kg·m <sup>2</sup> )	0.0018	0.004
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10	
<b>Rotation range (°)</b>	310	

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may vary depending on the moment of inertia. Check the maximum speed while referring to the "Moment of inertia vs. Acceleration/deceleration" graph and the "Effective torque vs. speed" graph (reference).  
 Note 3. For moment of inertia and effective torque details, see P.604.

### Moment of inertia Acceleration/deceleration



### Effective torque vs. speed



### Allowable load

Allowable radial load (N)		Allowable thrust load (N)				Allowable moment (N·m)	
		(a)		(b)			
Standard model	High rigidity model	Standard model	High rigidity model	Standard model	High rigidity model	Standard model	High rigidity model
78	86	74	78	107	2.4	2.9	

Note. When purchasing the product, set the controller acceleration while carefully checking the "Moment of inertia vs. Acceleration/Deceleration" and "Effective torque vs. Speed" graphs.  
 For details, please refer to the TRANSERVO Series User's Manual.

### Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	
TS-SD	Pulse train control

### RF02-NN Limit rotation specification – Standard model

Stroke end  
Origin position in CW rotation direction [Origin]<sup>3</sup>

Origin mark

Origin<sup>2</sup>  
Origin position in CCW rotation direction [Stroke end]

310°

CCW direction

CW direction

\*1 Table movable range by return-to-origin operation.  
Be careful not to interfere with the workpiece or equipment around the table.  
 \*2 Return-to-origin position  
 \*3 Values and characters in [ ] show those when the return-to-origin direction is changed.

Manual operation screw (both sides)

Origin mark

31  
(24)

16

65.8

76

(40)

(15)

2

φ18H8 (+0.027/0)

φ8 (Through-hole)

φ15H8 (+0.027/0)

2

(tolerance range)

7

(tolerance range)

Cross-sectional drawing A-A

45°

51

A1

2

21

42

15

2

318 (+0.014/0) Depth 3.8

318 (+0.014) Depth 4

30°

2-φ5.2 drill-through φ9 deep spot facing, Depth 5.5 P.C.D.32

6-M4x0.7 Depth 6 (60° equally divided.)

52

42

φ43h8 (+0.039/0)

φ42h8 (+0.039/0)

6

3.5

32

10

(2.1)

85

(2.1)

Approx. 170

(Motor cable exit direction: Exit from left side)

51

3H8 (+0.014/0) Depth 4

2

14


52

2-M6x1.0 Depth 12





<b>Weight (kg)</b>	0.49
--------------------	------

Note 1. This drawing is output under the conditions below.  
 Bearing ..... Standard  
 Torque ..... Standard/High torque  
 Note 2. The minimum bending radius of the motor cable is R30.  
 Note 3. The motor cable exit direction is only the left side.

RF02-NH Limit rotation specification – High rigidity model



- \*1 Table movable range by return-to-origin operation.  
Be careful not to interfere with the workpiece or equipment around the table.
- \*2 Return-to-origin position
- \*3 Values and characters in [ ] show those when the return-to-origin direction is changed.



<b>Weight (kg)</b>	0.52
--------------------	------

- Note 1. This drawing is output under the conditions below.  
Bearing ..... High rigidity  
Torque ..... Standard/High torque
- Note 2. The minimum bending radius of the motor cable is R30.
- Note 3. The motor cable exit direction is only the left side.

# RF02-S

## Rotary type / Sensor specification



- CE compliance
- Limitless rotation

### Ordering method

**RF02** - **S** - **L** - **S2** - **SH**

<b>Model</b>	<b>Return-to-origin method</b> S: Sensor (Limitless rotation)	<b>Bearing</b> N: Standard H: High rigidity	<b>Torque</b> N: Standard torque H: High torque	<b>Cable entry location</b> L: From the left	<b>Rotation direction</b> N: CCW Z: CW	<b>Cable length</b> <sup>Note 1</sup> 1K: 1m 3K: 3m 5K: 5m 10K: 10m
--------------	--	---	---	---	--	---

<b>Robot positioner</b> S2: TS-S2 <sup>Note 2</sup>	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>
--	---

<b>Robot positioner</b> SH: TS-SH	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
--------------------------------------	---	---


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications


<b>Motor</b>	20 □ Step motor
<b>Resolution (Pulse/rotation)</b>	4096
<b>Repeatability</b> <sup>Note 1</sup> (°)	+/-0.05
<b>Drive method</b>	Special warm gear + belt
<b>Torque type</b>	Standard High torque
<b>Maximum speed</b> <sup>Note 2</sup> (°/sec)	420 280
<b>Rotating torque (N•m)</b>	0.22 0.32
<b>Max. pushing torque (N•m)</b>	0.11 0.16
<b>Backlash (°)</b>	+/-0.5
<b>Max. moment of inertia</b> <sup>Note 3</sup> (kg•m <sup>2</sup> )	0.0018 0.004
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10
<b>Rotation range (°)</b>	360

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may vary depending on the moment of inertia. Check the maximum speed while referring to the "Moment of inertia vs. Acceleration/deceleration" graph and the "Effective torque vs. speed" graph (reference).  
 Note 3. For moment of inertia and effective torque details, see P.604.

### Moment of inertia Acceleration/deceleration



### Effective torque vs. speed



### Allowable load



<b>Allowable radial load (N)</b>	<b>Allowable thrust load (N)</b>		<b>Allowable moment (N•m)</b>
Standard model	(a) Standard model	(b) Standard model	Standard model
High rigidity model	High rigidity model	High rigidity model	High rigidity model
78	74	78	2.4
86	107	2.9	

Note. When purchasing the product, set the controller acceleration while carefully checking the "Moment of inertia vs. Acceleration/Deceleration" and "Effective torque vs. Speed" graphs.  
 For details, please refer to the TRANSERVO Series User's Manual.


### Controller

<b>Controller</b>	<b>Operation method</b>
TS-S2S	I/O point trace / Remote command
TS-SHS	


### RF02-SN Sensor specification – Standard model





Note 1. This drawing is output under the conditions below.  
 Bearing ..... Standard  
 Torque ..... Standard/High torque  
 Note 2. The minimum bending radii of the motor cable and sensor cable are R30.  
 Note 3. The motor cable exit direction is only the left side.



RF02-SH Sensor specification – High rigidity model






\*1 Table movable range by return-to-origin operation. Be careful not to interfere with the workpiece or equipment around the table.  
\*2 The return-to-origin position may differ from that shown in this drawing. To align with the position shown in this drawing, refer to the TS Series User's Manual and change the origin coordinates.



Weight (kg)	0.55
-------------	------

Note 1. This drawing is output under the conditions below.  
Bearing..... High rigidity  
Torque..... Standard/High torque  
Note 2. The minimum bending radii of the motor cable and sensor cable are R30.  
Note 3. The motor cable exit direction is only the left side.



# RF03-N

## Rotary type / Limit rotation specification

- CE compliance
- Rotation range : 320°

### Ordering method

**RF03** - **N** - [ ] - [ ] - [ ] - [ ] - [ ] - **S2**

<b>Model</b>	<b>Return-to-origin method</b> N: Stroke end (Limit rotation)	<b>Bearing</b> N: Standard H: High rigidity	<b>Torque</b> N: Standard torque H: High torque	<b>Cable entry location</b> R: From the right L: From the left	<b>Rotation direction</b> N: CCW Z: CW	<b>Cable length</b> <sup>Note 1</sup> 1K: 1m 3K: 3m 5K: 5m 10K: 10m	<b>Robot positioner</b> S2: TS-S2 <sup>Note 2</sup>	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>
							<b>SH</b>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>SD</b>	<b>1</b>
							<b>Robot driver</b> SD: TS-SD	<b>I/O cable</b> t: 1m


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications


<b>Motor</b>	28 □ Step motor
<b>Resolution (Pulse/rotation)</b>	4096
<b>Repeatability</b> <sup>Note 1</sup> (°)	+/-0.05
<b>Drive method</b>	Special warm gear + belt
<b>Torque type</b>	Standard High torque
<b>Maximum speed</b> <sup>Note 2</sup> (°/sec)	420 280
<b>Rotating torque (N·m)</b>	0.8 1.2
<b>Max. pushing torque (N·m)</b>	0.4 0.6
<b>Backlash (°)</b>	+/-0.5
<b>Max. moment of inertia</b> <sup>Note 3</sup> (kg·m <sup>2</sup> )	0.012 0.027
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10
<b>Rotation range (°)</b>	320

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may vary depending on the moment of inertia. Check the maximum speed while referring to the "Moment of inertia vs. Acceleration/deceleration" graph and the "Effective torque vs. speed" graph (reference).  
 Note 3. For moment of inertia and effective torque details, see P.604.

### Moment of inertia Acceleration/deceleration



### Effective torque vs. speed



### Allowable load

Standard model	High rigidity model	Allowable radial load (N)				Standard model	High rigidity model	Standard model	High rigidity model	Standard model	High rigidity model
		(a)	(b)	(a)	(b)						
196	233	197	363	398	5.3	6.4					

Note. When purchasing the product, set the controller acceleration while carefully checking the "Moment of inertia vs. Acceleration/Deceleration" and "Effective torque vs. Speed" graphs. For details, please refer to the TRANSERVO Series User's Manual.

### Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Pulse train control
TS-SD	Pulse train control

### RF03-NN Limit rotation specification – Standard model






\*1 Table movable range by return-to-origin operation. Be careful not to interfere with the workpiece or equipment around the table.  
 \*2 Return-to-origin position  
 \*3 Values and characters in [ ] show those when the return-to-origin direction is changed.

<b>Weight (kg)</b>	1.1
--------------------	-----

Note 1. This drawing is output under the conditions below.  
 Bearing..... Standard  
 Torque..... Standard/High torque  
 Note 2. The minimum bending radius of the motor cable is R30.

**Cross-sectional drawing A-A**

RF03-NH Limit rotation specification – High rigidity model



# RF03-S

## Rotary type / Sensor specification

- CE compliance
- Limitless rotation

### Ordering method

<b>RF03</b>	<b>S</b>						<b>S2</b>	
<b>Model</b>	<b>Return-to-origin method</b> S: Sensor (Limitless rotation)	<b>Bearing</b> N: Standard H: High rigidity	<b>Torque</b> N: Standard torque H: High torque	<b>Cable entry location</b> R: From the right L: From the left	<b>Rotation direction</b> N: CCW Z: CW	<b>Cable length</b> <sup>Note 1</sup> 1K: 1m 3K: 3m 5K: 5m 10K: 10m	<b>Robot positioner</b> S2: TS-S2 <sup>Note 2</sup>	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>
							<b>SH</b>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>Robot positioner</b> SH: TS-SH	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications


<b>Motor</b>	28 □ Step motor	
<b>Resolution (Pulse/rotation)</b>	4096	
<b>Repeatability</b> <sup>Note 1</sup> (°)	±0.05	
<b>Drive method</b>	Special warm gear + belt	
<b>Torque type</b>	Standard	High torque
<b>Maximum speed</b> <sup>Note 2</sup> (°/sec)	420	280
<b>Rotating torque (N·m)</b>	0.8	1.2
<b>Max. pushing torque (N·m)</b>	0.4	0.6
<b>Backlash (°)</b>	±0.5	
<b>Max. moment of inertia</b> <sup>Note 3</sup> (kg·m <sup>2</sup> )	0.012	0.027
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10	
<b>Rotation range (°)</b>	360	

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may vary depending on the moment of inertia. Check the maximum speed while referring to the "Moment of inertia vs. Acceleration/deceleration" graph and the "Effective torque vs. speed" graph (reference).  
 Note 3. For moment of inertia and effective torque details, see P.604.

### Moment of inertia Acceleration/deceleration



### Effective torque vs. speed



### Allowable load

Allowable radial load (N)		Allowable thrust load (N)				Allowable moment (N·m)			
Standard model	High rigidity model	Standard model (a)	High rigidity model (a)	Standard model (b)	High rigidity model (b)	Standard model	High rigidity model		
196	233	197	363	363	398	5.3	6.4		

Note. When purchasing the product, set the controller acceleration while carefully checking the "Moment of inertia vs. Acceleration/Deceleration" and "Effective torque vs. Speed" graphs.  
 For details, please refer to the TRANSERVO Series User's Manual.

### Controller

Controller	Operation method
TS-S2S	I/O point trace /
TS-SHS	Remote command

### RF03-SN Sensor specification – Standard model

\*1 Table movable range by return-to-origin position. Be careful not to interfere with the workpiece or equipment around the table.  
 \*2 The return-to-origin position may differ from that shown in this drawing. To align with the position shown in this drawing, refer to the TS Series User's Manual and change the origin coordinates.

2-φ6.8 drill-through φ11 deep spot facing, Depth 6.5  
 P.C.D.48  
 6-M5x0.8 Depth 8 (60° equally divided.)  
 φ64h8(±0.046)  
 φ63h8(±0.046)  
 4H8(±0.016) Depth 5  
 2-M8x1.25 Depth 16  
 φ32H8(±0.039)  
 φ17 (Through-hole)  
 φ22H8(±0.033)  
 2 (Tolerance range)  
 8 (Tolerance range)



<b>Weight (kg)</b>	1.2
--------------------	-----

**Cross-sectional drawing A-A**

Note 1. This drawing is output under the conditions below.  
 Bearing ..... Standard  
 Torque ..... Standard/High torque  
 Note 2. The minimum bending radii of the motor cable and sensor cable are R30.




RF03-SH Sensor specification – High rigidity model



Weight (kg)	1.3
-------------	-----

Note 1. This drawing is output under the conditions below.  
Bearing ..... High rigidity  
Torque ..... Standard/High torque  
Note 2. The minimum bending radii of the motor cable and sensor cable are R30.



# RF04-N

## Rotary type / Limit rotation specification



- CE compliance
- Rotation range : 320°

### Ordering method

<b>RF04</b>	<b>N</b>					
<b>Model</b>	<b>Return-to-origin method</b> N: Stroke end (Limit rotation)	<b>Bearing</b> N: Standard H: High rigidity	<b>Torque</b> N: Standard torque H: High torque	<b>Cable entry location</b> R: From the right L: From the left	<b>Rotation direction</b> N: CCW Z: CW	<b>Cable length</b> <sup>Note 1</sup> 1K: 1m 3K: 3m 5K: 5m 10K: 10m

<b>S2</b>	<b>I/O</b>
<b>Robot positioner</b> S2: TS-S2 <sup>Note 2</sup>	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>
<b>SH</b>	<b>Battery</b>
<b>Robot positioner</b> SH: TS-SH	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
<b>SD</b>	<b>1</b>
<b>Robot driver</b> SD: TS-SD	<b>I/O cable</b> t: 1m


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications


<b>Motor</b>	42 □ Step motor	
<b>Resolution (Pulse/rotation)</b>	20480	
<b>Repeatability</b> <sup>Note 1</sup> (°)	+/-0.05	
<b>Drive method</b>	Special warm gear + belt	
<b>Torque type</b>	Standard	High torque
<b>Maximum speed</b> <sup>Note 2</sup> (°/sec)	420	280
<b>Rotating torque (N·m)</b>	6.6	10
<b>Max. pushing torque (N·m)</b>	3.3	5
<b>Backlash (°)</b>	+/-0.5	
<b>Max. moment of inertia</b> <sup>Note 3</sup> (kg·m <sup>2</sup> )	0.04	0.1
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10	
<b>Rotation range (°)</b>	320	

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may vary depending on the moment of inertia. Check the maximum speed while referring to the "Moment of inertia vs. Acceleration/deceleration" graph and the "Effective torque vs. speed" graph (reference).  
 Note 3. For moment of inertia and effective torque details, see P.604.

### Moment of inertia Acceleration/deceleration



### Effective torque vs. speed



### Allowable load



Allowable radial load (N)		Allowable thrust load (N)				Allowable moment (N·m)	
Standard model	High rigidity model	(a)		(b)		Standard model	High rigidity model
314	378	Standard model	High rigidity model	Standard model	High rigidity model	9.7	12.0
		296	398	517			

Note. When purchasing the product, set the controller acceleration while carefully checking the "Moment of inertia vs. Acceleration/Deceleration" and "Effective torque vs. Speed" graphs. For details, please refer to the TRANSERVO Series User's Manual.

### Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Pulse train control
TS-SD	


### RF04-NN Limit rotation specification – Standard model




**Weight (kg)** | 2.2

Note 1. This drawing is output under the conditions below.  
 Bearing ..... Standard  
 Torque ..... Standard/High torque  
 Note 2. The minimum bending radius of the motor cable is R30.

RF04-NH Limit rotation specification – High rigidity model



- \*1 Table movable range by return-to-origin operation. Be careful not to interfere with the workpiece or equipment around the table.
- \*2 Return-to-origin position
- \*3 Values and characters in [ ] show those when the return-to-origin direction is changed.



<b>Weight (kg)</b>	2.4
--------------------	-----

Note 1. This drawing is output under the conditions below.  
 Bearing..... High rigidity  
 Torque..... Standard/High torque  
 Note 2. The minimum bending radius of the motor cable is R30.

# RF04-S

## Rotary type / Sensor specification

- CE compliance
- Limitless rotation

### Ordering method

**RF04-S**

<b>Model</b>	<b>Return-to-origin method</b> S: Sensor (Limitless rotation)	<b>Bearing</b> N: Standard H: High rigidity	<b>Torque</b> N: Standard torque H: High torque	<b>Cable entry location</b> R: From the right L: From the left	<b>Rotation direction</b> N: CCW Z: CW	<b>Cable length</b> <sup>Note 1</sup> 1K: 1m 3K: 3m 5K: 5m 10K: 10m
--------------	--	---	---	--	--	---

<b>S2</b>	<b>Robot positioner</b> S2: TS-S2 <sup>Note 2</sup>	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>
-----------	--	---

<b>SH</b>	<b>Robot positioner</b> SH: TS-SH	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
-----------	--------------------------------------	---	---


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

### Basic specifications


<b>Motor</b>	42 □ Step motor
<b>Resolution (Pulse/rotation)</b>	20480
<b>Repeatability</b> <sup>Note 1</sup> (°)	+/-0.05
<b>Drive method</b>	Special worm gear + belt
<b>Torque type</b>	Standard High torque
<b>Maximum speed</b> <sup>Note 2</sup> (°/sec)	420 280
<b>Rotating torque (N•m)</b>	6.6 10
<b>Max. pushing torque (N•m)</b>	3.3 5
<b>Backlash (°)</b>	+/-0.5
<b>Max. moment of inertia</b> <sup>Note 3</sup> (kg•m <sup>2</sup> )	0.04 0.1
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10
<b>Rotation range (°)</b>	360

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may vary depending on the moment of inertia. Check the maximum speed while referring to the "Moment of inertia vs. Acceleration/ deceleration" graph and the "Effective torque vs. speed" graph (reference).  
 Note 3. For moment of inertia and effective torque details, see P.604.

### Moment of inertia Acceleration/deceleration



### Effective torque vs. speed



### Allowable load



	(a)	(b)	
<b>Allowable radial load (N)</b>	<b>Allowable thrust load (N)</b>		<b>Allowable moment (N•m)</b>
Standard model	Standard model	Standard model	Standard model
High rigidity model	High rigidity model	High rigidity model	High rigidity model
314	296	398	9.7
378	517	12.0	

### Controller


Controller	Operation method
TS-S2S	I/O point trace / Remote command
TS-SHS	Remote command

Note. When purchasing the product, set the controller acceleration while carefully checking the "Moment of inertia vs. Acceleration/Deceleration" and "Effective torque vs. Speed" graphs.  
 For details, please refer to the TRANSERVO Series User's Manual.


### RF04-SN Sensor specification – Standard model





Note 1. This drawing is output under the conditions below.  
 Bearing ..... Standard  
 Torque ..... Standard/High torque  
 Note 2. The minimum bending radii of the motor cable and sensor cable are R30.



RF04-SH Sensor specification – High rigidity model




\*1 Table movable range by return-to-origin operation. Be careful not to interfere with the workpiece or equipment around the table.  
\*2 The return-to-origin position may differ from that shown in this drawing. To align with the position shown in this drawing, refer to the TS Series User's Manual and change the origin coordinates.



Weight (kg) 2.5

Note 1. This drawing is output under the conditions below.  
Bearing..... High rigidity  
Torque..... Standard/High torque  
Note 2. The minimum bending radii of the motor cable and sensor cable are R30.



# BD04

Belt type

CE compliance

## Ordering method

<b>BD04</b>	<b>48</b>	<b>N</b>	<b>N</b>			<b>S2</b>	
<b>Model</b>	<b>Lead</b> 48: 48mm	<b>Brake</b> N: With no brake	<b>Origin position</b> N: Standard	<b>Stroke</b> 300: 300mm 500: 500mm 600: 600mm 700: 700mm 800: 800mm 900: 900mm 1000: 1000mm	<b>Cable length</b> <small>Note 1</small> 1K: 1m 3K: 3m 5K: 5m 10K: 10m	<b>Robot positioner</b> S2: TS-S2 <small>Note 2</small>	<b>I/O</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <small>Note 3</small>
						<b>SH</b>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
						<b>SD</b>	<b>1</b>
						<b>Robot driver</b> SD: TS-SD	<b>I/O cable</b> t: 1m


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>Motor</b>	28 □ Step motor
<b>Resolution (Pulse/rotation)</b>	4096
<b>Repeatability</b> <small>Note 1</small> (mm)	+/-0.1
<b>Drive method</b>	Belt
<b>Equivalent lead (mm)</b>	48
<b>Maximum speed</b> <small>Note 2</small> (mm/sec)	1100
<b>Maximum payload (kg)</b>	1
<b>Stroke (mm)</b>	300/500/600/700/800/900/1000
<b>Overall length (mm) (Horizontal installation)</b>	Stroke + 195.5
<b>Maximum outside dimension of body cross-section (mm)</b>	W40 × H101.9
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed needs to be changed in accordance with the payload.  
 See the "Speed vs. payload" graph shown on the right.


## Allowable overhang Note



Horizontal installation (Unit: mm)				Wall installation (Unit: mm)			
	A	B	C		A	B	C
0.5kg	8036	1950	1504	0.5kg	1614	1942	8013
1kg	3933	968	747	1kg	798	961	3969


Note. Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000km (This does not warrant the service life of the product.). (Service life is calculated for 600mm stroke models.)

## Static loading moment



(Unit: N·m)		
MY	MP	MR
10	10	20

## Speed vs. payload




Quick reference		
Payload (kg)	Speed (mm/sec)	%
1	900	90
0.5	1000	95
0	1100	100

## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control

## BD04



Effective stroke	300	500	600	700	800	900	1000
<b>L</b>	495.5	695.5	795.5	895.5	995.5	1095.5	1195.5
<b>M</b>	2	4	4	5	6	6	7
<b>N</b>	6	10	10	12	14	14	16
<b>Weight (kg)</b>	1.19	1.45	1.58	1.71	1.84	1.97	2.1

Note 1. Position from both ends to the mechanical stopper. (Movable range during return-to-origin)  
 Note 2. When installing using the main unit installation reference surface, make the mating or positioning height 2mm or more higher than the reference surface since the R-chamfering is provided on the main unit. (Recommended height, 5mm)  
 Note 3. The minimum bending radius of the motor cable is R30.

# BD05

Belt type

CE compliance

## Ordering method

<b>BD05</b>	<b>48</b>	<b>N</b>	<b>N</b>			<b>S2</b>	
<b>Model</b>	<b>Lead</b>	<b>Brake</b>	<b>Origin position</b>	<b>Stroke</b>	<b>Cable length</b> <small>Note 1</small>	<b>Robot positioner</b>	<b>I/O</b>
	48: 48mm	N: With no brake	N: Standard	300: 300mm 500: 500mm 600: 600mm 700: 700mm 800: 800mm 900: 900mm 1000: 1000mm 1200: 1200mm 1500: 1500mm 1800: 1800mm 2000: 2000mm	1K: 1m 3K: 3m 5K: 5m 10K: 10m	S2: TS-S2 <small>Note 2</small>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <small>Note 3</small>
						<b>SH</b>	
						<b>Robot positioner</b>	<b>I/O</b>
						SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <small>Note 3</small>
							<b>Battery</b>
							B: With battery (Absolute) N: None (Incremental)
						<b>SD</b>	<b>1</b>
						<b>Robot driver</b>	<b>I/O cable</b>
						SD: TS-SD	t: 1m


Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>Motor</b>	42 □ Step motor
<b>Resolution (Pulse/rotation)</b>	20480
<b>Repeatability</b> <small>Note 1</small> (mm)	+/-0.1
<b>Drive method</b>	Belt
<b>Equivalent lead (mm)</b>	48
<b>Maximum speed</b> <small>Note 2</small> (mm/sec)	1400
<b>Maximum payload (kg)</b>	5
<b>Stroke (mm)</b>	300/500/600/700/800/900/ 1000/1200/1500/1800/2000
<b>Overall length (mm) (Horizontal installation)</b>	Stroke + 241.8
<b>Maximum outside dimension of body cross-section (mm)</b>	W58 × H123
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed needs to be changed in accordance with the payload.  
 See the "Speed vs. payload" graph shown on the right.


## Allowable overhang Note



Horizontal installation (Unit: mm)				Wall installation (Unit: mm)			
	A	B	C		A	B	C
1kg	9445	2274	1681	1kg	1784	2312	9545
3kg	2982	702	553	3kg	573	743	3082
5kg	1689	385	325	5kg	331	429	1789


Note. Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000km (This does not warrant the service life of the product.). (Service life is calculated for 600mm stroke models.)

## Static loading moment



(Unit: N·m)		
MY	MP	MR
27	27	52

## Speed vs. payload




Quick reference	Payload (kg)	Speed (mm/sec)	%
	5	550	39
	3	700	50
	1	1000	71
	0	1400	100

## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control

## BD05



Note 1. Position from both ends to the mechanical stopper. (Movable range during return-to-origin)  
 Note 2. When installing using the main unit installation reference surface, make the mating or positioning height 2mm or more higher than the reference surface since the R-chamfering is provided on the main unit. (Recommended height, 5mm)  
 Note 3. The minimum bending radius of the motor cable is R30.

# BD07

Belt type



CE compliance

## Ordering method

<b>BD07</b>	<b>48</b>	<b>N</b>	<b>N</b>			<b>S2</b>	
<b>Model</b>	<b>Lead</b> 48: 48mm	<b>Brake</b> N: With no brake	<b>Origin position</b> N: Standard	<b>Stroke</b>	<b>Cable length</b> <sup>Note 1</sup>	<b>Robot positioner</b> S2: TS-S2 <sup>Note 2</sup>	<b>I/O</b>
				300: 300mm 500: 500mm 600: 600mm 700: 700mm 800: 800mm 900: 900mm 1000: 1000mm 1200: 1200mm 1500: 1500mm 1800: 1800mm 2000: 2000mm	1K: 1m 3K: 3m 5K: 5m 10K: 10m		NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>
						<b>SH</b>	
						<b>Robot positioner</b> SH: TS-SH	<b>I/O</b>
							NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>
						<b>SD</b>	<b>1</b>
						<b>Robot driver</b> SD: TS-SD	<b>I/O cable</b> t: 1m

Note 1. The robot cable is flexible and resists bending.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>Motor</b>	56 □ Step motor
<b>Resolution (Pulse/rotation)</b>	20480
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.1
<b>Drive method</b>	Belt
<b>Equivalent lead (mm)</b>	48
<b>Maximum speed</b> <sup>Note 2</sup> (mm/sec)	1500
<b>Maximum payload (kg)</b>	14
<b>Stroke (mm)</b>	300/500/600/700/800/900/ 1000/1200/1500/1800/2000
<b>Overall length (mm) (Horizontal installation)</b>	Stroke + 285.6
<b>Maximum outside dimension of body cross-section (mm)</b>	W70 × H147.5
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed needs to be changed in accordance with the payload.  
 See the "Speed vs. payload" graph shown on the right.

## Allowable overhang


Horizontal installation (Unit: mm)				Wall installation (Unit: mm)			
	A	B	C		A	B	C
<b>3kg</b>	5767	1353	1247	<b>3kg</b>	1324	1354	5588
<b>8kg</b>	1839	399	458	<b>8kg</b>	474	399	1658
<b>14kg</b>	829	154	254	<b>14kg</b>	255	151	643

Note. Distance from center of slider upper surface to carrier center-of-gravity at a guide service life of 10,000km (This does not warrant the service life of the product.). (Service life is calculated for 600mm stroke models.)

## Static loading moment

(Unit: N·m)		
MY	MP	MR
46	46	101


## Speed vs. payload



## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control

## BD07



Effective stroke	300	500	600	700	800	900	1000	1200	1500	1800	2000
<b>L</b>	585.6	785.6	885.6	985.6	1085.6	1185.6	1285.6	1485.6	1785.6	2085.6	2285.6
<b>M</b>	2	3	3	4	4	5	5	6	8	9	10
<b>N</b>	6	8	8	10	10	12	12	14	18	20	22
<b>Weight (kg)</b>	4.12	4.8	5.14	5.48	5.82	6.16	6.5	7.18	8.2	9.22	9.9

Note 1. Position from both ends to the mechanical stopper. (Movable range during return-to-origin)  
 Note 2. When installing using the main unit installation reference surface, make the mating or positioning height 2mm or more higher than the reference surface since the R-chamfering is provided on the main unit. (Recommended height, 5mm)  
 Note 3. The minimum bending radius of the motor cable is R30.





Articulated robots  
YA



Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEURO



Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER



Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

T type

F type

GF type

N type

B/R type

# SINGLE-AXIS ROBOTS

# FLIP-X

## SERIES

## CONTENTS

<ul style="list-style-type: none"> <li>■ <b>FLIP-X SPECIFICATION SHEET</b> ..... 170</li> <li>■ <b>Robot ordering method description</b> ..... 172</li> <li>■ <b>Robot ordering method terminology</b> ..... 173</li> </ul>	<ul style="list-style-type: none"> <li>F17L ..... 193</li> <li>GF17XL ..... 194</li> <li>F20 ..... 195</li> <li>F20N ..... 197</li> </ul>
<ul style="list-style-type: none"> <li><b>T TYPE FRAME-LESS STRUCTURE MODEL</b></li> <li>T4L ..... 174</li> <li>T4LH ..... 175</li> <li>T5L ..... 176</li> <li>T5LH ..... 177</li> <li>T6L ..... 178</li> <li>T9 ..... 179</li> <li>T9H ..... 180</li> </ul>	<ul style="list-style-type: none"> <li><b>N TYPE NUT ROTATION TYPE MODEL</b></li> <li>N15 ..... 198</li> <li>N15D ..... 200</li> <li>N18 ..... 202</li> <li>N18D ..... 204</li> </ul>
<ul style="list-style-type: none"> <li><b>F TYPE / GF TYPE HIGH RIGIDITY FRAME MODEL</b></li> <li>F8 ..... 181</li> <li>F8L ..... 182</li> <li>F8LH ..... 184</li> <li>F10 ..... 185</li> <li>F10H ..... 186</li> <li>F14 ..... 188</li> <li>F14H ..... 189</li> <li>GF14XL ..... 190</li> <li>F17 ..... 191</li> </ul>	<ul style="list-style-type: none"> <li><b>B TYPE TIMING BELT DRIVE MODEL</b></li> <li>B10 ..... 206</li> <li>B14 ..... 208</li> <li>B14H ..... 210</li> <li><b>R TYPE ROTATION AXIS TYPE MODEL</b></li> <li>R5 ..... 212</li> <li>R10 ..... 213</li> <li>R20 ..... 214</li> </ul>





# Robot ordering method description

In the order format for the YAMAHA single-axis robots FLIP-X series, the notation (letters/numbers) for the mechanical section is shown linked to the controller section notation.

## [Example]

### ● Mechanical ▶ F8

- Lead ▷ 20mm
- Brake ▷ Yes
- Origin position ▷ Non-motor side
- Grease ▷ Standard
- Stroke ▷ 500mm
- Cable length ▷ 3.5m

### ● Controller ▶ SR1-X

- Usable for CE ▷ Not required
- Regenerative unit ▷ Not required
- I/O selection ▷ NPN
- Battery ▷ With battery

### ● Ordering method

# F8-20-BK-Z-500-3L-SR1-X05-N-B

Mechanical section

Controller section

This page describes using the ordering form for mechanical components.

To find detailed controller information see the controller page.

SR1-X ▶ [P.516](#), TS-X ▶ [P.490](#), RDV-X ▶ [P.504](#)

## Mechanical section

### ● T type / F type (F8 / F8L / F8LH)

① Model	③ Lead designation	④ Brake	⑩ Option	⑪ Stroke	⑫ Cable length
T4L F8	30 30mm	No entry / No brakes	Origin position change: Z / Non-motor side Grease type: None / Standard / GC / Clean	3L 3.5m 5L 5m 10L 10m 3K 3.5m 5K 5m 10K 10m	
T4LH F8L	20 20mm	BK / Brakes provided			
T5L F8LH	12 12mm				
T5LH	10 10mm				
T6	6 6mm				
T9	5 5mm				
T9H	2 2mm				

### ● F type (Except F8 / F8L / F8LH)

① Model	③ Lead designation	④ Brake	⑥ Cable entry location	⑩ Option	⑪ Stroke	⑫ Cable length
F10 F20	50 50mm	No entry / No brakes	No entry / Standard (S) U / From the top R / From the right L / From the left	Origin position change: None / Standard / Z / Non-motor side Grease type: None / Standard / GC / Clean	3L 3.5m 5L 5m 10L 10m 3K 3.5m 5K 5m 10K 10m	
F10H F20N	40 40mm	BK / Brakes provided				
F14	30 30mm					
F14H	20 20mm					
F17	10 10mm					
F17L	5 5mm					

### ● GF type

① Model	② Model	⑤ Take out direction	③ Lead designation	⑥ Cable entry location	⑩ Option	⑪ Stroke	⑫ Cable length
GF14XL	S / Straight model	H / Horizontal installation	20 20mm	No entry / Standard (S) U / From the top R / From the right L / From the left	Origin position change: None / Standard / Z / Non-motor side Frame entry: No entry (Spot facing) / Tapping	Grease type: None / Standard / GC / Clean	3L 3.5m 5L 5m 10L 10m 3K 3.5m 5K 5m 10K 10m
GF17XL							

### ● N type (Single carriage)

① Model	③ Lead designation	⑦ Cable carrier entry location	⑧ Cable carrier specification	⑩ Option	⑪ Stroke	⑫ Cable length
N15	20 20mm	RH / Horizontal, right LH / Horizontal, left RW / Wall, right LW / Wall, left	S / Standard cable carrier M / Optional cable carrier	Origin position change: None / Standard / Z / Non-motor side Grease type: None / Standard / GC / Clean	3L 3.5m 5L 5m 10L 10m 3K 3.5m 5K 5m 10K 10m	
N18						

### ● N type (Double carriage)

① Model	③ Lead designation	⑤ Take out direction	⑧ Cable carrier specification	⑩ Option	⑪ Stroke	⑫ Cable length
N15D	20 20mm	H / Horizontal installation	S / Standard cable carrier	Grease type: None / Standard / GC / Clean	3L 3.5m 5L 5m 10L 10m 3K 3.5m 5K 5m 10K 10m	
N18D						













### ● B type

① Model	⑨ Motor installation direction	⑩ Option	⑪ Stroke	⑫ Cable length
B10	L / Motor leftward, horizontal position	Grease type: None / Standard / GC / Clean	3L 3.5m 5L 5m 10L 10m 3K 3.5m 5K 5m 10K 10m	
B14	R / Motor rightward, horizontal position			
B14H	LU / Motor leftward, upper position			
	RU / Motor rightward, upper position			
	LD / Motor leftward, lower position			
	RD / Motor rightward, lower position			

### ● R type

① Model	⑥ Cable entry location	⑫ Cable length
R5	No entry / Standard (S)	3L 3.5m
R10	B / From the side	5L 5m
R20		10L 10m
		3K 3.5m
		5K 5m
		10K 10m

# Robot ordering method terminology

① <b>Model</b>	Enter the robot unit model.
② <b>Model</b>	Straight model only (GF type)
③ <b>Lead designation</b>	Select the ball screw lead.
④ <b>Brake</b>	Select Brake or No-brake. <b>Horizontal specs</b> : No-brake <b>Vertical specs</b> : with Brake
⑤ <b>Take out direction</b>	Select what direction to install the robot (horizontal / wall mounted).
⑥ <b>Cable entry location</b>	Select what direction to extract the robot cable connecting the robot and controller.
⑦ <b>Cable carrier entry location</b>	Select what direction to install the robot (horizontal / wall mounted) and what direction to extract the robot cable carrier.  <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p><b>RH</b> Horizontal, right</p>  </div> <div style="text-align: center;"> <p><b>RW</b> Wall, right</p>  </div> <div style="text-align: center;"> <p><b>LH</b> Horizontal, left</p>  </div> <div style="text-align: center;"> <p><b>LW</b> Wall, left</p>  </div> </div> <p>Note. Be sure to install in the direction as specified (in cable carrier take-out direction drawing and various specification drawings) individually. Installation in any other way will cause a failure. For requirement of installation in any way other than the above standard installation, please consult YAMAHA as special arrangement will be available.</p>
⑧ <b>Cable carrier specification</b>	Select the cable carrier size for the customer wiring.  <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p><b>S type</b> Standard cable carrier</p>  </div> <div style="text-align: center;"> <p><b>M type</b> Optional cable carrier</p>  </div> </div> <p>Note. Cannot pass more than 3 urethane hoses (φ6 x 4).  <span style="display: inline-block; width: 10px; height: 10px; background-color: #ccc; border: 1px solid #000;"></span> Space for optional cable for users</p>
⑨ <b>Motor installation direction</b>	Select what direction to install the motor.  <div style="display: grid; grid-template-columns: repeat(2, 1fr); gap: 10px;"> <div style="text-align: center;"> <p><b>L type</b> Leftward at horizontal position</p>  </div> <div style="text-align: center;"> <p><b>R type</b> Rightward at horizontal position</p>  </div> <div style="text-align: center;"> <p><b>LU type</b> Leftward at upper position</p>  </div> <div style="text-align: center;"> <p><b>RU type</b> Rightward at upper position</p>  </div> <div style="text-align: center;"> <p><b>LD type</b> Leftward at lower position</p>  </div> <div style="text-align: center;"> <p><b>RD type</b> Rightward at lower position</p>  </div> </div>
⑩ <b>Option</b>	<b>Origin position change:</b> Origin point position can be changed.
	<b>Frame:</b> Hole to secure the frame can be selected. (Spot facing/tapping)
	<b>Grease type:</b> Clean grease can be selected.
⑪ <b>Stroke</b>	Select the stroke for the robot movement range.
⑫ <b>Cable length</b>	Select the robot cable length to use for connecting the robot to the controller. <b>1L</b> : 1m (You can select a 1m cable only when you use T4L/T5L.) <b>3L</b> : 3.5m (Standard) <b>5L</b> : 5m <b>10L</b> : 10m <b>3K</b> : 3.5m (Flexible cable) <b>5K</b> : 5m (Flexible cable) <b>10K</b> : 10m (Flexible cable)

Articulated robots	YA
Linear conveyor modules	LCM100
Compact single-axis robots	TRANSERVO
Single-axis robots	FLIP-X
Linear motor single-axis robots	PHASER
Cartesian robots	XY-X
SCARA robots	YK-X
Pick & place robots	YP-X
CLEAN	
CONTROLLER INFORMATION	
T type	
F type	
GF type	
N type	
B/R type	

# T4L

Origin on the non-motor side is selectable

Controller: 24V



## Ordering method

<b>T4L</b>							<b>ERC D</b>	
<b>Model</b>	<b>Lead designation</b>	<b>Brake</b>	<b>Origin position change</b>	<b>Grease type</b>	<b>Stroke</b>	<b>Cable length</b> <sup>Note 1</sup>	<b>Controller</b>	<b>I/O connector specification</b>
	12: 12mm 6: 6mm 2: 2mm	No entry: No brakes BK: Brakes provided	None: Standard Z: Non-motor side	None: Standard GC: Clean	50 to 400 (50mm pitch)	1L: 1m 3L: 3.5m 5L: 5m 10L: 10m 1K/3K/5K/10K (Flexible cable)		CN1: I/O flat cable 1m (Standard) CN2: Twisted-pair cable 2m (pulse train function)

Note 1. The robot cable is standard cable (1L/3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.

## Specifications

<b>AC servo motor output (W)</b>	30		
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.02		
<b>Deceleration mechanism</b>	Ball screw $\phi 8$ (Class C10)		
<b>Ball screw lead (mm)</b>	12	6	2
<b>Maximum speed (mm/sec)</b>	720	360	120
<b>Maximum payload (kg)</b>	<b>Horizontal</b>	6	
	<b>Vertical</b>	1.2	2.4
<b>Rated thrust (N)</b>		32	64
<b>Stroke (mm)</b>	50 to 400 (50mm pitch)		
<b>Overall length (mm)</b>	<b>Horizontal</b>	Stroke+198	
	<b>Vertical</b>	Stroke+236	
<b>Maximum dimensions of cross section of main unit (mm)</b>	W45 x H53		
<b>Cable length (m)</b>	Standard: 3.5 / Option: 1.5, 10		
<b>Linear guide type</b>	2 rows of gothic arch grooves x 1 rail		
<b>Position detector</b>	Resolvers <sup>Note 2</sup>		
<b>Resolution (Pulse/rotation)</b>	16384		

Note 1. Positioning repeatability in one direction.

Note 2. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang<sup>Note</sup>

Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				Vertical installation (Unit: mm)				
Lead	Weight	A	B	Lead	Weight	A	B	Lead	Weight	C		
Lead 12	2kg	433	87	180	Lead 12	2kg	149	54	Lead 12	1.2kg	125	125
	4.5kg	223	33	75		4.5kg	50	1		148	2.4kg	56
Lead 6	3kg	515	58	135	Lead 6	3kg	107	24	Lead 6	3kg	41	42
	6kg	340	26	62		6kg	31	0		195	7.2kg	0
Lead 2	3kg	1585	58	142	Lead 2	3kg	113	24	Lead 2	3kg	41	42
	6kg	755	27	66		6kg	32	0		440	7.2kg	0

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

Note. Service life is calculated for 300mm stroke models.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
15	19	18

## Controller

Controller	Operation method
ERC D	Pulse train control / Programming / I/O point trace / Remote command / Operation using RS-232C communication

## T4L



Note 1. Stop positions are determined by the mechanical stoppers at both ends.

Note 2. Minimum bend radius of motor cable is R30.

Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.

Note 4. The under-head length of the hex socket-head bolt (M4x0.7) to be used for the installation work is 12mm or less.

Note 5. External view of T4LH is identical to T4L.



## Ordering method

### T4LH

<b>Model</b>							
<b>Lead designation</b>	12: 12mm 6: 6mm 2: 2mm	<b>Brake</b>	No entry: No brakes BK: Brakes provided	<b>Origin position change</b>	None: Standard Z: Non-motor side	<b>Grease type</b>	None: Standard GC: Clean
<b>Stroke</b>	50 to 400 (50mm pitch)		<b>Cable length</b> <sup>Note 1</sup>	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)			

### TSX

<b>Positioner</b> <sup>Note 3</sup>	TS-X	<b>Driver: Power-supply voltage / Power capacity</b>	105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b>	No entry: None L: With LCD	<b>I/O selection</b>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> EP: EtherNet/IP <sup>TM</sup> PT: PROFIBUS GW: No I/O board <sup>Note 3</sup>	<b>Battery</b>	B: With battery (Absolute) N: None (Incremental)
-------------------------------------	------	--	--	--------------------	-------------------------------	----------------------	---	----------------	---

### SR1-X

<b>Controller</b>	05	<b>Driver: Power capacity</b>	05: 100W or less	<b>Usable for CE</b>	No entry: Standard E: CE marking	<b>I/O selection</b>	N: NPN P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS	<b>Battery</b>	B: With battery (Absolute) N: None (Incremental)
-------------------	----	-------------------------------	------------------	----------------------	-------------------------------------	----------------------	--	----------------	---

### RDV-X

<b>Driver</b>	2	<b>Power-supply voltage</b>	2: AC200V	<b>05</b>	<b>Driver: Power capacity</b>	05: 100W or less
---------------	---	-----------------------------	-----------	-----------	-------------------------------	------------------

Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable.  
See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Specifications

<b>AC servo motor output (W)</b>	30	
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.02	
<b>Deceleration mechanism</b>	Ball screw φ8 (Class C10)	
<b>Ball screw lead (mm)</b>	12	6
<b>Maximum speed (mm/sec)</b>	720	360
<b>Maximum payload (kg)</b>	<b>Horizontal</b>	4.5
	<b>Vertical</b>	1.2
<b>Rated thrust (N)</b>	<b>Horizontal</b>	32
	<b>Vertical</b>	64
<b>Stroke (mm)</b>	50 to 400 (50mm pitch)	
<b>Overall length (mm)</b>	<b>Horizontal</b>	Stroke+198
	<b>Vertical</b>	Stroke+236
<b>Maximum dimensions of cross section of main unit (mm)</b>	W45 x H53	
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5,10	
<b>Linear guide type</b>	2 rows of gothic arch grooves x 1 rail	
<b>Position detector</b>	Resolvers <sup>Note 2</sup>	
<b>Resolution (Pulse/rotation)</b>	16384	

Note 1. Positioning repeatability in one direction.  
Note 2. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang<sup>Note</sup>

Horizontal installation (Unit: mm)		Wall installation (Unit: mm)		Vertical installation (Unit: mm)				
Lead	Stroke	Lead	Stroke	Lead	Stroke			
Lead 12	2kg	A: 341	B: 90	C: 174	2kg	A: 140	B: 73	C: 300
	4.5kg	172	37	72	4.5kg	47	22	119
	6kg	235	27	62	6kg	31	11	135
Lead 6	3kg	355	58	134	3kg	105	42	260
	6kg	235	27	62	6kg	31	11	135
	6kg	520	27	66	6kg	32	11	305

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

Note. Service life is calculated for 300mm stroke models.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
15	19	18

## Controller

Controller	Operation method
SR1-X05	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X205	I/O point trace / Remote command
RDV-X205	Pulse train control

## T4LH



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Minimum bend radius of motor cable is R30.  
Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.  
Note 4. The under-head length of the hex socket-head bolt (M4x0.7) to be used for the installation work is 12mm or less.  
Note 5. External view of T4LH is identical to T4L.

# T5L

- High lead: Lead 20
- Origin on the non-motor side is selectable
- Controller: 24V



## Ordering method

<b>T5L</b>							<b>ERCD</b>	
<b>Model</b>	<b>Lead designation</b>	<b>Brake</b> <sup>Note 1</sup>	<b>Origin position change</b>	<b>Grease type</b>	<b>Stroke</b>	<b>Cable length</b> <sup>Note 2</sup>	<b>Controller</b>	<b>I/O connector specification</b>
	20: 20mm 12: 12mm 6: 6mm	No entry: No brakes BK: Brakes provided	None: Standard Z: Non-motor side	None: Standard GC: Clean	50 to 800 (50mm pitch)	1L: 1m 3L: 3.5m 5L: 5m 10L: 10m 1K/3K/5K/10K (Flexible cable)		CN1: I/O flat cable 1m (Standard) CN2: Twisted-pair cable 2m (pulse train function)




Note 1. The model with a lead of 20mm cannot select specifications with brake (vertical specifications).  
Note 2. The robot cable is standard cable (1L/3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.

## Specifications

<b>AC servo motor output (W)</b>	30
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.02
<b>Deceleration mechanism</b>	Ball screw $\phi 12$ (Class C10)
<b>Ball screw lead (mm)</b>	20 12 6
<b>Maximum speed</b> <sup>Note 2</sup> (mm/sec)	1200 800 400
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 3 5 9 <b>Vertical</b> - 1.2 2.4
<b>Rated thrust (N)</b>	19 32 64
<b>Stroke (mm)</b>	50 to 800 (50mm pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+201.5 <b>Vertical</b> Stroke+239.5
<b>Maximum dimensions of cross section of main unit (mm)</b>	W55×H52
<b>Cable length (m)</b>	Standard: 3.5 / Option: 1.5, 10
<b>Linear guide type</b>	2 rows of gothic arch grooves × 1 rail
<b>Position detector</b>	Resolvers <sup>Note 3</sup>
<b>Resolution (Pulse/rotation)</b>	16384

Note 1. Positioning repeatability in one direction.  
Note 2. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang<sup>Note</sup>




Horizontal installation (Unit: mm)		A	B	C
Lead 20	1kg	600	323	683
	3kg	675	103	247
	2kg	1170	159	406
Lead 12	5kg	555	59	155
	3kg	1498	104	294
	9kg	628	31	89

Wall installation (Unit: mm)		A	B	C
Lead 20	1kg	600	291	600
	3kg	215	73	589
	2kg	368	127	1082
Lead 12	5kg	127	30	449
	3kg	263	73	970
	9kg	54	0	400

Vertical installation (Unit: mm)		A	C
Lead 12	1.2kg	242	240
	2.4kg	113	113

## Static loading moment




(Unit: N·m)		
MY	MP	MR
30	34	40

## Controller

Controller	Operation method
ERCD	Pulse train control / Programming / I/O point trace / Remote command / Operation using RS-232C communication

## T5L



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Minimum bend radius of motor cable is R30.  
Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.  
Note 4. The under-head length of the hex socket-head bolt (M4×0.7) to be used for the installation work is 15mm or less.  
Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.  
Note 6. External view of T5LH is identical to T5L.





## Ordering method

<b>T5LH</b>	<b>Model</b>	<b>Lead designation</b> 20: 20mm 12: 12mm 6: 6mm	<b>Brake</b> <sup>Note 1</sup> No entry: No brakes BK: Brakes provided	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Grease type</b> None: Standard GC: Clean	<b>Stroke</b> 50 to 800 (50mm pitch)	<b>Cable length</b> <sup>Note 2</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>Positioner</b> <sup>Note 3</sup> TS-X	<b>Driver: Power supply voltage / Power capacity</b> 105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
	<b>SR1-X</b>	<b>05</b>						<b>Controller</b>	<b>Driver: Power capacity</b> 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
	<b>RDV-X</b>	<b>2</b>						<b>Driver</b>	<b>Power supply voltage</b> 2: AC200V		<b>05</b>	<b>Driver: Power capacity</b> 05: 100W or less

- Note 1. The model with a lead of 20mm cannot select specifications with brake (vertical specifications).
- Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.
- Note 3. See P.498 for DIN rail mounting bracket.
- Note 4. Select this selection when using the gateway function. For details, see P.60

## Specifications

<b>AC servo motor output (W)</b>	30			
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.02			
<b>Deceleration mechanism</b>	Ball screw $\phi$ 12 (Class C10)			
<b>Ball screw lead (mm)</b>	20	12	6	
<b>Maximum speed</b> <sup>Note 2</sup> (mm/sec)	1200	800	400	
<b>Maximum payload</b> (kg)	<b>Horizontal</b>	3	5	9
	<b>Vertical</b>	-	1.2	2.4
<b>Rated thrust (N)</b>	19		32	64
<b>Stroke (mm)</b>	50 to 800 (50mm pitch)			
<b>Overall length (mm)</b>	<b>Horizontal</b>	Stroke+201.5		
	<b>Vertical</b>	Stroke+239.5		
<b>Maximum dimensions of cross section of main unit (mm)</b>	W55×H52			
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5,10			
<b>Linear guide type</b>	2 rows of gothic arch grooves × 1 rail			
<b>Position detector</b>	Resolvers <sup>Note 3</sup>			
<b>Resolution (Pulse/rotation)</b>	16384			

- Note 1. Positioning repeatability in one direction.
- Note 2. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.
- Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang

<b>Horizontal installation</b> (Unit: mm)		<b>Wall installation</b> (Unit: mm)			<b>Vertical installation</b> (Unit: mm)						
Stroke	A	B	C	Stroke	A	B	C	Stroke	A	C	
<b>Lead 20</b>	967	324	598	<b>Lead 20</b>	551	304	925	<b>Lead 12</b>	1.2kg	240	239
1kg	429	104	226	3kg	185	89	378	<b>Lead 6</b>	2.4kg	109	110
2kg	916	159	398	2kg	347	141	800				
5kg	436	60	152	5kg	119	44	355				
3kg	1194	105	294	3kg	259	87	950				
9kg	624	31	89	9kg	50	15	385				

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

Note. Service life is calculated for 600mm stroke models.


## Static loading moment

<b>MY</b>	<b>MP</b>	<b>MR</b>
30	34	40

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105 TS-X205	I/O point trace / Remote command
RDV-X205	Pulse train control

## T5LH



Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800				
<b>L</b>	251.5	301.5	351.5	401.5	451.5	501.5	551.5	601.5	651.5	701.5	751.5	801.5	851.5	901.5	951.5	1001.5				
<b>A</b>	130	180	230	280	330	380	430	480	530	580	630	680	730	780	830	880				
<b>C</b>	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800				
<b>D</b>	-	-	-	-	-	-	230	230	230	230	230	230	230	230	230	230				
<b>M</b>	0	1	2	3	4	5	0	1	2	3	4	5	6	7	8	9				
<b>N</b>	4	6	8	10	12	14	6	8	10	12	14	16	18	20	22	24				
<b>Weight (kg)</b> <sup>Note 3</sup>	1.7	1.8	2.0	2.2	2.3	2.5	2.7	2.8	3.0	3.2	3.3	3.5	3.7	3.8	4.0	4.2				
<b>Maximum speed for each stroke</b> <sup>Note 5</sup> (mm/sec)	Lead 20		1200		Lead 12		800		Lead 6		400		320		280		240		220	
<b>Speed setting</b>	80%		70%		60%		55%													

- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. Minimum bend radius of motor cable is R30.
- Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.
- Note 4. The under-head length of the hex socket-head bolt (M4×0.7) to be used for the installation work is 15mm or less.
- Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.
- Note 6. External view of T5LH is identical to T5L.



# T9

● High lead: Lead 30

● Origin on the non-motor side is selectable: Lead 10-20-30

Note. Strokes longer than 1050mm are special order items. Please consult us for delivery time.

## Ordering method

**T9**

<b>Model</b>	
<b>Lead designation</b>	30: 30mm 20: 20mm 10: 10mm 5: 5mm
<b>Brake</b>	No entry: No brakes BK: Brakes provided
<b>Origin position change</b>	None: Standard Z: Non-motor side
<b>Grease type</b>	None: Standard GC: Clean
<b>Stroke</b>	Lead 20-10-5: 150 to 1050 (50mm pitch) Lead 30: 150 to 1250 (50mm pitch)
<b>Cable length</b>	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)

**TSX**

<b>Positioner</b>	TS-X
<b>Driver: Power supply voltage Power capacity</b>	105: 100V/100W or less 205: 200V/100W or less
<b>Regenerative unit</b>	No entry: None R: With RGT
<b>LCD monitor</b>	No entry: None L: With LCD
<b>I/O selection</b>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board
<b>Battery</b>	B: With battery (Absolute) N: None (Incremental)

**SR1-X 05**

<b>Controller</b>	05: 100W or less
<b>Usable for CE</b>	No entry: Standard E: CE marking
<b>Regenerative unit</b>	No entry: None R: With RGT1
<b>I/O selection</b>	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS
<b>Battery</b>	B: With battery (Absolute) N: None (Incremental)

**RDV-X 2 05 RBR1**

<b>Driver</b>	2: AC200V
<b>Power supply voltage</b>	05: 100W or less
<b>Driver: Power capacity</b>	
<b>Regenerative unit</b>	

- Note 1. The model with a lead of 30mm cannot select specifications with brake (vertical specifications).
- Note 2. If selecting 5mm lead specifications then the origin point cannot be changed to the non-motor side.
- Note 3. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.
- Note 4. See P.498 for DIN rail mounting bracket.
- Note 5. Select this selection when using the gateway function. For details, see P.60.

## Specifications

<b>AC servo motor output (W)</b>	100
<b>Repeatability (mm)</b>	+/-0.01
<b>Deceleration mechanism</b>	Ball screw (Class C7)
<b>Ball screw lead (mm)</b>	30 20 10 5
<b>Maximum speed (mm/sec)</b>	1800 1200 600 300
<b>Maximum payload (kg)</b>	Horizontal 15 30 55 80 Vertical — 4 10 20
<b>Rated thrust (N)</b>	56 84 169 339
<b>Stroke (mm)</b>	150 to 1250 (50mm pitch)
<b>Overall length (mm)</b>	Horizontal Stroke+259 Vertical Stroke+289
<b>Maximum dimensions of cross section of main unit (mm)</b>	W94 × H98
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5.10
<b>Linear guide type</b>	4 rows of circular arc grooves × 1 rail
<b>Position detector</b>	Resolvers
<b>Resolution (Pulse/rotation)</b>	16384

- Note 1. Positioning repeatability in one direction.
- Note 2. When the stroke is longer than 700mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.
- Note 3. Strokes longer than 1050mm are available only for high lead (Lead 30). (Special order item)
- Note 4. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang

	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C	A	C	
Lead 30									
5kg	864	501	383	5kg	348	384	776		
15kg	491	156	140	15kg	87	40	306		
Lead 20									
5kg	1292	505	462	5kg	416	388	1186		
15kg	572	158	151	15kg	92	42	386		
30kg	455	73	75	30kg	0	0	61		
Lead 10									
20kg	617	119	127	10kg	193	132	910		
40kg	422	53	59	20kg	53	0	400		
55kg	420	36	40	30kg	0	0	109		
50kg	722	42	47	10kg	197	133	2360		
60kg	657	33	37	20kg	54	0	985		
80kg	577	23	25	30kg	0	0	427		
Lead 5									
20kg									
30kg									
40kg									
50kg									

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


	(Unit: N·m)		
	MY	MP	MR
	86	133	117

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105 TS-X205 RDV-X205-RBR1	I/O point trace / Remote command / Pulse train control

Note. Regenerative unit is required when the models used vertically and with 700mm or larger stroke.

## T9



- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. 167.5±4 when the high lead specification (Lead 30) is used.
- Note 3. 94±4 when the high lead specification (Lead 30) is used.
- Note 4. 41.5±1 when the high lead specification (Lead 30) is used.
- Note 5. When installing the unit, washers, etc., cannot be used in the φ11 counter bore hole.
- Note 6. Minimum bend radius of motor cable is R5.
- Note 7. Weight of models with no brake. The weight of brake-attached models is 0.5 kg heavier than the models with no brake shown in the table.

Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250												
	L	409	459	509	559	609	659	709	759	809	859	909	959	1009	1059	1109	1159	1209	1259	1309	1359	1409	1459	1509											
A	64	54	44	94	84	74	64	54	44	94	84	74	64	54	44	94	84	74	64	54	44	94	84												
N	4	5	6	6	7	8	9	10	11	11	12	13	14	15	16	16	17	18	19	20	21	21	22												
<b>Weight (kg)</b>	5.5	5.9	6.2	6.6	6.9	7.3	7.6	8.0	8.3	8.7	9.0	9.4	9.7	10.0	10.3	10.7	11.0	11.4	11.7	12.1	12.5	12.9	13.3												
<b>Maximum speed (mm/sec)</b>	Lead 30	1800																																	
	Lead 20	1200																																	
	Lead 10	600																																	
	Lead 5	300																																	
<b>Speed setting</b>	80%												65%											50%								45%			

- Note 8. When the stroke is longer than 700mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.
- Note 9. Strokes longer than 1050mm are special order items. Please contact us for speed setting.



# F8

- High lead: Lead 20
- Origin on the non-motor side is selectable



## Ordering method

**F8** Model: [ ] Lead designation: [ ] Brake: [ ] Origin position change: [ ] Grease type: [ ] Stroke: [ ] Cable length: [ ]

**TSX** Positioner: [ ] Driver: [ ] LCD monitor: [ ] I/O selection: [ ] Battery: [ ]

**SR1-X** Controller: [ ] Driver: [ ] Usable for CE: [ ] I/O selection: [ ] Battery: [ ]

**RDV-X** Driver: [ ] Driver: [ ] Driver: [ ] Regenerative unit: [ ]

**Model** [ ] **Lead designation** [ ] **Brake** [ ] **Origin position change** [ ] **Grease type** [ ] **Stroke** [ ] **Cable length** [ ]

**Positioner** [ ] **Driver** [ ] **LCD monitor** [ ] **I/O selection** [ ] **Battery** [ ]

**Controller** [ ] **Driver** [ ] **Usable for CE** [ ] **I/O selection** [ ] **Battery** [ ]

**Driver** [ ] **Driver** [ ] **Driver** [ ] **Regenerative unit** [ ]

Note 1. The model with a lead of 20mm cannot select specifications with brake (vertical specifications).  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Specifications

AC servo motor output (W)	100
Repeatability (mm)	+/-0.02
Deceleration mechanism	Ball screw (Class C10)
Ball screw lead (mm)	20 12 6
Maximum speed (mm/sec)	1200 720 360
Maximum payload (kg)	Horizontal: 12 20 40 Vertical: - 4 8
Rated thrust (N)	84 141 283
Stroke (mm)	150 to 800 (50mm pitch)
Overall length (mm)	Horizontal: Stroke+286 Vertical: Stroke+316
Maximum dimensions of cross section of main unit (mm)	W80 x H65
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves x 1 rail
Position detector	Resolvers
Resolution (Pulse/rotation)	16384

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 550mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.  
 Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang

Horizontal installation (Unit: mm)

Lead	A	B	C
Lead 20	197	76	120
10kg	100	32	54
10kg	85	25	43
Lead 12	364	89	188
10kg	203	39	87
15kg	139	22	51
20kg	103	14	33
10kg	403	43	113
20kg	214	16	43
30kg	140	6	20
40kg	113	0	8

Wall installation (Unit: mm)

Lead	A	B	C
Lead 20	104	67	174
10kg	37	23	72
12kg	27	15	55
Lead 12	171	81	340
10kg	69	32	172
15kg	33	15	100
20kg	15	6	55
10kg	94	36	369
20kg	25	9	157
30kg	0	0	14
40kg	0	0	0

Vertical installation (Unit: mm)

Lead	A	C
Lead 12	447	448
2kg	214	216
3kg	137	138
4kg	98	99
2kg	244	245
4kg	113	113
6kg	69	69
8kg	46	46

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


(Unit: N·m)

MY	MP	MR
70	95	110

## Controller

Controller	Operation method
SR1-X05	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221/222	
RCX240/340	
TS-X105	I/O point trace / Remote command
TS-X205	
RDV-X205-RBR1	Pulse train control

## F8



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	436	486	536	586	636	686	736	786	836	886	936	986	1036	1086
A	0	0	1	1	2	2	3	3	4	4	5	5	6	6
B	100	150	100	150	100	150	100	150	100	150	100	150	100	150
C	8	8	10	10	12	12	14	14	16	16	18	18	20	20
D	240	290	340	390	440	490	540	590	640	690	740	790	840	890
Weight (kg)	3.6	3.9	4.2	4.4	4.7	5.0	5.3	5.6	5.9	6.2	6.4	6.7	7.0	7.3
Maximum speed (mm/sec)	Lead 20: 1200	Lead 12: 720	Lead 6: 360											
Speed setting	90% 75% 65% 60% 50%													

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. When installing the robot, do not use washers inside the robot body.  
 Note 3. Minimum bend radius of motor cable is R50.  
 Note 4. When using this φ10 knock-pin hole to position the robot body, the knock-pin must not protrude more than 10mm inside the robot body.  
 Note 5. Weight of models with no brake. The weight of brake-attached models is 0.3 kg heavier than the models with no brake shown in the table.  
 Note 6. When the stroke is longer than 550mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.

# F8L

- High lead: Lead 30
- Origin on the non-motor side is selectable

## Ordering method

<b>F8L</b>	<b>Model</b>	<b>Lead designation</b> 30: 30mm 20: 20mm 10: 10mm 5: 5mm	<b>Brake Note 1</b> No entry: No brakes BK: Brakes provided	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Grease type</b> None: Standard GC: Clean	<b>Stroke</b> 150 to 1050 (50mm pitch)	<b>Cable length Note 2</b> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)
------------	--------------	---	---	--	---	--	---

<b>TSX</b>				
<b>Positioner</b> (TS-X)	<b>Driver: Power supply voltage / Power capacity</b> 105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFIBUS GW: No I/O board Note 4	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
<b>SR1-X</b>	<b>05</b>			
<b>Controller</b>	<b>Driver: Power capacity</b> 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
<b>RDV-X</b>	<b>2</b>	<b>05</b>		<b>RBR1</b>
<b>Driver</b>	<b>Power supply voltage</b> 2: AC200V	<b>Driver: Power capacity</b> 05: 100W or less		<b>Regenerative unit</b>


Note 1. The model with a lead of 30mm cannot select specifications with brake (vertical specifications).  
Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 3. See P.498 for DIN rail mounting bracket.  
Note 4. Select this selection when using the gateway function. For details, see P.60.

## Specifications

<b>AC servo motor output (W)</b>	100		
<b>Repeatability Note 1 (mm)</b>	+/-0.01		
<b>Deceleration mechanism</b>	Ball screw (Class C7)		
<b>Ball screw lead (mm)</b>	30	20	10
<b>Maximum speed Note 2 (mm/sec)</b>	1800	1200	600
<b>Maximum payload (kg)</b>	<b>Horizontal</b>		<b>Vertical</b>
	7	20	40
	-	4	8
<b>Rated thrust (N)</b>	56	84	169
<b>Stroke (mm)</b>	150 to 1050	(50mm pitch)	
<b>Overall length (mm)</b>	<b>Horizontal</b>		<b>Vertical</b>
	Stroke+300		Stroke+322
<b>Maximum dimensions of cross section of main unit (mm)</b>	W80 x H65		
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5.10		
<b>Linear guide type</b>	4 rows of circular arc grooves x 1 rail		
<b>Position detector</b>	Resolvers Note 3		
<b>Resolution (Pulse/rotation)</b>	16384		

Note 1. Positioning repeatability in one direction.  
Note 2. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.


## Allowable overhang Note



<b>Horizontal installation (Unit: mm)</b>				<b>Wall installation (Unit: mm)</b>				<b>Vertical installation (Unit: mm)</b>			
	A	B	C		A	B	C		A	B	C
<b>Lead 30</b>	5kg	112	80	80	5kg	55	57	77	2kg	236	240
	7kg	78	43	49	7kg	21	19	34	4kg	106	110
	5kg	211	108	147	5kg	119	89	176	2kg	310	311
	10kg	116	45	69	10kg	38	26	69	4kg	141	143
	15kg	76	24	39	15kg	7	0	16	6kg	85	86
	20kg	58	14	26	20kg	0	0	0	8kg	57	58
<b>Lead 20</b>	10kg	251	56	122	10kg	85	39	202	5kg	123	124
	20kg	121	20	46	20kg	7	0	30	10kg	47	48
	30kg	74	8	20	30kg	0	0	0	15kg	22	22
	40kg	35	0	6	40kg	0	0	0	16kg	19	19
<b>Lead 10</b>	20kg	249	23	62	20kg	19	7	140			
	30kg	170	10	29	30kg	0	0	0			
	40kg	138	4	12	40kg	0	0	0			
<b>Lead 5</b>	50kg	51	0	0	50kg	0	0	0			

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.


## F8L



Cross-section E-E		150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050
<b>Effective stroke</b>	L	442	492	542	592	642	692	742	792	842	892	942	992	1042	1092	1142	1192	1242	1292	1342
	A	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9
	B	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100
	C	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26
	D	240	290	340	390	440	490	540	590	640	690	740	790	840	890	940	990	1040	1090	1140
<b>Weight (kg) Note 5</b>	<b>Lead 20</b>	3.9	4.2	4.5	4.8	5.1	5.4	5.7	6.1	6.4	6.7	7.0	7.3	7.6	7.9	8.2	8.5	8.8	9.2	9.5
	<b>Lead 10</b>	1200																		
	<b>Lead 5</b>	600																		
	<b>Speed setting</b>	300																		
	<b>Maximum speed Note 6 (mm/sec)</b>	Lead 20	1020	900	780	720	660	600	540	480	510	450	390	360	330	300	270	240	220	200
	Lead 10	255	225	195	180	165	150	135	120	85%	75%	65%	60%	55%	50%	45%	40%			

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. When installing the robot, do not use washers inside the robot body.  
Note 3. Minimum bend radius of motor cable is R50.  
Note 4. When using this φ10 knock-pin hole to position the robot body, the knockpin must not protrude more than 10mm inside the robot body.  
Note 5. Weight of models with no brake. The weight of brake-attached models is 0.3 kg heavier than the models with no brake shown in the table.  
Note 6. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.

F8L High lead type: Lead 30



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	
L	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	
A	0	0	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	
B	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	
C	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	
D	240	290	340	390	440	490	540	590	640	690	740	790	840	890	940	990	1040	1090	1140	
Weight (kg)	3.9	4.2	4.5	4.8	5.1	5.4	5.7	6.1	6.4	6.7	7.0	7.3	7.6	7.9	8.2	8.5	8.8	9.2	9.5	
Maximum speed <sup>Notes</sup> (mm/sec)	Lead 30	1800																		
	Speed setting	-																		
													85%	75%	65%	60%	55%	50%	45%	40%

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. When installing the robot, do not use washers inside the robot body.  
 Note 3. Minimum bend radius of motor cable is R50.  
 Note 4. When using this  $\phi 10$  knockpin hole to position the robot body, the knockpin must not protrude more than 10mm inside the robot body.

Note 5. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.

### Ordering method

<b>F8LH</b>	<b>Model</b>	<b>Lead designation</b> 20: 20mm 10: 10mm 5: 5mm	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Grease type</b> None: Standard GC: Clean	<b>Stroke</b> 150 to 1050 (50mm pitch)	<b>Cable length</b> <sup>Note2</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>Positioner</b> <sup>Note2</sup> TS-X	<b>Driver: Power-supply voltage / Power capacity</b> 105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note3</sup>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>SR1-X</b>	<b>05</b>			
							<b>Controller</b>	<b>Driver: Power capacity</b> 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PB: PROFINET	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>RDV-X</b>	<b>2</b>	<b>05</b>	<b>RBR1</b>	
							<b>Driver</b>	<b>Power-supply voltage</b> 2: AC200V	<b>Driver: Power capacity</b> 05: 100W or less	<b>Regenerative unit</b>	

Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

### Specifications

<b>AC servo motor output (W)</b>	100
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.01
<b>Deceleration mechanism</b>	Ball screw (Class C7)
<b>Ball screw lead (mm)</b>	20 10 5
<b>Maximum speed</b> <sup>Note 2</sup> (mm/sec)	1200 600 300
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 30 60 80
<b>Rated thrust (N)</b>	84 169 339
<b>Stroke (mm)</b>	150 to 1050 (50mm pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+368
<b>Maximum dimensions of cross section of main unit (mm)</b>	W80 × H65
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5.10
<b>Linear guide type</b>	4 rows of circular arc grooves × 1 rail
<b>Position detector</b>	Resolvers <sup>Note 3</sup>
<b>Resolution (Pulse/rotation)</b>	16384

Note 1. Positioning repeatability in one direction.  
Note 2. When the stroke is longer than 800mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

### Allowable overhang

Horizontal installation (Unit: mm)			
	A	B	C
Lead 20	573	256	176
10kg	573	256	176
20kg	334	116	81
30kg	279	70	50
Lead 10	629	137	111
20kg	479	57	47
60kg	382	30	25
Lead 5	1094	148	127
40kg	851	63	54
60kg	714	34	29
80kg	601	20	17
Wall installation (Unit: mm)			
	A	B	C
Lead 20	147	215	515
10kg	147	215	515
20kg	53	75	255
30kg	20	29	160
Lead 10	80	99	545
40kg	15	19	270
60kg	-	-	-
Lead 5	96	112	1005
20kg	22	26	604
40kg	-	-	-
60kg	-	-	-
80kg	-	-	-

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.


### Static loading moment

	(Unit: N·m)		
MY	MP	MR	
128	163	143	

### Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105 TS-X205	I/O point trace / Remote command
RDV-X205-RBR1	Pulse train control

### F8LH



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	
<b>L</b>	518	568	618	668	718	768	818	868	918	968	1018	1068	1118	1168	1218	1268	1318	1368	1418	
<b>A</b>	0	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	
<b>B</b>	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	
<b>C</b>	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	
<b>D</b>	290	340	390	440	490	540	590	640	690	740	790	840	890	940	990	1040	1090	1140	1190	
<b>Weight (kg)</b>	4.7	5.0	5.3	5.6	5.9	6.2	6.6	6.9	7.2	7.5	7.8	8.1	8.4	8.7	9.0	9.3	9.7	10.0	10.3	
<b>Maximum speed</b> <sup>Note 5</sup> (mm/sec)	<b>Lead 20</b>	1200										1020	900	780	720	660	600	540	480	420
	<b>Lead 10</b>	600										510	450	390	360	330	300	270	240	210
	<b>Lead 5</b>	300										255	225	195	180	165	150	135	120	105
	<b>Speed setting</b>	-										85%	75%	65%	60%	55%	50%	45%	40%	35%

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. When installing the robot, do not use washers inside the robot body.  
Note 3. Minimum bend radius of motor cable is R50.  
Note 4. When using this  $\phi 10$  knock-pin hole to position the robot body, the knock-pin must not protrude more than 10mm inside the robot body.


Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.







## F10H High lead type: Lead 30



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000
L	505	555	605	655	705	755	805	855	905	955	1005	1055	1105	1155	1205	1255	1305	1355
A	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50
M	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5
N	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16
K	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100
Weight (kg)	6.9	7.3	7.7	8.1	8.4	8.8	9.2	9.6	10.0	10.3	10.7	11.1	11.5	11.9	12.2	12.6	13.0	13.4
Maximum speed (mm/sec)	Lead 30											1440	1260	1080	900		720	630
	Lead 20											960	840	720	600		480	420
	Lead 10											480	420	360	300		240	210
	Lead 5											240	210	180	150		120	105
	Speed setting											80%	70%	60%	50%		40%	35%

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. When installing the unit, washers, etc., cannot be used in the φ9.5 counter bore hole.  
 Note 3. Minimum bend radius of motor cable is R50.  
 Note 4. When using this φ10 knock-pin hole to position the robot body, the knock-pin must not protrude more than 10mm inside the robot body.

Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.





# GF14XL

● Origin on the non-motor side is selectable

Note. If you need an installation posture other than the horizontal installation, please contact us.

## Ordering method

### GF14XL - S H - 20

<b>Model</b>	<b>Model</b> S: Straight model	<b>Installation direction</b> H: Horizontal installation	<b>Lead designation</b>	<b>Cable entry location</b> No entry: Standard (S) U: From the top R: From the right L: From the left	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Frame</b> No entry: Standard Spot facing T: Tapping	<b>Grease type</b> None: Standard GC: Clean	<b>Stroke</b> 750 to 2000 (50mm pitch)	<b>Cable length</b> <sup>Note 1</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)
--------------	-----------------------------------	---	-------------------------	--	---	--	---	--	--

<b>TSX</b>	<b>SR1-X 10</b>	<b>RDV-X 2</b>	<b>20</b>	<b>RBR1</b>
<b>Positioner</b> TS-X	<b>Controller</b> 10: 200W	<b>Driver</b> 2: AC200V	<b>Driver: Power capacity</b> 20: 600W or less	<b>Regenerative unit</b>
<b>Driver: Power-supply voltage</b> 110: 100V/200V 210: 200V/200W	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>Power-supply voltage</b> 2: AC200V	<b>Driver: Power capacity</b> 20: 600W or less	
<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>			
<b>Battery</b> B: With battery (Absolute) N: None (Incremental)	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)			

Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.


- [Cautions after purchase]
- When changing the origin position, contact us since the adjustment is needed.
  - When changing the cable entry location, contact us since necessary parts may vary depending on the cable entry location.
  - Do not install the robot with the horizontal installation specifications in a direction other than the horizontal direction.

## Specifications

AC servo motor output (W)	200
Repeatability <sup>Note 1</sup> (mm)	+/-0.01
Deceleration mechanism	Ball screw $\phi$ 15 (Class C7)
Ball screw lead (mm)	20
Maximum speed (mm/sec)	1200
Maximum payload (kg)	45
Rated thrust (N)	170
Stroke (mm)	750 to 2000 (50mm pitch)
Overall length (mm)	Stroke+561
Maximum dimensions of cross section of main unit (mm)	W140×H91.5
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves × 2 rail
Position detector	Resolvers <sup>Note 2</sup>
Resolution (Pulse/rotation)	20480

Note 1. Positioning repeatability in one direction.  
Note 2. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang <sup>Note</sup>




Horizontal installation (Unit: mm)				
Lead 20	A	B	C	
	10kg	3550	1340	1210
	20kg	2075	685	633
45kg	1280	326	308	

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

Note. Service life is calculated for 1000mm stroke models.

## Static loading moment




(Unit: N·m)		
MY	MP	MR
551	552	485

## Controller

<b>Controller</b>	<b>Operation method</b>
SR1-X10 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X110	I/O point trace / Remote command
TS-X210	Remote command
RDV-X220-RBR1	Pulse train control

## GF14XL




Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. When changing the return-to-origin direction, the adjustment is needed. (The standard is the origin on the motor side.)  
Note 3. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
Note 4. The cable's minimum bend radius is R30.  
Note 5. The length under head of the hexagonal socket head bolts (M6 x 1.0) that are used to install the main body with the spot facing hole installation specifications is 20mm or more. It is recommended that the length under head of the hexagonal socket head bolts (M6 x 1.0) that are used to install the main body with the tapping hole installation specifications is the thickness of the installation base + 10mm or less.

Effective stroke	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450	1500	1550	1600	1650	1700	1750	1800	1850	1900	1950	2000
L	1311	1361	1411	1461	1511	1561	1611	1661	1711	1761	1811	1861	1911	1961	2011	2061	2111	2161	2211	2261	2311	2361	2411	2461	2511	2561
A	1050	1100	1150	1200	1250	1300	1350	1400	1450	1500	1550	1600	1650	1700	1750	1800	1850	1900	1950	2000	2050	2100	2150	2200	2250	2300
B	14	14	14	16	16	16	16	18	18	18	18	20	20	20	20	22	22	22	22	24	24	24	24	26	26	26
C	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150
Weight (kg)	22.5	23.2	23.8	24.5	25.2	25.9	26.5	27.2	27.9	28.6	29.2	29.9	30.6	31.3	31.9	32.6	33.3	33.9	34.6	35.3	36.0	36.6	37.3	38.0	38.7	39.3



- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN CONTROLLER INFORMATION
- T type
- F type
- GF type
- N type
- B/R type

## F17 High lead type: Lead 40



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. When installing the robot, do not use washers inside the robot body.

Note 3. Minimum bend radius of motor cable is R50.

Effective stroke	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450				
L	575	625	675	725	775	825	875	925	975	1025	1075	1125	1175	1225	1275	1325	1375	1425	1475	1525	1575	1625	1675	1725	1775	1825				
A	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100				
M	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6	6	7	7	7	7	8	8				
N	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18	18	20	20				
C	240	240	420	420	420	600	600	600	600	780	780	780	780	960	960	960	960	1140	1140	1140	1140	1320	1320	1320	1320	1320				
Weight (kg)	14.7	15.5	16.4	17.2	18.0	18.8	19.7	20.5	21.3	22.1	23.0	23.8	24.6	25.4	26.3	27.1	27.9	28.7	29.6	30.4	31.2	32.0	32.8	33.6	34.4	35.2				
Maximum speed <sup>Note 4</sup> (mm/sec)	Lead 40														2400		1920		1680		1440		1200		960		840		720	
Speed setting	-														-		80%		70%		60%		50%		40%		35%		30%	

Note 4. When the stroke is longer than 800mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.



# F17L

● Origin on the non-motor side is selectable

Note. Upper robot cable (U) on models with brakes is a special order item, so please consult our sales office or sales representative for assistance. (External dimensions: overall length + 20 mm)

## Ordering method

### F17L- 50

Model	Lead designation	Brake	Cable entry location	Origin position change	Grease type	Stroke	Cable length (mm)	TSX	220	R	I/O selection	Battery	
		No entry: No brakes BK: Brakes provided	No entry: Standard (S) U: From the top R: From the right L: From the left	None: Standard Z: Non-motor side	None: Standard GC: Clean	1100 to 2050 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	Positioner (Note 1) TS-X	Driver: Power supply voltage / Power capacity (Note 4) 220: 200V/400 to 600W	Regenerative unit R: With RGT	LCD monitor No entry: None L: With LCD	I/O selection N: NPN P: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFIBUS GW: No I/O board (Note 5)	Battery B: With battery (Absolute) N: None (Incremental)
								SR1-X	20	R	I/O selection	Battery	
								Controller	Driver: Power capacity (Note 4) 20: 400 to 600W	Usable for CE No entry: Standard E: CE marking	Regenerative unit R: With RG1	I/O selection N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	Battery B: With battery (Absolute) N: None (Incremental)
								RDV-X	2	20	Regenerative unit	Battery	
								Driver	Power supply voltage 2: AC200V	Driver: Power capacity (Note 4) 20: 600W or less	Regenerative unit RBR1 (Horizontal) RBR2 (Vertical)		


- Note 1. Upper robot cable (U) on models equipped with brake is a special-order item.
- Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.
- Note 3. See P.498 for DIN rail mounting bracket.
- Note 4. Acceleration / deceleration is different depending the Positioner or Controller or Driver.
- Note 5. Select this selection when using the gateway function. For details, see P.60.

## Specifications

AC servo motor output (W)	600
Repeatability (mm)	+/-0.02
Deceleration mechanism	Ball screw (Class C10)
Ball screw lead (mm)	50
Maximum speed (mm/sec)	2200
Maximum payload (kg)	Horizontal: 50 Vertical: 10
Rated thrust (N)	204
Stroke (mm)	1100 to 2050 (50mm pitch)
Overall length (mm)	Horizontal: Stroke+475 Vertical: Stroke+505
Maximum dimensions of cross section of main unit (mm)	W168 × H100
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves × 2 rail
Position detector	Resolvers (Note 3)
Resolution (Pulse/rotation)	16384

- Note 1. Positioning repeatability in one direction.
- Note 2. When the stroke is longer than 1200mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.
- Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.


## Allowable overhang



Lead 50	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C	A	B	C
10kg	4000	2755	2608	2720	2681	4000	2kg	1200	1200
30kg	3045	895	1175	1185	821	3045	5kg	3000	3000
50kg	2602	523	715	680	449	2602	10kg	2650	2650

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment




(Unit: N-m)		
MY	MP	MR
1032	1034	908

## Controller

Controller	Operation method
SR1-X20-R RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X220-R RDV-X220-RBR1 (Horizontal) RDV-X220-RBR2 (Vertical)	I/O point trace / Remote command Pulse train control

## F17L



- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. It is not allowed to use a counter bore washer, etc. when installing the main unit.
- Note 3. This is the weight of the model without a brake. The weight of the model equipped with a brake is 1.2kg heavier than this value.
- Note 4. Make a separate consultation with us regarding robot cable (brake specifications) U extraction. (External dimensions: overall length + 20 mm)

Effective stroke	1100	1150	1200	1250	1300	1350	1400	1450	1500	1550	1600	1650	1700	1750	1800	1850	1900	1950	2000	2050
	L	1575	1625	1675	1725	1775	1825	1875	1925	1975	2025	2075	2125	2175	2225	2275	2325	2375	2425	2475
A	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150
M	6	7	7	7	7	7	7	7	7	7	7	7	7	7	7	7	7	7	7	7
N	16	18	18	18	18	20	20	20	20	22	22	22	22	24	24	24	24	26	26	26
K	1140	1140	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320
Weight (kg) (Note 3)	34.1	34.9	35.8	36.7	37.6	38.4	39.3	40.2	41.1	42	42.9	43.8	44.7	45.6	46.5	47.3	48.2	49.1	50	50.9
Maximum speed (mm/sec)	2200		-		1900		-		1500		-		1200		-		900		-	
Speed setting	-		-		86%		-		68%		-		54%		-		40%		36%	

Note 5. When the stroke exceeds 1200mm, although depending on the moving range, the ball screw may resonate (critical speed). In that case, make adjustment to lower the speed on the program using the maximum speed given in the above table as a guide.

# GF17XL

Origin on the non-motor side is selectable

Note. If you need an installation posture other than the horizontal installation, please contact us.

## Ordering method

### GF17XL - S H - 20

Model	Model	Installation direction	Lead designation	Cable entry location	Origin position change	Frame	Grease type	Stroke	Cable length
S: Straight model	H: Horizontal installation	No entry: Standard (S) U: From the top R: From the right L: From the left	No entry: Standard Z: Non-motor side	No entry: Standard (Spot facing) T: Tapping	None: Standard GC: Clean	850 to 2500 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)		

TSX	220	SR1-X	20	RDV-X	2	20	RBR1
Positioner TS-X	Driver: Power supply voltage / Power capacity 220: 200V/400 to 600W	Controller 20: 400 to 600W	Usable for CE No entry: Standard E: CE marking R: With RGT	Driver 2: AC200V	Driver: Power capacity 20: 600W or less	Regenerative unit No entry: None L: With LCD	I/O selection N: NPN P: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board


- Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.  
 Note 4. When operating the robot at a speed that is a maximum speed of 750 mm/sec or less, the regenerative unit is not needed.

- [Cautions after purchase]  
 • When changing the origin position, contact us since the adjustment is needed.  
 • When changing the cable entry location, contact us since necessary parts may vary depending on the cable entry location.  
 • Do not install the robot with the horizontal installation specifications in a direction other than the horizontal direction.

## Specifications

AC servo motor output (W)	400
Repeatability (mm)	+/-0.01
Deceleration mechanism	Ball screw $\phi$ 20 (Class C7)
Ball screw lead (mm)	20
Maximum speed (mm/sec)	1200
Maximum payload (kg)	90
Rated thrust (N)	339
Stroke (mm)	850 to 2500 (50mm pitch)
Overall length (mm)	Stroke+686
Maximum dimensions of cross section of main unit (mm)	W168xH105.5
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves x 2 rail
Position detector	Resolvers
Resolution (Pulse/rotation)	20480


## Allowable overhang



Horizontal installation (Unit: mm)	A	B	C
30kg	4050	1090	1405
50kg	2755	650	835
90kg	1610	345	450

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.  
 Note. Service life is calculated for 1000mm stroke models.

## Static loading moment




(Unit: N·m)		
MY	MP	MR
1032	1034	908

## Controller

Controller	Operation method
SR1-X20 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X220	I/O point trace / Remote command
RDV-X220-RBR1	Pulse train control

Note. To operate the unit at a speed exceeding 750 mm/sec. (Max. speed), a regeneration unit is required.

## GF17XL




- Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. When changing the return-to-origin direction, the adjustment is needed. (The standard is the origin on the motor side.)  
 Note 3. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 4. The cable's minimum bend radius is R30.  
 Note 5. The length under head of the hexagonal socket head bolts (M8 x 1.25) that are used to install the main body with the spot facing hole installation specifications is 45 mm or more. It is recommended that the length under head of the hexagonal socket head bolts (M8 x 1.25) that are used to install the main body with the tapping hole installation specifications is the thickness of the installation base + 15 mm or less.

Effective stroke	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450	1500	1550	1600	1650	1700	1750	1800	1850	1900	1950	2000	2050	2100	2150	2200	2250	2300	2350	2400	2450	2500
L	1536	1586	1636	1686	1736	1786	1836	1886	1936	1986	2036	2086	2136	2186	2236	2286	2336	2386	2436	2486	2536	2586	2636	2686	2736	2786	2836	2886	2936	2986	3036	3086	3136	3186
A	1250	1300	1350	1400	1450	1500	1550	1600	1650	1700	1750	1800	1850	1900	1950	2000	2050	2100	2150	2200	2250	2300	2350	2400	2450	2500	2550	2600	2650	2700	2750	2800	2850	2900
B	16	16	16	18	18	18	18	20	20	20	20	22	22	22	22	22	22	24	24	24	26	26	26	26	28	28	28	30	30	30	30	32	32	32
C	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150
Weight (kg)	37.4	38.4	39.4	40.3	41.3	42.3	43.2	44.2	45.2	46.1	47.1	48.1	49.0	50.0	51.0	51.9	52.9	53.9	54.8	55.8	56.8	57.7	58.7	59.7	60.6	61.6	62.6	63.5	64.5	65.5	66.4	67.4	68.4	69.3



- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- T type
- F type
- GF type
- N type
- B/R type

## F20 High lead type: Lead 40



Note 1. Stop positions are determined by the mechanical stoppers at both ends.

Note 3. Minimum bend radius of motor cable is R50.

Note 2. When installing the robot, do not use washers inside the robot body.

Effective stroke	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450
L	627	677	727	777	827	877	927	977	1027	1077	1127	1177	1227	1277	1327	1377	1427	1477	1527	1577	1627	1677	1727	1777	1827	1877
A	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100
M	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	6	6	6	6	7	7	7	7	7	8	8
N	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18	18	20	20
K	420	420	420	420	600	600	600	600	780	780	780	780	960	960	960	960	1140	1140	1140	1320	1320	1320	1320	1320	1320	1320
Weight (kg)	21.2	22.2	23.1	24.0	25.0	25.9	26.8	27.7	28.7	29.6	30.5	31.4	32.3	33.2	34.2	35.1	36.0	36.9	37.9	38.8	39.7	40.6	41.5	42.4	43.3	44.2
Maximum speed <sup>Note 4</sup> (mm/sec)	Lead 40		2400																							
Speed setting			-																							
			80%																							
			70%																							
			60%																							
			50%																							
			40%																							
			35%																							
			30%																							

Note 4. When the stroke is longer than 800mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.

Note 5. Longer than 1250mm stroke can be handled by the high lead specification (Lead 40) only.

# F20N



## Ordering method

### F20N - 20

<b>Model</b>	<b>Lead designation</b>	<b>Origin position change</b>	<b>Grease type</b>	<b>Stroke</b>	<b>Cable length<sup>Note 1</sup></b>
		None: Standard 2: Non-motor side	None: Standard GC: Clean	1150 to 2050 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)

<b>TSX</b>	<b>220</b>				
<b>Positioner<sup>Note 2</sup></b>	<b>Driver: Power-supply voltage / Power capacity</b>	<b>Regenerative unit</b>	<b>LCD monitor</b>	<b>I/O selection</b>	<b>Battery</b>
TS-X	220: 200V/400 to 600W	No entry: None R: With RGT	No entry: None L: With LCD	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	B: With battery (Absolute) N: None (Incremental)
<b>SR1-X</b>	<b>20</b>				
<b>Controller</b>	<b>Driver: Power capacity</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>I/O selection</b>	<b>Battery</b>
	20: 400 to 600W	No entry: Standard E: CE marking	No entry: None R: With RGT	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	B: With battery (Absolute) N: None (Incremental)
<b>RDV-X</b>	<b>2</b>	<b>20</b>			
<b>Driver</b>	<b>Power-supply voltage</b>	<b>Driver: Power capacity</b>	<b>RBR1</b>	<b>Regenerative unit</b>	
	2: AC200V	20: 600W or less			


Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Specifications

AC servo motor output (W)	400
Repeatability <sup>Note 1</sup> (mm)	+/-0.04
Deceleration mechanism	Ball screw (Class C10)
Ball screw lead (mm)	20
Maximum speed (mm/sec)	1000 (1200 <sup>Note 2</sup> )
Maximum payload (kg)	80
Rated thrust (N)	339
Stroke (mm)	1150 to 2050 (100mm pitch)
Overall length (mm)	Stroke+420
Maximum dimensions of cross section of main unit (mm)	W202 x H120
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves x 2 rail
Position detector	Resolvers <sup>Note 3</sup>
Resolution (Pulse/rotation)	16384

Note 1. Positioning repeatability in one direction.  
Note 2. A regenerative unit is needed if using the SR1-X, TS-X at maximum speeds exceeding 1000mm/sec.. If using the RDV-X, then the regenerative unit RBR1 is required regardless of the installation conditions.  
Note 3. Position detectors(resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.


## Allowable overhang<sup>Note</sup>



Lead 20	Horizontal installation (Unit: mm)			
		A	B	C
	20kg	3397	2332	2683
	40kg	2795	1144	1361
	60kg	2443	749	914
	80kg	2193	551	695

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment




(Unit: N-m)		
MY	MP	MR
1196	1199	1052

## Controller


Controller	Operation method
SR1-X20 <sup>Note</sup> RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X220 <sup>Note</sup> RDV-X220-RBR1	I/O point trace / Remote command / Pulse train control

Note. When the unit is operated at a speed exceeding the maximum speed of 1,000mm/sec., a regeneration unit is required.


## F20N



C section detailed chart



Cross section of cable guide



Effective stroke	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050
L	1570	1670	1770	1870	1970	2070	2170	2270	2370	2470
A	100	200	100	200	100	200	100	200	100	200
B	602	648	694	740	786	832	878	924	970	1016
E	1320	1320	1320	1320	1320	1320	1320	1320	1320	1320
M	7	7	8	8	9	9	10	10	11	11
N	18	18	20	20	22	22	24	24	26	26
Weight (kg)	54.0	56.2	58.4	60.6	62.9	65.1	67.3	69.6	71.8	74.0

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. The shaded position indicates the user cable extraction port.  
Note 3. When installing the robot, do not use washers inside the robot body.  
Note 4. The origin is set on the left (L) side of the slipping.

# N15



## Ordering method

### N15-20

Model	Lead designation	Cable carrier entry location	Cable carrier specification	Origin position change	Grease type	Stroke	Cable length
		RH: Horizontal, right LH: Horizontal, left RW: Wall, right LW: Wall, left	S: Standard M: Optional C: Cable carrier	Horizontal: None, R side (Standard) Z: L side Wall: None, L side (Standard) Z: R side	None: Standard GC: Clean	500 to 2000 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)

TSX	220	R			
Positioner	Driver: Power-supply voltage / Power capacity 220: 200V/400 to 600W	Regenerative unit R: With RGT	LCD monitor No entry: None L: With LCD	I/O selection NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	Battery B: With battery (Absolute) N: None (Incremental)
SR1-X	20		R		
Controller	Driver: Power capacity 20: 400 to 600W	Usable for CE No entry: Standard E: CE marking	Regenerative unit R: With RG1	I/O selection N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	Battery B: With battery (Absolute) N: None (Incremental)
RDV-X	2		20		RBR1
Driver	Power-supply voltage 2: AC200V		Driver: Power capacity 20: 600W or less		Regenerative unit

Note 1. To find information on cable carrier extraction directions see P.173.  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Specifications

AC servo motor output (W)	400
Repeatability (mm)	+/-0.01
Deceleration mechanism	Ball screw φ15 (Class C7)
Ball screw lead (mm)	20
Maximum speed (mm/sec)	1200
Maximum payload (kg)	50
Rated thrust (N)	339
Stroke (mm)	500 to 2000 (100mm pitch)
Overall length (mm)	Stroke+330
Maximum dimensions of cross section of main unit (mm)	W145 × H120
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves × 2 rail
Position detector	Resolvers
Resolution (Pulse/rotation)	16384

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may not be reached when the moving distance is short.  
 Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang

	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)		
	A	B	C	A	B	C
Lead 20	10kg 3048	2322	1259	10kg 1258	1823	2449
	30kg 1489	841	500	30kg 428	545	1039
	50kg 1278	544	344	50kg 248	289	749

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
691	692	608


## Controller

Controller	Operation method
SR1-X20-R RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X220-R	I/O point trace / Remote command
RDV-X220-RBR1	Pulse train control

## Cable carrier for users




## N15: Horizontal installation / Standard Cable carrier specification RH




Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. When using φ7 holes for installation, do not use a washer, spring washer, etc. in the main unit.  
 Note 3. When shipped from the factory, the horizontal model has the origin on the right side and the wall model has the origin on the left side. (This diagram shows the machine whose cable carrier taken out from right.)  
 Note 4. If the model is a standard cable carrier specification, it is not possible to pass 3 or more φ6 × 4 urethane air hoses.  
 Note 5. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 6. Contact us for vertical installation.  
 Note 7. Weight of models with no brake. The weight of brake-attached models is 1 kg heavier than the models with no brake shown in the table.  
 Note 8. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
A	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
B	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
C	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
D	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
E	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
F	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
G	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
Weight (kg)	19	20	22	23	24	26	27	29	30	32	33	35	36	38	39	40


N15: Horizontal installation / Optional Cable carrier specification **RH**



N15: Wall installation / Standard Cable carrier specification **RW**



N15: Wall installation / Optional Cable carrier specification **RW**



- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XX-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- T type
- F type
- GF type
- N type
- BR type

# N15D

Double carriage

## Ordering method

<b>N15D-20</b>							<b>RCX222HP</b>				<b>R</b>			
Model	Lead designation	Installation direction	Cable carrier specification	Option	Stroke	Cable length	Controller <sup>Note 1</sup>	Usable for CE	Regenerative unit	I/O selection 1	I/O selection 2			
		H: Horizontal installation W: Wall installation	S: Standard Cable carrier M: Optional Cable carrier	Grease type None: Standard GC: Clean	250 to 1750 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 5</sup>	RCX222HP SR1-X (2 units) <sup>Note 2</sup> TS-X (2 units) <sup>Note 2</sup> RDV-X (2 units) <sup>Note 2</sup>	No entry : Standard E: CE marking	R: RG2	N: NPN <sup>Note 3</sup> P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet <sup>Note 3</sup>	No entry: None NT: OPDIO24/16 (NPN) <sup>Note 3</sup> Pt: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3, Note 4</sup>			

- Note 1. To find controller selection options for other than the RCX222HP, see the ordering method on each controller page.  
 Note 2. 2 units are required when using SR1-X, TS-X or RDV-X.  
 Note 3. NPN and Ethernet cannot be selected when using CE marking.  
 Note 4. Only when you have selected CC, DN or PB for Input/Output selection 1, you can select EN for Input/Output selection 2.  
 Note 5. If a flexible cable is needed for the SR1-X, TS-X, or RDV-X, then select 3K/5K/10K. On the RCX222HP, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.

## Specifications

AC servo motor output (W)	400
Repeatability <sup>Note 1</sup> (mm)	+/-0.01
Deceleration mechanism	Ball screw $\phi 15$ (Class C7)
Ball screw lead (mm)	20
Maximum speed <sup>Note 2</sup> (mm/sec)	1200
Maximum payload (kg)	50
Rated thrust (N)	339
Stroke (mm)	250 to 1750 (100mm pitch)
Overall length (mm)	Stroke+330
Maximum dimensions of cross section of main unit (mm)	W145 x H120
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves x 2 rail
Position detector	Resolvers <sup>Note 3</sup>
Resolution (Pulse/rotation)	16384

- Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may not be reached when the moving distance is short.  
 Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.

## Allowable overhang<sup>Note</sup>

Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				
	A	B	C		A	B	C	
Lead 20	10kg	3048	2322	1259	10kg	1258	1823	2449
	30kg	1489	841	500	30kg	428	545	1039
	50kg	1278	544	344	50kg	248	289	749

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


(Unit: N·m)		
MY	MP	MR
691	692	608

## Controller


Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication
SR1-X20-R <sup>Note</sup>	I/O point trace / Remote command
TS-X220-R <sup>Note</sup>	I/O point trace / Remote command
RDV-X20-RBR1 <sup>Note</sup>	Pulse train control

Note. 2 units are required when using SR-1, TS-X or RDV-X.

## Cable carrier for users



## N15D: Horizontal installation / Standard Cable carrier specification




- Note 1. Position of table carriage when searched to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. When using  $\phi 7$  holes for installation, do not use a washer, spring washer, etc. in the main unit.  
 Note 4. If the model is a standard cable carrier specification, it is not possible to pass 3 or more  $\phi 6 \times 4$  urethane air hoses.  
 Note 5. When using a  $\phi 10H7$  hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 6. Contact us for vertical installation.  
 Note 7. Weight of models with no brake. The weight of brake attached models is 1 kg heavier than the models with no brake shown in the table.  
 Note 8. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.


Effective stroke	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
A	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
B	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
C	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
D	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
E	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
F	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
G	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
Weight (kg) <sup>Note 7</sup>	24	26	27	29	30	32	33	35	36	38	39	40	42	43	45	46




N15D: Horizontal installation / Optional Cable carrier specification



N15D: Wall installation / Standard Cable carrier specification



N15D: Wall installation / Optional Cable carrier specification



# N18



## Ordering method

**N18- 20**

<b>Model</b>	<b>Lead designation</b>	<b>Cable carrier entry location</b> RH: Horizontal, right LH: Horizontal, left RW: Wall, right LW: Wall, left	<b>Cable carrier specification</b> S: Standard C: Cable carrier M: Optional W: Wall	<b>Origin position change</b> Horizontal: None, R side (Standard) Z: L side Wall: None, L side (Standard) Z: R side	<b>Grease type</b> None, Standard GC: Clean	<b>Stroke</b> 500 to 2500 (100mm pitch)	<b>Cable length</b> <sup>Note 2</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>TSX</b> Positioner <sup>Note 3</sup> TS-X	<b>220</b> Driver: Power-supply voltage / Power capacity 220: 200V/400 to 600W	<b>R</b> Regenerative unit R: With RGT	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN P: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 4</sup>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
<b>SR1-X</b>	<b>20</b>							<b>Controller</b> SR1-X	<b>Driver: Power capacity</b> 20: 400 to 600W	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>R</b> Regenerative unit R: With RGT	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
<b>RDV-X</b>	<b>2</b>							<b>Driver</b> RDV-X	<b>Power-supply voltage</b> 2: AC200V		<b>20</b> Driver: Power capacity 20: 600W or less	<b>RBR1</b> Regenerative unit	


Note 1. To find information on cable carrier extraction directions see P.173.  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Specifications

AC servo motor output (W)	400
Repeatability <sup>Note 1</sup> (mm)	±0.01
Deceleration mechanism	Ball screw φ20 (Class C7)
Ball screw lead (mm)	20
Maximum speed <sup>Note 2</sup> (mm/sec)	1200
Maximum payload (kg)	80
Rated thrust (N)	339
Stroke (mm)	500 to 2500 (100mm pitch)
Overall length (mm)	Stroke+362
Maximum dimensions of cross section of main unit (mm)	W180 × H115
Cable length (m)	Standard: 3.5 / Option: 5.10
Linear guide type	4 rows of circular arc grooves × 2 rail
Position detector	Resolvers <sup>Note 3</sup>
Resolution (Pulse/rotation)	16384

Note 1. Repeatability for single oscillation.  
 Note 2. The maximum speed may not be reached when the moving distance is short.  
 Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.


## Allowable overhang<sup>Note</sup>



Lead 20	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)		
	A	B	C	A	B	C
30kg	3045	1629	1902	30kg	1928	1553 3045
50kg	2602	961	1150	50kg	1157	885 2602
80kg	2193	586	716	80kg	707	509 2193

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment




(Unit: N·m)		
MY	MP	MR
1161	1163	1021

## Controller

Controller	Operation method
SR1-X20-R RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X220-R	I/O point trace / Remote command
RDV-X220-RBR1	Pulse train control


## Cable carrier for users

**S type** Standard cable carrier



Note. Cannot pass more than 3 urethane hoses (φ6 × 4).


**M type** Optional cable carrier



Space for optional cable for users

## N18: Horizontal installation / Standard Cable carrier specification


RH




Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. When using φ9 holes for installation, do not use a washer, spring washer, etc. in the main unit.  
 Note 3. When shipped from the factory, the horizontal model has the origin on the right side and the wall model has the origin on the left side. (This diagram shows the machine whose cable carrier taken out from right.)  
 Note 4. If the model is a standard cable carrier specification, it is not possible to pass 3 or more φ6 × 4 urethane air hoses.  
 Note 5. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 6. Contact us for vertical installation.  
 Note 7. For the robot with more than 2,100 stroke, a roller is installed to prevent the cable carrier hanging.  
 Note 8. Weight of models with no brake. The weight of brake-attached models is 1 kg heavier than the models with no brake shown in the table.  
 Note 9. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500
L	862	962	1062	1162	1262	1362	1462	1562	1662	1762	1862	1962	2062	2162	2262	2362	2462	2562	2662	2762	2862
A	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131
B	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13
C	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28
D	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650
Weight (kg) <sup>Note 8</sup>	27	29	31	33	35	37	39	41	43	45	47	48	50	52	54	56	58	60	62	64	66


N18: Horizontal installation / Optional Cable carrier specification **RH**



N18: Wall installation / Standard Cable carrier specification **RW**



N18: Wall installation / Optional Cable carrier specification **RW**



- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XX-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- T type
- F type
- GF type
- N type
- B/R type

# N18D

Double carriage

## Ordering method

<b>N18D - 20</b>							<b>RCX222HP</b>		<b>R</b>		
<b>Model</b>	<b>Lead designation</b>	<b>Installation direction</b>	<b>Cable carrier specification</b>	<b>Option</b>	<b>Stroke</b>	<b>Cable length</b>	<b>Controller</b> <sup>Note 1</sup>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>I/O selection1</b>	<b>I/O selection2</b>
		H: Horizontal installation W: Wall installation	S: Standard Cable carrier M: Optional Cable carrier	Grease type: None: Standard GC: Clean	250 to 2250 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 5</sup>	RCX222HP SR1-X (2 units) <sup>Note 2</sup> TS-X (2 units) <sup>Note 2</sup> RDV-X (2 units) <sup>Note 2</sup>	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 3</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet <sup>Note 3</sup>	No entry: None N1: OP.DI024/16 (PNP) <sup>Note 3</sup> P1: OP.DI024/17 (PNP) EN: Ethernet <sup>Note 3</sup>



Note 1. To find controller selection options for other than the RCX222HP, see the ordering method on each controller page.  
 Note 2. 2 units are required when using SR1-X, TS-X or RDV-X.  
 Note 3. NPN and Ethernet cannot be selected when using CE marking.  
 Note 4. Only when you have selected CC, DN or PB for Input/Output selection 1, you can select EN for Input/Output selection 2.  
 Note 5. If a flexible cable is needed for the SR1-X, TS-X, or RDV-X, then select 3K/5K/10K. On the RCX222HP, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.

## Specifications

<b>AC servo motor output (W)</b>	400
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.01
<b>Deceleration mechanism</b>	Ball screw φ20 (Class C7)
<b>Ball screw lead (mm)</b>	20
<b>Maximum speed</b> <sup>Note 2</sup> (mm/sec)	1200
<b>Maximum payload (kg)</b>	80
<b>Rated thrust (N)</b>	339
<b>Stroke (mm)</b>	250 to 2250 (100 pitch)
<b>Overall length (mm)</b>	Stroke+362
<b>Maximum dimensions of cross section of main unit (mm)</b>	W180 × H115
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5.10
<b>Linear guide type</b>	4 rows of circular arc grooves × 2 rail
<b>Position detector</b>	Resolvers <sup>Note 3</sup>
<b>Resolution (Pulse/rotation)</b>	16384

Note 1. Positioning repeatability in one direction.  
 Note 2. The maximum speed may not be reached when the moving distance is short.  
 Note 3. Position detectors (resolvers) are common to incremental and absolute specifications. If the controller has a backup function then it will be absolute specifications.


## Allowable overhang <sup>Note</sup>

Horizontal installation (Unit: mm)	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)	Wall installation (Unit: mm)		
	A	B	C		A	B	C
<b>Lead 20</b>	3045	1629	1902	<b>Lead 20</b>	3045	1629	1902
<b>30kg</b>	3045	1629	1902	<b>30kg</b>	1928	1553	3045
<b>50kg</b>	2602	961	1150	<b>50kg</b>	1157	885	2602
<b>80kg</b>	2193	586	716	<b>80kg</b>	707	509	2193

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment



(Unit: N·m)		
MY	MP	MR
1161	1163	1021


## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication
SR1-X20-R <sup>Note</sup>	I/O point trace / Remote command
TS-X220-R <sup>Note</sup>	I/O point trace / Remote command
RDV-X20-RBR1 <sup>Note</sup>	Pulse train control


Note. 2 units are required when using SR1-X, TS-X or RDV-X.

## Cable carrier for users

**S type** Standard cable carrier




**M type** Optional cable carrier



Note. Cannot pass more than 3 urethane hoses (φ6 × 4).

Space for optional cable for users


## N18D: Horizontal installation / Standard Cable carrier specification




Note 1. Position of table carriage when searched to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. When using φ9 holes for installation, do not use a washer, spring washer, etc. in the main unit.  
 Note 4. If the model is a standard cable carrier specification, it is not possible to pass 3 or more φ6 × 4 urethane air hoses.  
 Note 5. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 6. Contact us for vertical installation.  
 Note 7. For the robot with more than 2,050 stroke, a roller to prevent the cable carrier from hanging is provided.  
 Note 8. Weight of models with no brake. The weight of brake-attached models is 1 kg heavier than the models with no brake shown in the table.  
 Note 9. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250
<b>L</b>	862	962	1062	1162	1262	1362	1462	1562	1662	1762	1862	1962	2062	2162	2262	2362	2462	2562	2662	2762	2862
<b>A</b>	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131	81	131
<b>B</b>	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13
<b>C</b>	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28
<b>D</b>	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650
<b>Weight (kg)</b> <sup>Note 8</sup>	35	37	39	41	43	45	47	48	50	52	54	56	58	60	62	64	66	68	70	72	74


N18D: Horizontal installation / Optional Cable carrier specification



N18D: Wall installation / Standard Cable carrier specification




N18D: Wall installation / Optional Cable carrier specification






B10 RU type (Motor rightward, upper position)




Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Cables can be extracted in upward, downward, forward or rearward directions. (This figure shows the downward direction.)

B10 RD type (Motor rightward, lower position)



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Cables can be extracted in upward, downward, forward or rearward directions. (This figure shows the upward direction.)

B10 LU type (Motor leftward, upper position)




Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Cables can be extracted in upward, downward, forward or rearward directions. (This figure shows the downward direction.)







B14 RU type (Motor rightward, upper position)



B14 RD type (Motor rightward, lower position)




B14 LU type (Motor leftward, upper position)






## B14H RU type (Motor rightward, upper position)




- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. Cables can be extracted in upward, downward, forward or rearward directions. (This figure shows the downward direction.)

## B14H RD type (Motor rightward, lower position)



- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. Cables can be extracted in upward, downward, forward or rearward directions. (This figure shows the upward direction.)

## B14H LU type (Motor leftward, upper position)



- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. Cables can be extracted in upward, downward, forward or rearward directions. (This figure shows the downward direction.)

# R5



## Ordering method

### R5

Model	Cable entry location	Cable length <sup>Note 1</sup>
	No entry: Standard (S) B: From the side	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)

### TSX

Positioner <sup>Note 2</sup>	Driver: Power-supply voltage / Power capacity	LCD monitor	I/O selection	Battery
TS-X	105: 100V/100W or less 205: 200V/100W or less	No entry: None L: With LCD	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	B: With battery (Absolute) N: None (Incremental)

### SR1-X

Controller	05	Usable for CE	I/O selection	Battery
	Driver: Power capacity 05: 100W or less	No entry: Standard E: CE marking	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	B: With battery (Absolute) N: None (Incremental)

### RDV-X

Driver	2	05	RBR1
	Power-supply voltage 2: AC200V	Driver: Power capacity 05: 100W or less	Regenerative unit


Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Specifications

AC servo motor output (W)	50
Repeatability (°)	+/-0.0083
Maximum speed (°/sec)	360
Maximum allowable moment inertia (kgm <sup>2</sup> [kgfcm <sup>2</sup> ])	0.12 [1.2]
Rated torque (Nm[kgfm])	5.29 [0.54]
Speed reduction ratio	1/50
Rotation range (°)	360
Cable length (m)	Standard: 3.5 / Option: 5.10
Speed reducer type	Harmonic drive
Position detector	Resolvers
Resolution (Pulse/rotation)	16384

## Maximum allowable moment inertia

Payload parameters W (kg)	1	2	3	4	5	6	7	8	9	10
Maximum allowable moment inertia J (kgfcm <sup>2</sup> )	0.12	0.24	0.36	0.48	0.60	0.72	0.84	0.96	1.08	1.20




Note. When the weight of a tool or workpiece attached to the shaft R5 is W (kg), its moment of inertia (J) must be smaller than the values shown in the table above. (For example, enter 4kg if W is 3kg and J is 0.48kgf cm sec<sup>2</sup>) Enter the above mass parameter value for the controller, and optimum acceleration is automatically set based on this value.

Note. For calculation (equation) of the inertia moment, please refer to P.611.

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105	I/O point trace / Remote command
TS-X205	Remote command
RDV-X205-RBR1	Pulse train control

## R5



Weight (kg) 3.0 Note 1. The cable extraction port can be changed.

# R10



## Ordering method

R10			TSX		SR1-X		RDV-X					
<b>Model</b>	<b>Cable entry location</b> No entry: Standard (S) B: From the side	<b>Cable length</b> <small>Note 1</small> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>Positioner</b> <small>Note 2</small> TS-X	<b>Driver: Power-supply voltage / Power capacity</b> 105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <small>Note 3</small>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)	<b>Controller</b>	<b>Driver: Power capacity</b> 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
			<b>Driver</b>	<b>Power-supply voltage</b> 2: AC200V	<b>05</b>	<b>RBR1</b>	<b>Regenerative unit</b>					


Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable.  
See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Specifications

AC servo motor output (W)	100
Repeatability (°)	+/-0.0083
Maximum speed (°/sec)	360
Maximum allowable moment inertia (kgm <sup>2</sup> [kgfcm <sup>2</sup> ])	0.36 [3.71]
Rated torque (Nm[kgfm])	10.78 [1.10]
Speed reduction ratio	1/50
Rotation range (°)	360
Cable length (m)	Standard: 3.5 / Option: 5,10
Speed reducer type	Harmonic drive
Position detector	Resolvers
Resolution (Pulse/rotation)	16384

## Maximum allowable moment inertia

Payload parameters W (kg)	1	2	3	4	5	6	7	8	9	10
Maximum allowable moment inertia J (kgfcm <sup>2</sup> )	0.25	0.49	0.74	0.99	1.24	1.48	1.73	1.98	2.23	2.47
Payload parameters W (kg)	11	12	13	14	15					
Maximum allowable moment inertia J (kgfcm <sup>2</sup> )	2.72	2.97	3.22	3.46	3.71					




Note. When the weight of a tool or workpiece attached to the shaft R10 is W (kg), its moment of inertia (J) must be smaller than the values shown in the table above. (For example, enter 4kg if W is 3kg and J is 0.99kgf cm sec<sup>2</sup>.) Enter the above mass parameter value for the controller, and optimum acceleration is automatically set based on this value.

Note. For calculation (equation) of the inertia moment, please refer to P.611.

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105	I/O point trace /
TS-X205	Remote command
RDV-X205-RBR1	Pulse train control

## R10



Weight (kg) 3.5

Note 1. The cable extraction port can be changed.

Controller

SR1-X ▶ 516 TS-X ▶ 490 RDV-X ▶ 504

# R20



## Ordering method

<b>R20</b>	<b>Model</b>	<b>Cable entry location</b> No entry: Standard (S) B: From the side	<b>Cable length</b> <sup>Note 1</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>TSX</b>	<b>Positioner</b> <sup>Note 2</sup> TS-X	<b>Driver: Power-supply voltage / Power capacity</b> 110: 100V/200W or less 210: 200V/200W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
	<b>SR1-X</b>	<b>Controller</b>	<b>Driver: Power capacity</b> 10: 200W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)			
	<b>RDV-X</b>	<b>Driver</b>	<b>Power-supply voltage</b> 2: AC200V	<b>10</b>	<b>Driver: Power capacity</b> 10: 200W or less	<b>RBR1</b>	<b>Regenerative unit</b>		


Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable.  
See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Specifications

<b>AC servo motor output (W)</b>	200
<b>Repeatability (°)</b>	+/-0.0083
<b>Maximum speed (°/sec)</b>	360
<b>Maximum allowable moment inertia (kgm<sup>2</sup>[kgfcm<sup>2</sup>])</b>	1.83 [18.7]
<b>Rated torque (Nm[kgfm])</b>	21.46 [2.19]
<b>Speed reduction ratio</b>	1/50
<b>Rotation range (°)</b>	360
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5,10
<b>Speed reducer type</b>	Harmonic drive
<b>Position detector</b>	-
<b>Resolution (Pulse/rotation)</b>	16384

## Maximum allowable moment inertia

<b>Payload parameters W (kg)</b>	1	2	3	4	5	6	7	8	9	10
<b>Maximum allowable moment inertia J (kgfcm<sup>2</sup>)</b>	0.93	1.8	2.8	3.7	4.6	5.6	6.5	7.4	8.4	9.3
<b>Payload parameters W (kg)</b>	11	12	13	14	15	16	17	18	19	20
<b>Maximum allowable moment inertia J (kgfcm<sup>2</sup>)</b>	10.2	11.2	12.1	13.1	14	14.9	15.9	16.8	17.7	18.7




Note. When the weight of a tool or workpiece attached to the shaft R20 is W (kg), its moment of inertia (J) must be smaller than the values shown in the table above. (For example, enter 4kg if W is 3kg and J is 3.7kgf cm sec<sup>2</sup>.) Enter the above mass parameter value for the controller, and optimum acceleration is automatically set based on this value.


Note. For calculation (equation) of the inertia moment, please refer to P.611.

## Controller

Controller	Operation method
SR1-X10 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X110	I/O point trace / Remote command
TS-X210	Remote command
RDV-X210-RBR1	Pulse train control

## R20





## LINEAR MOTOR SINGLE-AXIS ROBOTS

# PHASER SERIES

## CONTENTS

■ PHASER SPECIFICATION SHEET .....	216
■ Robot ordering method description .....	216
■ Robot ordering method terminology .....	217
<b>MF TYPE</b>	
MF7/MF7D .....	218
MF15/MF15D .....	224
MF20/MF20D .....	228
MF30/MF30D .....	231
MF75/MF75D .....	234
<b>MR TYPE</b>	
MR12/MR12D .....	236

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

MF type

MR type

# PHASER SPECIFICATION SHEET

Type	Size (mm) <sup>Note 1</sup>	Model	Carrier	Maximum payload (kg)	Maximum speed (mm/sec.)	Stroke (mm)	Detailed info page
<b>MF type</b> Flat type with core Linear motor specifications	W85 × H80	MF7	Single	10 (7) <sup>Note 2</sup>	2500	100 to 4000 (Horizontal) 100 to 2000 (Wall mount)	<a href="#">P.218</a>
		MF7D	Double			100 to 3800 (Horizontal) 100 to 1800 (Wall mount)	<a href="#">P.218</a>
	W100 × H80	MF15	Single	30 (15) <sup>Note 2</sup>		100 to 4000 (Horizontal) 100 to 2000 (Wall mount)	<a href="#">P.224</a>
		MF15D	Double			100 to 3800 (Horizontal) 100 to 1800 (Wall mount)	<a href="#">P.224</a>
	W150 × H80	MF20	Single	40 (20) <sup>Note 2</sup>		150 to 4050	<a href="#">P.228</a>
		MF20D	Double			150 to 3850	<a href="#">P.228</a>
		MF30	Single	60 (30) <sup>Note 2</sup>		100 to 4000	<a href="#">P.231</a>
		MF30D	Double			150 to 3750	<a href="#">P.231</a>
	W210 × H100	MF75	Single	160 (75) <sup>Note 2</sup>		1000 to 4000	<a href="#">P.234</a>
		MF75D	Double			680 to 3680	<a href="#">P.234</a>
<b>MR type</b> Shaft type Linear motor specifications	W60 × H90	MR12	Single	5	50 to 1050	<a href="#">P.236</a>	
		MR12D	Double		50 to 1050	<a href="#">P.236</a>	

Note 1. The size shows approximate maximum cross sectional size.

Note 2. When using at the maximum speed, the maximum payload becomes the value in ( ).

## ⚠️ Precautions for use

### ■ Handling

- Please be sure to read "PHASER Series Instruction Manual" carefully to have full understanding of its contents before using this product and strictly observe each instruction.
- Dropping or hitting this product may cause it to break. Always handle it carefully.
- Never disassemble this product. Entry of a foreign object will cause deterioration of accuracy.
- This product uses a magnetic type linear scale. Do not bring anything that generates a strong magnetic field near the robot itself as it may cause damage to the linear scale.

### ■ Installation place and environment

When installing this product, avoid the place where any of the following conditions applies.

- The ambient temperature is outside of the 0 °C to 40 °C range.
- Dielectric powder such as iron powder, dust, moist, salt or organic solvent is produced and flies in the air.
- Strong electric field, strong magnetic field, etc. occur.
- The product is affected by vibration or impact.
- Dewing occurs, or corrosive gas or combustible gas is generated.
- The product is exposed to direct sun or radiant heat.
- A noise source exists in the surrounding area.
- Inspection and cleaning cannot be performed.

### ■ Safety precaution

- A high performance rare earth magnets are used in the motor section of this product. For this reason, bringing a magnetic response type device or a medical device such as a heart pace maker close to the robot may cause it to malfunction. Be careful not to bring such a device close to the robot.

## Robot ordering method description

In the order format for the YAMAHA linear motor single-axis robots PHASER series, the notation (letters/numbers) for the mechanical section is shown linked to the controller section notation.

### [Example]

#### ● Mechanical ▶ MF20

- Cable carrier take out direction ▶ RH
- Grease ▶ Standard
- Optional cable carrier for users ▶ S
- Stroke ▶ 550mm
- Origin position ▶ Change (R side)
- Cable length ▶ 3.5m

#### ● Controller ▶ SR1-P

- Regenerative unit ▶ Required
- I/O selection ▶ NPN

#### ● Ordering method

**MF20 - RH - S - Z - 550 - 3L - SR1 - P10 - R - N**

Mechanical section

Controller section

This page describes using the ordering form for mechanical components.

To find detailed controller information see the controller page.

SR1-P ▶ [P.516](#), TS-P ▶ [P.490](#), RDV-P ▶ [P.504](#)

## Mechanical section

### ● Single carriage










① Model		② Cable carrier entry location		④ Optional cable carrier for users		⑤ Origin position change		⑥ Grease type		⑦ Stroke		⑧ Cable length	
MF7	MF7A	RH	Horizontal, right	No entry	None	No entry	L side	No entry	Standard	3L	3.5m	5L	5m
MF15	MF15A	LH	Horizontal, left	S	S type	Z	R side	GC	Clean	10L	10m	3K	3.5m
MF20	MF20A	RW	Wall mounted, right	M	M type					5K	5m	5K	5m
MF30	MF30A	LW	Wall mounted, left	L	L type					10K	10m	10K	10m
MF75	MF75A												

### ● Double carriage

① Model		③ Installing direction		④ Optional cable carrier for users		⑥ Grease type		⑦ Stroke		⑧ Cable length	
MF7D	MF7AD	H	Horizontal installation	No entry	None	No entry	Standard	3L	3.5m	5L	5m
MF15D	MF15AD			S	S type	GC	Clean	10L	10m	3K	3.5m
MF20D	MF20AD	W	Wall mounted installation	M	M type			5K	5m	5K	5m
MF30D	MF30AD			L	L type			10K	10m	10K	10m
MF75D	MF75AD										



# Robot ordering method terminology

<p>① <b>Model</b></p>	<p>Enter the robot unit model. Select from 2 types: incremental specifications and semi-absolute specifications.</p>
<p>② <b>Cable carrier entry location</b></p>	<p>Select what direction to install the robot (horizontal / wall mounted) and what direction to extract the robot cable carrier.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> <p><b>RH</b> Horizontal, right</p>  </div> <div style="text-align: center;"> <p><b>RW</b> Wall hanging, right</p>  </div> <div style="text-align: center;"> <p><b>LH</b> Horizontal, left</p>  </div> <div style="text-align: center;"> <p><b>LW</b> Wall hanging, left</p>  </div> </div> <p>Note. Be sure to install in the direction as specified (in cable carrier take-out direction drawing and various specification drawings) individually. Installation in any other way will cause a failure. For requirement of installation in any way other than the above standard installation, please consult YAMAHA as special arrangement will be available.</p>
<p>③ <b>Installing direction</b></p>	<p>Select what direction to install the robot (horizontal / wall mounted).</p> <p>Please specify if a cable carrier is needed for customer wiring. <b>[MF type]</b> (For MF20)</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>S type</b></p>  </div> <div style="text-align: center;"> <p><b>M type</b></p>  </div> <div style="text-align: center;"> <p><b>L type</b></p>  </div> </div> <p>Cable and pipe guide S : <math>\phi 8</math> flexible cable x 1, <math>\phi 4</math> air tube x 1 M : <math>\phi 8</math> flexible cable x 2, <math>\phi 6</math> air tube x 2 L : <math>\phi 8</math> flexible cable x 2, <math>\phi 8</math> air tube x 3</p> <p style="text-align: right;"><span style="border: 1px solid black; display: inline-block; width: 10px; height: 10px;"></span> Space for optional cable for users</p> <p><b>[MR type]</b></p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p><b>S type</b></p>  </div> <div style="text-align: center;"> <p><b>M type</b></p>  </div> </div> <p style="text-align: center;"><span style="border: 1px solid black; display: inline-block; width: 10px; height: 10px;"></span> Space for optional cable for users</p> <p>Note. The cable and air hoses should take up less than 30% of the space when storing them inside the cable carrier. Lay out the cables and air hoses in rows inside the cable carrier so they do not cross each other.</p>
<p>⑤ <b>Origin position change</b></p>	<p>Origin point position can be changed.</p>
<p>⑥ <b>Grease type</b></p>	<p>Clean grease can be selected.</p>
<p>⑦ <b>Stroke</b></p>	<p>Select the stroke for the robot operating range.</p>
<p>⑧ <b>Cable length</b></p>	<p>Select the length of the robot cable connecting the robot to the controller.</p> <p><b>3L</b> : 3.5m (Standard)  <b>5L</b> : 5m  <b>10L</b> : 10m  <b>3K</b> : 3.5m (Flexible cable)  <b>5K</b> : 5m (Flexible cable)  <b>10K</b> : 10m (Flexible cable)</p>

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- MF type
- MR type

# MF7/MF7D

- Flat type available
- Can be used for wall-mount



## Ordering method

### Single carriage model

**MF7**

<b>Model</b> MF7: Incremental MF7A: Semi-absolute <sup>Note 1</sup>	<b>Cable carrier entry location</b> RH: Horizontal, right LH: Horizontal, left FRH: Horizontal, right (Flat) FLH: Horizontal, left (Flat) RW: Wall mount, right LW: Wall mount, left	<b>Optional cable carrier for users<sup>Note 2</sup></b> No entry: None S: S type M: M type L: L type	<b>Origin position change</b> No entry: L side (Standard) Z: R side No entry: R side (Standard) Z: L side	<b>Grease type</b> No entry: Standard GC: Clean	<b>Stroke<sup>Note 3</sup></b> Horizontal (100mm pitch) 100 to 4000 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 5</sup>	<b>Cable length<sup>Note 4</sup></b> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 5</sup>
---	--	---	---	---	--	---

**TSP**

<b>Positioner<sup>Note 6</sup></b> TS-P	<b>Driver: Power-supply voltage / Power capacity</b> 110: 100V/200W 210: 200V/200W	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ GW: No I/O board <sup>Note 7</sup>
--	--	---	---

**SR1-P** **10**

<b>Controller</b>	<b>Driver: Power capacity</b> 10: 200W	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS
-------------------	---	---	---

**RDV-P** **2** **10** **RBR1**

<b>Driver</b>	<b>Power-supply voltage</b> 2: AC200V	<b>Driver: Power capacity</b> 10: 200W or less	<b>Regenerative unit</b>
---------------	--	---	--------------------------

- Note 1. For the details of the semi-absolute model, please refer to P.33. RDV-P has an incremental model only.  
 Note 2. For models with a 2,100mm or longer stroke, optional L type cable carriers can only be used. Flat type cannot be selected for L type.  
 Note 3. Maximum stroke for flat type is 2000mm.  
 Note 4. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 5. If a flexible cable is needed for the SR1-P, TS-P, or RDV-P, then select 3K/5K/10K. On the RCX221, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.  
 Note 6. These controllers can be mounted on DIN rails. See P.498 for details.  
 Note 7. Select this selection when using the gateway function. For details, see P.60.  
 Note. It is possible to provide the model without a cable carrier. To find information on wiring (cable terminals) within the cable carrier see P.602.

### Double carriage model

**MF7D**

<b>Model</b> MF7D: Incremental MF7AD: Semi-absolute <sup>Note 1</sup>	<b>Installing direction</b> H: Horizontal installation FH: Horizontal installation (Flat) W: Wall mount installation	<b>Optional cable carrier for users<sup>Note 2</sup></b> No entry: None S: S type M: M type L: L type	<b>Grease type</b> No entry: Standard GC: Clean	<b>Stroke<sup>Note 3</sup></b> Horizontal (100mm pitch) 100 to 3800 100 to 1800 (100mm pitch) Wall	<b>Cable length</b> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 5</sup>	<b>RCX221 Controller</b> RCX221 SR1-P (2 units) TS-P (2 units) RDV-P (2 units)	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection 1</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet	<b>I/O selection 2</b> No entry: None N1: OPDI024/16 (NPN) P1: OPDI024/17 (PNP) EN: Ethernet
---	---	---	---	---	--	--	---	---	--


## Specifications

Model	MF7	MF7D
<b>Driving method</b>	Steel cored linear motor with falt magnet	
<b>Repeatability (µm)</b>	+/-5	
<b>Scale (µm)</b>	Magnetic type: resolution of 1	
<b>Maximum speed<sup>Note 2</sup> (mm/sec)</b>	2500	
<b>Rated thrust (N)</b>	37	
<b>Maximum payload (kg)</b>	Horizontal 10 <sup>Note 1</sup>	7
<b>Stroke (mm)</b>	<b>Horizontal</b>	100 to 4000 (100mm pitch) / 100 to 3800 (100mm pitch)
	<b>Wall mount</b>	100 to 2000 (100mm pitch) / 100 to 1800 (100mm pitch)
<b>Linear guide</b>	4 rows of circular arc grooves × 1 rail	
<b>Maximum cross-section outside dimensions (mm)</b>	W85 × H80 (except the cable carrier section)	
<b>Total length (mm)</b>	Stroke+280	Stroke+480
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5.10	


Note. A vertical model (with brake) is not available with the PHASER series.  
 Note. The basic specifications of semi-absolute model are the same as those of the incremental model.

Note 1. Payload per carrier. When the payload exceeds 7kg, please consult our sales office or sales representative.

Note 2. Table of maximum speed



## Allowable overhang



	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)		
	A	B	C	A	B	C
<b>1kg</b>	3000	3000	680	700	3000	3000
<b>3kg</b>	3000	1350	215	195	1260	3000
<b>5kg</b>	2900	830	125	90	630	2480
<b>7kg</b>	2400	580	85	50	360	1680
<b>9kg</b>	2200	460	60			
<b>10kg</b>	2100	410	55			

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment

MY	MP	MR
156	156	194

(Unit: N·m)

## Controller

Controller	Operating method
SR1-P10	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221 RCX240/340	Operation using RS-232C communication
TS-P110	I/O point trace / Remote command
TS-P210	Remote command
RDV-P210-RBR1	Pulse train control

## Cable carrier entry location

<b>RH Horizontal, right</b>	<b>LH Horizontal, left</b>
<b>RW Wall mounted, right</b>	<b>LW Wall mounted, left</b>

Note. Be sure to install in the direction as specified (in cable carrier take-out direction drawing and various specification drawings) individually. Installation in any other way will cause a failure. For requirement of installation in any way other than the above standard installation, please consult YAMAHAs as special arrangement will be available.

## Optional cable carrier for users

<b>S type</b>	<b>M type</b>	<b>L type</b>
---------------	---------------	---------------

Cable and air tube guide

S: φ8 flexible cable x 1, φ4 air tube x 1  
 M: φ8 flexible cable x 2, φ6 air tube x 2  
 L: φ8 flexible cable x 2, φ8 air tube x 3

Space for optional cable for users

MF7 single carriage horizontal mount model **RH**

**Optional cable carrier M type**      **Optional cable carrier S type**

**Detail of section D**      **Cross-section of E-E**

**Cross-section of cable carrier**

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	380	480	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280
A	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
B	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46
C	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100
Weight (kg)	5.8	6.5	7.3	8	8.7	9.4	10.1	10.9	11.6	12.3	13	13.7	14.5	15.2	15.9	16.6	17.3	18.1	18.8	19.5

MF7 single carriage wall mount model **RW**

**Cross-section of optional cable carrier**      **Cross-section of F-F**


**Detail of section G**

**Cross-section of optional cable carrier**      **Optional cable carrier M type**      **Standard and S types**

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	380	480	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280
A	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
B	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46
C	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100
D	220	270	320	370	420	470	520	570	620	670	720	770	820	870	920	970	1020	1070	1120	1170
Weight (kg)	5.8	6.5	7.3	8	8.7	9.4	10.1	10.9	11.6	12.3	13	13.7	14.5	15.2	15.9	16.6	17.3	18.1	18.8	19.5

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
MF type  
MR type


## MF7 single carriage horizontal mount model **RH-L** Optional L-type cable carrier



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. The origin is set on the L side at the time of shipment. It can be changed to the R side by parameter setting.  
 Note 3. The drawings on this page show the unit with horizontal-right-type cable carrier (RH).  
 Note 4. For models with a 3,000mm or longer stroke, a roller is installed to prevent the cable carrier from sagging.  
 Note 5. Protrusion is the distance the cable carrier extends from the edge of the unit.  
 Note 6. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000
<b>L</b>	380	480	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280	2380	2480	2580	2680	2780	2880	2980	3080	3180	3280	3380	3480	3580	3680	3780	3880	3980	4080	4180	4280
<b>A</b>	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42
<b>B</b>	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78	80	82	84	86
<b>C</b>	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100
<b>Weight (kg)</b>	5.8	6.5	7.3	8.0	8.7	9.4	10.1	10.9	11.6	12.3	13.0	13.7	14.5	15.2	15.9	16.6	17.3	18.1	18.8	19.5	20.2	20.9	21.7	22.4	23.1	23.8	24.5	25.3	26.0	26.7	27.4	28.1	28.9	29.6	30.3	31.0	31.7	32.5	33.2	33.9

## MF7 single carriage horizontal mount model **FRH** Flat type



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. The origin is set on the L side at the time of shipment. It can be changed to the R side by parameter setting.  
 Note 3. The drawings on this page show the unit with horizontal-right-type cable carrier (RH).  
 Note 4. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
<b>L</b>	380	480	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280
<b>A</b>	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
<b>B</b>	8	10	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46
<b>C</b>	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100
<b>Weight (kg)</b>	5.8	6.5	7.3	8	8.7	9.4	10.1	10.9	11.6	12.3	13	13.7	14.5	15.2	15.9	16.6	17.3	18.1	18.8	19.5

MF7D double carriage horizontal mount model **H**

**Optional cable carrier M type**      **Optional cable carrier S type**

**Detail of section D**      **Cross-section of E-E**

**Cross-section of cable carrier**

**Table:**

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280	2380	2480
A	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
B	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46	48	50
C	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300
Weight (kg)	9.3	10.2	11.1	12.0	12.9	13.9	14.8	15.7	16.6	17.5	18.5	19.4	20.3	21.2	22.1	23.1	24.0	24.9	25.8	26.7

**Notes:**  
 Note 1. Position of the table slider when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

MF7D double carriage wall mount model **W**

**Cross-section of optional cable carrier**      **Cross-section of F-F**

**Detail of section G**

**Optional cable carrier L type**      **Optional cable carrier M type**      **Standard and S types**


**Table:**

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800
L	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280
A	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22
B	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46
C	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100
D	220	270	320	370	420	470	520	570	620	670	720	770	820	870	920	970	1020	1070
Weight (kg)	9.3	10.2	11.1	12.0	12.9	13.9	14.8	15.7	16.6	17.5	18.5	19.4	20.3	21.2	22.1	23.1	24.0	24.9

**Notes:**  
 Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Cable carrier's protrusion amount from the mechanical end.  
 Note 3. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

- Articulated robots  
YA
- Linear conveyer/modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XX-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- MF type
- MR type


## MF7D double carriage horizontal mount model (H-L) Optional L-type cable carrier



Note 1. Position of the table slider when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. For models with a 3,000mm or longer stroke, a roller is installed to prevent the cable carrier from sagging.  
 Note 4. Protrusion is the distance the cable carrier extends from the edge of the unit.  
 Note 5. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800
L	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280	2380	2480	2580	2680	2780	2880	2980	3080	3180	3280	3380	3480	3580	3680	3780	3880	3980	4080	4180	4280
A	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42
B	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46	48	50	52	54	56	58	60	62	64	66	68	70	72	74	76	78	80	82	84	86
C	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100
Weight (kg)	9.3	10.2	11.1	12.0	12.9	13.9	14.8	15.7	16.6	17.5	18.5	19.4	20.3	21.2	22.1	23.1	24.0	24.9	25.8	26.7	27.7	28.6	29.5	30.4	31.3	32.3	33.2	34.1	35.0	35.9	36.9	37.8	38.7	39.6	40.5	41.5	42.4	43.3

## MF7D double carriage horizontal mount model (FH) Flat type



Note 1. Position of the table slider when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	580	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280	2380	2480
A	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
B	12	14	16	18	20	22	24	26	28	30	32	34	36	38	40	42	44	46	48	50
C	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300
Weight (kg)	9.3	10.2	11.1	12.0	12.9	13.9	14.8	15.7	16.6	17.5	18.5	19.4	20.3	21.2	22.1	23.1	24.0	24.9	25.8	26.7

Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER


INFORMATION

MF type

MR type

# MF15/MF15D

Can be used for wall-mount



## Ordering method

Single carriage model

**MF15**

Model	Cable carrier entry location	Optional cable carrier for users <sup>Note 2</sup>	Origin position change	Grease type	Stroke	Cable length <sup>Note 3</sup>
MF15: Incremental MF15A: Semi-absolute <sup>Note 1</sup>	RH: Horizontal, right LH: Horizontal, left RW: Wall mount, right LW: Wall mount, left	No entry: None S: S type M: M type L: L type	No entry: L side (Standard) Z: R side No entry: R side (Standard) Z: L side	No entry: Standard GC: Clean	Horizontal (100mm pitch) Wall (100 to 2000 (100mm pitch))	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 4</sup>

**TSP**

Positioner <sup>Note 5</sup>	Driver: Power-supply voltage / Power capacity	LCD monitor	I/O selection
TS-P	110: 100V/200W 210: 200V/200W	No entry: None L: With LCD	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ GW: No I/O board <sup>Note 6</sup>

**SR1-P 10**

Controller	Driver: Power capacity	Usable for CE	I/O selection
	10: 200W	No entry: Standard E: CE marking	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS

**RDV-P 2 10 RBR1**

Driver	Power-supply voltage	Driver: Power capacity	Regenerative unit
	2: AC200V	10: 200W or less	

Note 1. For the details of the semi-absolute model, please refer to P.33. RDV-P has an incremental model only.  
 Note 2. For models with a 2,100mm or longer stroke, optional L type cable carriers can only be used.  
 Note 3. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 4. If a flexible cable is needed for the SR1-P, TS-P, or RDV-P, then select 3K/5K/10K. On the RCX221, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.  
 Note 5. These controllers can be mounted on DIN rails. See P.498 for details.  
 Note 6. Select this selection when using the gateway function. For details, see P.60.  
 Note. It is possible to provide the model without a cable carrier. To find information on wiring (cable terminals) within the cable carrier see P.602.

Double carriage model

**MF15D**

Model	Installing direction	Optional cable carrier for users <sup>Note 2</sup>	Grease type	Stroke	Cable length
MF15D: Incremental MF15AD: Semi-absolute <sup>Note 1</sup>	H: Horizontal installation W: Wall mount installation	No entry: None S: S type M: M type L: L type	No entry: Standard GC: Clean	Horizontal (100mm pitch) Wall (100 to 1800 (100mm pitch))	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 4</sup>

**RCX221**

Controller	Usable for CE	I/O selection 1	I/O selection 2
RCX221 SR1-P (2 units) TS-P (2 units) RDV-P (2 units)	No entry: Standard E: CE marking	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet	No entry: None NT: OPDIO24/16 (NPN) PT: OPDIO24/17 (PNP) EN: Ethernet


## Specifications

Model	MF15	MF15D
Driving method	Steel cored linear motor with falt magnet	
Repeatability (μm)	+/-5	
Scale (μm)	Magnetic type: resolution of 1	
Maximum speed <sup>Note 2</sup> (mm/sec)	2500	
Rated thrust (N)	54	
Maximum payload <sup>Note 1</sup> (kg)	30	
Stroke (mm)	Horizontal	100 to 4000 (100mm pitch) / 100 to 3800 (100mm pitch)
	Wall mount	100 to 2000 (100mm pitch) / 100 to 1800 (100mm pitch)
Linear guide	4 rows of circular arc grooves x 2 rail	
Maximum cross-section outside dimensions (mm)	W100 x H80 (except the cable carrier section)	
Total length (mm)	Stroke+260	Stroke+460
Cable length (m)	Standard: 3.5 / Option: 5,10	

Note. A vertical model (with brake) is not available with the PHASER series.  
 Note. The basic specifications of semi-absolute model are the same as those of the incremental model.

Note 1. Payload per carrier. When the payload exceeds 15kg, please consult our sales office or sales representative.

Note 2. Table of maximum speed



## Allowable overhang

**Horizontal installation (Unit: mm)**

	A	B	C
5kg	3000	3000	915
10kg	2604	1542	481
15kg	2368	1051	340
20kg	1820	600	260
25kg	1470	450	175
30kg	1250	310	145

**Wall installation (Unit: mm)**

	A	B	C
5kg	865	1880	3060
10kg	410	905	2115
15kg	255	575	1910
20kg	170	410	1780
25kg	120	295	1660
30kg	90	215	1440

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment

MY	MP	MR
290	291	256

(Unit: N·m)

## Controller

Controller	Operating method
SR1-P10	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221 RCX240/340	Operation using RS-232C communication
TS-P110	I/O point trace / Remote command
TS-P210	Remote command
RDV-P210-RBR1	Pulse train control

## Cable carrier entry location

**RH Horizontal, right** **LH Horizontal, left**

**RW Wall mounted, right** **LW Wall mounted, left**

Note. Be sure to install in the direction as specified (in cable carrier take-out direction drawing and various specification drawings) individually. Installation in any other way will cause a failure. For requirement of installation in any way other than the above standard installation, please consult YAMAHA as a special arrangement will be available.

## Optional cable carrier for users

**S type** **M type** **L type**


Cable and air tube guide

S: φ8 flexible cable x 1, φ4 air tube x 1  
 M: φ8 flexible cable x 2, φ6 air tube x 2  
 L: φ8 flexible cable x 2, φ8 air tube x 3

Space for optional cable for users




MF15 single carriage horizontal mount model **RH**



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. The origin is set on the L side at the time of shipment. It can be changed to the R side by parameter setting.  
 Note 3. For models with a 2,100mm or longer stroke, optional L type cable carriers can only be used.  
 Note 4. For models with a 3,000mm or longer stroke and an optional L type cable carrier, a roller is installed to prevent the cable carrier from sagging.  
 Note 5. Protrusion is the distance the cable carrier extends from the edge of unit when an optional L type cable carrier is used.  
 Note 6. When using  $\phi 10$  H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.  
 Note 7. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000		
L	360	460	560	660	760	860	960	1060	1160	1260	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260	2360	2460	2560	2660	2760	2860	2960	3060	3160	3260	3360	3460	3560	3660	3760	3860	3960	4060	4160	4260		
A	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30
B	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	16	17	17	18	18	19	19	20	20	21	21	
C	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	36	38	38	40	40	42	42	44	44	
D	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100		
Weight (kg)	6.3	7.3	8.3	9.3	10.3	11.3	12.3	13.3	14.3	15.4	16.4	17.4	18.4	19.4	20.4	21.4	22.4	23.4	24.4	25.4	26.4	27.4	28.4	29.4	30.4	31.4	32.4	33.4	34.4	35.4	36.4	37.4	38.4	39.4	40.4	41.4	42.4	43.4	44.4	45.4	46.4	

MF15D double carriage horizontal mount model **H**



Note 1. Position of table carriage when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. For models with a 2,100mm or longer stroke, optional L type cable carriers can only be used.  
 Note 4. For models with a 3,050mm or longer stroke and an optional L type cable carrier, a roller is installed to prevent the cable carrier from sagging.  
 Note 5. Protrusion is the distance the cable carrier extends from the edge of unit when an optional L type cable carrier is used.  
 Note 6. When using  $\phi 10$  H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.  
 Note 7. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100	
L	560	660	760	860	960	1060	1160	1260	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260	2360	2460	2560	2660	2760	2860	2960	3060	3160	3260	3360	3460	3560	3660	3760	3860	3960	4060	4160	4260				
A	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30
B	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	16	17	17	18	18	19	19	20	20	21	21			
C	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	36	38	38	40	40	42	42	44	44			
D	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100				
Weight (kg)	10.3	11.5	12.6	13.7	14.8	16.0	17.1	18.2	19.3	20.5	21.6	22.7	23.8	24.9	26.1	27.2	28.3	29.5	30.6	31.7	32.8	33.9	35.1	36.2	37.3	38.4	39.5	40.6	41.7	42.8	43.9	45.0	46.1	47.2	48.3	49.4	50.5	51.6	52.7	53.8	54.9	

Articulated robots  
YA

Linear conveyer/modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X


CLEAN

CONTROLLER INFORMATION

MF type

MR type

## MF15 single carriage wall mount model RW




Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. The origin is set on the R side at the time of shipment. It can be changed to the L side by parameter setting.  
 Note 3. Protrusion is the distance the cable carrier extends from the edge of unit when an optional L type cable carrier is used.  
 Note 4. When using φ10 H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.  
 Note 5. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
<b>L</b>	360	460	560	660	760	860	960	1060	1160	1260	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260
<b>A</b>	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30
<b>B</b>	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11
<b>C</b>	4	6	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24
<b>D</b>	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100
<b>E</b>	220	270	320	370	420	470	520	570	620	670	720	770	820	870	920	970	1020	1070	1120	1170
<b>Weight (kg)</b>	6.3	7.3	8.3	9.3	10.3	11.3	12.3	13.3	14.3	15.4	16.4	17.4	18.4	19.4	20.4	21.4	22.4	23.4	24.4	25.4

MF15D double carriage wall mount model

W



- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. Protrusion is the distance the cable carrier extends from the edge of unit when an optional L type cable carrier is used.
- Note 3. When using φ10 H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.
- Note 4. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	100	200	300	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800
L	560	660	760	860	960	1060	1160	1260	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260
A	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30	80	30
B	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11
C	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24
D	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100
E	220	270	320	370	420	470	520	570	620	670	720	770	820	870	920	970	1020	1070
Weight (kg)	10.3	11.5	12.6	13.7	14.8	16.0	17.1	18.2	19.3	20.5	21.6	22.7	23.8	25.0	26.1	27.2	28.3	29.5

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

MF type

MR type

# MF20/MF20D

Can be used for wall-mount



## Ordering method

Single carriage model

**MF20**

Model	Cable carrier entry location	Optional cable carrier for users <sup>Note 2</sup>	Origin position change	Grease type	Stroke	Cable length <sup>Note 3</sup>
MF20: Incremental MF20AD: Semi-absolute <sup>Note 1</sup>	RH: Horizontal, right LH: Horizontal, left RW: Wall mount, right LW: Wall mount, left	No entry: None S: S type M: M type L: L type	No entry: L side (Standard) Z: R side No entry: R side (Standard) Z: L side	No entry: Standard GC: Clean	150 to 4050 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 4</sup>

**TSP**

Positioner <sup>Note 5</sup>	Driver: Power-supply voltage / Power capacity	Regenerative unit	LCD monitor	I/O selection
TS-P	110: 100V/200W 210: 200V/200W	R: With RGT	No entry: None L: With LCD	N: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ GW: No I/O board <sup>Note 6</sup>

**SR1-P 10**

Controller	Driver: Power capacity	Usable for CE	Regenerative unit	I/O selection
	10: 200W	No entry: Standard E: CE marking	R: With RGT1	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS

**RDV-P 2 10 RBR1**

Driver	Power-supply voltage	Driver: Power capacity	Regenerative unit
	2: AC200V	10: 200W or less	

Note 1. For the details of the semi-absolute model, please refer to P.33. RDV-P has an incremental model only.  
 Note 2. For models with a 2,050mm or longer stroke, optional L type cable carriers can only be used.  
 Note 3. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 4. If a flexible cable is needed for the SR1-P, TS-P, or RDV-P, then select 3K/5K/10K. On the RCX221, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.  
 Note 5. These controllers can be mounted on DIN rails. See P.498 for details.  
 Note 6. Select this selection when using the gateway function. For details, see P.60.  
 Note. It is possible to provide the model without a cable carrier. To find information on wiring (cable terminals) within the cable carrier see P.602.

Double carriage model


**MF20D**

Model	Installing direction	Optional cable carrier for users <sup>Note 2</sup>	Grease type	Stroke	Cable length	Controller	Usable for CE	Regenerative unit	I/O selection 1	I/O selection 2
MF20D: Incremental MF20AD: Semi-absolute <sup>Note 1</sup>	H: Horizontal installation W: Wall mount installation	No entry: None S: S type M: M type L: L type	No entry: Standard GC: Clean	150 to 3850 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 4</sup>	RCX221 SR1-P (2 units) TS-P (2 units) RDV-P (2 units)	No entry: Standard E: CE marking	R: RG2 (RCX221)	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet	No entry: None NI: OP.DIO24/16 (NPN) PI: OP.DIO24/17 (PNP) EN: Ethernet


## Specifications

Model	MF20	MF20D
Driving method	Steel cored linear motor with falt magnet	
Repeatability (µm)	+/-5	
Scale (µm)	Magnetic type: resolution of 1	
Maximum speed <sup>Note 2</sup> (mm/sec)	2500	
Rated thrust (N)	86	
Maximum payload <sup>Note 1</sup> (kg)	40	
Stroke (mm)	150 to 4050 (100mm pitch)	150 to 3850 (100mm pitch)
Linear guide	4 rows of circular arc grooves x 2 rail W150 x H80	
Maximum cross-section outside dimensions (mm)	(except the cable carrier section)	
Total length (mm)	Stroke+260	Stroke+460
Cable length (m)	Standard: 3.5 / Option: 5.10	

Note. A vertical model (with brake) is not available with the PHASER series.  
 Note. The basic specifications of semi-absolute model are the same as those of the incremental model.  
 Note 1. Payload per carrier. When the payload exceeds 20kg, please consult our sales office or sales representative.  
 Note 2. Table of maximum speed



## Allowable overhang



	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			
	A	B	C	A	B	C	
10kg	3156	1747	1196	10kg	1220	1320	2540
15kg	2811	1176	883	15kg	870	850	2200
20kg	2679	890	717	20kg	670	610	2030
25kg	2190	720	505	25kg	485	400	1280
30kg	1830	605	370	30kg	350	325	1050
35kg	1580	525	275	35kg	265	270	890
40kg	1390	465	225	40kg	235	230	765

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


MY	MP	MR
373	373	328

(Unit: N·m)

## Controller

Controller	Operating method
SR1-P10-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221-R RCX240/340	Operation using RS-232C communication
TS-P110-R	I/O point trace / Remote command
TS-P210-R	Remote command
RDV-P210-RBR1	Pulse train control

## Cable carrier entry location



## Optional cable carrier for users

**S type**

**M type**

**L type**


Cable and air tube guide

S: φ8 flexible cable x 1, φ4 air tube x 1  
 M: φ8 flexible cable x 2, φ6 air tube x 2  
 L: φ8 flexible cable x 2, φ8 air tube x 3

Space for optional cable for users




## MF20D double carriage horizontal mount model



Note 1. Position of table carriage when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. For models with a 2,050mm or longer stroke, optional L type cable carriers can only be used.  
 Note 4. For models with a 3,050mm or longer stroke and an optional L type cable carrier, a roller is installed to prevent the cable carrier from sagging.  
 Note 5. Protrusion is the distance the cable carrier extends from the edge of unit when an optional L type cable carrier is used.  
 Note 6. When using  $\phi 10$  H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.  
 Note 7. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050	3150	3250	3350	3450	3550	3650	3750	3850		
L	610	710	810	910	1010	1110	1210	1310	1410	1510	1610	1710	1810	1910	2010	2110	2210	2310	2410	2510	2610	2710	2810	2910	3010	3110	3210	3310	3410	3510	3610	3710	3810	3910	4010	4110	4210	4310		
A	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55
B	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	16	17	17	18	18	19	19	20	20	21	21	
C	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	36	38	38	40	40	42	42	44	44	
D	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100		
Weight (kg)	14.9	16.6	18.3	20.0	21.7	23.5	25.2	26.9	28.6	30.3	32.0	33.7	35.4	37.1	38.8	40.5	42.2	43.9	45.6	47.3	49.0	50.7	52.4	54.1	55.8	57.5	59.2	60.9	62.6	64.3	66.0	67.7	69.4	71.1	72.8	74.5	76.2	77.9		

## MF20D double carriage wall mount model



Note 1. Position of table carriage when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. For models with a 2,050mm or longer stroke, optional L type cable carriers can only be used.  
 Note 4. For models with a 3,050mm or longer stroke and an optional L type cable carrier, a roller is installed to prevent the cable carrier from sagging.  
 Note 5. Protrusion is the distance the cable carrier extends from the edge of unit when an optional L type cable carrier is used.  
 Note 6. When using  $\phi 10$  H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.  
 Note 7. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050	3150	3250	3350	3450	3550	3650	3750	3850		
L	610	710	810	910	1010	1110	1210	1310	1410	1510	1610	1710	1810	1910	2010	2110	2210	2310	2410	2510	2610	2710	2810	2910	3010	3110	3210	3310	3410	3510	3610	3710	3810	3910	4010	4110	4210	4310		
A	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55	105	55
B	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	16	17	17	18	18	19	19	20	20	21	21	
C	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	36	38	38	40	40	42	42	44	44	
D	400	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100		
E	220	270	320	370	420	470	520	570	620	670	720	770	820	870	920	970	1020	1070	1120	1170	1220	1270	1320	1370	1420	1470	1520	1570	1620	1670	1720	1770	1820	1870	1920	1970	2020	2070		
Weight (kg)	14.9	16.6	18.3	20.0	21.7	23.5	25.2	26.9	28.6	30.3	32.0	33.7	35.4	37.1	38.8	40.5	42.2	43.9	45.6	47.3	49.0	50.7	52.4	54.1	55.8	57.5	59.2	60.9	62.6	64.3	66.0	67.7	69.4	71.1	72.8	74.5	76.2	77.9		

# MF30/MF30D

Can be used for wall-mount



## Ordering method

Single carriage model

**MF30**

Model	Cable carrier entry location	Optional cable carrier for users <sup>Note 2</sup>	Origin position change	Grease type	Stroke	Cable length
MF30: Incremental MF30A: Semi-absolute <sup>Note 1</sup>	RH: Horizontal, right LH: Horizontal, left RW: Wall mount, right LW: Wall mount, left	No entry: None S: S type M: M type L: L type	No entry: L side (Standard) Z: R side No entry: R side (Standard) Z: L side	No entry: Standard GC: Clean	100 to 4000 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 4</sup>

**TSP 220 R**

Positioner	Driver: Power-supply voltage / Power capacity	Regenerative unit	LCD monitor	I/O selection
TS-P	220: 200V/400 to 600W	R: With RGT	No entry: None L: With LCD	N: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ GW: No I/O board <sup>Note 5</sup>

**SR1-P 20 R**

Controller	Driver: Power capacity	Usable for CE	Regenerative unit	I/O selection
	20: 400 to 600W	No entry: Standard E: CE marking	R: With RGT1	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS

**RDV-P 2 20 RBR1**

Driver	Power-supply voltage	Driver: Power capacity	Regenerative unit
	Z: AC200V	20: 400W or less	

Note 1. For the details of the semi-absolute model, please refer to P.33. RDV-P has an incremental model only.  
 Note 2. For models with a stroke of 2100 or longer (2050 or longer for double carriage models), only the optional L type cable carriers can be used.  
 Note 3. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 4. If a flexible cable is needed for the SR1-P, TS-P, or RDV-P, then select 3K/5K/10K. On the RCX221HP, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.  
 Note 5. These controllers can be mounted on DIN rails. See P.498 for details.  
 Note 6. Select this selection when using the gateway function. For details, see P.60.  
 Note. It is possible to provide the model without a cable carrier. To find information on wiring (cable terminals) within the cable carrier see P.602.

Double carriage model

**MF30D**

Model	Installing direction	Optional cable carrier for users <sup>Note 2</sup>	Grease type	Stroke	Cable length
MF30D: Incremental MF30AD: Semi-absolute <sup>Note 1</sup>	H: Horizontal installation W: Wall mount installation	No entry: None S: S type M: M type L: L type	No entry: Standard GC: Clean	150 to 3750 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 4</sup>


**RCX221HP R**

Controller	Usable for CE	Regenerative unit	I/O selection 1	I/O selection 2
RCX221HP SR1-P (2 units) TS-P (2 units) RDV-P (2 units)	No entry: Standard E: CE marking	R: RG2 (RCX221HP)	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet	No entry: None Nt: OP.DIO24/16 (NPN) Pt: OP.DIO24/17 (PNP) EN: Ethernet

## Specifications

Model	MF30	MF30D
Driving method	Steel cored linear motor with falt magnet	
Repeatability (μm)	+/-5	
Scale (μm)	Magnetic type: resolution of 1	
Maximum speed <sup>Note 2</sup> (mm/sec)	2500	
Rated thrust (N)	125	
Maximum payload <sup>Note 1</sup> (kg)	60	
Stroke (mm)	100 to 4000 (100mm pitch)	150 to 3750 (100mm pitch)
Linear guide	4 rows of circular arc grooves x 2 rail	
Maximum cross-section outside dimensions (mm)	W150 x H80 (except the cable carrier section)	
Total length (mm)	Stroke+310	Stroke+560
Cable length (m)	Standard: 3.5 / Option: 5,10	

Note. A vertical model (with brake) is not available with the PHASER series.  
 Note. The basic specifications of semi-absolute model are the same as those of the incremental model.  
 Note 1. Payload per carrier. When the payload exceeds 30kg, please consult our sales office or sales representative.  
 Note 2. Table of maximum speed



## Allowable overhang

**Horizontal installation (Unit: mm)**

	A	B	C
10kg	3364	2485	1284
20kg	2298	1265	694
30kg	2060	859	507
40kg	1570	600	310
50kg	1265	400	180
60kg	1070	350	135

**Wall installation (Unit: mm)**

	A	B	C
10kg	1290	1320	2730
20kg	650	610	1750
30kg	430	360	1460
40kg	205	230	610
50kg	145	175	470
60kg	105	140	380

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment

MY	MP	MR
373	373	328

(Unit: N·m)

## Controller

Controller	Operating method
SR1-P20-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221HP-R RCX240/340	I/O point trace / Remote command
TS-P220-R	Pulse train control
RDV-P220-RBR1	

## Cable carrier entry location

Note. Be sure to install in the direction as specified (in cable carrier take-out direction drawing and various specification drawings) individually. Installation in any other way will cause a failure. For requirement of installation in any way other than the above standard installation, please consult YAMAHA as special arrangement will be available.

## Optional cable carrier for users

Cable and air tube guide

S: φ8 flexible cable x 1, φ4 air tube x 1  
 M: φ8 flexible cable x 2, φ6 air tube x 2  
 L: φ8 flexible cable x 2, φ8 air tube x 3

Space for optional cable for users








# MF75/MF75D




## Ordering method


### Single carriage model



- Note 1. For the details of the semi-absolute model, please refer to P.33. RDV-P has an incremental model only.  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. If a flexible cable is needed for the SR1-P, TS-P, or RDV-P, then select 3K/5K/10K. On the RCX221HP, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.  
 Note 4. These controllers can be mounted on DIN rails. See P.498 for details.  
 Note 5. Select this selection when using the gateway function. For details, see P.60.  
 Note. It is possible to provide the model without a cable carrier. To find information on wiring (cable terminals) within the cable carrier see P.602.



### Double carriage model




## Specifications


Model	MF75	MF75D
<b>Driving method</b>	Steel cored linear motor with falt magnet	
<b>Repeatability (µm)</b>	+/-5	
<b>Scale (µm)</b>	Magnetic type: resolution of 1	
<b>Maximum speed<sup>Note 2</sup> (mm/sec)</b>	2500	
<b>Rated thrust (N)</b>	260	
<b>Maximum payload<sup>Note 1</sup> (kg)</b>	160	
<b>Stroke (mm)</b>	1000 to 4000 (100mm pitch)	680 to 3680 (100mm pitch)
<b>Linear guide</b>	4 rows of circular arc grooves x 2 rail	
<b>Maximum cross-section outside dimensions (mm)</b>	W210xH100 (except the cable carrier section)	
<b>Total length (mm)</b>	Stroke+360	Stroke+680
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5,10	

Note. A vertical model (with brake) is not available with the PHASER series.  
 Note. The basic specifications of semi-absolute model are the same as those of the incremental model.  
 Note 1. Payload per carrier. When the payload exceeds 75kg, please consult our sales office or sales representative.

Note 2. Table of maximum speed



## Allowable overhang




Horizontal installation (Unit: mm)

	A	B	C
20kg	3397	2841	1840
40kg	2795	1389	964
60kg	2200	530	450
80kg	1800	175	150
100kg	1500	130	110
120kg	1250	100	80
140kg	1100	80	65
160kg	950	60	50

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment




(Unit: N-m)

MY	MP	MR
830	831	730


## Controller

Controller	Operating method
SR1-P20-R (RGU-2)	Programming / I/O point trace /
RCX221HP-R (RG2)	Remote command / Operation using RS-232C communication
TS-P220-R (RGU-2)	I/O point trace / Remote command
RDV-P225-RBR2	Pulse train control


## Cable carrier entry location



## Cable carrier




MF75 single carriage horizontal mount model **RH**



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. The origin is set on the L side (as shown above) at the time of shipment. It can be changed to the R side by parameter setting.  
 Note 3. The length under head of M8 hex socket head bolts for installing the robot body must not be longer than 30mm.  
 Note 4. For models with a 3,000mm or longer stroke, a roller is installed to prevent the cable carrier from sagging.  
 Note 5. When using  $\phi 10$  H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.  
 Note 6. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000
L	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260	2360	2460	2560	2660	2760	2860	2960	3060	3160	3260	3360	3460	3560	3660	3760	3860	3960	4060	4160	4260	4360
A	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80
B	5	5	7	7	7	7	9	9	9	9	11	11	11	11	13	13	13	13	15	15	15	17	17	17	17	17	19	19	19	19	21
C	12	12	16	16	16	16	20	20	20	24	24	24	24	28	28	28	28	32	32	32	32	32	36	36	36	36	40	40	40	40	44
D	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180
E	6	6	6	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18	18	20	20	20
F	14	14	14	14	18	18	18	18	22	22	22	22	26	26	26	26	30	30	30	30	34	34	34	34	38	38	38	38	42	42	42
G	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100
Weight (kg)	46	49	51	54	56	59	61	64	66	69	71	74	76	79	81	84	86	89	91	94	96	99	101	104	106	109	111	114	116	119	121

MF75D double carriage mount model **H**



Note 1. Position of table carriage when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. The length under head of M8 hex socket head bolts for installing the robot body must not be longer than 30mm.  
 Note 4. For models with a 3,080mm or longer stroke, a roller is installed to prevent the cable carrier from sagging.  
 Note 5. When using  $\phi 10$  H7 hole, do not insert the pin more than the depth stated in the drawing. Otherwise, the motor may break.  
 Note 6. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

Effective stroke	680	780	880	980	1080	1180	1280	1380	1480	1580	1680	1780	1880	1980	2080	2180	2280	2380	2480	2580	2680	2780	2880	2980	3080	3180	3280	3380	3480	3580	3680
L	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260	2360	2460	2560	2660	2760	2860	2960	3060	3160	3260	3360	3460	3560	3660	3760	3860	3960	4060	4160	4260	4360
A	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80
B	5	5	7	7	7	7	9	9	9	9	11	11	11	11	13	13	13	13	15	15	15	17	17	17	17	17	19	19	19	19	21
C	12	12	16	16	16	16	20	20	20	20	24	24	24	24	28	28	28	28	32	32	32	32	32	36	36	36	36	40	40	40	44
D	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180	230	80	130	180
E	6	6	6	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18	18	20	20	20
F	14	14	14	14	18	18	18	18	22	22	22	22	26	26	26	26	30	30	30	30	34	34	34	34	38	38	38	38	42	42	42
G	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600	2700	2800	2900	3000	3100	3200	3300	3400	3500	3600	3700	3800	3900	4000	4100
Weight (kg)	57	60	62	65	67	70	73	75	78	81	83	86	88	91	94	96	99	101	104	107	109	112	114	117	120	122	125	127	130	133	135

# MR12/MR12D

Can be used for wall-mount

## Ordering method

Single carriage model

### MR12

<b>Model</b> MR12: Incremental MR12A: Semi-absolute <sup>Note 1</sup>	<b>Cable carrier entry location</b> RH: Horizontal, right LH: Horizontal, left RW: Wall mounted, right LW: Wall mounted, left	<b>Optional cable carrier for users</b> No entry: None S: S type M: M type	<b>Origin position change</b> Horizontal: No entry: L side (Standard) Z: R side Wall: No entry: R side (Standard) Z: L side	<b>Grease type</b> No entry: Standard GC: Clean	<b>Stroke</b> 50 to 1050 (100mm pitch)	<b>Cable length</b> <sup>Note 2</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 3</sup>	<b>TSP</b> <b>Positioner</b> <sup>Note 4</sup> TS-P	<b>Driver: Power-supply voltage / Power capacity</b> 105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ GW: No I/O board <sup>Note 5</sup>
							<b>SR1-P</b> <b>Controller</b>	<b>05</b> Driver: Power capacity 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS
							<b>RDV-P</b> <b>Driver</b>	<b>2</b> Power-supply voltage 2: AC200V	<b>05</b> Driver: Power capacity 05: 100W or less	

- Note 1. For the details of the semi-absolute model, please refer to P.33. RDV-P has an incremental model only.  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. If a flexible cable is needed for the SR1-P, TS-P, or RDV-P, then select 3K/5K/10K. On the RCX221, the standard cable is a flexible cable, so enter 3L/5L/10L when ordering.  
 Note 4. These controllers can be mounted on DIN rails. See P.498 for details.  
 Note 5. Select this selection when using the gateway function. For details, see P.60.  
 Note. It is possible to provide the model without a cable carrier. To find information on wiring (cable terminals) within the cable carrier see P.602.

Double carriage model

### MR12D

<b>Model</b> MR12D: Incremental MR12AD: Semi-absolute <sup>Note 1</sup>	<b>Installing direction</b> H: Horizontal installation W: Wall mounted installation	<b>Optional cable carrier for users</b> No entry: None S: S type M: M type	<b>Grease type</b> No entry: Standard GC: Clean	<b>Stroke</b> 50 to 1050 (100mm pitch)	<b>Cable length</b> <sup>Note 2</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable) <sup>Note 3</sup>	<b>RCX221</b> <b>Controller</b> RCX221 SR1-P (2 units) TS-P (2 units) RDV-P (2 units)	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection 1</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet	<b>I/O selection 2</b> No entry: None N1: OP.DIO24/16 (NPN) P1: OP.DIO24/17 (PNP) EN: Ethernet
---	---	---	---	--	--	--	---	---	--

## Specifications <sup>Note</sup>

Model	MR12	MR12D
Driving method / Shaft diameter	Shaft motor / $\phi 12$	
Repeatability ( $\mu\text{m}$ )	+/-5 or less	
Scale ( $\mu\text{m}$ )	Magnetic type: resolution of 1	
Maximum speed <sup>Note 1</sup> (mm/sec)	2500	
Rated thrust (N)	18	
Maximum payload <sup>Note 2</sup> (kg)	5	
Stroke (mm)	50 to 1050 (50mm pitch)	
Linear guide	4 rows of circular arc grooves $\times$ 2 rail	
Maximum cross-section outside dimensions (mm)	W60 $\times$ H90 (except the cable carrier section)	
Total length (mm)	Stroke+288	Stroke+488
Cable length (m)	Standard: 3.5 / Option: 5, 10	

- Note. A vertical model (with brake) is not available with the PHASER series.  
 Note. The basic specifications of semi-absolute model are the same as those of the incremental model.  
 Note 1. Maximum speed may not be obtained depending on operating conditions.  
 Note 2. Maximum payload per carriage.

## Allowable overhang <sup>Note</sup>

**Horizontal installation** (Unit: mm)

	A	B	C
1kg	600	600	600
2kg	1200	1200	598
3kg	1800	1800	406
5kg	3000	1561	241

**Wall installation** (Unit: mm)

	A	B	C
1kg	600	600	600
2kg	529	1200	1200
3kg	323	1450	1800
5kg	162	589	3000

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


MY	MP	MR
107	107	89

(Unit: N·m)

## Controller


Controller	Operating method
SR1-P05	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221 RCX240/340	Operation using RS-232C communication
TS-P105	I/O point trace / Remote command
TS-P205	Remote command
RDV-P205	Pulse train control

## Cable carrier entry location




Note. Be sure to install in the direction as specified (in cable carrier take-out direction drawing and various specification drawings) individually. Installation in any other way will cause a failure. For requirement of installation in any way other than the above standard installation, please consult YAMAHA as special arrangement will be available.

## Optional cable carrier for users




## MR12 single carriage horizontal mount model **RH**



Effective stroke	50	150	250	350	450	550	650	750	850	950	1050
L	338	438	538	638	738	838	938	1038	1138	1238	1338
M	2	3	4	5	6	7	8	9	10	11	12
N	6	8	10	12	14	16	18	20	22	24	26
Weight (kg)	3.9	4.4	5.0	5.6	6.1	6.7	7.3	7.9	8.4	9.0	9.5

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.  
 Note. The origin is set on the L side at the time of shipment. It can be changed to the R side by parameter setting.


## MR12 single carriage wall mount model **RW**



Effective stroke	50	150	250	350	450	550	650	750	850	950	1050
L	338	438	538	638	738	838	938	1038	1138	1238	1338
M	2	3	4	5	6	7	8	9	10	11	12
N	6	8	10	12	14	16	18	20	22	24	26
Weight (kg)	3.9	4.4	5.0	5.6	6.1	6.7	7.3	7.9	8.4	9.0	9.5

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.  
 Note. The origin is set on the R side at the time of shipment. It can be changed to the L side by parameter setting.


## MR12D double carriage horizontal mount model H



Effective stroke	50	150	250	350	450	550	650	750	850	950	1050
L	538	638	738	838	938	1038	1138	1238	1338	1438	1538
M	4	5	6	7	8	9	10	11	12	13	14
N	10	12	14	16	18	20	22	24	26	28	30
Weight (kg)	5.7	6.3	6.8	7.3	8.0	8.6	9.1	9.7	10.2	10.8	11.3


Note 1. Position of the table slider when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.

## MR12D double carriage wall mount model W



Effective stroke	50	150	250	350	450	550	650	750	850	950	1050
L	538	638	738	838	938	1038	1138	1238	1338	1438	1538
M	4	5	6	7	8	9	10	11	12	13	14
N	10	12	14	16	18	20	22	24	26	28	30
Weight (kg)	5.7	6.3	6.8	7.3	8.0	8.6	9.1	9.7	10.2	10.8	11.3

Note 1. Position of the table slider when returned to the origin.  
 Note 2. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 3. Depending on the stroke and the operating conditions, the cable carrier bending radius might be larger, making it higher than the dimensions shown in the diagram.



## CARTESIAN ROBOTS

# XY-X SERIES

## CONTENTS

- **Arm & cable variations** ..... 240
- **2-axis spec selection guide**... 242
- **3-axis spec selection guide**... 244
- **Robot ordering method description** ..... 248
- **Robot ordering method terminology** ..... 249

### ARM TYPE

PXYx 2 axes C	250
FXYx 2 axes C	252
FXYx 2 axes / IO C	254
FXYx 3 axes / ZS C	255
FXYx 3 axes / ZT C	256
FXYBx 2 axes C	258
FXYBx 2 axes S	260
FXYBx 2 axes / IO C	262
SXYx 2 axes C	264
SXYx 2 axes S	266
SXYx 2 axes / IO C	268
SXYx 3 axes / ZF C	270
SXYx 3 axes / ZF S	271
SXYx 3 axes / ZFL20	272
SXYx 3 axes / ZFH C	273
SXYx 3 axes / ZS C	274
SXYx 3 axes / ZS S	275
SXYx 4 axes / ZRF C	276
SXYx 4 axes / ZRF S	277
SXYx 4 axes / ZRFL20 C	278
SXYx 4 axes / ZRFH C	279
SXYx 4 axes / ZRS C	280
SXYx 4 axes / ZRS S	281
SXYBx 2 axes C	282
SXYBx 3 axes / ZF C	284
SXYBx 3 axes / ZFL20 C	285

SXYBx 3 axes / ZFH C	286
SXYBx 3 axes / ZS C	287
SXYBx 4 axes / ZRS C	288
NXY 2 axes C	290
NXY 3 axes / ZFL C	292
NXY 3 axes / ZFH C	294
NXY-W 4 axes C	296
NXY-W 6 axes / ZFL C	297
NXY-W 6 axes / ZFH C	298
MXYx 2 axes C	300
MXYx 2 axes S	302
MXYx 2 axes / IO C	304
MXYx 3 axes / ZFL20/10 C	305
MXYx 3 axes / ZFH C	306
MXYx 4 axes / ZRFL20/10 C	307
MXYx 4 axes / ZRFH C	308
HXYx 2 axes C	310
HXYx 3 axes / ZL C	312
HXYx 3 axes / ZH C	313
HXYx 4 axes / ZRL C	314
HXYx 4 axes / ZRH C	315
HXYLx 2 axes C	316

### GANTRY TYPE

MXYx 2 axes C	318
MXYx 2 axes / IO C	320
MXYx 3 axes / ZFL20/10 C	321
MXYx 3 axes / ZFH C	322
MXYx 4 axes / ZRFL20/10 C	323
MXYx 4 axes / ZRFH C	324
HXYx 2 axes C	326
HXYx 3 axes / ZL C	328
HXYx 3 axes / ZH C	329
HXYx 4 axes / ZRL C	330
HXYx 4 axes / ZRH C	331
HXYLx 2 axes C	332

### MOVING ARM TYPE

SXYx 2 axes S	334
SXYx 3 axes / ZF S	336
SXYx 3 axes / ZFL20 S	337
SXYx 3 axes / ZFH S	338
SXYx 3 axes / ZS S	339
MXYx 2 axes C	340
MXYx 3 axes / ZFL20/10 C	342
MXYx 3 axes / ZFH C	343
HXYx 2 axes C	344
HXYx 3 axes / ZH C	346

### POLE TYPE

SXYx 2 axes S	348
MXYx 2 axes C	349
MXYx 2 axes S	350
MXYx 3 axes / ZPMH C	351
HXYx 2 axes C	352
HXYx 2 axes S	353
HXYx 3 axes / ZPH C	354
HXYx 3 axes / ZPH S	355

### XZ TYPE

SXYx 2 axes / ZF C	356
SXYx 2 axes / ZF S	357
SXYx 2 axes / ZFL20 C	358
SXYx 2 axes / ZS C	359
SXYx 2 axes / ZF C	360
SXYBx 2 axes / ZFL20 C	361
MXYx 2 axes / ZFL10 C	362
MXYx 2 axes / ZFH C	363
HXYx 2 axes / ZL C	364
HXYx 2 axes / ZH C	365


# Arm & cable variations

## Cable variations

Two cable types are available; cable carrier type and whipover type. (except PXYX) The cable carrier type is supplied with a user cable as standard so that cable can be added easily. The whipover type is supplied with a user cable and tube as standard set. A cable duct specially designed for clean rooms is also available. (See P.456 to P.461 for detailed information on Clean Cartesian robots.)

### Cable carrier (C)


When adding cables to a cable carrier track, keep the cable occupation rate at 30% or less.



Note. User cable 10 cores, 0.2 sq.

### Whipover (S)

Adding a load on whipover will result in sagging and cut. Sagging may also occur when using long strokes.



Note. User cable: 7 cores, 0.2 sq.  
Note. User tube: 2 φ4 air tubes.

## Arm variations

The first step for selection of Cartesian type robot models is to check for applicable models according to specific use and operation area.

### Arm type


The type with moving Y-axis carriage.



P.250

### Gantry type

The type with a guide railing at the end of Y-axis for support.



P.318

### Moving arm type


The type with a moving Y-axis arm.



P.334

### Pole type

The type with vertically moving Y-axis carriage.



P.348

### XZ type


The type with combination of X-axis for horizontal movement and Z-axis for vertical movement.



P.356

### Clean type


Special model for clean rooms with moving Y-axis carriage installed upward.




P.456




A1




A2




A3




A4




G1




G2




G3




G4




M1




M3




P1




P2




F1




F3



T1



T3



# 2-axis spec selection guide

## Setting method

While checking conditions in order starting from ①, proceed to the right. Select the desired model in ⑥.

① Select the arm variation

### Arm type

The type with moving Y-axis carriage.

### Gantry type

The type with a guide railing at the end of Y-axis for support.

### Moving arm type

The type with a moving Y-axis arm.

### Pole type

The type with vertically moving Y-axis carriage.

### XZ type

The type with combination of X-axis for horizontal movement and Z-axis for vertical movement.




② Select a line satisfying both the Y-axis stroke and payload and move to the right.

③ Check the cable types

④ Check the X axis stroke

⑤ Select the desired speed

⑥ Decide the model



		Y-axis stroke (mm)									
		50	100	150	200	250	300	350	400	450	500
Payload (kg)		4.5	4.5	3.5	2.5	2	1.5				

		Y-axis stroke (mm)									
		150	250	350	450	550	650	750	850	950	1050
Payload (kg)		12		11	9	7					
		12		11	9	7					
		7	6		5	3					
		7	6		5	3					
		7	6		5	3					
		20	17	15	13	11	9				
		20	17	15	13	11	9				
		19	16	14	12	10	8				
		14	12	10	8	7					
		25	21	18	16	13	11				
		30		25		20	16				
		30		25		20	16				
		29		24		19	15				
			40		35		30				
		40		35		30					

		Y-axis stroke (mm)									
		150	250	350	450	550	650	750	850	950	1050
Payload (kg)					30			25	20		
					29			24	19		
							50				
							50				

		Y-axis stroke (mm)									
		150	250	350	450	550	650	750	850	950	1050
Payload (kg)		15	14	13							
				20							
					30						

		Y-axis stroke (mm)									
		150	250	350	450	550	650	750	850	950	1050
Payload (kg)				8							
				20							
				20							
							30				
							30				

		Z-axis stroke (mm)									
		150	250	350	450	550	650	750	850	950	1050
Payload (kg)		10									
		10									
		8									
		3									
		5									
		10									
		8									
		15									
		14	13	12							
				20							
				30							

③	④	⑤	⑥ Decide the model	
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model <sup>(Note 1)</sup>	Detailed info page
Cable carrier	150 to 650	720 / 720	PXYx-C-A*	<a href="#">P250</a>
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model	Detailed info page
Cable carrier	150 to 1050	1200 / 800	FXyX-C-A*	<a href="#">P252</a>
Cable carrier	150 to 1050	1200 / 800	FXyX-C-A* (I/O)	<a href="#">P254</a>
Cable carrier	150 to 2450	1875 / 1875	FXyBx-C-A*	<a href="#">P258</a>
Whipover	150 to 950	1875 / 1875	FXyBx-S-A*	<a href="#">P260</a>
Cable carrier	150 to 2450	1875 / 1875	FXyBx-C-A* (I/O)	<a href="#">P262</a>
Cable carrier	150 to 1050	1200 / 1200	SXYx-C-A*	<a href="#">P264</a>
Whipover	150 to 850	1200 / 1200	SXYx-S-A*	<a href="#">P266</a>
Cable carrier	150 to 1050	1200 / 1200	SXYx-C-A* (I/O)	<a href="#">P268</a>
Cable carrier	150 to 3050	1875 / 1875	SXYBx-C-A*	<a href="#">P282</a>
Cable carrier	500 to 2000	1200 / 1200	NXY-C-A*	<a href="#">P290</a>
Cable carrier	250 to 1250	1200 / 1200	MXyX-C-A*	<a href="#">P300</a>
Whipover	250 to 850	1200 / 1200	MXyX-S-A*	<a href="#">P302</a>
Cable carrier	250 to 1250	1200 / 1200	MXyX-C-A* (I/O)	<a href="#">P304</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-A*	<a href="#">P310</a>
Cable carrier	1150 to 2050	1200 / 1200	HXYLx-C-A*	<a href="#">P316</a>
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model	Detailed info page
Cable carrier	250 to 1050	1200 / 1200	MXyX-C-G*	<a href="#">P318</a>
Cable carrier	250 to 1050	1200 / 1200	MXyX-C-G* (I/O)	<a href="#">P320</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-G*	<a href="#">P326</a>
Cable carrier	1150 to 2050	1200 / 1200	HXYLx-C-G*	<a href="#">P332</a>
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model	Detailed info page
Cable carrier	150 to 850	1200 / 1200	SXYx-C-M*	<a href="#">P334</a>
Cable carrier	250 to 1250	1200 / 1200	MXyX-C-M*	<a href="#">P340</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-M*	<a href="#">P346</a>
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model	Detailed info page
Whipover	150 to 850	1200 / 600	SXYx-S-P*	<a href="#">P348</a>
Cable carrier	250 to 1250	1200 / 600	MXyX-C-P*	<a href="#">P349</a>
Whipover	250 to 950	1200 / 600	MXyX-S-P*	<a href="#">P350</a>
Cable carrier	250 to 1250	1200 / 600	HXYx-C-P*	<a href="#">P352</a>
Whipover	250 to 850	1200 / 600	HXYx-S-P*	<a href="#">P353</a>
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model	Detailed info page
Cable carrier	150 to 1050	1200 / 600	SXYx-C-F* (ZF)	<a href="#">P356</a>
Whipover	150 to 850	1200 / 600	SXYx-S-F* (ZF)	<a href="#">P357</a>
Cable carrier	150 to 1050	1200 / 1200	SXYx-C-F* (ZFL20)	<a href="#">P358</a>
Cable carrier	150 to 1050	1200 / 1000	SXYx-C-F* (ZS12)	<a href="#">P359</a>
Cable carrier	150 to 1050	1200 / 500	SXYx-C-F* (ZS6)	<a href="#">P359</a>
Cable carrier	150 to 3050	1875 / 600	SXYBx-C-F* (ZF)	<a href="#">P360</a>
Cable carrier	150 to 3050	1875 / 1200	SXYBx-C-F* (ZFL20)	<a href="#">P361</a>
Cable carrier	150 to 1050	1200 / 600	MXyX-C-F* (ZFL10)	<a href="#">P362</a>
Cable carrier	150 to 1050	1200 / 600	MXyX-C-F* (ZFH)	<a href="#">P363</a>
Cable carrier	250 to 1250	1200 / 600	HXYx-C-F* (ZL)	<a href="#">P364</a>
Cable carrier	250 to 1250	1200 / 300	HXYx-C-F* (ZH)	<a href="#">P365</a>

Note 1. The figure entered at \* inside the form, expresses the arm variation. See P. 240 for more information.

# 3-axis spec selection guide

## Setting method

While checking conditions in order starting from ①, proceed to the right. Select the desired model in ⑥.

① Select the arm variation

### Arm type

The type with moving Y-axis carriage.

### Gantry type

The type with a guide railing at the end of Y-axis for support.

### Moving arm type

The type with a moving Y-axis arm.

### Pole type

The type with vertically moving Y-axis carriage.

①

### Arm type

②


### Z-axis

Speed (mm/sec)	Stroke (mm)	Installation method
1000	150	Shaft vertical type
500	150	
800	50 to 300	Clamped base · moving table type (60W)
600	150	Clamped base · moving table type (100W)
	250	
	350	
	150	Clamped base · moving table type (100W)
1200	250	Clamped base · moving table type (200W)
	350	
	150	
600	150	Clamped table · moving base type (200W)
	250	
	350	
1000	150	Shaft vertical type
500	150	
600	150	Clamped base · moving table type (100W)
	250	
	350	
1200	150	Clamped base · moving table type (200W)
	250	
	350	
600	150	Clamped table · moving base type (200W)
	250	
	350	
1000	150	Shaft vertical type
500	150	
1200	150	Clamped base · moving table type (200W)
	250	
	350	
600	150	Clamped table · moving base type (200W)
	250	
	350	
600	150	Clamped base · moving table type (200W)
	250	
	350	
1200	150	Clamped base · moving table type (200W)
	250	
	350	
600	150	Clamped table · moving base type (200W)
	250	
	450	
	550	
300	250	Clamped table · moving base type (200W)
	350	
	450	
	550	

③

### Y-axis stroke (mm)

Payload (kg)	150	250	350	450	550	650	750	850	950	1050
		3								
	5				3					
	3									
	10	9	7	5	3					
	10	8	6	4	2					
	10	9	7	5	3	1				
	10	9	7	5	3					
	10	10	8	6	4	2				
	10	9	7	5	3	1				
	8			6	4	2				
	8		7	5	3	1				
	8		6	4	2	1				
	13	10	8	6	4	2				
	12	9	7	5	3	1				
	11	8	6	4	2	1				
	3									
	3									
	5									
	5									
	8	6	4	2	1					
	7	5	3	1						
	6	4	2							
	7	5	3	1						
	6	4	2							
	5	3	1							
	7	5	3	1						
	6	4	2							
	5	3	1							
	3									
	5			4	3					
	8				5	3				
	8			7	4	2				
	8		6	3	1					
	13	12	10	8	5	3				
	13	11	9	7	4	2				
	12	10	8	6	3	1				
	15			12	12	8				
	15			11	11	7				
	15			10	10	6				
	8									
	8					7				
	8					6				
	14			12		8				
	13			11		7				
	12			10		6				
	20				18					
	20				17					
	20		19	16						
	20		18	15						
	25		20	18						
	25		20	17						
	24		19	16						
	23		18	15						



④	⑤	⑥	⑦ Decide the model	
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model <sup>(Note 1)</sup>	Detailed info page
Cable carrier	150 to 1050	1200 / 800	FXYx-C-A*-ZS12	<a href="#">P.255</a>
			FXYx-C-A*-ZS6	<a href="#">P.255</a>
			FXYx-C-A*-ZT6	<a href="#">P.256</a>
Cable carrier	150 to 1050	1200 / 1200	SXYx-C-A*-ZF	<a href="#">P.270</a>
Whipover	150 to 850	1200 / 1200	SXYx-S-A*-ZF	<a href="#">P.271</a>
Cable carrier	150 to 1050	1200 / 1200	SXYx-C-A*-ZFL20	<a href="#">P.272</a>
Cable carrier	150 to 1050	1200 / 1200	SXYx-C-A*-ZFH	<a href="#">P.273</a>
Cable carrier	150 to 1050	1200 / 1200	SXYx-C-A*-ZS12	<a href="#">P.274</a>
Whipover	150 to 850		SXYx-S-A*-ZS12	<a href="#">P.274</a>
Cable carrier	150 to 1050		SXYx-C-A*-ZS6	<a href="#">P.275</a>
Whipover	150 to 850		SXYx-S-A*-ZS6	<a href="#">P.275</a>
Cable carrier	150 to 3050	1875 / 1875	SXYBx-C-A*-ZF	<a href="#">P.284</a>
Cable carrier	150 to 3050	1875 / 1875	SXYBx-C-A*-ZFL20	<a href="#">P.285</a>
Cable carrier	150 to 3050	1875 / 1875	SXYBx-C-A*-ZFH	<a href="#">P.286</a>
Cable carrier	150 to 3050	1875 / 1875	SXYBx-C-A*-ZS12	<a href="#">P.287</a>
Cable carrier	150 to 3050	1875 / 1875	SXYBx-C-A*-ZS6	<a href="#">P.287</a>
Cable carrier	500 to 2000	1200 / 1200	NXY-C-A*-ZFL20	<a href="#">P.292</a>
Cable carrier	500 to 2000	1200 / 1200	NXY-C-A*-ZFH	<a href="#">P.294</a>
Cable carrier	250 to 1250	1200 / 1200	MXYx-C-A*-ZFL10	<a href="#">P.305</a>
Cable carrier	250 to 1250	1200 / 1200	MXYx-C-A*-ZFL20	<a href="#">P.305</a>
Cable carrier	250 to 1250	1200 / 1200	MXYx-C-A*-ZFH	<a href="#">P.306</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-A*-ZL	<a href="#">P.312</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-A*-ZH	<a href="#">P.313</a>

Note 1. The figure entered at \* inside the form, expresses the arm variation. See P.240 for more information.

# 3-axis spec selection guide

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- Arm type
- Gantry type
- Moving arm type
- Pole type
- XZ type

## ① Gantry type

Z-axis		
Speed (mm/sec)	Stroke (mm)	Installation method
600	150	Clamped base · moving table type (200W)
	250	
	350	
1200	150	Clamped base · moving table type (200W)
	250	
	350	
600	150	Clamped table · moving base type (200W)
	250	
	350	
600	250	Clamped base · moving table type (200W)
	350	
	450	
	550	
300	250	Clamped table · moving base type (200W)
	350	
	450	
	550	

Payload (kg)	Y-axis stroke (mm)										
	150	250	350	450	550	650	750	850	950	1050	
	15							12			
	15							11			
	15							10			
	8										
	8										
	8										
	14							12			
	13							11			
	12							10			
						20					
						20					
						20					
					20						
					30						
					30						
					30						
					30						

## Moving arm type

Z-axis		
Speed (mm/sec)	Stroke (mm)	Installation method
600	150	Clamped base · moving table type (100W)
	250	
	350	
1200	150	Clamped base · moving table type (200W)
	250	
	350	
600	150	Clamped table · moving base type (200W)
	250	
	350	
1000	150	Shaft vertical type
500	150	
600	150	Clamped base · moving table type (200W)
	250	
	350	
1200	150	Clamped base · moving table type (200W)
	250	
	350	
600	150	Clamped table · moving base type (200W)
	250	
	350	
300	250	Clamped table · moving base type (200W)
	350	
	450	
	550	

Payload (kg)	Y-axis stroke (mm)										
	150	250	350	450	550	650	750	850	950	1050	
	9	8	7								
	8	7	6								
	7	6	5								
	8	8	7								
	8	7	6								
	7	6	5								
	9	8	7								
	8	7	6								
	7	6	5								
	3										
	5										
	12										
11											
10											
8											
12											
11											
10											
			18								
			18		17						
			18		16						
			18		15						

## Pole type

Z-axis		
Speed (mm/sec)	Stroke (mm)	Installation method
1200	150	Clamped table · moving base type (200W)
	250	
	350	
1200	250	Clamped table · moving base type (200W)
	350	
	450	
	550	
	650	
1200	250	Clamped table · moving base type (200W)
	350	
	450	
	550	
	650	

Payload (kg)	Y-axis stroke (mm)										
	150	250	350	450	550	650	750	850	950	1050	
	10										
	9										
	8										
							15				
							15				
							15				
							15				
							15				
							15				
							15				
							15				
							15				

④	⑤	⑥	⑦ Decide the model	
Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model <sup>(Note 1)</sup>	Detailed info page
Cable carrier	250 to 1050	1200 / 1200	MXYx-C-G*-ZFL10	<a href="#">P.321</a>
Cable carrier	250 to 1050	1200 / 1200	MXYx-C-G*-ZFL20	<a href="#">P.321</a>
Cable carrier	250 to 1050	1200 / 1200	MXYx-C-G*-ZFH	<a href="#">P.322</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-G*-ZL	<a href="#">P.328</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-G*-ZH	<a href="#">P.329</a>

Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model <sup>(Note 1)</sup>	Detailed info page
Whipover	150 to 850	1200 / 1200	SXYx-S-M*-ZF	<a href="#">P.336</a>
Whipover	150 to 850	1200 / 1200	SXYx-S-M*-ZFL20	<a href="#">P.337</a>
Whipover	150 to 850	1200 / 1200	SXYx-S-M*-ZFH	<a href="#">P.338</a>
Whipover	150 to 850	1200 / 1200	SXYx-S-M*-ZS12	<a href="#">P.339</a>
Whipover	150 to 850	1200 / 1200	SXYx-S-M*-ZS6	<a href="#">P.339</a>
Cable carrier	250 to 1250	1200 / 1200	MXYx-C-M*-ZFL10	<a href="#">P.342</a>
Cable carrier	250 to 1250	1200 / 1200	MXYx-C-M*-ZFL20	<a href="#">P.342</a>
Cable carrier	250 to 1250	1200 / 1200	MXYx-C-M*-ZFH	<a href="#">P.343</a>
Cable carrier	250 to 1250	1200 / 1200	HXYx-C-M*-ZH	<a href="#">P.346</a>

Note 1. The figure entered at \* inside the form, expresses the arm variation. See P.240 for more information.

Cable type	X-axis stroke (mm)	Maximum speed (X-axis / Y-axis) (mm/sec)	Model	Detailed info page
Cable carrier	250 to 1250	1200 / 600	MXYx-C-P2-ZPMH	<a href="#">P.351</a>
Cable carrier	250 to 1250	1200 / 600	HXYx-C-P2-ZPH	<a href="#">P.354</a>
Whipover	250 to 850	1200 / 600	HXYx-S-P1-ZPH	<a href="#">P.355</a>

# Robot ordering method description

In the order format for the YAMAHA cartesian robots XY-X series, the notation (letters/numbers) for the mechanical section is shown linked to the controller section notation.

## [Example]

### 2-axis specifications

#### Mechanical ▶ FXYx (Arm type)

- Cable variations ▷ Cable carrier
- Combination (Arm variations) ▷ A1
- X-axis stroke ▷ 450mm
- Y-axis stroke ▷ 350mm
- Robot cable length ▷ 3.5M

#### Controller ▶ RCX222


### Ordering method

**FXYx - C - A1 - 45 - 35 - 3L - RCX222**

Mechanical section

Controller section

To find detailed controller information see the controller page. **RCX222 ▶ P.524**



Note 1. To find detailed information on arm variations (combinations) see P.240.

## [Example]

### 3 / 4-axis specifications

#### Mechanical ▶ SXYx (Moving arm type)

- Cable variations ▷ Whipover
- Combination (Arm variations) ▷ M3
- X-axis stroke ▷ 850mm
- Y-axis stroke ▷ 150mm
- Z-axis stroke ▷ 150mm
- Robot cable length ▷ 5M

#### Controller ▶ RCX240S


### Ordering method

**SXYx - S - M3 - 85 - 15 - ZFH - 15 - 5L - RCX240S**

Mechanical section







Controller section

To find detailed controller information see the controller page. **RCX240 ▶ P.532, RCX340 ▶ P.542**





# Robot ordering method terminology

① <b>Model</b>	Enter the robot unit model.
② <b>Cable</b>	Cable specs can be selected. To find detailed information see P.240. C: Cable carrier S: Whipover
③ <b>Combination (Arm variations)</b>	<p>Select the arm variation and combination method.</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 15%;"> <p>● <b>Arm type</b> The type with moving Y-axis carriage.</p>  </div> <div style="width: 15%;"> <p>● <b>Gantry type</b> The type with a guide railing at the end of Y-axis for support.</p>  </div> <div style="width: 15%;"> <p>● <b>Moving arm type</b> The type with a moving Y-axis arm.</p>  </div> <div style="width: 15%;"> <p>● <b>Pole type</b> The type with vertically moving Y-axis carriage.</p>  </div> <div style="width: 15%;"> <p>● <b>XZ type</b> The type with combination of X-axis for horizontal movement and Z-axis for vertical movement.</p>  </div> <div style="width: 15%;"> <p>● <b>Clean type</b> Special model for clean rooms with moving Y-axis carriage installed upward.</p>  </div> </div> <p>To find information on combinations see P.240.</p>
④ <b>X-axis stroke</b>	Select the X axis stroke. Enter in centimeters (cm). (For example enter 50 for a stroke of 500mm.)
⑤ <b>Y-axis stroke</b>	Select the Y axis stroke. Enter in centimeters (cm). (For example enter 50 for a stroke of 500mm.)
⑥ <b>ZR-axis</b>	<p>Select the Z axis installation direction. The R axis is installed with 4-axis specifications. To find more information see P.37.</p> <p><b>[3-axes]</b></p> <p>ZS : Shaft vertical type          ZT : Clamped base · moving table type (60W)          ZF : Clamped base · moving table type (100W)          ZFL/ZL : Clamped base · moving table type (200W)          ZFH/ZH : Clamped table · moving base type (200W)          ZPMH/ZPH : Clamped table · moving base type (200W) for pole type</p> <p><b>[4-axes]</b></p> <p>ZRF : Clamped base · moving table type (100W)+R axis          ZRS : ZR axis integrated type          ZRL/ZRFL : Clamped base · moving table type (200W)+R axis          ZRH/ZRFH : Clamped table · moving base type (200W)+R axis</p>
⑦ <b>Z-axis stroke</b>	Select the Z axis stroke. Enter in centimeters (cm). (For example enter 15 for a stroke of 150mm.)
⑧ <b>Cable</b>	Select the length of the robot cable connecting the robot and controller. <b>3L</b> : 3.5m <b>5L</b> : 5m <b>10L</b> : 10m
⑨ <b>Controller</b>	<b>2-axis specifications:</b> Select the RCX222. <b>3 / 4-axis specifications:</b> Select either the RCX240 (RCX240S) or RCX340.

Articulated robots
YA
Linear conveyor modules
LCM100
Compact single-axis robots
TRANSEVO
Single-axis robots
FLIP-X
Linear motor single-axis robots
PHASER
Cartesian robots
XX-X
SCARA robots
YK-X
Pick & place robots
YP-X
CLEAN
CONTROLLER INFORMATION
Arm type
Gantry type
Moving arm type
Pole type
XZ type

# PXYx 2 axes

● Arm type   ● Cable carrier



## Ordering method

<b>PXYx - C</b>					<b>RCX222</b>				
Model	Cable	Combination	X-axis stroke	Y-axis stroke	Cable	Controller	Usable for CE	Input/Output selection 1	Input/Output selection 2
A1			15 to 65cm	5 to 30cm	3L: 3.5m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup> YC: YC-Link <sup>Note 3</sup>
A2					5L: 5m				
A3					10L: 10m				
A4									

Note 1. NPN cannot be selected if using CE marking.  
Note 2. Available only for the master. See P.66 for details on YC-Link system.  
Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
Axis construction <sup>Note 1</sup>	—	T4H
AC servo motor output (W)	60	30
Repeatability <sup>Note 2</sup> (mm)	+/-0.02	+/-0.02
Drive system	Ball screw (Class C10)	Ball screw (Class C10)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	12	12
Maximum speed <sup>Note 4</sup> (mm/sec)	720	720
Moving range (mm)	150 to 650	50 to 300
Robot cable length (m)	Standard: 3.5   Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
Note 2. Positioning repeatability in one direction.  
Note 3. Leads not listed in the catalog are also available. Contact us for details.  
Note 4. When the X-axis stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
50	4.5
100	4.5
150	3.5
200	2.5
250	2
300	1.5

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## PXYx 2 axes A1




Use M4 x 0.7 hex socket head bolt with length head bolt with length (under head) of 15mm or more.

X stroke	150	250	350	450	550	650
L	404.5	504.5	604.5	704.5	804.5	904.5
M	5	8	10	13	15	18
N	12	18	22	28	32	38
Y stroke	50	100	150	200	250	300
Maximum speed for each stroke (mm/sec) <sup>Note 2</sup>	720					600
Speed setting	—					83%


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. When the X-axis stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.


PXYx 2 axes **A2**



PXYx 2 axes **A3**



PXYx 2 axes **A4**



# FXYx 2 axes



- Arm type
- Cable carrier

## Ordering method

<b>FXYx - C</b>					<b>RCX222</b>				
Model	Cable	Combination	X-axis stroke	Y-axis stroke	Cable	Controller	Usable for CE	Input/Output selection 1	Input/Output selection 2
A1			15 to 105cm	15 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ <sup>Note 1</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b>	—	—
<b>AC servo motor output (W)</b>	100	60
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.01	+/-0.02
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C10)
<b>Ball screw lead</b> <sup>Note 2</sup> (Deceleration ratio) (mm)	20	12
<b>Maximum speed</b> <sup>Note 3</sup> (mm/sec)	1200	800
<b>Moving range (mm)</b>	150 to 1050	150 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Positioning repeatability in one direction.  
 Note 2. Leads not listed in the catalog are also available. Contact us for details.  
 Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	12
250	12
350	11
450	9
550	7

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## FXYx 2 axes A1




X stroke	150	250	350	450	550	650	750	850	950	1050
	L	460	560	660	760	860	960	1060	1160	1260
K	200	100	200	100	200	100	200	100	200	100
D	240	240	420	420	600	600	780	960	960	1140
M	0	1	1	2	2	3	3	4	4	5
N	6	8	8	10	10	12	12	14	14	16
Y stroke	150	250	350	450	550					
<b>Maximum speed for each stroke (mm/sec)</b>	X-axis		1200			960		780	600	540
<b>Speed setting</b>			—			80%		65%	50%	45%


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.


**FXYx 2 axes A2**



**FXYx 2 axes A3**




**FXYx 2 axes A4**



Articulated robots  
 YA  
 Linear conveyor modules  
 LCM100  
 Compact single-axis robots  
 TRANSEVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XX-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER INFORMATION  
 Arm type  
 Gantry type  
 Moving arm type  
 Pole type  
 XZ type

# FXYx 2 axes / IO



- Arm type
- Cable carrier
- Type with Y-axis I/O cable carrier added

## Ordering method

<b>FXYx - C</b>					<b>IO</b>		<b>RCX222</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>ZR-axis</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1			15 to 105cm	15 to 55cm		3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b>	-	-
<b>AC servo motor output (W)</b>	100	60
<b>Repeatability<sup>Note 1</sup> (mm)</b>	+/-0.01	+/-0.02
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C10)
<b>Ball screw lead<sup>Note 2</sup> (Deceleration ratio) (mm)</b>	20	12
<b>Maximum speed<sup>Note 3</sup> (mm/sec)</b>	1200	800
<b>Moving range (mm)</b>	150 to 1050	150 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	

Note 1. Positioning repeatability in one direction.  
 Note 2. Leads not listed in the catalog are also available. Contact us for details.  
 Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	12
250	12
350	11
450	9
550	7

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## FXYx 2 axes / IO A1



X stroke	Y stroke										
	150	250	350	450	550	650	750	850	950	1050	
<b>L</b>	460	560	660	760	860	960	1060	1160	1260	1360	
<b>K</b>	200	100	200	100	200	100	200	100	200	100	
<b>D</b>	240	240	420	420	600	600	780	960	960	1140	
<b>M</b>	0	1	1	2	2	3	3	4	4	5	
<b>N</b>	6	8	8	10	10	12	12	14	14	16	
<b>Y stroke</b>	<b>150</b>	<b>250</b>	<b>350</b>	<b>450</b>	<b>550</b>						
<b>Maximum speed for each stroke (mm/sec)<sup>Note 3</sup></b>	<b>X-axis</b>	1200				960	780	600	540		
	<b>Speed setting</b>	-				80%	65%	50%	45%		

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# FXYx 3 axes / ZS

- Arm type
- Cable carrier
- Z-axis shaft vertical type



## Ordering method

<b>FXYx - C</b>							<b>15</b>							<b>RCX340-3</b>								
Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery	Specify various controller setting items. RCX340 ▶ <b>P.542</b>						
A1		A1	15 to 105cm	15 to 55cm	ZS12		3L: 3.5m	<b>RCX240S</b>							Specify various controller setting items. RCX240/RCX240S ▶ <b>P.532</b>							
A2		A2			ZS6		5L: 5m	Controller	CE Marking	Expansion I/O	Network option	IVY System	Gripper	Battery								
A3		A3					10L: 10m															
A4		A4																				

## Specification

	X-axis	Y-axis	Z-axis: ZS12	Z-axis: ZS6
Axis construction	-	-	-	
AC servo motor output (W)	100	60	60	
Repeatability <sup>Note 1</sup> (mm)	+/-0.01	+/-0.02	+/-0.02	
Drive system	Ball screw (Class C7)	Ball screw (Class C10)	Ball screw (Class C10)	
Ball screw lead <sup>Note 2</sup> (Deceleration ratio) (mm)	20	12	12	6
Maximum speed <sup>Note 3</sup> (mm/sec)	1200	800	1000	500
Moving range (mm)	150 to 1050	150 to 550	150	
Robot cable length (m)	Standard: 3.5 Option: 5,10			

Note 1. Positioning repeatability in one direction.  
 Note 2. Leads not listed in the catalog are also available. Contact us for details.  
 Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.



## Maximum payload (kg)

Y stroke (mm)	ZS12	ZS6
150	3	5
250	3	5
350	3	5
450	3	5
550	3	3

## Controller

Controller	Operation method
RCX340 RCX240S	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## FXYx 3 axes / ZS (A1)



X stroke											
	150	250	350	450	550	650	750	850	950	1050	
L	460	560	660	760	860	960	1060	1160	1260	1360	
K	200	100	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	960	1140	
M	0	1	1	2	2	3	3	4	4	5	
N	6	8	8	10	10	12	12	14	14	16	
Y stroke	150	250	350	450	550						
Z stroke	150										
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis		1200				960	780	600	540	
	Speed setting		-				80%	65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

- Articulated robots
- YA
- Linear conveyor modules
- LCM100
- Compact single-axis robots
- TRANSERVO
- Single-axis robots
- FLIP-X
- Linear motor single-axis robots
- PHASER
- Cartesian robots
- XX-X
- SCARA robots
- YK-X
- Pick & place robots
- YP-X
- CLEAN
- CONTROLLER INFORMATION
- Arm type
- Gantry type
- Moving arm type
- Pole type
- XZ type

# FXYx

## 3 axes / ZT



- Arm type
- Cable carrier
- Z-axis: clamped base / moving table type (60W)

### Ordering method

<b>FXYx - C</b>				<b>ZT6-12</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>ZR-axis</b>	<b>Lead</b>	<b>Z-axis stroke</b>
		A1 A2 A3 A4	15 to 105cm	15 to 55cm			3L: 3.5m 5L: 5m 10L: 10m

<b>RCX340-3</b>									
<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>		

Specify various controller setting items. RCX340 ▶ **P.542**

<b>RCX240S</b>									
<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>iVY System</b>	<b>Gripper</b>	<b>Battery</b>			

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <small>Note 1</small>	-	-	T6-12-BK
<b>AC servo motor output (W)</b>	100	60	60
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.02	+/-0.02
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C10)	Ball screw (Class C10)
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	12	12
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1200	800	800
<b>Moving range (mm)</b>	150 to 1050	150 to 550	50 to 300
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

### Maximum payload (kg)



Y stroke (mm)	ZT
150 to 550	3

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S	

### FXYx 3 axes / ZT (A1)



X stroke	150	250	350	450	550	650	750	850	950	1050
<b>L</b>	460	560	660	760	860	960	1060	1160	1260	1360
<b>K</b>	200	100	200	100	200	100	200	100	200	100
<b>D</b>	240	240	420	420	600	600	780	960	960	1140
<b>M</b>	0	1	1	2	2	3	3	4	4	5
<b>N</b>	6	8	8	10	10	12	12	14	14	16
<b>Y stroke</b>	150	250	350	450	550					
<b>Z stroke</b>	50	100	150	200	250	300				
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 1</small>	<b>X-axis</b>		1200				960	780	600	540
<b>Speed setting</b>			-				80%	65%	50%	45%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type

XZ type

# FXyBx 2 axes

- Arm type
- Cable carrier



## Ordering method

<b>FXyBx - C</b>					<b>RCX222</b>				
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1			15 to 245cm	15 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>
A2									
A3									
A4									

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	B10	-
<b>AC servo motor output (W)</b>	100	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.04	+/-0.04
<b>Drive system</b>	Timing belt	Timing belt
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25
<b>Maximum speed (mm/sec)</b>	1875	1875
<b>Moving range (mm)</b>	150 to 2450	150 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	XY axes
150	7
250	6
350	5
450	5
550	3

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## FXyBx 2 axes A1




Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.  
 Note 3. The dimension marked with an asterisk (\*) indicates the height of the screw.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450
L	560	660	760	860	960	1060	1160	1260	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260	2360	2460	2560	2660	2760	2860
K	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200
M	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12
N	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30
G	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50
J	330	330	430	430	530	530	630	630	730	730	830	830	930	930	1030	1030	1130	1130	1230	1230	1330	1330	1430	1430
Y stroke	150	250	350	450	550																			


**FXYBx 2 axes** **A2**








**Detail of section A**




**Detail of section B**




**Cross-section of cable carrier**




**FXYBx 2 axes** **A3**








**Detail of section A**





**Detail of section B**




**Cross-section of cable carrier**




**FXYBx 2 axes** **A4**







**Detail of section A**



**Detail of section B**



**Cross-section of cable carrier**



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type

Moving arm type

Pole type

XZ type

# FXyBx 2 axes

● Arm type ● Whipover

## Ordering method

<b>FXyBx - S</b>					<b>RCX222</b>				
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1			15 to 95cm	15 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	B10	-
<b>AC servo motor output (W)</b>	100	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.04	+/-0.04
<b>Drive system</b>	Timing belt	Timing belt
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25
<b>Maximum speed (mm/sec)</b>	1875	1875
<b>Moving range (mm)</b>	150 to 950	150 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	7
250	6
350	5
450	5
550	3

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## FXyBx 2 axes A1




X stroke	150	250	350	450	550	650	750	850	950
<b>L</b>	560	660	760	860	960	1060	1160	1260	1360
<b>K</b>	100	200	100	200	100	200	100	200	100
<b>M</b>	1	1	2	2	3	3	4	4	5
<b>N</b>	8	8	10	10	12	12	14	14	16
<b>Y stroke</b>	150	250	350	450	550				

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. The dimension marked with an asterisk (\*) indicates the height of the screw.


**FXYBx 2 axes (A2)**



**FXYBx 2 axes (A3)**




**FXYBx 2 axes (A4)**



# FXyBx 2 axes / IO

- Arm type
- Cable carrier
- Type with Y-axis I/O cable carrier added



## Ordering method

<b>FXyBx - C</b>				<b>IO</b>		<b>RCX222</b>				
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>ZR-axis</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1		A1	15 to 245cm	15 to 55cm		3L: 3.5m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>
A2		A2				5L: 5m				
A3		A3				10L: 10m				
A4		A4								

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	B10	-
<b>AC servo motor output (W)</b>	100	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.04	+/-0.04
<b>Drive system</b>	Timing belt	Timing belt
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25
<b>Maximum speed (mm/sec)</b>	1875	1875
<b>Moving range (mm)</b>	150 to 2450	150 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	7
250	6
350	5
450	5
550	3

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## FXyBx 2 axes / IO (A1)



Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper. Note 3. The dimension marked with an asterisk (\*) indicates the height of the screw.  
 Note 2. The shaded position indicates a user cable extraction port.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450
<b>L</b>	560	660	760	860	960	1060	1160	1260	1360	1460	1560	1660	1760	1860	1960	2060	2160	2260	2360	2460	2560	2660	2760	2860
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200
<b>M</b>	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30
<b>G</b>	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50
<b>J</b>	330	330	430	430	530	530	630	630	730	730	830	830	930	930	1030	1030	1130	1130	1230	1230	1330	1330	1430	1430
<b>Y stroke</b>	150	250	350	450	550																			

Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type

XZ type

# SXYx 2 axes

● Arm type   ● Cable carrier



## Ordering method

<b>SXYx - C</b>					<b>RCX222</b>				
Model	Cable	Combination	X-axis stroke	Y-axis stroke	Cable	Controller	Usable for CE	Input/Output selection 1	Input/Output selection 2
A1			15 to 105cm	15 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14
<b>AC servo motor output (W)</b>	200	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	150 to 1050	150 to 650
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	20
250	17
350	15
450	13
550	11
650	9

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 2 axes A1




X stroke	Y stroke										
	150	250	350	450	550	650	750	850	950	1050	
<b>L</b>	470	570	670	770	870	970	1070	1170	1270	1370	
<b>K</b>	200	100	200	100	200	100	200	100	200	100	
<b>D</b>	240	240	420	420	600	600	780	960	960	1140	
<b>M</b>	0	1	1	2	2	3	3	4	4	5	
<b>N</b>	4	6	6	8	8	10	10	12	12	14	
<b>Y stroke</b>	150	250	350	450	550	650					
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>	1200					960	780	600	540	
	<b>Speed setting</b>	-					80%	65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.


Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.




SXYx 2 axes **A2**



SXYx 2 axes **A3**




SXYx 2 axes **A4**



# SXYx 2 axes

● Arm type ● Whipover



## Ordering method

<b>SXYx - S</b>					<b>RCX222</b>				
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1			15 to 85cm	15 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14
<b>AC servo motor output (W)</b>	200	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	150 to 850	150 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.



## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	20
250	17
350	15
450	13
550	11
650	9

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## SXYx 2 axes A1





Detail of section A



Detail of section B



Detail of section C




X stroke	150	250	350	450	550	650	750	850	
<b>L</b>	470	570	670	770	870	970	1070	1170	
<b>K</b>	200	100	200	100	200	100	200	100	
<b>D</b>	240	240	420	420	600	600	780	960	
<b>M</b>	0	1	1	2	2	3	3	4	
<b>N</b>	4	6	6	8	8	10	10	12	
<b>Y stroke</b>	150	250	350	450	550	650			
<b>Maximum speed for each stroke (mm/sec)</b>	<b>X-axis</b>		1200				960	780	
	<b>Speed setting</b>		-				80%	65%	


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table above.


SXYx 2 axes **A2**



SXYx 2 axes **A3**



SXYx 2 axes **A4**



Articulated robots  
**YA**

Linear conveyor modules  
**LCM100**

Compact single-axis robots  
**TRANSEVO**

Single-axis robots  
**FLIP-X**

Linear motor single-axis robots  
**PHASER**

Cartesian robots  
**XX-X**

SCARA robots  
**YK-X**

Pick & place robots  
**YP-X**

**CLEAN**

**CONTROLLER**

**INFORMATION**

Arm type

Gantry type


Moving arm type

Pole type

XZ type

# SXYx 2 axes / IO

● Arm type ● Cable carrier



## Ordering method

<b>SXYx - C</b>				<b>IO</b>		<b>RCX222</b>				
Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Cable	Controller	Usable for CE	Input/Output selection 1	Input/Output selection 2
A1			15 to 105cm	15 to 65cm		3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
Axis construction <sup>Note 1</sup>	F14H	F14
AC servo motor output (W)	200	100
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200
Moving range (mm)	150 to 1050	150 to 650
Robot cable length (m)	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	19
250	16
350	14
450	12
550	10
650	8

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 2 axes / IO A1



X stroke	150	250	350	450	550	650	750	850	950	1050
L	470	570	670	770	870	970	1070	1170	1270	1370
K	200	100	200	100	200	100	200	100	200	100
D	240	240	420	420	600	600	780	960	960	1140
M	0	1	1	2	2	3	3	4	4	5
N	4	6	6	8	8	10	10	12	12	14
Y stroke	150	250	350	450	550	650				
T	55	110	165	220	275	330				

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200	960	780	600	540
Speed setting		-	80%	65%	50%	45%

Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type

XZ type

# SXYx 3 axes / ZF

● Arm type ● Cable carrier ● Z-axis: clamped base / moving table type (100W)



## Ordering method

**SXYx - C** [ ] [ ] [ ] **ZF** [ ] [ ] [ ]

**Model** - **Cable** - **Combination** - **X-axis stroke** - **Y-axis stroke** - **ZR-axis** - **Z-axis stroke** - **Cable**

A1: 15 to 105cm  
 A2: 15 to 65cm  
 A3: 15 to 35cm  
 A4: 15 to 35cm

3L: 3.5m  
 5L: 5m  
 10L: 10m

**RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller / Number of controllable axes - Safety standard - Option A (OP.A) - Option B (OP.B) - Option C (OP.C) - Option D (OP.D) - Option E (OP.E) - Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller - CE Marking - Expansion I/O - Network option - iVY System - Gripper - Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14	F10-BK
<b>AC servo motor output (W)</b>	200	100	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200	600
<b>Moving range (mm)</b>	150 to 1050	150 to 650	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10		

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	10	10	10
250	10	10	9
350	9	8	7
450	7	6	5
550	5	4	3
650	3	2	1

## Controller


Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S	

## SXYx 3 axes / ZF A1



X stroke	L										
	150	250	350	450	550	650	750	850	950	1050	
L	470	570	670	770	870	970	1070	1170	1270	1370	
K	200	100	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	960	1140	
M	0	1	1	2	2	3	3	4	4	5	
N	4	6	6	8	8	10	10	12	12	14	
Y stroke	T										
	150	250	350	450	550	650					
T	55	110	165	220	275	330					
Z stroke	T										
	150	250	350								
T	55	110	165								
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	1200						960	780	600	540	
<b>Speed setting</b>	-						80%	65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.  
 Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



### Ordering method

**SXYx - S** [ ] [ ] [ ] **ZF** [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** - **Cable** - **Combination** - **X-axis stroke** - **Y-axis stroke** - **ZR-axis** - **Z-axis stroke** - **Cable**

A1	15 to 85cm	15 to 65cm	15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m
A2				
A3				
A4				

**RCX340-3** Controller / Number of controllable axes - Safety standard - Option A (OP.A) - Option B (OP.B) - Option C (OP.C) - Option D (OP.D) - Option E (OP.E) - Absolute battery

**RCX240S** Controller - CE Marking - Expansion I/O - Network option - iVY System - Gripper - Battery

Specify various controller setting items. RCX340 ▶ **P.542**

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis
Axis construction <sup>Note 1</sup>	F14H	F14	F10-BK
AC servo motor output (W)	200	100	100
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	600
Moving range (mm)	150 to 850	150 to 650	150 to 350
Robot cable length (m)	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	10	10	10
250	10	10	9
350	9	8	7
450	7	6	5
550	5	4	3
650	3	2	1

### Controller

Controller	Operation method
RCX340 RCX240S	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### SXYx 3 axes / ZF (A1)



X stroke	Y stroke								
	150	250	350	450	550	650	750	850	
L	470	570	670	770	870	970	1070	1170	
K	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	
M	0	1	1	2	2	3	3	4	
N	4	6	6	8	8	10	10	12	
Y stroke	150	250	350	450	550	650			
Z stroke	150	250	350						
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200				960	780		
	Speed setting	-				80%	65%		

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type

Moving arm type

Pole type

XZ type

# SXYx **3 axes / ZFL20**

- Arm type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)



## Ordering method

**SXYx - C**   **ZFL20**   **RCX340-3**   **RCX240S**

Model   Cable   Combination   X-axis stroke   Y-axis stroke   ZR-axis   Z-axis stroke   Cable

Controller / Number of controllable axes   Safety standard   Option A (OP.A)   Option B (OP.B)   Option C (OP.C)   Option D (OP.D)   Option E (OP.E)   Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

Controller   CE Marking   Regenerative unit   Expansion I/O   Network option   iVY System   Gripper   Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specification

	X-axis	Y-axis	Z-axis
Axis construction <sup>Note 1</sup>	F14H	F14	F10-BK equivalent guide-reinforced model
AC servo motor output (W)	200	100	200
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	20
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	1200
Moving range (mm)	150 to 1050	150 to 650	150 to 350
Robot cable length (m)	Standard: 3.5   Option: 5, 10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	8	8	8
250	8	8	8
350	8	7	6
450	6	5	4
550	4	3	2
650	2	1	1

## Controller

Controller	Operation method
RCX340 RCX240S-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 3 axes / ZFL20 **A1**



X stroke													
	150	250	350	450	550	650	750	850	950	1050			
L	470	570	670	770	870	970	1070	1170	1270	1370			
K	200	100	200	100	200	100	200	100	200	100			
D	240	240	420	420	600	600	780	960	960	1140			
M	0	1	1	2	2	3	3	4	4	5			
N	4	6	6	8	8	10	10	12	12	14			
Y stroke	150	250	350	450	550	650							
T	55	110	165	220	275	330							
Z stroke	150	250	350										
Maximum speed for each stroke (mm/sec)	X-axis		1200			960		780		600		540	
Speed setting			-			80%		65%		50%		45%	


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



# SXYx 3 axes / ZFH

● Arm type ● Cable carrier ● Z-axis: clamped table / moving base type (200W)



## Ordering method

**SXYx - C** [ ] [ ] [ ] **ZFH** [ ] [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** - **Cable** - **Combination** - **X-axis stroke** - **Y-axis stroke** - **ZR-axis** - **Z-axis stroke** - **Cable**

A1: 15 to 105cm  
 A2: 15 to 65cm  
 A3: 15 to 35cm  
 A4: 3L: 3.5m, 5L: 5m, 10L: 10m

**RCX340-3** Controller / Number of controllable axes - Safety standard - Option A (OP.A) - Option B (OP.B) - Option C (OP.C) - Option D (OP.D) - Option E (OP.E) - Absolute battery

**RCX240S** Controller - CE Marking - Regenerative unit - Expansion I/O - Network option - IVY System - Gripper - Battery

Specify various controller setting items. **RCX340 ▶ P.542**  
**RCX240S ▶ P.532**

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	200	100	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200	600
<b>Moving range (mm)</b>	150 to 1050	150 to 650	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	13	12	11
250	10	9	8
350	8	7	6
450	6	5	4
550	4	3	2
650	2	1	1

## Controller

Controller	Operation method
RCX340 RCX240S-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## SXYx 3 axes / ZFH A1



X stroke	X stroke										
	150	250	350	450	550	650	750	850	950	1050	
L	470	570	670	770	870	970	1070	1170	1270	1370	
K	200	100	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	960	1140	
M	0	1	1	2	2	3	3	4	4	5	
N	4	6	6	8	8	10	10	12	12	14	
Y stroke	Y stroke										
	150	250	350	450	550	650					
T	55	110	165	220	275	330					
Z stroke	Z stroke										
	150	250	350								
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200					960	780	600	540	
	Speed setting	-					80%	65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.  
 Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYx 3 axes / ZS



- Arm type
- Cable carrier
- Z-axis shaft vertical type

## Ordering method

**SXYx - C** [ ] [ ] [ ] [ ] **15** [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X-axis stroke** **Y-axis stroke** **ZR-axis** **Z-axis stroke** **Cable** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**RCX240S** [ ]

**Specify various controller setting items. RCX340 ▶ P.542**  
**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specification

	X-axis	Y-axis	Z-axis ZS12	Z-axis ZS6
<b>Axis construction</b> <small>Note 1</small>	F14H	F14	-	
<b>AC servo motor output (W)</b>	200	100	60	
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01	+/-0.02	
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C10)	
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	12	6
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1200	1200	1000	500
<b>Moving range (mm)</b>	150 to 1050	150 to 650	150	
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10			

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	ZS12	ZS6
150 to 650	3	5

## Controller


Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S	

## SXYx 3 axes / ZS (A1)



X stroke	150	250	350	450	550	650	750	850	950	1050			
<b>L</b>	470	570	670	770	870	970	1070	1170	1270	1370			
<b>K</b>	200	100	200	100	200	100	200	100	200	100			
<b>D</b>	240	240	420	420	600	600	780	960	960	1140			
<b>M</b>	0	1	1	2	2	3	3	4	4	5			
<b>N</b>	4	6	6	8	8	10	10	12	12	14			
<b>Y stroke</b>	150	250	350	450	550	650							
<b>T</b>	55	110	165	215	270	325							
<b>Z stroke</b>	150												
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	X-axis		1200			960		780		600		540	
<b>Speed setting</b>	-		-			80%		65%		50%		45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.  
 Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



### Ordering method

**SXYx - S** [ ] [ ] [ ] [ ] **15** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
A1			15 to 85cm	15 to 65cm	ZS12		3L: 3.5m
A2					ZS6		5L: 5m
A3							10L: 10m
A4							

**RCX340-3** [ ]

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S** [ ]

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis: ZS12	Z-axis: ZS6
Axis construction <sup>Note 1</sup>	F14H	F14	-	
AC servo motor output (W)	200	100	60	
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.02	
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C10)	
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	12	6
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	1000	500
Moving range (mm)	150 to 850	150 to 650	150	
Robot cable length (m)	Standard: 3.5 Option: 5,10			

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	ZS12	ZS6
150 to 650	3	5

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S	

### SXYx 3 axes / ZS (A1)



X stroke	150	250	350	450	550	650	750	850	
L	470	570	670	770	870	970	1070	1170	
K	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	
M	0	1	1	2	2	3	3	4	
N	4	6	6	8	8	10	10	12	
Y stroke	150	250	350	450	550	650			
Z stroke	150								
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis		1200			960	780		
Speed setting			-			80%	65%		

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type

Moving arm type

Pole type

XZ type

# SXYx 4 axes / ZRF

- Arm type
- Cable carrier
- Z-axis: clamped base / moving table type (100W)+R-axis



## Ordering method

**SXYx - C**    **ZRF**    **RCX340-4**    **RCX240S**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
		A1	15 to 105cm	15 to 65cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m								

Specify various controller setting items. RCX340 ▶ P.542

Specify various controller setting items. RCX240/RCX240S ▶ P.532

## Specification

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis construction</b> <small>Note 1</small>	F14H	F14	F10-BK	R5
<b>AC servo motor output (W)</b>	200	100	100	50
<b>Repeatability</b> <small>Note 2</small> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	10	(1/50)
<b>Maximum speed</b> <small>Note 4</small> (XYZ: mm/sec) (R: °/sec)	1200	1200	600	360
<b>Moving range (XYZ: mm) (R: °)</b>	150 to 1050	150 to 650	150 to 350	360
<b>Robot cable length (m)</b>	Standard: 3.5    Option: 5, 10			

- Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	6	6	6
250	6	5	4
350	4	3	2
450	3	2	1
550	2	1	-
650	1	-	-

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S	

## SXYx 4 axes / ZRF A1




X stroke													
	150	250	350	450	550	650	750	850	950	1050			
<b>L</b>	470	570	670	770	870	970	1070	1170	1270	1370			
<b>K</b>	200	100	200	100	200	100	200	100	200	100			
<b>D</b>	240	240	420	420	600	600	780	960	960	1140			
<b>M</b>	0	1	1	2	2	3	3	4	4	5			
<b>N</b>	4	6	6	8	8	10	10	12	12	14			
<b>Y stroke</b>													
<b>T</b>	55	110	165	220	275	330							
<b>Z stroke</b>													
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	<b>X-axis</b>		1200			960		780		600		540	
	<b>Speed setting</b>		-			80%		65%		50%		45%	

- Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

- Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYx 4 axes / ZRF

● Arm type ● Whipover ● Z-axis: clamped base / moving table type (100W)+R-axis



## Ordering method

**SXYx - S** [ ] [ ] [ ] **ZRF** [ ] [ ]

<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>ZR-axis</b>	<b>Z-axis stroke</b>	<b>Cable</b>
A1			15 to 85cm	15 to 65cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m
A2							
A3							
A4							

**RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ]

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P542**

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ]

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>iVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

## Specification

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis construction</b> <small>Note 1</small>	F14H	F14	F10-BK	R5
<b>AC servo motor output (W)</b>	200	100	100	50
<b>Repeatability</b> <small>Note 2</small> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	10	(1/50)
<b>Maximum speed</b> <small>Note 4</small> (XYZ: mm/sec) (R: °/sec)	1200	1200	600	360
<b>Moving range (XYZ: mm) (R: °)</b>	150 to 850	150 to 650	150 to 350	360
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10			

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.







## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	6	6	6
250	6	5	4
350	4	3	2
450	3	2	1
550	2	1	-
650	1	-	-

## Controller

Controller	Operation method
RCX340 RCX240S	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 4 axes / ZRF A1



X stroke	150	250	350	450	550	650	750	850	
	<b>L</b>	470	570	670	770	870	970	1070	1170
<b>K</b>	200	100	200	100	200	100	200	100	
<b>D</b>	240	240	420	420	600	600	780	960	
<b>M</b>	0	1	1	2	2	3	3	4	
<b>N</b>	4	6	6	8	8	10	10	12	
Y stroke		150	250	350	450	550	650		
Z stroke		150	250	350					
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	<b>X-axis</b>	1200					960	780	
	<b>Speed setting</b>	-					80%	65%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YA-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type


Gantry type

Moving arm type

Pole type

XZ type

- Arm type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)+R-axis



### Ordering method

**SXYx - C - ZRFL20 - RCX340-4**

Model: Cable, Combination (A1-A4), X-axis stroke (15 to 105cm), Y-axis stroke (15 to 55cm), ZR-axis, Z-axis stroke (15 to 35cm), Cable (3L: 3.5m, 5L: 5m, 10L: 10m)

**RCX340-4**: Controller / Number of controllable axes, Safety standard, Option A (OP.A), Option B (OP.B), Option C (OP.C), Option D (OP.D), Option E (OP.E), Absolute battery

**RCX240S - R**: Controller, CE Marking, Regenerative unit, Expansion I/O, Network option, IVY System, Gripper, Battery

**Specify various controller setting items. RCX340 ▶ P.542**

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

### Specification

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14	F10-BK equivalent guide-reinforced model	R5
<b>AC servo motor output (W)</b>	200	100	200	50
<b>Repeatability</b> <sup>Note 2</sup> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	20	(1/50)
<b>Maximum speed</b> <sup>Note 4</sup> (XYZ: mm/sec) (R: %/sec)	1200	1200	1200	360
<b>Moving range</b> (XYZ: mm) (R: °)	150 to 1050	150 to 550	150 to 350	360
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5.10			

### Maximum payload (kg)


Y stroke (mm)	Z stroke (mm)		
	150	250	350
<b>150</b>	4	4	4
<b>250</b>	4	4	3
<b>350</b>	4	3	1
<b>450</b>	2	1	-
<b>550</b>	1	-	-

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S-R	

### SXYx 4 axes / ZRFL20 A1




X stroke	150	250	350	450	550	650	750	850	950	1050	
	L	470	570	670	770	870	970	1070	1170	1270	1370
K	200	100	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	960	1140	
M	0	1	1	2	2	3	3	4	4	5	
N	4	6	6	8	8	10	10	12	12	14	
<b>Y stroke</b>											
T	150	250	350	450	550						
<b>Z stroke</b>											
	150	250	350								
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	X-axis		1200				960	780	600	540	
<b>Speed setting</b>	-		-				80%	65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYx 4 axes / ZRFH

- Arm type
- Cable carrier
- Z-axis: clamped table / moving base type (200W)+R-axis



## Ordering method

**SXYx - C**      **ZRFH**      **RCX340-4**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
A1	A1		15 to 105cm	15 to 55cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m								

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240S**      **R**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specification

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14	F10-BK equivalent guide-reinforced model	R5
<b>AC servo motor output (W)</b>	200	100	200	50
<b>Repeatability</b> <sup>Note 2</sup> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10	(1/50)
<b>Maximum speed</b> <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1200	1200	600	360
<b>Moving range (XYZ: mm)(R: °)</b>	150 to 1050	150 to 550	150 to 350	360
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10			

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	9	8	7
250	6	5	4
350	4	3	1
450	2	1	-
550	1	-	-

## Controller

Controller	Operation method
RCX340 RCX240S-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 4 axes / ZRFH (A1)



X stroke										
	150	250	350	450	550	650	750	850	950	1050
L	470	570	670	770	870	970	1070	1170	1270	1370
K	200	100	200	100	200	100	200	100	200	100
D	240	240	420	420	600	600	780	960	960	1140
M	0	1	1	2	2	3	3	4	4	5
N	4	6	6	8	8	10	10	12	12	14

Y stroke					
T	55	110	165	220	275

Z stroke			
	150	250	350

Maximum speed for each stroke (mm/sec)	X-axis					
Speed setting		1200	960	780	600	540
		-	80%	65%	50%	45%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. The shaded position indicates an user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type


Gantry type

Moving arm type

Pole type

XZ type

# SXYx 4 axes / ZRS



- Arm type
- Cable carrier
- ZR axis integrated type

## Ordering method

**SXYx - C** [ ] [ ] [ ] [ ] **15** [ ]

**Model**   **Cable**   **Combination**   **X-axis stroke**   **Y-axis stroke**   **ZR-axis**   **Z-axis stroke**   **Cable**

A1   15 to 105cm   15 to 65cm   ZRS12   3L: 3.5m  
A2   5L: 5m  
A3   10L: 10m  
A4

**RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller / Number of controllable axes**   **Safety standard**   **Option A (OP.A)**   **Option B (OP.B)**   **Option C (OP.C)**   **Option D (OP.D)**   **Option E (OP.E)**   **Absolute battery**

**Specify various controller setting items. RCX340 ▶ P542**

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller**   **CE Marking**   **Expansion I/O**   **Network option**   **IVY System**   **Gripper**   **Battery**

**Specify various controller setting items. RCX240/RCX240S ▶ P532**

## Specification

	X-axis	Y-axis	Z-axis: ZRS12	Z-axis: ZRS6	R-axis
<b>Axis construction</b> <small>Note 1</small>	F14H	F14	-	-	-
<b>AC servo motor output (W)</b>	200	100	60	100	100
<b>Repeatability</b> <small>Note 2</small> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.02	+/-0.005	+/-0.005
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C10)	Harmonic gear	
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	12	6	(1/50)
<b>Maximum speed</b> <small>Note 4</small> (XYZ: mm/sec) (R: °/sec)	1200	1200	1000	500	1020
<b>Moving range (XYZ: mm) (R: °)</b>	150 to 1050	150 to 650	150	150	360
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5, 10				

## Maximum payload (kg)


Y stroke (mm)	ZRS12	ZRS6
150	3	5
250	3	5
350	3	5
450	3	5
550	3	5
650	3	4

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S	


## SXYx 4 axes / ZRS A1



X stroke	150	250	350	450	550	650	750	850	950	1050	
	L	470	570	670	770	870	970	1070	1170	1270	1370
K	200	100	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	960	1140	
M	0	1	1	2	2	3	3	4	4	5	
N	4	6	6	8	8	10	10	12	12	14	
Y stroke	150	250	350	450	550	650					
T	55	110	165	220	275	330					
Z stroke	150										
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	X-axis		1200			960		780	600	540	
<b>Speed setting</b>			-			80%		65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.  
 Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.





### Ordering method

**SXYx - S** [ ] [ ] [ ] [ ] **15** [ ] [ ] [ ] [ ] [ ]

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
A1			15 to 85cm	15 to 65cm	ZRS12		3L: 3.5m
A2					ZRS6		5L: 5m
A3							10L: 10m
A4							

**RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller / Number of controllable axes | Safety standard | Option A (OP.A) | Option B (OP.B) | Option C (OP.C) | Option D (OP.D) | Option E (OP.E) | Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller | CE Marking | Expansion I/O | Network option | IVY System | Gripper | Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis: ZRS12	Z-axis: ZRS6	R-axis
Axis construction <sup>Note 1</sup>	F14H	F14	-	-	-
AC servo motor output (W)	200	100	60	100	100
Repeatability <sup>Note 2</sup> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.02	+/-0.005	+/-0.005
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C10)	Harmonic gear	
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	12	6	(1/50)
Maximum speed <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1200	1200	1000	500	1020
Moving range (XYZ: mm) (R: °)	150 to 850	150 to 650	150		360
Robot cable length (m)	Standard: 3.5 Option: 5,10				

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	ZRS12	ZRS6
150	3	5
250	3	5
350	3	5
450	3	5
550	3	5
650	3	4

### Controller

Controller	Operation method
RCX340 RCX240S	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### SXYx 4 axes / ZRS (A1)



X stroke	150	250	350	450	550	650	750	850	
	L	470	570	670	770	870	970	1070	1170
K	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	
M	0	1	1	2	2	3	3	4	
N	4	6	6	8	8	10	10	12	
Y stroke	150	250	350	450	550	650			
Z stroke	150								
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200					960	780	
Speed setting		-					80%	65%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type


Gantry type

Moving arm type

Pole type

XZ type

# SXYBx 2 axes



● Arm type ● Cable carrier

## Ordering method

<b>SXYBx - C</b>						<b>RCX222</b>					
Model	Cable	Combination	X-axis stroke	Y-axis stroke	Cable	Controller	Usable for CE	Regenerative unit	Input/Output selection 1	Input/Output selection 2	
A1			15 to 305cm	15 to 55cm	3L: 3.5m	RCX222	No entry: Standard E: CE marking	No entry: None R: RG2	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link	No entry: None NT: OP.DIO24/16 (NPN) PT: OP.DIO24/17 (PNP) EN: Ethernet	
A2					5L: 5m						
A3					10L: 10m						
A4											

Note 1. Regenerative unit RG2 is required when the maximum speed on the RCX222 exceeds 1250mm/sec.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Available only for the master. See P.66 for details on YC-Link system.  
 Note 4. Only when CC or DN or PB was selected for I/O select 1 above, EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
Axis construction	B14H	B14
AC servo motor output (W)	200	100
Repeatability (mm)	+/-0.04	+/-0.04
Drive system	Timing belt	Timing belt
Ball screw lead (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25
Maximum speed (mm/sec)	1875	1875
Moving range (mm)	150 to 3050	150 to 550
Robot cable length (m)	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.

## Maximum payload (kg)


Y stroke (mm)	XY 2 axes
150	14
250	12
350	10
450	8
550	7

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. Regenerative unit RG2 is required when the maximum speed exceeds 1250mm/sec.




## SXYBx 2 axes A1






Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050	
L	588	688	788	888	988	1088	1188	1288	1388	1488	1588	1688	1788	1888	1988	2088	2188	2288	2388	2488	2588	2688	2788	2888	2988	3088	3188	3288	3388	3488	
K	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	
C	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	
D	-	-	-	-	-	-	-	-	-	240	240	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	
E	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	240	240	420	420	600	600	780	960
F	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	4	4	4	4	4	
M	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	
N	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	
G	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	
J	330	330	430	430	530	530	630	630	730	730	830	830	930	930	1030	1030	1130	1130	1230	1230	1330	1330	1430	1430	1530	1530	1630	1630	1730	1730	
Y stroke	150	250	350	450	550																										




SXYBx 2 axes **A2**



SXYBx 2 axes **A3**



SXYBx 2 axes **A4**




Articulated robots	YA
Linear conveyor modules	LCM100
Compact single-axis robots	TRANSEVO
Single-axis robots	FLIP-X
Linear motor single-axis robots	PHASER
Cartesian robots	XX-X
SCARA robots	YK-X
Pick & place robots	YP-X
CLEAN	CLEAN
CONTROLLER	CONTROLLER
INFORMATION	INFORMATION
Arm type	Arm type
Gantry type	Gantry type
Moving arm type	Moving arm type
Pole type	Pole type
XZ type	XZ type



# SXYBx

3 axes / ZFL20

- Arm type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)



## Ordering method

**SXYBx - C** [ ] [ ] [ ] **ZFL20** [ ] [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** - **Cable** - **Combination** - **X-axis stroke** - **Y-axis stroke** - **ZR-axis** - **Z-axis stroke** - **Cable**

Controller / Number of controllable axes: RCX340-3  
 Safety standard: [ ]  
 Option A (OP.A): [ ]  
 Option B (OP.B): [ ]  
 Option C (OP.C): [ ]  
 Option D (OP.D): [ ]  
 Option E (OP.E): [ ]  
 Absolute battery: [ ]

Specify various controller setting items. RCX340 ▶ **P542**

**RCX240S** [ ] **R** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller: RCX240S-R  
 CE Marking: [ ]  
 Regenerative unit: [ ]  
 Expansion I/O: [ ]  
 Network option: [ ]  
 iVY System: [ ]  
 Gripper: [ ]  
 Battery: [ ]

Specify various controller setting items. RCX240/RCX240S ▶ **P532**

## Specification

	X-axis	Y-axis	Z-axis
Axis construction <sup>Note 1</sup>	B14H	B14	F10-BK equivalent guide-reinforced model
AC servo motor output (W)	200	100	200
Repeatability <sup>Note 2</sup> (mm)	+/-0.04	+/-0.04	+/-0.01
Drive system	Timing belt	Timing belt	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25	20
Maximum speed (mm/sec)	1875	1875	1200
Moving range (mm)	150 to 3050	150 to 450	150 to 350
Robot cable length (m)	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	7	6	5
250	5	4	3
350	3	2	1
450	1	-	-

## Controller

Controller	Operation method
RCX340 RCX240S-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYBx 3 axes / ZFL20 (A1)



	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050						
<b>X stroke</b>	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050						
<b>L</b>	588	688	788	888	988	1088	1188	1288	1388	1488	1588	1688	1788	1888	1988	2088	2188	2288	2388	2488	2588	2688	2788	2888	2988	3088	3188	3288	3388	3488						
<b>K</b>	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100						
<b>C</b>	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140					
<b>D</b>	-	-	-	-	-	-	-	-	-	-	240	240	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140					
<b>E</b>	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	240	240	420	420	600	600	780	960				
<b>F</b>	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	4	4	4	4	4	4	4	4	4				
<b>M</b>	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	16					
<b>N</b>	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	36					
<b>G</b>	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0					
<b>J</b>	330	330	430	430	530	530	630	630	730	730	830	830	930	930	1030	1030	1130	1130	1230	1230	1330	1330	1430	1430	1530	1530	1630	1630	1730	1730	1730					
<b>Y stroke</b>	150	250	350	450																																
<b>Z stroke</b>	150	250	350																																	


Controller

RCX340 ▶ 542 RCX240S ▶ 532

# SXYBx

3 axes / ZFH

- Arm type
- Cable carrier
- Z-axis: clamped table / moving base type (200W)



## Ordering method

**SXYBx - C** **ZFH** **RCX340-3** **RCX240S** **R**

Specify various controller setting items. RCX340 ▶ P.542  
Specify various controller setting items. RCX240/RCX240S ▶ P.532

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	B14H	B14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	200	100	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.04	+/-0.04	+/-0.01
<b>Drive system</b>	Timing belt	Timing belt	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25	10
<b>Maximum speed (mm/sec)</b>	1875	1875	600
<b>Moving range (mm)</b>	150 to 3050	150 to 450	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
Note 2. Positioning repeatability in one direction.  
Note 3. Leads not listed in the catalog are also available. Contact us for details.

## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	7	6	5
250	5	4	3
350	3	2	1
450	1	-	-

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S-R	

## SXYBx 3 axes / ZFH A1

**Detail of section A**  
4 - M5 x 0.8 Depth 9  
2-φ5H7 Depth 8  
(Between knocks +/-0.02)

**Detail of section B**  
φ9.7  
φ10.1  
φ9.9  
φ8.2  
φ7.6


**Cross-sectional drawing S-S**  
See the cross-sectional drawing of S-S.  
F-φ10H7:  
N-M6x1.0 Depth 10  
C+/-0.02 D+/-0.02 E+/-0.02  
φ10H7  
5.5  
18.5

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
Note 2. The shaded position indicates an user cable extraction port.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050							
L	588	688	788	888	988	1088	1188	1288	1388	1488	1588	1688	1788	1888	1988	2088	2188	2288	2388	2488	2588	2688	2788	2888	2988	3088	3188	3288	3388	3488							
K	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200						
C	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140						
D	-	-	-	-	-	-	-	-	-	-	240	240	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140						
E	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	240	240	420	420	600	600	780	960							
F	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	4	4	4	4	4	4	4	4						
M	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	16						
N	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	36						
G	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0						
J	330	330	430	430	530	530	630	630	730	730	830	830	930	930	1030	1030	1130	1130	1230	1230	1330	1330	1430	1430	1530	1530	1630	1630	1730	1730	1730						
Y stroke	150	250	350	450																																	
Z stroke	150	250	350																																		

# SXYBx 3 axes / ZS

● Arm type ● Cable carrier ● Z-axis shaft vertical type



## Ordering method

**SXYBx - C**   **ZS - 15**   **RCX340-3**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
A1 A2 A3 A4			15 to 305cm	15 to 55cm	ZS12 ZS6		3L: 3.5m 5L: 5m 10L: 10m

**RCX340-3** Controller / Number of controllable axes   Safety standard   Option A (OP.A)   Option B (OP.B)   Option C (OP.C)   Option D (OP.D)   Option E (OP.E)   Absolute battery

Specify various controller setting items. RCX340 ▶ **P542**

**RCX240S**   **R**

Controller   CE Marking   Regenerative unit   Expansion I/O   Network option   I/IV System   Gripper   Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P532**

## Specification

	X-axis	Y-axis	Z-axis: ZS12	Z-axis: ZS6
Axis construction <sup>Note 1</sup>	B14H	B14	-	
AC servo motor output (W)	200	100	60	
Repeatability <sup>Note 2</sup> (mm)	+/-0.04	+/-0.04	+/-0.02	
Drive system	Timing belt	Timing belt	Ball screw (Class C10)	
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25	12	6
Maximum speed (mm/sec)	1875	1875	1000	500
Moving range (mm)	150 to 3050	150 to 550	150	
Robot cable length (m)	Standard: 3.5   Option: 5,10			

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	ZS12	ZS6
150	3	5
250	3	5
350	3	5
450	3	4
550	3	3

## Controller

Controller	Operation method
RCX340 RCX240S-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYBx 3 axes / ZS A1



Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050	
L	588	688	788	888	988	1088	1188	1288	1388	1488	1588	1688	1788	1888	1988	2088	2188	2288	2388	2488	2588	2688	2788	2888	2988	3088	3188	3288	3388	3488	
K	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	
C	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	
D	-	-	-	-	-	-	-	-	-	-	240	240	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	
E	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	240	240	420	420	600	600	780	960	
F	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	4	4	4	4	4	4	4	4	
M	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	15	16	
N	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	
G	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	
J	330	330	430	430	530	530	630	630	730	730	830	830	930	930	1030	1030	1130	1130	1230	1230	1330	1330	1430	1430	1530	1530	1630	1630	1730	1730	
Y stroke	150	250	350	450	550																										
Z stroke	150																														

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type

Moving arm type


Pole type

XZ type

# SXYBx

4 axes / ZRS

- Arm type
- Cable carrier
- ZR axis integrated type



## Ordering method

**SXYBx - C** [ ] [ ] [ ] [ ] - **15** [ ] **RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
		A1 A2 A3 A4	15 to 305cm	15 to 55cm	ZRS12 ZRS6		3L: 3.5m 5L: 5m 10L: 10m	Specify various controller setting items. RCX340 ▶ <b>P542</b>							

**RCX240S** [ ] [ ] **R** [ ] [ ] [ ] [ ] [ ]

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P532**

## Specification

	X-axis	Y-axis	Z-axis: ZRS12	Z-axis: ZRS6	R-axis
<b>Axis construction</b> <small>Note 1</small>	B14H	B14	-		
<b>AC servo motor output (W)</b>	200	100	60		
<b>Repeatability</b> <small>Note 2</small> (XYZ: mm)(R: °)	+/-0.04	+/-0.04	+/-0.02		
<b>Drive system</b>	Timing belt	Timing belt	Ball screw (Class C10)	Harmonic gear	
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	Equivalent to lead 25	Equivalent to lead 25	12	6	(1/50)
<b>Maximum speed (XYZ: mm/sec)(R: °/sec)</b>	1875	1875	1000	500	1020
<b>Moving range (XYZ: mm)(R: °)</b>	150 to 3050	150 to 550	150		360
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10				

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	ZRS12	ZRS6
150	3	5
250	3	5
350	3	5
450	3	3
550	2	2

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S-R	

## SXYBx 4 axes / ZRS A1



Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050						
<b>L</b>	588	688	788	888	988	1088	1188	1288	1388	1488	1588	1688	1788	1888	1988	2088	2188	2288	2388	2488	2588	2688	2788	2888	2988	3088	3188	3288	3388	3488						
<b>K</b>	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100						
<b>C</b>	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140						
<b>D</b>	-	-	-	-	-	-	-	-	-	-	240	240	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140						
<b>E</b>	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	240	240	420	420	600	600	780	960					
<b>F</b>	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	4	4	4	4	4	4						
<b>M</b>	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	11	12	12	13	13	14	14	15	16						
<b>N</b>	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36						
<b>G</b>	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50	0	50						
<b>J</b>	330	330	430	430	530	530	630	630	730	730	830	830	930	930	1030	1030	1130	1130	1230	1230	1330	1330	1430	1430	1530	1530	1630	1630	1730	1730						
<b>Y stroke</b>	150	250	350	450	550																															
<b>Z stroke</b>	150																																			



Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type


XZ type

# NXY 2 axes

● Arm type ● Cable carrier



## Ordering method



Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
Axis construction <sup>Note 1</sup>	N15	F14
AC servo motor output (W)	400	100
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7) $\phi$ 15	Ball screw (Class C7) $\phi$ 15
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
Maximum speed (mm/sec)	1200	1200
Moving range (mm)	500 to 2000	150 to 650
Robot cable length (m)	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	25
250	21
350	18
450	16
550	13
650	11

## Controller


Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## NXY 2 axes A1




Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The origin of the X axis is set originally as the drawing and it is possible to change it to the R side origin by changing parameters.  
 Note 3. When using  $\phi$ 7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.  
 Note 4. When using a  $\phi$ 10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 5. Use M4 tap of the box next to X axis for the user grounding terminal.  
 Note 6. The M4 taps at both ends of the cable carriage can be used for fixing cables.

NXY 2 axes **A3**



X stroke	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
D	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
E	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
F	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
G	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
H	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
I	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
J	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
K	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400
Y stroke	150	250	350	450	550	650										

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The origin of the X axis is set originally as the drawing and it is possible to change it to the R side origin by changing parameters.  
 Note 3. When using φ7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.  
 Note 4. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 5. Use M4 tap of the box next to X axis for the user grounding terminal.  
 Note 6. The M4 taps at both ends of the cable carriage can be used for fixing cables.



● Arm type   ● Cable carrier   ● Z-axis: clamped base / moving table type (200W)

### Ordering method

**NXY - C** [ ] [ ] [ ] **ZFL20** [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model   Cable   Combination (A1, A3)   X-axis stroke (50 to 200cm)   Y-axis stroke (15 to 65cm)   ZR-axis   Z-axis stroke (15 to 35cm)   Cable (3L: 3.5m, 5L: 5m, 10L: 10m)

**RCX340-3** Controller / Number of controllable axes   Safety standard   Option A (OP.A)   Option B (OP.B)   Option C (OP.C)   Option D (OP.D)   Option E (OP.E)   Absolute battery

**RCX240** Controller Note 1   CE Marking   Regenerative unit   Expansion I/O   Network option   IVY System   Gripper   Battery

Specify various controller setting items. **RCX340** ▶ **P542**

Specify various controller setting items. **RCX240/RCX240S** ▶ **P532**

Note 1. Reference of special order: RCX222+SR1-X

### Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> Note 1	N15	F14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	400	100	200
<b>Repeatability</b> Note 2 (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15
<b>Ball screw lead</b> Note 3 (Deceleration ratio) (mm)	20	20	20
<b>Maximum speed (mm/sec)</b>	1200	1200	1200
<b>Moving range (mm)</b>	500 to 2000	150 to 650	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5, 10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	8	8	8
250	8	8	8
350	8	8	8
450	8	7	6
550	5	4	3
650	3	2	1

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	Remote command / Operation using RS-232C communication


### NXY 3 axes / ZFL20 (A1)



X stroke	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
D	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
E	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
F	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
G	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
H	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
I	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
J	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
K	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400
<b>Y stroke</b>	<b>150</b>	<b>250</b>	<b>350</b>	<b>450</b>	<b>550</b>	<b>650</b>										
<b>Z stroke</b>	<b>150</b>	<b>250</b>	<b>350</b>													

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The origin of the X axis is set originally as the drawing and it is possible to change it to the R side origin by changing parameters.  
 Note 3. When using φ7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.  
 Note 4. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 5. Use M4 tap of the box next to X axis for the user grounding terminal.  
 Note 6. The M4 taps at both ends of the cable carriage can be used for fixing cables.

NXY 3 axes / ZFL20 **A3**



X stroke	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
D	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
E	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
F	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
G	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
H	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
I	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
J	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
K	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400
Y stroke	150	250	350	450	550	650										
Z stroke	150	250	350													

- Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.
- Note 2. The origin of the X axis is set originally as the drawing and it is possible to change it to the R side origin by changing parameters.
- Note 3. When using φ7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.
- Note 4. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.
- Note 5. Use M4 tap of the box next to X axis for the user grounding terminal.
- Note 6. The M4 taps at both ends of the cable carriage can be used for fixing cables.



- Arm type
- Cable carrier
- Z-axis clamped table: moving base type (200W)

### Ordering method

**NXY - C** [ ] [ ] [ ] **ZFH** [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
		A1 A3	50 to 200cm	15 to 65cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m

**Specify various controller setting items. RCX340 ▶ P542**

**RCX240** [ ] **R** [ ] [ ] [ ] [ ] [ ] [ ]

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
Note 1							

**Specify various controller setting items. RCX240/RCX240S ▶ P532**

Note 1. Reference of special order: RCX222+SR1-X

### Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	N15	F14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	400	100	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed (mm/sec)</b>	1200	1200	600
<b>Moving range (mm)</b>	500 to 2000	150 to 650	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	13	13	12
250	12	11	10
350	10	9	8
450	8	7	6
550	5	4	3
650	3	2	1

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	


### NXY 3 axes / ZFH A1




X stroke	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
D	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
E	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
F	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
G	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
H	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
I	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
J	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
K	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400
Y stroke	150	250	350	450	550	650										
Z stroke	150	250	350													

- Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The origin of the X axis is set originally as the drawing and it is possible to change it to the R side origin by changing parameters.  
 Note 3. When using φ7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.  
 Note 4. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 5. Use M4 tap of the box next to X axis for the user grounding terminal.  
 Note 6. The M4 taps at both ends of the cable carriage can be used for fixing cables.


NXY 3 axes / ZFH **A3**



Detail of section A




Detail of section B







Cross-section C-C


Use M6 x 1.0 hex socket head bolt with length head bolt with length (under head) of 20mm or more.



Cross-section of cable carrier  
Dimension in the parentheses ( ) is for the Y to Z cable.



2-φ10H7 Depth17  
See cross-section C-C. (Note 4)



X stroke	500	600	700	800	900	1000	1100	1200	1300	1400	1500	1600	1700	1800	1900	2000
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
D	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
E	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
F	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
G	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
H	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
I	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
J	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
K	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250	1300	1350	1400
Y stroke	150	250	350	450	550	650										
Z stroke	150	250	350													

- Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.
- Note 2. The origin of the X axis is set originally as the drawing and it is possible to change it to the R side origin by changing parameters.
- Note 3. When using φ7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.
- Note 4. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.
- Note 5. Use M4 tap of the box next to X axis for the user grounding terminal.
- Note 6. The M4 taps at both ends of the cable carriage can be used for fixing cables.

# NXY-W 4 axes



- Arm type
- Cable carrier
- Double Y axes specifications

## Ordering method

**NXY - C - WA1**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	Cable
			25 to 175cm	15 to 65cm <sup>Note 1</sup>	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

Note 1. When the Y-axis stroke is different between the right and left, it will be an order-made.  
 Note 2. Reference of special order: 2 units of RCX222

**RCX240**

Controller <sup>Note 2</sup>	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specification

	X-axis	Y-axis <sup>Note 1</sup>
Axis construction <sup>Note 2</sup>	N15D	F14
AC servo motor output (W)	400	100
Repeatability <sup>Note 3</sup> (mm)	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7) $\phi$ 15	Ball screw (Class C7) $\phi$ 15
Ball screw lead <sup>Note 4</sup> (Deceleration ratio) (mm)	20	20
Maximum speed (mm/sec)	1200	1200
Moving range (mm)	250 to 1750	150 to 650
Robot cable length (m)	Standard: 3.5 Option: 5, 10	

Note 1. The same two Y axes are installed and they have same specifications. If axes of individually different stroke are desired, it will be an order-made. In that case, consult YAMAHA.  
 Note 2. Use caution that the frame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 3. Positioning repeatability in one direction.  
 Note 4. Leads not listed in the catalog are also available. Contact us for details.



## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	25
250	21
350	18
450	16
550	13
650	11


## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

## NXY-W 4 axes WA1






Detail of section B




Use M6 x 1.0 hex socket head bolt with length head bolt with length (under head) of 20mm or more.

Cross-section C-C



Space for wiring by the user

Cross-section of XY cable carrier



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
D	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
E	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
F	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
G	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
H	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
I	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
J	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
Y stroke	150	250	350	450	550	650										


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. When using  $\phi$ 7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.  
 Note 3. When using a  $\phi$ 10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 4. Use M4 tap of the box next to X axis for the user grounding terminal.  
 Note 5. The M4 taps at both ends of the cable carriage can be used for fixing cables.  
 Note 6. Minimum dimension between LX and RX sliders.



# NXY-W

6 axes / ZFL

- Arm type
- Cable carrier
- Double Y axes specifications
- Z-axis: clamped base / moving table type (200W)



## Ordering method

**NXY-C-WA1** [ ] [ ] - **ZFL20** [ ] [ ] [ ] [ ] **RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model Cable Combination X-axis stroke (25 to 175cm) Y-axis stroke (15 to 65cm<sup>Note 1</sup>) ZR-axis Z-axis stroke (15 to 35cm) Cable (3L: 3.5m, 6L: 6m, 10L: 10m)

Controller / Number of controllable axes Safety standard Option A (OP.A) Option B (OP.B) Option C (OP.C) Option D (OP.D) Option E (OP.E) Absolute battery

**RCX240** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] **R**

Controller<sup>Note 2</sup> CE Marking Regenerative unit Expansion I/O Network option IVY System Gripper Battery

Note 1. When either one or both of Y-axis or Z-axis stroke is different, it will be an order-made.  
 Note 2. If you enter "RCX240", 2 units will be shipped automatically.  
 Reference of special order: 2 sets of RCX222+SR1-X.

Specify various controller setting items. **RCX340 ▶ P.542**

Specify various controller setting items. **RCX240/RCX240S ▶ P.532**

## Specification

	X-axis	Y-axis <sup>Note 1</sup>	Z-axis
Axis construction <sup>Note 2</sup>	N15D	F14	F10-BK equivalent guide-reinforced model
AC servo motor output (W)	400	100	200
Repeatability <sup>Note 3</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15
Ball screw lead <sup>Note 4</sup> (Deceleration ratio) (mm)	20	20	20
Maximum speed (mm/sec)	1200	1200	1200
Moving range (mm)	250 to 1750	150 to 650	150 to 350
Robot cable length (m)	Standard: 3.5 Option: 5, 10		

Note 1. The same two Y axes are installed and they have same specifications. If axes of individually different stroke are desired, it will be an order-made. In that case, consult YAMAHA.  
 Note 2. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 3. Positioning repeatability in one direction.  
 Note 4. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	8	8	8
250	8	8	8
350	8	8	8
450	8	7	6
550	5	4	3
650	3	2	1

## Controller


Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## NXY-W 6 axes / ZFL (WA1)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750
L	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
D	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
E	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
F	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
G	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
H	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
I	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
J	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
Y stroke	150	250	350	450	550	650										
Z stroke	150	250	350													

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. When using φ7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.  
 Note 3. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 4. Use M4 tap of the box next to X axis for the user grounding terminal.  
 Note 5. The M4 taps at both ends of the cable carriage can be used for fixing cables.  
 Note 6. Minimum dimension between LX and RX sliders.



- Arm type
- Cable carrier
- Double Y axes specifications
- Z-axis: clamped table / moving base type (200W)

### Ordering method

**NXY-C-WA1** - [ ] - [ ] - **ZFH** - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ]

**RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**RCX240** **R** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model - Cable - Combination - X-axis stroke (25 to 175cm) - Y-axis stroke (15 to 65cm)<sup>Note 1</sup> - ZR-axis - Z-axis stroke (15 to 35cm) - Cable (3L: 3.5m, 5L: 5m, 10L: 10m)

Controller / Number of controllable axes - Safety standard - Option A (OP.A) - Option B (OP.B) - Option C (OP.C) - Option D (OP.D) - Option E (OP.E) - Absolute battery

Specify various controller setting items. **RCX340** ▶ **P.542**

Controller<sup>Note 2</sup> - CE Marking - Regenerative unit - Expansion I/O - Network option - IVY System - Gripper - Battery

Specify various controller setting items. **RCX240/RCX240S** ▶ **P.532**

Note 1. When either one or both of Y-axis or Z-axis stroke is different, it will be an order-made.  
 Note 2. If you enter "RCX240", 2 units will be shipped automatically.  
 Reference of special order: 2 sets of RCX222+SR1-X.

### Specification

	X-axis	Y-axis <sup>Note 1</sup>	Z-axis
<b>Axis construction</b> <sup>Note 2</sup>	N15D	F14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	400	100	200
<b>Repeatability</b> <sup>Note 3</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15	Ball screw (Class C7) φ15
<b>Ball screw lead</b> <sup>Note 4</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed (mm/sec)</b>	1200	1200	600
<b>Moving range (mm)</b>	250 to 1750	150 to 650	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10		

Note 1. The same two Y axes are installed and they have same specifications. If axes of individually different stroke are desired, it will be an order-made. In that case, consult YAMAHA.  
 Note 2. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 3. Positioning repeatability in one direction.  
 Note 4. Leads not listed in the catalog are also available. Contact us for details.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)			
	150	250	350	650
150	13	13	12	
250	12	11	10	
350	10	9	8	
450	8	7	6	
550	5	4	3	
650	3	2	1	

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

### NXY-W 6 axes / ZFH WA1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750
<b>L</b>	830	930	1030	1130	1230	1330	1430	1530	1630	1730	1830	1930	2030	2130	2230	2330
<b>D</b>	15	65	15	65	15	65	15	65	15	65	15	65	15	65	15	65
<b>E</b>	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11
<b>F</b>	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24
<b>G</b>	115	165	115	165	115	165	115	165	115	165	115	165	115	165	115	165
<b>H</b>	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10
<b>I</b>	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22
<b>J</b>	620	720	820	920	1020	1120	1220	1320	1420	1520	1620	1720	1820	1920	2020	2120
<b>Y stroke</b>	150	250	350	450	550	650										
<b>Z stroke</b>	150	250	350													

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. When using φ7 holes for installation, you must not use a washer, spring washer, etc. in the main unit.  
 Note 3. When using a φ10H7 hole, make sure that the pin does not go into deeper than as shown in the drawing.  
 Note 4. Use M4 tap of the box next to X axis for the user grounding terminal.  
 Note 5. The M4 taps at both ends of the cable carriage can be used for fixing cables.  
 Note 6. Minimum dimension between LX and RX sliders.

Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type

XZ type

# MXYx 2 axes

● Arm type ● Cable carrier



## Ordering method

<b>MXYx - C</b>					<b>RCX222</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1		A1	25 to 125cm	15 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	150 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	30
250	30
350	25
450	20
550	20
650	16

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 2 axes A1



X stroke	Y stroke											
	150	250	350	450	550	650	750	850	950	1050	1150	1250
<b>L</b>	615	715	815	915	1015	1115	1215	1315	1415	1515	1615	
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100	
<b>C</b>	240	420	600	600	780	780	960	960	1140	1140	1320	
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7	
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18	


  

Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis								
	150	250	350	450	550	650			
<b>Speed setting</b>			1200		960	840	720	600	480
					80%	70%	60%	50%	40%


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.


MXyX 2 axes **A2**



MXyX 2 axes **A3**



MXyX 2 axes **A4**



- Articulated robots
- YA
- Linear conveyor modules
- LCM100
- Compact single-axis robots
- TRANSEVO
- Single-axis robots
- FLIP-X
- Linear motor single-axis robots
- PHASER
- Cartesian robots
- XX-X
- SCARA robots
- YK-X
- Pick & place robots
- YP-X
- CLEAN
- CONTROLLER
- INFORMATION
- Arm type
- Gantry type
- Moving arm type
- Pole type
- XZ type

# MXYx 2 axes

● Arm type   ● Whipover



## Ordering method

<b>MXYx - S</b>					<b>RCX222</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1			25 to 85cm	15 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 850	150 to 650
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.







## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	30
250	30
350	25
450	20
550	20
650	16

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 2 axes A1




X stroke	250	350	450	550	650	750	850
<b>L</b>	615	715	815	915	1015	1115	1215
<b>K</b>	100	200	100	200	100	200	100
<b>C</b>	240	420	600	600	780	780	960
<b>M</b>	2	2	3	3	4	4	5
<b>N</b>	8	8	10	10	12	12	14
<b>Y stroke</b>	150	250	350	450	550	650	
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>				1200		960
<b>Speed setting</b>					-		80%


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.


MXYx 2 axes **A2**



MXYx 2 axes **A3**



MXYx 2 axes **A4**




Articulated robots	YA
Linear conveyor modules	LCM100
Compact single-axis robots	TRANSEVO
Single-axis robots	FLIP-X
Linear motor single-axis robots	PHASER
Cartesian robots	XX-X
SCARA robots	YK-X
Pick & place robots	YP-X
CLEAN	
CONTROLLER	
INFORMATION	
Arm type	
Gantry type	
Moving arm type	
Pole type	
XZ type	

# MXYx

2 axes / IO

- Arm type
- Cable carrier
- Type with Y-axis I/O cable carrier added



## Ordering method

<b>MXYx - C</b>					<b>IO</b>		<b>RCX222</b>			<b>R</b>		
Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Cable	Controller	Usable for CE	Regenerative unit	Input/Output selection 1	Input/Output selection 2	
A1			25 to 125cm	15 to 65cm		3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>	

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	150 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	29
250	29
350	24
450	19
550	19
650	15

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 2 axes / IO (A1)




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
<b>L</b>	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100
<b>C</b>	240	420	600	780	780	960	960	1140	1140	1320	1320
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18
<b>Y stroke</b>	150	250	350	450	550	650					
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>		1200				960	840	720	600	480
<b>Speed setting</b>			-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.





### Ordering method

**MXYx - C**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
		A1 A2 A3 A4	25 to 125cm	15 to 65cm	ZFL20 ZFL10	15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-3**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P532**

### Specification

	X-axis	Y-axis	Z-axis: ZFL20	Z-axis: ZFL10
Axis construction <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model	
AC servo motor output (W)	400	200	200	
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01	
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	20	10
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	1200	600
Moving range (mm)	250 to 1250	150 to 650	150 to 350	
Robot cable length (m)	Standard: 3.5 Option: 5,10			

Note. The standard types are ZFL with higher rigidity as compared with ZF types which are conventional standard types. When you need the ZF type, please consult YAMAHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

	Z stroke (mm)					
	ZFL20			ZFL10		
	150	250	350	150	250	350
150	8	8	8	15	15	15
250	8	8	8	15	15	15
350	8	8	8	15	15	15
450	8	8	8	12	11	10
550	8	8	8	12	11	10
650	8	7	6	8	7	6

### Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### MXYx 3 axes / ZFL20/10 A1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100
C	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	150	250	350	450	550	650					
Z stroke	150	250	350								
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis		1200				960	840	720	600	480
Speed setting			-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION


Arm type

Gantry type

Moving arm type

Pole type

XZ type



● Arm type ● Cable carrier ● Z-axis: clamped table / moving base type (200W)

### Ordering method

**MXYx - C** [ ] [ ] [ ] **ZFH** [ ] [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X-axis stroke** **Y-axis stroke** **ZR-axis** **Z-axis stroke** **Cable** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**A1** **25 to 125cm** **15 to 65cm** **15 to 35cm** **3L: 3.5m** **5L: 5m** **10L: 10m** **RCX340** **P542**

**A2** **A3** **A4** **RCX240** **R**

**Controller** **CE Marking** **Regenerative unit** **Expansion I/O** **Network option** **iVY System** **Gripper** **Battery**

Specify various controller setting items. RCX340 ▶ P.542  
Specify various controller setting items. RCX240/RCX240S ▶ P.532

### Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	400	200	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200	600
<b>Moving range (mm)</b>	250 to 1250	150 to 650	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note. The standard types are ZFH with higher rigidity as compared with ZF types which are conventional standard types. When you need the ZF type, please consult YAMAHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	14	13	12
250	14	13	12
350	14	13	12
450	12	11	10
550	12	11	10
650	8	7	6

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

### MXYx 3 axes / ZFH (A1)




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100
C	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	150	250	350	450	550	650					
Z stroke	150	250	350								
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 1</sup>	<b>X-axis</b>		1200				960	840	720	600	480
<b>Speed setting</b>			-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



### Ordering method

**MXYx - C**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
A1			25 to 125cm	15 to 65cm	ZRFL20	15 to 35cm	3L: 3.5m
A2					ZRFL10		5L: 5m
A3							10L: 10m
A4							

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis: ZRFL20	Z-axis: ZRFL10	R-axis
Axis construction <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model		R5
AC servo motor output (W)	400	200	200		50
Repeatability <sup>Note 2</sup> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.01		+/-0.0083
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)		Harmonic gear
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	20	10	(1/50)
Maximum speed <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1200	1200	1200	600	360
Moving range (XYZ: mm)(R: °)	250 to 1250	150 to 650	150 to 350		360
Robot cable length (m)	Standard: 3.5 Option: 5, 10				

Note. The standard types are ZRFL with higher rigidity as compared with ZRF types which are conventional standard types. When you need the ZRF type, please consult YAMAHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)					
	ZRFL20			ZRFL10		
150	4	4	4	11	11	11
250	4	4	4	11	11	11
350	4	4	4	11	11	11
450	4	4	4	8	7	6
550	4	4	4	8	7	6
650	4	4	4	4	3	2

### Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### MXYx 4 axes / ZRFL20/10 (A1)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100
C	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	150	250	350	450	550	650					
Z stroke	150	250	350								
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis		1200				960	840	720	600	480
	Speed setting		-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION


Arm type

Gantry type

Moving arm type

Pole type

XZ type



● Arm type   ● Cable carrier   ● Z-axis: clamped table / moving base type (200W)+R-axis

### Ordering method

**MXy<sub>x</sub> - C** [ ] [ ] [ ] **ZRFH** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model**   **Cable**   **Combination**   **X-axis stroke**   **Y-axis stroke**   **ZR-axis**   **Z-axis stroke**   **Cable**

A1   25 to 125cm   15 to 65cm   15 to 35cm   3L: 3.5m  
A2   15 to 65cm   15 to 65cm   15 to 35cm   5L: 5m  
A3   15 to 65cm   15 to 65cm   15 to 35cm   10L: 10m  
A4

**RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller / Number of controllable axes**   **Safety standard**   **Option A (OP.A)**   **Option B (OP.B)**   **Option C (OP.C)**   **Option D (OP.D)**   **Option E (OP.E)**   **Absolute battery**

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller**   **CE Marking**   **Regenerative unit**   **Expansion I/O**   **Network option**   **IVY System**   **Gripper**   **Battery**

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model	R5
<b>AC servo motor output (W)</b>	400	200	200	50
<b>Repeatability</b> <sup>Note 2</sup> (XYZ: mm)(R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10	(1/50)
<b>Maximum speed</b> <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1200	1200	600	360
<b>Moving range (XYZ: mm)(R: °)</b>	250 to 1250	150 to 650	150 to 350	360
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5, 10			

Note. The standard types are ZRFH with higher rigidity as compared with ZRF types which are conventional standard types. When you need the ZRF type, please consult YAMAHHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	11	9	8
250	11	9	8
350	11	9	8
450	8	7	6
550	8	7	6
650	4	3	2

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

### MXy<sub>x</sub> 4 axes / ZRFH A1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	L	615	715	815	915	1015	1115	1215	1315	1415	1515
K	100	200	100	200	100	200	100	200	100	200	100
C	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
<b>Y stroke</b>	<b>150</b>	<b>250</b>	<b>350</b>	<b>450</b>	<b>550</b>	<b>650</b>					
<b>Z stroke</b>	<b>150</b>	<b>250</b>	<b>350</b>								
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 1</sup>	<b>X-axis</b>		1200			960		840	720	600	480
<b>Speed setting</b>	-		-			80%		70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type

XZ type

# HXYx 2 axes

● Arm type ● Cable carrier



## Ordering method

<b>HXYx - C</b>					<b>RCX222HP</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
A1			25 to 125cm	25 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222HP	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDI024/16 (NPN) <sup>Note 1</sup> P1: OPDI024/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20	F17
<b>AC servo motor output (W)</b>	600	400
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	250 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
250	40
350	40
450	35
550	30
650	30

## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 2 axes A1




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
<b>L</b>	667	767	867	967	1067	1167	1267	1367	1467	1567	1667
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100
<b>C</b>	420	420	600	600	780	780	960	960	1140	1320	1320
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18
<b>Y stroke</b>	250	350	450	550	650						
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>		1200				960	840	720	600	480
<b>Speed setting</b>			-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.


Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

HXYx 2 axes **A2**





Detail of section A

Detail of section B




Cross-section of cable carrier

2-φ10H7: See detail drawing of B section




HXYx 2 axes **A3**





Detail of section A



Detail of section B




Cross-section of cable carrier






HXYx 2 axes **A4**



Detail of section A



Detail of section B




Cross-section of cable carrier

Articulated robots YA
Linear conveyor modules LCM100
Compact single-axis robots TRANSEVO
Single-axis robots FLIP-X
Linear motor single-axis robots PHASER
Cartesian robots XX-X
SCARA robots YK-X
Pick & place robots YP-X
CLEAN
CONTROLLER
INFORMATION
Arm type
Gantry type
Moving arm type
Pole type
XZ type

# HXYx

3 axes / ZL



- Arm type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)

## Ordering method

**HXYx - C** [ ] [ ] [ ] **ZL** [ ] [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X-axis stroke** **Y-axis stroke** **ZR-axis** **Z-axis stroke** **Cable** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**A1** **A2** **A3** **A4** **25 to 125cm** **25 to 65cm** **25 to 55cm** **3L: 3.5m** **5L: 5m** **10L: 10m** **RCX340** **R** **CE Marking** **Regenerative unit** **Expansion I/O** **Network option** **IVY System** **Gripper** **Battery**

**Specify various controller setting items. RCX340 ▶ P.542**

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <small>Note 1</small>	F20	F17	F14H-BK
<b>AC servo motor output (W)</b>	600	400	200
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1200	1200	600
<b>Moving range (mm)</b>	250 to 1250	250 to 650	250 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

- Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)			
	250	350	450	550
250	20	20	20	20
350	20	20	20	20
450	20	20	19	18
550	18	17	16	15
650	18	17	16	15

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

## HXYx 3 axes / ZL (A1)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	L	667	767	867	967	1067	1167	1267	1367	1467	1567
K	100	200	100	200	100	200	100	200	100	200	100
C	420	420	600	600	780	780	960	960	1140	1320	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
<b>Y stroke</b>	<b>250</b>	<b>350</b>	<b>450</b>	<b>550</b>	<b>650</b>						
<b>Z stroke</b>	<b>250</b>	<b>350</b>	<b>450</b>	<b>550</b>							
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	<b>X-axis</b>	1200			960		840	720	600	480	
	<b>Speed setting</b>	-			80%		70%	60%	50%	40%	

- Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

- Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.




# HXYx

3 axes / ZH

● Arm type

● Cable carrier

● Z-axis: clamped table / moving base type (200W)



## Ordering method

HXYx - C

Model

Cable

Combination

X-axis stroke

Y-axis stroke

ZR-axis

Z-axis stroke

Cable

A1
A2
A3
A4

25 to 125cm

25 to 65cm

25 to 55cm

3L: 3.5m  
5L: 5m  
10L: 10m

RCX340-3

Controller / Number of controllable axes

Safety standard

Option A (OP.A)

Option B (OP.B)

Option C (OP.C)

Option D (OP.D)

Option E (OP.E)

Absolute battery

Specify various controller setting items. RCX340 ▶ P.542

RCX240

R

Controller

CE Marking

Regenerative unit

Expansion I/O

Network option

IVY System

Gripper

Battery

Specify various controller setting items. RCX240/RCX240S ▶ P.532

## Specification

	X-axis	Y-axis	Z-axis
Axis construction <sup>Note 1</sup>	F20	F17	F14H-BK
AC servo motor output (W)	600	400	200
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	5
Maximum speed <sup>Note 4</sup> (mm/sec) (°/sec)	1200	1200	300
Moving range (mm)	250 to 1250	250 to 650	250 to 550
Robot cable length (m)	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)			
	250	350	450	550
250	25	25	24	23
350	25	25	24	23
450	20	20	19	18
550	18	17	16	15
650	18	17	16	15

## Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 3 axes / ZH (A1)



X stroke	L										
	250	350	450	550	650	750	850	950	1050	1150	1250
L	667	767	867	967	1067	1167	1267	1367	1467	1567	1667
K	100	200	100	200	100	200	100	200	100	200	100
C	420	420	600	600	780	780	960	960	1140	1320	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	C										
	250	350	450	550	650						
Z stroke	250	350	450	550							
ZK	100	200	100	200							
ZM	1	1	2	2							
ZN	10	10	12	12							

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.


Maximum speed for each stroke (mm/sec)	X-axis						
	Speed setting	1200	960	840	720	600	480
		-	80%	70%	60%	50%	40%

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Controller

RCX340 ▶ 542 RCX240 ▶ 532

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XX-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- Arm type
- Gantry type
- Moving arm type
- Pole type
- XZ type



- Arm type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)+R-axis

### Ordering method

**HXYx - C**    **ZRL**    **RCX340-4**    **RCX240**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
		A1 A2 A3 A4	25 to 125cm	25 to 65cm		25 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX340							
								RCX240		R					

Specify various controller setting items. RCX340 ▶ **P.542**  
Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis construction</b> <small>Note 1</small>	F20	F17	F14H-BK	R20
<b>AC servo motor output (W)</b>	600	400	200	200
<b>Repeatability</b> <small>Note 2</small> (XYZ: mm)(R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	10	(1/50)
<b>Maximum speed</b> <small>Note 4</small> (XYZ: mm/sec) (R: °/sec)	1200	1200	600	360
<b>Moving range (XYZ: mm) (R: °)</b>	250 to 1250	250 to 650	250 to 550	360
<b>Robot cable length (m)</b>	Standard: 3.5    Option: 5, 10			

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
Note 2. Positioning repeatability in one direction.  
Note 3. Leads not listed in the catalog are also available. Contact us for details.  
Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)			
	250	350	450	550
250	12	12	12	12
350	12	12	12	12
450	12	12	12	11
550	10	9	8	7
650	10	9	8	7

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	


### HXYx 4 axes / ZRL (A1)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
<b>L</b>	667	767	867	967	1067	1167	1267	1367	1467	1567	1667
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100
<b>C</b>	420	420	600	600	780	780	960	960	1140	1320	1320
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18
<b>Y stroke</b>	250	350	450	550	650						
<b>Z stroke</b>	250	350	450	550							
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	X-axis		1200				960	840	720	600	480
<b>Speed setting</b>			-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



### Ordering method

**HXYx - C** [ ] [ ] [ ] **ZRH** [ ] [ ] [ ] **RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
A1		A1	25 to 125cm	25 to 65cm		25 to 55cm	3L: 3.5m 5L: 5m 10L: 10m
A2		A2					
A3		A3					
A4		A4					

**RCX340-4** Controller / Number of controllable axes Safety standard Option A (OP.A) Option B (OP.B) Option C (OP.C) Option D (OP.D) Option E (OP.E) Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** [ ] **R** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**RCX240** Controller CE Marking Regenerative unit Expansion I/O Network option iVY System Gripper Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis	R-axis
Axis construction <sup>Note 1</sup>	F20	F17	F14H-BK	R20
AC servo motor output (W)	600	400	200	200
Repeatability <sup>Note 2</sup> (XYZ: mm)(R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	5	(1/50)
Maximum speed <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1200	1200	300	360
Moving range (XYZ: mm) (R: °)	250 to 1250	250 to 650	250 to 550	360
Robot cable length (m)	Standard: 3.5 Option: 5,10			

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)			
	250	350	450	550
250	12	12	12	12
350	12	12	12	12
450	12	12	12	11
550	11	10	9	8
650	11	10	9	8

### Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### HXYx 4 axes / ZRH A1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
	L	667	767	867	967	1067	1167	1267	1367	1467	1567	1667
K	100	200	100	200	100	200	100	200	100	200	100	
C	420	420	600	600	780	780	960	960	1140	1320	1320	
M	2	2	3	3	4	4	5	5	6	6	7	
N	8	8	10	10	12	12	14	14	16	16	18	
Y stroke	250	350	450	550	650							
Z stroke	250	350	450	550								
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200				960	840	720	600	480		
	Speed setting	-				80%	70%	60%	50%	40%		

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type

Moving arm type

Pole type

XZ type

# HXYLx 2 axes

● Arm type   ● Cable carrier



## Ordering method

<b>HXYLx - C</b>					<b>RCX222HP</b>			<b>R</b>		
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
	A1 A2 A3 A4	115 to 205cm 25 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222HP	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet <sup>Note 3</sup> YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>		

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20N	F17
<b>AC servo motor output (W)</b>	400	400
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.04	+/-0.01
<b>Drive system</b>	Ball screw (Class C10)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed (mm/sec)</b>	1200	1200
<b>Moving range (mm)</b>	1150 to 2050	250 to 650
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5, 10	

Note 1. Use caution that the frame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
250	40
350	40
450	35
550	30
650	30

## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## HXYLx 2 axes A1




X stroke	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050
<b>L</b>	1570	1670	1770	1870	1970	2070	2170	2270	2370	2470
<b>D</b>	528	574	620	666	712	758	804	850	896	942
<b>K</b>	100	200	100	200	100	200	100	200	100	200
<b>M</b>	7	7	8	8	9	9	10	10	11	11
<b>N</b>	18	18	20	20	22	22	24	24	26	26
<b>Y stroke</b>	250	350	450	550	650					

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.


HXYLx 2 axes **A2**



**Detail of section A**





**Detail of section B**




**Detail of section C**


Use M8 x 1.25 hex socket head bolt with length head bolt with length (under head) of 45mm or more.




**Cross-section of cable carrier**



HXYLx 2 axes **A3**





**Detail of section A**





**Detail of section C**

Use M8 x 1.25 hex socket head bolt with length head bolt with length (under head) of 45mm or more.





**Cross-section of cable carrier**




**Detail of section B**


HXYLx 2 axes **A4**



**Detail of section A**




**Detail of section B**





**Detail of section C**

Use M8 x 1.25 hex socket head bolt with length head bolt with length (under head) of 45mm or more.




**Cross-section of cable carrier**



- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XX-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER
- INFORMATION
- Arm type
- Gantry type
- Moving arm type
- Pole type
- XZ type

# MXYx 2 axes



- Gantry type
- Cable carrier

## Ordering method

**MXYx - C**         **RCX222**   **R**    

Model	Cable	Combination	X-axis stroke	Y-axis stroke	Cable	Controller	Usable for CE	Regenerative unit	Input/Output selection 1	Input/Output selection 2
G1			25 to 125cm	15 to 85cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	150 to 850
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	30
250	30
350	30
450	30
550	30
650	30
750	25
850	20

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 2 axes G1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	L	615	715	815	915	1015	1115	1215	1315	1415	1515
K	100	200	100	200	100	200	100	200	100	200	100
D	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18

Y stroke	150	250	350	450	550	650	750	850		
	<b>Maximum speed for each stroke</b> <sup>Note 3</sup> (mm/sec)									
X-axis			1200			960	840	720	600	480
Speed setting			-			80%	70%	60%	50%	40%
Y-axis		1200				960	780			
Speed setting		-				80%	65%			

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

INFORMATION

INFORMATION

Arm type


Gantry type

Moving arm type


Pole type

XZ type


MXyX 2 axes **G2**




MXyX 2 axes **G3**



MXyX 2 axes **G4**



# MXYx 2 axes / IO



● Gantry type ● Cable carrier ● Type with Y-axis I/O cable carrier added

## Ordering method

<b>MXYx - C</b>							<b>IO</b>		<b>RCX222</b>			<b>R</b>		
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>ZR-axis</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>			
G1		G1	25 to 125cm	15 to 85cm		3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None Nt: OP.DIO24/16 (NPN) <sup>Note 1</sup> Pt: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>			

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	150 to 850
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	29
250	29
350	29
450	29
550	29
650	29
750	24
850	19

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 2 axes / IO G1




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
	<b>L</b>	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100	
<b>D</b>	240	420	600	600	780	780	960	960	1140	1140	1320	
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7	
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18	
Y stroke	150	250	350	450	550	650	750	850				
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>	1200					960	840	720	600	480	
	<b>Speed setting</b>	-					80%	70%	60%	50%	40%	
	<b>Y-axis</b>	1200					960	780				
	<b>Speed setting</b>	-					80%	65%				

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



- Gantry type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)



### Ordering method

**MXYx-C**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
G1			25 to 125cm	15 to 85cm	ZFL20	15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m
G2					ZFL10		
G3							
G4							

**RCX340-3**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P532**

### Specification

	X-axis	Y-axis	Z-axis: ZFL20	Z-axis: ZFL10
Axis construction <sup>Note 1</sup>	F17	F14H-BK	F10-BK equivalent guide-reinforced model	
AC servo motor output (W)	400	200	200	
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01	
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	20	10
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	1200	600
Moving range (mm)	250 to 1250	150 to 850	150 to 350	
Robot cable length (m)	Standard: 3.5 Option: 5, 10			

Note. The standard types are ZFL with higher rigidity as compared with ZF types which are conventional standard types. When you need the ZF type, please consult YAMAHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)					
	ZFL20			ZFL10		
150	8	8	8	15	15	15
250	8	8	8	15	15	15
350	8	8	8	15	15	15
450	8	8	8	15	15	15
550	8	8	8	15	15	15
650	8	8	8	15	15	15
750	8	8	8	15	15	15
850	8	8	8	12	11	10

### Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### MXYx 3 axes / ZFL20/10 G1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
	L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100	
D	240	420	600	600	780	780	960	960	1140	1140	1320	
M	2	2	3	3	4	4	5	5	6	6	7	
N	8	8	10	10	12	12	14	14	16	16	18	
Y stroke	150	250	350	450	550	650	750	850				
Z stroke	150	250	350									
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200					960	840	720	600	480	
	Speed setting	-					80%	70%	60%	50%	40%	
Y-axis	Speed setting	1200					960	780				
	Speed setting	-					80%	65%				


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# MXYx 3 axes / ZFH

- Gantry type
- Cable carrier
- Z-axis: clamped table / moving base type (200W)



## Ordering method

**MXYx - C**    **ZFH**

Model    Cable    Combination    X-axis stroke    Y-axis stroke    ZR-axis    Z-axis stroke    Cable

G1    25 to 125cm    15 to 85cm    15 to 35cm    3L: 3.5m  
5L: 5m  
10L: 10m

**RCX340-3**    Safety standard    Option A (OP.A)    Option B (OP.B)    Option C (OP.C)    Option D (OP.D)    Option E (OP.E)    Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**    R    Controller    CE Marking    Regenerative unit    Expansion I/O    Network option    IVY System    Gripper    Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	400	200	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200	600
<b>Moving range (mm)</b>	250 to 1250	150 to 850	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5    Option: 5, 10		

Note. The standard types are ZFH with higher rigidity as compared with ZF types which are conventional standard types. When you need the ZF type, please consult YAMAHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	14	13	12
250	14	13	12
350	14	13	12
450	14	13	12
550	14	13	12
650	14	13	12
750	14	13	12
850	12	11	10

## Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 3 axes / ZFH G1




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	L	615	715	815	915	1015	1115	1215	1315	1415	1515
K	100	200	100	200	100	200	100	200	100	200	100
D	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	150	250	350	450	550	650	750	850			
Z stroke	150	250	350								
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>		1200				960	840	720	600	480
	<b>Speed setting</b>		-				80%	70%	60%	50%	40%
	<b>Y-axis</b>		1200				960	780			
	<b>Speed setting</b>		-				80%	65%			

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

- Gantry type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)+R-axis



### Ordering method

#### MXy<sub>x</sub> - C

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
G1			25 to 125cm	15 to 85cm	ZRFL20	15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m
G2					ZRFL10		
G3							
G4							

#### RCX340-4

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ P.542

#### RCX240

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	iVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ P.532

### Specification

	X-axis	Y-axis	Z-axis: ZRFL20	Z-axis: ZRFL10	R-axis
Axis construction <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model		R5
AC servo motor output (W)	400	200	200		50
Repeatability <sup>Note 2</sup> (XYZ: mm)(R: °)	+/-0.01	+/-0.01	+/-0.01		+/-0.0083
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)		Harmonic gear
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	20	10	(1/50)
Maximum speed <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1200	1200	1200	600	360
Moving range (XYZ: mm)(R: °)	250 to 1250	150 to 850	150 to 350		360
Robot cable length (m)	Standard: 3.5 Option: 5,10				

Note. The standard types are ZRFL with higher rigidity as compared with ZRF types which are conventional standard types. When you need the ZRF type, please consult YAMAHA.  
 Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)					
	ZRFL20			ZRFL10		
150	4	4	4	11	11	11
250	4	4	4	11	11	11
350	4	4	4	11	11	11
450	4	4	4	11	11	11
550	4	4	4	11	11	11
650	4	4	4	11	11	11
750	4	4	4	11	11	11
850	4	4	4	8	7	6

### Controller

Controller	Operation method
RCX340	Programming / I/O port trace / Remote command / Operation using RS-232C communication
RCX240-R	

### MXy<sub>x</sub> 4 axes / ZRFL20/10 (G1)




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
	L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100	
D	240	420	600	600	780	780	960	960	1140	1140	1320	
M	2	2	3	3	4	4	5	5	6	6	7	
N	8	8	10	10	12	12	14	14	16	16	18	
Y stroke	150	250	350	450	550	650	750	850				
Z stroke	150	250	350									
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200					960	840	720	600	480	
	Speed setting	-					80%	70%	60%	50%	40%	
	Y-axis	1200					960	780				
Speed setting	-					80%	65%					

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Arm type  
Gantry type  
Moving arm type  
Pole type  
XZ type

# MXYx 4 axes / ZRFH



● Gantry type ● Cable carrier ● Z-axis: clamped table / moving base type (200W)+R-axis

## Ordering method

**MXYx - C** [ ] [ ] [ ] **ZRFH** [ ] [ ] [ ]

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
G1		G1	25 to 125cm	15 to 85cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m
G2		G2					
G3		G3					
G4		G4					

**RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller / Number of controllable axes Safety standard Option A (OP.A) Option B (OP.B) Option C (OP.C) Option D (OP.D) Option E (OP.E) Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller CE Marking Regenerative unit Expansion I/O Network option IVY System Gripper Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specification

	X-axis	Y-axis	Z-axis	R-axis
Axis construction <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model	R5
AC servo motor output (W)	400	200	200	50
Repeatability <sup>Note 2</sup> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10	(1/50)
Maximum speed <sup>Note 4</sup> (XYZ: mm/sec) (R: %/sec)	1200	1200	600	360
Moving range (XYZ: mm) (R: °)	250 to 1250	150 to 850	150 to 350	360
Robot cable length (m)	Standard: 3.5 Option: 5.10			

Note. The standard types are ZRFH with higher rigidity as compared with ZRF types which are conventional standard types. When you need the ZRF type, please consult YAMHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	10	9	8
250	10	9	8
350	10	9	8
450	10	9	8
550	10	9	8
650	10	9	8
750	10	9	8
850	8	7	6

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

## MXYx 4 axes / ZRFH (G1)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	L	615	715	815	915	1015	1115	1215	1315	1415	1515
K	100	200	100	200	100	200	100	200	100	200	100
D	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	150	250	350	450	550	650	750	850			
Z stroke	150	250	350								

Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis	1200		960	840	720	600	480
	Speed setting	-	-	80%	70%	60%	50%	40%
Y-axis	1200		960	780				
Speed setting	-	-	80%	65%				

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm (750mm for Y-axis), resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type


Gantry type

Moving arm  
type

Pole type

XZ type

# HXYx 2 axes



- Gantry type
- Cable carrier

## Ordering method

<b>HXYx - C</b>					<b>RCX222HP</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
G1			25 to 125cm	25 to 105cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222HP	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None Nt: OPDIO24/16 (NPN) <sup>Note 1</sup> Pt: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20	F17
<b>AC servo motor output (W)</b>	600	400
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	250 to 1050
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
250 to 1050	50

## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 2 axes G1




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	<b>L</b>	667	767	867	967	1067	1167	1267	1367	1467	1567
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100
<b>F</b>	420	420	600	600	780	780	960	960	1140	1320	1320
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18
Y stroke	250	350	450	550	650	750	850	950	1050		
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 4</sup>	<b>X-axis</b>		1200				960	840	720	600	480
	<b>Y-axis</b>		1200				960	840	720		
	<b>Speed setting</b>		-				80%	70%	60%	50%	40%


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. Dimension of reinforced bracket (To be installed when the Y stroke is 750mm or longer)

Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.


HXYx 2 axes **G2**




Detail of section A





Detail of section B




Detail of section C




Cross-section of cable carrier




HXYx 2 axes **G3**




Detail of section A





Detail of section B





Detail of section C




Cross-section of cable carrier




HXYx 2 axes **G4**




Detail of section A





Detail of section B



Detail of section C




Cross-section of cable carrier



Cross-section of cable carrier

# HXYx 3 axes / ZL

- Gantry type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)



## Ordering method

**HXYx - C** [ ] [ ] [ ] **ZL** [ ] [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X-axis stroke** **Y-axis stroke** **ZR-axis** **Z-axis stroke** **Cable** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**RCX240** [ ] **R** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller** **CE Marking** **Regenerative unit** **Expansion I/O** **Network option** **IVY System** **Gripper** **Battery**

Specify various controller setting items. RCX340 ▶ **P542**  
Specify various controller setting items. RCX240/RCX240S ▶ **P532**

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <small>Note 1</small>	F20	F17	F14H-BK
<b>AC servo motor output (W)</b>	600	400	200
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1200	1200	600
<b>Moving range (mm)</b>	250 to 1250	250 to 1050	250 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)
250 to 1050	250 to 550
	20

## Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 3 axes / ZL G1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
<b>L</b>	667	767	867	967	1067	1167	1267	1367	1467	1567	1667	
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100	
<b>F</b>	420	420	600	600	780	780	960	960	1140	1320	1320	
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7	
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18	
<b>Y stroke</b>	250	350	450	550	650	750	850	950	1050			
<b>Z stroke</b>	250	350	450	550								
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 4</small>	<b>X-axis</b>	1200					960	840	720	600	480	
	<b>Y-axis</b>	1200					960	840	720			
	<b>Speed setting</b>	-					80%	70%	60%	50%	40%	


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. Dimension of reinforced bracket (To be installed when the Y stroke is 750mm or longer)

Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



# HXYx **3 axes / ZH**

● Gantry type ● Cable carrier ● Z-axis: clamped table / moving base type (200W)



## Ordering method

**HXYx - C** [ ] [ ] [ ] **ZH** [ ] [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model Cable Combination X-axis stroke Y-axis stroke ZR-axis Z-axis stroke Cable

Specify various controller setting items. **RCX340 ▶ P.542**

**RCX240** [ ] **R** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller CE Marking Regenerative unit Expansion I/O Network option IVY System Gripper Battery

Specify various controller setting items. **RCX240/RCX240S ▶ P.532**

## Specification

	X-axis	Y-axis	Z-axis
Axis construction <sup>Note 1</sup>	F20	F17	F14H-BK
AC servo motor output (W)	600	400	200
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	5
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	300
Moving range (mm)	250 to 1250	250 to 1050	250 to 550
Robot cable length (m)	Standard: 3.5 Option: 5,10		

- Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)
250 to 1050	30

## Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 3 axes / ZH (G1)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	L	667	767	867	967	1067	1167	1267	1367	1467	1567
K	100	200	100	200	100	200	100	200	100	200	100
F	420	420	600	600	780	780	960	960	1140	1320	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	250	350	450	550	650	750	850	950	1050		
Z stroke	250	350	450	550							
ZK	100	200	100	200							
ZM	1	1	2	2							
ZN	10	10	12	12							

- Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. Dimension of reinforced bracket (To be installed when the Y stroke is 750mm or longer)

Maximum speed for each stroke (mm/sec) <sup>Note 4</sup>	X-axis	1200					960	840	720	600	480
	Y-axis	1200					960	840	720		
	Speed setting	-					80%	70%	60%	50%	40%

- Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type


Moving arm type

Pole type

XZ type

# HXYx 4 axes / ZRL

- Gantry type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)+R-axis



## Ordering method

**HXYx - C** - [ ] - [ ] - [ ] - **ZRL** - [ ] - [ ] - [ ] - [ ] - [ ]

**Model** - **Cable** - **Combination** - **X-axis stroke** - **Y-axis stroke** - **ZR-axis** - **Z-axis stroke** - **Cable**

**RCX340-4** - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ]

**Controller / Number of controllable axes** - **Safety standard** - **Option A (OP.A)** - **Option B (OP.B)** - **Option C (OP.C)** - **Option D (OP.D)** - **Option E (OP.E)** - **Absolute battery**

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240** - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ] - [ ]

**Controller** - **CE Marking** - **Regenerative unit** - **Expansion I/O** - **Network option** - **IVY System** - **Gripper** - **Battery**

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specification

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20	F17	F14H-BK	R20
<b>AC servo motor output (W)</b>	600	400	200	200
<b>Repeatability</b> <sup>Note 2</sup> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.01	+/-0.0083
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	Harmonic gear
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10	(1/50)
<b>Maximum speed</b> <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1200	1200	600	360
<b>Moving range (XYZ: mm) (R: °)</b>	250 to 1250	250 to 1050	250 to 550	360
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10			

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)
250 to 1050	250 to 550
	12

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

## HXYx 4 axes / ZRL (G1)




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
	L	667	767	867	967	1067	1167	1267	1367	1467	1567
K	100	200	100	200	100	200	100	200	100	200	100
F	420	420	600	600	780	780	960	960	1140	1320	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	250	350	450	550	650	750	850	950	1050		
Z stroke	250	350	450	550							
Maximum speed for each stroke (mm/sec)	X-axis	1200			960			840	720	600	480
	Y-axis	1200			960			840	720		
	Speed setting	-			80%			70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. Dimension of reinforced bracket (To be installed when the Y stroke is 750mm or longer)

Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



# HXYLx 2 axes



- Gantry type
- Cable carrier

## Ordering method

<b>HXYLx - C</b>					<b>RCX222HP</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
G1			115 to 205cm	25 to 105cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222HP	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20N	F17
<b>AC servo motor output (W)</b>	400	400
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.04	+/-0.01
<b>Drive system</b>	Ball screw (Class C10)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	1150 to 2050	250 to 1050
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
250 to 1050	50

## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYLx 2 axes G1




X stroke	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050
<b>L</b>	1570	1670	1770	1870	1970	2070	2170	2270	2370	2470
<b>E</b>	528	574	620	666	712	758	804	850	896	942
<b>K</b>	100	200	100	200	100	200	100	200	100	200
<b>M</b>	7	7	8	8	9	9	10	10	11	11
<b>N</b>	18	18	20	20	22	22	24	24	26	26
<b>F</b>	14	16	16	18	18	20	20	22	22	24
<b>Y stroke</b>	250	350	450	550	650	750	850	950	1050	
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 4</sup>	<b>Y-axis</b>		1200				960		840	720
<b>Speed setting</b>			-				80%		70%	60%


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. Dimension of reinforced bracket (To be installed when the Y stroke is 750mm or longer)

Note 4. When the Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.


HXYLx 2 axes **G2**



HXYLx 2 axes **G3**



HXYLx 2 axes **G4**



Articulated robots  
 YA  
 Linear conveyor modules  
 LCM100  
 Compact single-axis robots  
 TRANSEVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XX-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 INFORMATION  
 INFORMATION  
 Arm type  
 Gantry type  
 Moving arm type  
 Pole type  
 XZ type

# SXYx 2 axes

● Moving arm type ● Whipover



## Ordering method

<b>SXYx - S</b>					<b>RCX222</b>				
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b> Note 1	<b>Y-axis stroke</b> Note 1	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
M1		M1	15 to 85cm	15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN Note 2 P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link Note 3	No entry: None N1: OP.DIO24/16 (NPN) Note 2 P1: OP.DIO24/17 (PNP) EN: Ethernet Note 4

Note 1. The total of the X and Y strokes should be 1000mm or less.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Available only for the master. See P.66 for details on YC-Link system.  
 Note 4. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> Note 1	F14H	F14
<b>AC servo motor output (W)</b>	200	100
<b>Repeatability</b> Note 2 (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> Note 3 (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> Note 4 (mm/sec)	1200	1200
<b>Moving range (mm)</b>	150 to 850	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	15
250	14
350	13

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 2 axes M1




X stroke	150	250	350	450	550	650	750	850
<b>L</b>	470	570	670	770	870	970	1070	1170
<b>K</b>	200	100	200	100	200	100	200	100
<b>D</b>	240	240	420	420	600	600	780	960
<b>M</b>	0	1	1	2	2	3	3	4
<b>N</b>	4	6	6	8	8	10	10	12
<b>Y stroke</b>	150	250	350					
<b>Maximum speed for each stroke (mm/sec)</b>	X-axis		1200		960		780	
<b>Speed setting</b>			-		80%		65%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. The total of the X and Y strokes should be 1000mm or less.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

SXYx 2 axes M3



X stroke <sup>Note 3</sup>	150	250	350	450	550	650	750	850
L	470	570	670	770	870	970	1070	1170
K	200	100	200	100	200	100	200	100
D	240	240	420	420	600	600	780	960
M	0	1	1	2	2	3	3	4
N	4	6	6	8	8	10	10	12
Y stroke <sup>Note 3</sup>	150	250	350					
Maximum speed for each stroke (mm/sec) <sup>Note 4</sup>	X-axis		1200			960		780
Speed setting			-			80%		65%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.


Note 2. The shaded position indicates an user cable extraction port.

Note 3. The total of the X and Y strokes should be 1000mm or less.

Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYx 3 axes / ZF

● Moving arm type ● Whipover ● Z-axis: clamped base / moving table type (100W)



## Ordering method

**SXYx - S** [ ] [ ] [ ] **ZF** [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X-axis stroke** **Y-axis stroke** **ZR-axis** **Z-axis stroke** **Cable** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**M1** **M3** **15 to 85cm** **15 to 35cm** **15 to 35cm** **3L: 3.5m** **5L: 5m** **10L: 10m** **RCX340** **P542**

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller** **CE Marking** **Expansion I/O** **Network option** **iVY System** **Gripper** **Battery** **Specify various controller setting items. RCX240/RCX240S ▶ P.532**

Note 1. The total of the X and Y strokes should be 1000mm or less.

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14	F10-BK
<b>AC servo motor output (W)</b>	200	100	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200	600
<b>Moving range (mm)</b>	150 to 850	150 to 350	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	9	8	7
250	8	7	6
350	7	6	5

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S	

## SXYx 3 axes / ZF M1




X stroke <sup>Note 3</sup>	150	250	350	450	550	650	750	850	
	<b>L</b>	470	570	670	770	870	970	1070	1170
<b>K</b>	200	100	200	100	200	100	200	100	
<b>D</b>	240	240	420	420	600	600	780	960	
<b>M</b>	0	1	1	2	2	3	3	4	
<b>N</b>	4	6	6	8	8	10	10	12	
<b>Y stroke</b> <sup>Note 3</sup>	150	250	350						
<b>Z stroke</b>	150	250	350						
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 4</sup>	X-axis		1200			960		780	
<b>Speed setting</b>			-			80%		65%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. The total of the X and Y strokes should be 1000mm or less.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.





### Ordering method

**SXYx - S** - **ZFL20** - **RCX340-3** - **RCX240S**

Model - Cable - Combination (M1, M3) - X-axis stroke (15 to 85cm, 15 to 35cm) - Y-axis stroke (15 to 35cm) - ZR-axis - Z-axis stroke (15 to 35cm) - Cable (3L: 3.5m, 5L: 5m, 10L: 10m)

**RCX340-3**: Controller / Number of controllable axes, Safety standard, Option A (OP.A), Option B (OP.B), Option C (OP.C), Option D (OP.D), Option E (OP.E), Absolute battery

**RCX240S**: Controller, CE Marking, Regenerative unit, Expansion I/O, Network option, IVY System, Gripper, Battery

Specify various controller setting items. **RCX340 ▶ P.542**  
**RCX240S ▶ P.532**

Note 1. The total of the X and Y strokes should be 1000mm or less.

### Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	200	100	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200	1200
<b>Moving range (mm)</b>	150 to 850	150 to 350	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	8	8	7
250	8	7	6
350	7	6	5

### Controller

Controller	Operation method
RCX340 RCX240S-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### SXYx 3 axes / ZFL20 M1



X stroke <sup>Note 3</sup>	150	250	350	450	550	650	750	850
	L	470	570	670	770	870	970	1070
A	200	100	200	100	200	100	200	100
D	240	240	420	420	600	600	780	960
M	0	1	1	2	2	3	3	4
N	4	6	6	8	8	10	10	12

Y stroke <sup>Note 3</sup>	150	250	350
Y stroke	150	250	350

Z stroke	150	250	350
Z stroke	150	250	350

Maximum speed for each stroke (mm/sec) <sup>Note 4</sup>	X-axis	1200	960	780
	Speed setting	-	80%	65%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.


Note 3. The total of the X and Y strokes should be 1000mm or less.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Single-axis robots  
TRANSEVO  
Compact single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Arm type  
Gantry type  
Moving arm type  
Pole type  
XZ type

# SXYx

**3 axes / ZFH**

- Moving arm type
- Whipover
- Z-axis: clamped table / moving base type (200W)



## Ordering method

**SXYx-S** [ ] [ ] [ ] **ZFH** [ ] [ ] [ ]

Model	Cable	Combination	X-axis stroke <sup>Note 1</sup>	Y-axis stroke <sup>Note 1</sup>	ZR-axis	Z-axis stroke	Cable
		M1 M3	15 to 85cm	15 to 35cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ P.542

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ P.532

Note 1. The total of the X and Y strokes should be 1000mm or less.

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	200	100	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec) (°/sec)	1200	1200	600
<b>Moving range (mm)</b>	150 to 850	150 to 350	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)		
	150	250	350
150	9	8	7
250	8	7	6
350	7	6	5

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240S-R	

## SXYx 3 axes / ZFH (M1)



X stroke <sup>Note 3</sup>	150	250	350	450	550	650	750	850	
	L	470	570	670	770	870	970	1070	1170
K	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	
M	0	1	1	2	2	3	3	4	
N	4	6	6	8	8	10	10	12	
<b>Y stroke<sup>Note 3</sup></b>	<b>150</b>	<b>250</b>	<b>350</b>						
<b>Z stroke</b>	<b>150</b>	<b>250</b>	<b>350</b>						
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 4</sup>	<b>X-axis</b>		1200			960		780	
<b>Speed setting</b>			-			80%		65%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.


Note 2. The shaded position indicates a user cable extraction port.

Note 3. The total of the X and Y strokes should be 1000mm or less.

Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYx **3 axes / ZS**

● Moving arm type    ● Whipover    ● Z-axis shaft vertical type



## Ordering method

<b>SXYx - S</b>								<b>15</b>				<b>RCX340-3</b>													
Model	Cable	Combination	X-axis stroke <sup>Note 1</sup>	Y-axis stroke <sup>Note 1</sup>	ZR-axis	Z-axis stroke	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery	Specify various controller setting items. RCX340 ▶ <b>P.542</b>									
M1		M3	15 to 85cm	15 to 35cm	ZS12 ZS6		3L: 3.5m 5L: 5m 10L: 10m	<b>RCX240S</b>								Specify various controller setting items. RCX240/RCX240S ▶ <b>P.532</b>									
								Controller	CE Marking	Expansion I/O	Network option	iVY System	Gripper	Battery											

Note 1. The total of the X and Y strokes should be 1000mm or less.

## Specification

	X-axis	Y-axis	Z-axis: ZS12	Z-axis: ZS6
Axis construction <sup>Note 1</sup>	F14H	F14		-
AC servo motor output (W)	200	100		60
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01		+/-0.02
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C10)	
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	12	6
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	1000	500
Moving range (mm)	150 to 850	150 to 350	150	
Robot cable length (m)	Standard: 3.5 Option: 5,10			

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	ZS12	ZS6
150 to 350	3	5

## Controller

Controller	Operation method
RCX340 RCX240S	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 3 axes / ZS M1



X stroke <sup>Note 3</sup>	150	250	350	450	550	650	750	850	
L	470	570	670	770	870	970	1070	1170	
K	200	100	200	100	200	100	200	100	
D	240	240	420	420	600	600	780	960	
M	0	1	1	2	2	3	3	4	
N	4	6	6	8	8	10	10	12	
Y stroke <sup>Note 3</sup>	150	250	350						
Z stroke	150								
Maximum speed for each stroke (mm/sec) <sup>Note 4</sup>	X-axis	1200					960	780	
Speed setting		-					80%	65%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. The shaded position indicates an user cable extraction port.

Note 3. The total of the X and Y strokes should be 1000mm or less.


Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Controller

**RCX340 ▶ 542 RCX240S ▶ 532**

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Arm type  
Gantry type  
Moving arm type  
Pole type  
XZ type

# MXYx 2 axes



- Moving arm type
- Cable carrier

## Ordering method

<b>MXYx - C</b>					<b>RCX222</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
M1		M1	25 to 125cm	15 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (PNP) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>
M3		M3								

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	150 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.







## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150 to 550	20

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 2 axes M1



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
<b>L</b>	615	715	815	915	1015	1115	1215	1315	1415	1515	1615	
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100	
<b>D</b>	240	420	600	600	780	780	960	960	1140	1140	1320	
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7	
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18	
<b>Y stroke</b>	150	250	350	450	550							
<b>Maximum speed for each stroke (mm/sec)</b>	<b>X-axis</b>		1200					960	840	720	600	480
	<b>Speed setting</b>		-					80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

MXYx 2 axes **M3**

**Detail of section A**  
 100  
 50  
 70  
 32  
 2-φ6H7 Depth6  
 12-M6 x 1.0 through  
 (Board thickness 10)  
 60  
 110  
 130  
 (Between knockouts ±0.02)  
 27 44

**Detail of section B**  
 26.5

**Cross-section of cable carrier**  
 93  
 77  
 25  
 35  
 φ9.7  
 φ8.2  
 φ7.6

Use M8 x 1.25 hex socket head bolt with length head bolt with length (under head) of 40mm or more.

**Main Assembly Diagram:**  
 X stroke: 234±3  
 Y stroke + (140±3) (When at the origin position)  
 Y stroke  
 Note 1  
 83  
 10  
 40  
 5  
 5  
 10  
 10  
 138  
 10  
 125  
 179  
 18.5  
 168  
 5  
 77.5  
 61  
 30  
 125  
 24  
 150  
 L (X stroke + 365)


**Side View:**  
 268  
 3  
 120  
 48  
 80  
 MAX. 900  
 100  
 136  
 230  
 299  
 A

**Front View:**  
 345  
 97.5  
 75  
 K  
 M x 200  
 40  
 200  
 N-φ9 through (B)  
 2-φ10H7 Depth16  
 C±0.02  
 166.5  
 132  
 50  
 135  
 165  
 103.5  
 80  
 37  
 5.5  
 φ29 (Note 2)  
 Grounding terminal (M4)

X stroke	250	350	450	550	650	750	850	950	1050	1150	1250		
L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615		
K	100	200	100	200	100	200	100	200	100	200	100		
D	240	420	600	600	780	780	960	960	1140	1140	1320		
M	2	2	3	3	4	4	5	5	6	6	7		
N	8	8	10	10	12	12	14	14	16	16	18		
Y stroke	150	250	350	450	550								
Maximum speed for each stroke (mm/sec) Note 3	X-axis				1200				960	840	720	600	480
Speed setting					-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

- Moving arm type
- Cable carrier
- Z-axis: clamped base / moving table type (200W)



### Ordering method

**MXYx - C**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
		M1 M3	25 to 125cm	15 to 55cm	ZFL20 ZFL10	15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-3**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis: ZFL20	Z-axis: ZFL10
<b>Axis construction</b> <small>Note 1</small>	F17	F14H	F10-BK equivalent guide-reinforced model	
<b>AC servo motor output (W)</b>	400	200	200	
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01	+/-0.01	
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)	
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	20	10
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1200	1200	1200	600
<b>Moving range (mm)</b>	250 to 1250	150 to 550	150 to 350	
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10			

Note. The standard types are ZFL with higher rigidity as compared with ZF types which are conventional standard types. When you need the ZF type, please consult YAMAHA.

Note 1. Use caution that the frame machining (installation holes, tap holes) differs from single-axis robots'.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)					
	ZFL20			ZFL10		
150 to 550	8	8	8	12	11	10

### Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

### MXYx 3 axes / ZFL20/10 M1



	X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
<b>L</b>		615	715	815	915	1015	1115	1215	1315	1415	1515	1615	
<b>K</b>		100	200	100	200	100	200	100	200	100	200	100	
<b>C</b>		240	420	600	600	780	780	960	960	1140	1140	1320	
<b>M</b>		2	2	3	3	4	4	5	5	6	6	7	
<b>N</b>		8	8	10	10	12	12	14	14	16	16	18	
<b>Y stroke</b>		150	250	350	450	550							
<b>Z stroke</b>		150	250	350									
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	<b>X-axis</b>	1200					960	840	720	600	480		
	<b>Speed setting</b>	-					80%	70%	60%	50%	40%		


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# MXYx 3 axes / ZFH

- Moving arm type
- Cable carrier
- Z-axis: clamped table / moving base type (200W)



## Ordering method

**MXYx - C**    **ZFH**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
		M1 M3	25 to 125cm	15 to 55cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-3**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**    **R**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	iVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specification

	X-axis	Y-axis	Z-axis
Axis construction <sup>Note 1</sup>	F17	F14H	F10-BK equivalent guide-reinforced model
AC servo motor output (W)	400	200	200
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	10
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	1200	600
Moving range (mm)	250 to 1250	150 to 550	150 to 350
Robot cable length (m)	Standard: 3.5 Option: 5,10		

Note. The standard types are ZFH with higher rigidity as compared with ZF types which are conventional standard types. When you need the ZF type, please consult YAMAHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.








## Maximum payload (kg)

	Z stroke (mm)		
Y stroke (mm)	150	250	350
150 to 550	12	11	10

## Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 3 axes / ZFH M1



X stroke <sup>Note 3</sup>	250	350	450	550	650	750	850	950	1050	1150	1250
L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100
D	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke <sup>Note 3</sup>	150			250		350		450		550	
Z stroke	150			250		350					
Maximum speed for each stroke (mm/sec) <sup>Note 4</sup>	X-axis		1200				960	840	720	600	480
	Speed setting		-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.


Note 3. The total of the Y and Z strokes should be 800mm or less.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.

- Articulated robots YA
- Linear conveyor modules LCM100
- Compact single-axis robots TRANSERVO
- Single-axis robots FLIP-X
- Linear motor single-axis robots PHASER
- Cartesian robots XX-X
- SCARA robots YK-X
- Pick & place robots YP-X
- CLEAN
- CONTROLLER INFORMATION
- Arm type
- Gantry type
- Moving arm type
- Pole type
- XZ type

# HXYx 2 axes

- Moving arm type
- Cable carrier



## Ordering method

<b>HXYx - C</b>					<b>RCX222HP</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>Y-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
M1		M1	25 to 125cm	25 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222HP	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20	F17
<b>AC servo motor output (W)</b>	600	400
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	250 to 1250	250 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
250 to 650	30

## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 2 axes M1







X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
<b>L</b>	667	767	867	967	1067	1167	1267	1367	1467	1567	1667
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100
<b>C</b>	420	420	600	600	780	780	960	960	1140	1320	1320
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18
<b>Y stroke</b>	250	350	450	550	650						
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>		1200				960	840	720	600	480
	<b>Speed setting</b>		-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



HXYx 2 axes **M3**




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
L	667	767	867	967	1067	1167	1267	1367	1467	1567	1667
K	100	200	100	200	100	200	100	200	100	200	100
C	420	420	600	600	780	780	960	960	1140	1320	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	250	350	450	550	650						
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis		1200				960	840	720	600	480
	Speed setting		-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# HXYx 3 axes / ZH

● Moving arm type ● Cable carrier ● Z-axis: clamped table / moving base type (200W)



## Ordering method

**HXYx - C** [ ] [ ] [ ] **ZH** [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X-axis stroke** **Y-axis stroke** **ZR-axis** **Z-axis stroke** **Cable** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**M1** **25 to 125cm** **25 to 65cm** **25 to 55cm** **3L: 3.5m** **5L: 5m** **10L: 10m** **RCX340** **R** **CE Marking** **Regenerative unit** **Expansion I/O** **Network option** **IVY System** **Gripper** **Battery**

**M3** **25 to 125cm** **25 to 65cm** **25 to 55cm** **3L: 3.5m** **5L: 5m** **10L: 10m** **RCX240** **R** **CE Marking** **Regenerative unit** **Expansion I/O** **Network option** **IVY System** **Gripper** **Battery**

**Specify various controller setting items. RCX340 ▶ P542**  
**Specify various controller setting items. RCX240/RCX240S ▶ P532**

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <small>Note 1</small>	F20	F17	F14H-BK
<b>AC servo motor output (W)</b>	600	400	200
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	5
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1200	1200	300
<b>Moving range (mm)</b>	250 to 1250	250 to 650	250 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)			
	250	350	450	550
250	18	18	18	18
350	18	18	18	18
450	18	18	18	18
550	18	17	16	15
650	18	17	16	15

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 3 axes / ZH M1



X stroke	L											
	250	350	450	550	650	750	850	950	1050	1150	1250	
L	667	767	867	967	1067	1167	1267	1367	1467	1567	1667	
K	100	200	100	200	100	200	100	200	100	200	100	
C	420	420	600	600	780	780	960	960	1140	1320	1320	
M	2	2	3	3	4	4	5	5	6	6	7	
N	8	8	10	10	12	12	14	14	16	16	18	
<b>Y stroke</b>	<b>250</b>	<b>350</b>	<b>450</b>	<b>550</b>	<b>650</b>							
<b>Z stroke</b>	<b>250</b>	<b>350</b>	<b>450</b>	<b>550</b>								
ZK	100	200	100	200								
ZM	1	1	2	2								
ZN	10	10	12	12								
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 3</small>	<b>X-axis</b>	1200				960	840	720	600	480		
	<b>Speed setting</b>	-				80%	70%	60%	50%	40%		

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor  
modules  
LCMT100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type

XZ type

# SXYx 2 axes

● Pole type ● Whipover



## Ordering method

<b>SXYx - S - P1</b>				<b>RCX222</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke<sup>Note 1</sup></b>	<b>Y-axis stroke<sup>Note 1</sup></b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>
			15 to 85cm	15 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking
							<b>Input/Output selection 1</b>
							N: NPN <sup>Note 2</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 3</sup>
							<b>Input/Output selection 2</b>
							No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 2</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 4</sup>

Note 1. The total of the X and Y strokes should be 1100mm or less.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Available only for the master. See P.66 for details on YC-Link system.  
 Note 4. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction<sup>Note 1</sup></b>	F14H	F14-BK
<b>AC servo motor output (W)</b>	200	100
<b>Repeatability<sup>Note 2</sup> (mm)</b>	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead<sup>Note 3</sup> (Deceleration ratio) (mm)</b>	20	10
<b>Maximum speed<sup>Note 4</sup> (mm/sec)</b>	1200	600
<b>Moving range (mm)</b>	150 to 850	150 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150 to 550	8

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 2 axes P1




X stroke <sup>Note 3</sup>	150	250	350	450	550	650	750	850
<b>L</b>	470	570	670	770	870	970	1070	1170
<b>K</b>	200	100	200	100	200	100	200	100
<b>D</b>	240	240	420	420	600	600	780	780
<b>M</b>	0	1	1	2	2	3	3	4
<b>N</b>	4	6	6	8	8	10	10	12
Y stroke <sup>Note 3</sup>	150	250	350	450	550			
<b>Maximum speed for each stroke (mm/sec)<sup>Note 4</sup></b>	1200				960		780	
<b>Speed setting</b>	-				80%		65%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. The total of the X and Y strokes should be 1100mm or less.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# MXYx **2 axes**

● Pole type ● Cable carrier



## Ordering method

<b>MXYx - C - P2</b>				<b>RCX222</b>		<b>R</b>				
Model	Cable	Combination	X-axis stroke 25 to 125cm	Y-axis stroke 15 to 65cm	Cable 3L: 3.5m 5L: 5m 10L: 10m	Controller RCX222	Usable for CE No entry: Standard E: CE marking	Regenerative unit R: RG2	Input/Output selection 1 N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	Input/Output selection 2 No entry: None NT: OP.DIO24/16 (NPN) <sup>Note 1</sup> Pt: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
Axis construction <sup>Note 1</sup>	F17	F14H-BK
AC servo motor output (W)	400	200
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	600
Moving range (mm)	250 to 1250	150 to 650
Robot cable length (m)	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150 to 650	20

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## MXYx 2 axes **P2**



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100
C	240	420	600	600	780	780	960	960	1140	1140	1320
M	2	2	3	3	4	4	5	5	6	6	7
N	8	8	10	10	12	12	14	14	16	16	18
Y stroke	150	250	350	450	550	650					
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis		1200				960	840	720	600	480
Speed setting			-				80%	70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type

Moving arm type

Pole type

XZ type

# MXYx 2 axes

● Pole type ● Whipover



## Ordering method

<b>MXYx - S - P1</b>				<b>RCX222</b>		<b>R</b>				
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b> 25 to 95cm	<b>Y-axis stroke</b> 15 to 65cm	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m	<b>Controller</b> RCX222	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>Regenerative unit</b> R: RG2	<b>Input/Output selection 1</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link	<b>Input/Output selection 2</b> No entry: None N1: OPDIO24/16 (NPN) P1: OPDIO24/17 (PNP) EN: Ethernet

Note 1. The total of the X and Y strokes should be 1100mm or less.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Available only for the master. See P.66 for details on YC-Link system.  
 Note 4. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b>	F17	F14H-BK
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability (mm)</b>	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead (Deceleration ratio) (mm)</b>	20	10
<b>Maximum speed (mm/sec)</b>	1200	600
<b>Moving range (mm)</b>	250 to 950	150 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150 to 650	20

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## MXYx 2 axes P1



X stroke	250	350	450	550	650	750	850	950
<b>L</b>	615	715	815	915	1015	1115	1215	1315
<b>K</b>	100	200	100	200	100	200	100	200
<b>C</b>	240	420	600	600	780	780	960	960
<b>M</b>	2	2	3	3	4	4	5	5
<b>N</b>	8	8	10	10	12	12	14	14
<b>Y stroke</b>	150	250	350	450	550	650		
<b>Maximum speed for each stroke (mm/sec)</b>	<b>X-axis</b>		1200				960	840
<b>Speed setting</b>			-				80%	70%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. The total of the X and Y strokes should be 1100mm or less.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



### Ordering method

**MXYx - C - P2**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	ZR-axis	Z-axis stroke	Cable
			25 to 125cm	15 to 65cm	ZPMHL ZPMHR	15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-3**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

### Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H-BK	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	400	200	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	600	1200
<b>Moving range (mm)</b>	250 to 1250	150 to 650	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5.10		

Note. The standard types are ZPMH with higher rigidity as compared with ZPM types which are conventional standard types. When you need the ZPM type, please consult YAMAHHA.

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

	Z stroke (mm)		
Y stroke (mm)	150	250	350
150 to 650	10	9	8

### Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### MXYx 3 axes / ZPMHL (P2)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
	L	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
K	100	200	100	200	100	200	100	200	100	200	100	
C	240	420	600	600	780	780	960	960	1140	1140	1320	
M	2	2	3	3	4	4	5	5	6	6	7	
N	8	8	10	10	12	12	14	14	16	16	18	
<b>Y stroke</b>	150	250	350	450	550	650						
<b>Z stroke</b>	150	250	350									
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>	1200					960	840	720	600	480	
	<b>Speed setting</b>	-					80%	70%	60%	50%	40%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. This figure shows the combination for ZPMHL. For the combination for ZPMHR, see the top view in the figure.

Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type


Gantry type

Moving arm type

Pole type

XZ type

# HXYx 2 axes



● Pole type   ● Cable carrier

## Ordering method

**HXYx - C - P2**   **RCX222HP**   **R**

Model	Cable	Combination	X-axis stroke	Y-axis stroke	Cable	Controller	Usable for CE	Regenerative unit	Input/Output selection 1	Input/Output selection 2
			25 to 125cm	25 to 105cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222HP	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20	F20-BK
<b>AC servo motor output (W)</b>	600	600
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	600
<b>Moving range (mm)</b>	250 to 1250	250 to 1050
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5, 10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
250 to 1050	30

## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 2 axes P2



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
<b>L</b>	667	767	867	967	1067	1167	1267	1367	1467	1567	1667
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100
<b>C</b>	420	420	600	600	780	708	960	1140	1320	1320	1320
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18
<b>Y stroke</b>	250	350	450	550	650	750	850	950	1050		
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>		1200		960		840	720	600	480	
	<b>Y-axis</b>		600		480		420	360			
	<b>Speed setting</b>		-		80%		70%	60%	50%	40%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



# HXYx 2 axes

● Pole type ● Whipover



## Ordering method

<b>HXYx</b>	<b>S</b>	<b>P1</b>				<b>RCX222HP</b>		<b>R</b>		
Model	Cable	Combination	X-axis stroke <small>Note 1</small>	Y-axis stroke <small>Note 1</small>	Cable	Controller	Usable for CE	Regenerative unit	Input/Output selection 1	Input/Output selection 2
			25 to 85cm	25 to 85cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222HP	No entry: Standard E: CE marking	R: RG2	N: NPN <small>Note 2</small> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <small>Note 3</small>	No entry: None Nt: OPDIO24/16 (NPN) <small>Note 2</small> Pt: OPDIO24/17 (PNP) EN: Ethernet <small>Note 4</small>

Note 1. The total of the X and Y strokes should be 1100mm or less.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Available only for the master. See P.66 for details on YC-Link system.  
 Note 4. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Y-axis
Axis construction <small>Note 1</small>	F20	F20-BK
AC servo motor output (W)	600	600
Repeatability <small>Note 2</small> (mm)	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <small>Note 3</small> (Deceleration ratio) (mm)	20	10
Maximum speed <small>Note 4</small> (mm/sec)	1200	600
Moving range (mm)	250 to 850	250 to 850
Robot cable length (m)	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
250 to 850	30

## Controller

Controller	Operation method
RCX222HP-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 2 axes P1



X stroke <small>Note 3</small>	250	350	450	550	650	750	850	
	L	667	767	867	967	1067	1167	1267
K	100	200	100	200	100	200	100	
C	420	420	600	600	780	780	960	
M	2	2	3	3	4	4	5	
N	8	8	10	10	12	12	14	
Y stroke <small>Note 3</small>	250	350	450	550	650	750	850	
Maximum speed for each stroke (mm/sec) <small>Note 4</small>	X-axis	1200					960	
	Y-axis	600					480	
	Speed setting	-					80%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. The total of the X and Y strokes should be 1100mm or less.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type

Moving arm type


Pole type

XZ type

# HXYx

3 axes / ZPH

- Pole type
- Cable carrier
- Z-axis: Clamped table / moving base type (200W) for Pole type



## Ordering method

**HXYx - C - P2** [ ] [ ] [ ] [ ] [ ] [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X-axis stroke** Note 1 **Y-axis stroke** Note 1 **ZR-axis** **Z-axis stroke** **Cable** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**RCX240** [ ] **R** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller** **CE Marking** **Regenerative unit** **Expansion I/O** **Network option** **IVY System** **Gripper** **Battery**

**Specify various controller setting items. RCX340** ▶ **P.542**

**Specify various controller setting items. RCX240/RCX240S** ▶ **P.532**

Note 1. The total of the Y and Z strokes should be 1200mm or less.

## Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> Note 1	F20	F20-BK	F14H
<b>AC servo motor output (W)</b>	600	600	200
<b>Repeatability</b> Note 2 (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> Note 3 (Deceleration ratio) (mm)	20	10	20
<b>Maximum speed</b> Note 4 (mm/sec)	1200	600	1200
<b>Moving range (mm)</b>	250 to 1250	250 to 950	250 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.

Note 2. Positioning repeatability in one direction.

Note 3. Leads not listed in the catalog are also available. Contact us for details.

Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)
250 to 950	15

## Controller

Controller	Operation method
RCX340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240-R	

## HXYx 3 axes / ZPHL (P2)



X stroke	Note 4											
	250	350	450	550	650	750	850	950	1050	1150	1250	
<b>L</b>	667	767	867	967	1067	1167	1267	1367	1467	1567	1667	
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100	
<b>C</b>	420	420	600	600	780	780	960	960	1140	1320	1320	
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7	
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18	
Y stroke	Note 4											
	250	350	450	550	650	750	850	950				
Z stroke	Note 4											
	250	350	450	550	650							
<b>Maximum speed for each stroke (mm/sec)</b>	<b>X-axis</b>	1200					960	840	720	600	480	
	<b>Y-axis</b>	600					480	420				
	<b>Speed setting</b>	-					80%	70%	60%	50%	40%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.

Note 2. User cable extraction port.

Note 3. This figure shows the combination for ZPHL. For the combination for ZPHR, see the top view in the figure.

Note 4. The total of the Y and Z strokes should be 1200mm or less.

Note 5. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



● Pole type ● Whipover ● Z-axis: Clamped table / moving base type (200W) for Pole type

### Ordering method

**HXYx - S - P1**

Model	Cable	Combination	Y-axis stroke <sup>Note 1</sup>	Y-axis stroke <sup>Note 1</sup>	ZR-axis	Z-axis stroke	Cable
			25 to 85cm	25 to 85cm	ZPHL ZPHR	25 to 65cm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-3**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

Note 1. The total of the X and Y strokes should be 1100mm or less and that of the Y and Z strokes should be 1200mm or less.

### Specification

	X-axis	Y-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F20	F20-BK	F14H
<b>AC servo motor output (W)</b>	600	600	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10	20
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	600	1200
<b>Moving range (mm)</b>	250 to 850	250 to 850	250 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

Y stroke (mm)	Z stroke (mm)
250 to 850	15

### Controller

Controller	Operation method
RCX340 RCX240-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### HXYx 3 axes / ZPHL (P1)



X stroke <sup>Note 4</sup>	250	350	450	550	650	750	850
	L	667	767	867	967	1067	1167
K	100	200	100	200	100	200	100
D	420	420	600	600	780	780	960
M	2	2	3	3	4	4	5
N	8	8	10	10	12	12	14

Y stroke <sup>Note 4</sup>	250	350	450	550	650	750	850
Z stroke	250	350	450	550	650		

Maximum speed for each stroke (mm/sec) <sup>Note 5</sup>	X-axis	1200	960
	Y-axis	600	480
Speed setting		-	80%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.  
 Note 3. This figure shows the combination for ZPHL. For the combination for ZPHR, see the top view in the figure.  
 Note 4. The total of the X and Y strokes should be 1100mm or less and that of the Y and Z strokes should be 1200mm or less.  
 Note 5. When the X-axis/Y-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

- Articulated robots YA
- Linear conveyor modules LCM100
- Compact single-axis robots TRANSERVO
- Single-axis robots FLIP-X
- Linear motor single-axis robots PHASER
- Cartesian robots XX-X
- SCARA robots YK-X
- Pick & place robots YP-X
- CLEAN
- CONTROLLER INFORMATION
- Arm type
- Gantry type
- Moving arm type
- Pole type
- XZ type

# SXYx 2 axes / ZF

● XZ type   ● Cable carrier   ● Z-axis: clamped base / moving table type (100W)



## Ordering method

<b>SXYx - C</b>				<b>ZF</b>			<b>RCX222</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>ZR-axis</b>	<b>Z-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
F1		F1	15 to 105cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet <sup>Note 2</sup> YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14	F10-BK
<b>AC servo motor output (W)</b>	100	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	600
<b>Moving range (mm)</b>	150 to 1050	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

X stroke (mm)	Z stroke (mm)
150 to 1050	150 to 350
	10

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 2 axes / ZF F1




X stroke	150	250	350	450	550	650	750	850	950	1050
<b>L</b>	405	505	605	705	805	905	1005	1105	1205	1305
<b>K</b>	200	100	200	100	200	100	200	100	200	100
<b>C</b>	240	240	420	420	600	600	780	780	960	960
<b>M</b>	0	1	1	2	2	3	3	4	4	5
<b>N</b>	4	6	6	8	8	10	10	12	12	14
<b>Z stroke</b>	150	250	350							
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	X-axis		1200			960		780	600	540
<b>Speed setting</b>			-			80%		65%	50%	45%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYx 2 axes / ZF

● XZ type ● Whipover ● Z-axis: clamped base / moving table type (100W)



## Ordering method

<b>SXYx - S</b>			<b>ZF</b>			<b>RCX222</b>				
Model	Cable	Combination	X-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller	Usable for CE	Input/Output selection 1	Input/Output selection 2
		F1 F3	15 to 85cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None Nt: OPDIO24/16 (NPN) <sup>Note 1</sup> Pt: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
Axis construction <sup>Note 1</sup>	F14	F10-BK
AC servo motor output (W)	100	100
Repeatability <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
Drive system	Ball screw (Class C7)	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10
Maximum speed <sup>Note 4</sup> (mm/sec)	1200	600
Moving range (mm)	150 to 850	150 to 350
Robot cable length (m)	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

X stroke (mm)	Z stroke (mm)
150 to 850	150 to 350
	10

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYx 2 axes / ZF (F1)



X stroke	150	250	350	450	550	650	750	850
L	405	505	605	705	805	905	1005	1105
K	200	100	200	100	200	100	200	100
C	240	240	420	420	600	600	780	780
M	0	1	1	2	2	3	3	4
N	4	6	6	8	8	10	10	12
Z stroke	150	250	350					
Maximum speed for each stroke (mm/sec) <sup>Note 3</sup>	X-axis		1200			960		780
Speed setting			-			80%		65%


Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Arm type  
Gantry type  
Moving arm type  
Pole type  
XZ type

# SXYx 2 axes / ZFL20

● XZ type ● Cable carrier ● Z-axis: clamped base / moving table type (200W)



## Ordering method

<b>SXYx - C</b>			<b>ZFL20</b>			<b>RCX222</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>ZR-axis</b>	<b>Z-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b> <small>Note 1</small>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
F1			15 to 105cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <small>Note 2</small> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <small>Note 3</small>	No entry: None Nt: OPDIO24/16 (NPN) <small>Note 2</small> Pt: OPDIO24/17 (PNP) EN: Ethernet <small>Note 4</small>

Note 1. DRCX0510 uses the RGU-2 regenerative unit. The RCX222 uses the RG2.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Available only for the master. See P.66 for details on YC-Link system.  
 Note 4. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
<b>Axis construction</b> <small>Note 1</small>	F14	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	100	200
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1200	1200
<b>Moving range (mm)</b>	150 to 1050	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

X stroke (mm)	Z stroke (mm)
150 to 1050	150 to 350
	8

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## SXYx 2 axes / ZFL20 (F1)



X stroke	Z stroke													
	150	250	350	450	550	650	750	850	950	1050				
<b>L</b>	405	505	605	705	805	905	1005	1105	1205	1305				
<b>K</b>	200	100	200	100	200	100	200	100	200	100				
<b>C</b>	240	240	420	420	600	600	780	780	960	960				
<b>M</b>	0	1	1	2	2	3	3	4	4	5				
<b>N</b>	4	6	6	8	8	10	10	12	12	14				
<b>Z stroke</b>	150	250	350											
<b>Maximum speed for each stroke (mm/sec)</b>	<b>X-axis</b>		1200				960		780		600		540	
<b>Speed setting</b>			-				80%		65%		50%		45%	

# SXYx 2 axes / ZS

- XZ type
- Cable carrier
- Z-axis shaft vertical type



## Ordering method

<b>SXYx - C</b>				<b>15</b>		<b>RCX222</b>				
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>ZR-axis</b>	<b>Z-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
	F1 F3		15 to 105cm	ZS12 ZS6		3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None Nt: OP.DIO24/16 (NPN) <sup>Note 1</sup> Pt: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis: ZS12	Z-axis: ZS6
<b>Axis construction</b> <sup>Note 1</sup>	F14	-	
<b>AC servo motor output (W)</b>	100	60	
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.02	
<b>Drive system</b>	Ball screw (Class C7)		Ball screw (Class C10)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	12	6
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	During RCX240 use	1200	500
	During DRCX use	1200	450
<b>Moving range (mm)</b>	150 to 1050	150	
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10		

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.



## Maximum payload (kg)

Y stroke (mm)	ZS12	ZS6
150 to 1050	3	5


## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## SXYx 2 axes / ZS F1






Detail of section A



Detail of section B



Cross-section of cable carrier



X stroke	150	250	350	450	550	650	750	850	950	1050	
<b>L</b>	405	505	605	705	805	905	1005	1105	1205	1305	
<b>K</b>	200	100	200	100	200	100	200	100	200	100	
<b>C</b>	240	240	420	420	600	600	780	780	960	960	
<b>M</b>	0	1	1	2	2	3	3	4	4	5	
<b>N</b>	4	6	6	8	8	10	10	12	12	14	
<b>Z stroke</b>	150										
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>	1200					960	780	600	540	
	<b>Speed setting</b>	-					80%	65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.


Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots YA  
 Linear conveyor modules LCM100  
 Compact single-axis robots TRANSEVO  
 Single-axis robots FLIP-X  
 Linear motor single-axis robots PHASER  
 Cartesian robots XX-X  
 SCARA robots YK-X  
 Pick & place robots YP-X  
 CLEAN  
 CONTROLLER INFORMATION  
 Arm type  
 Gantry type  
 Moving arm type  
 Pole type  
 XZ type


# SXYBx

2 axes / ZF

- XZ type
- Cable carrier
- Z-axis: clamped base / moving table type (100W)



## Ordering method



Note 1. Regenerative unit RG2 is required when the maximum speed on the RCX222 exceeds 1250mm/sec.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Available only for the master. See P.66 for details on YC-Link system.  
 Note 4. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	B14H	F10-BK
<b>AC servo motor output (W)</b>	200	100
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.04	+/-0.01
<b>Drive system</b>	Timing belt	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	10
<b>Maximum speed (mm/sec)</b>	1875	600
<b>Moving range (mm)</b>	150 to 3050	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.

## Maximum payload (kg)


X stroke (mm)	Z stroke (mm)
150 to 3050	150 to 350
	10

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. A regenerative unit is required when the maximum speed exceeds 1250mm/sec.

## SXYBx 2 axes / ZF (F1)




Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.  
 Note 3. LU specification should be used for installation of the X axis motor.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050	
L	538	638	738	838	938	1038	1138	1238	1338	1438	1538	1638	1738	1838	1938	2038	2138	2238	2338	2438	2538	2638	2738	2838	2938	3038	3138	3238	3338	3438	
K	-	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200
C	240	420	420	600	600	780	780	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140
D	-	-	-	-	-	-	-	-	-	-	-	240	240	420	600	600	780	780	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	
E	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	240	240	420	420	600	600	780	960	
F	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	4	4	4	4	4	4	4	
M	1	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	
N	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	
Z stroke	150	250	350																												



# SXYBx **2 axes / ZFL20**

● XZ type ● Cable carrier ● Z-axis: clamped base / moving table type (200W)



## Ordering method

<b>SXYBx - C</b>			<b>ZFL20</b>			<b>RCX222</b>		<b>R</b>			
Model	Cable	Combination	X-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller	Usable for CE	Regenerative unit	Input/Output selection 1	Input/Output selection 2
F1		F1	15 to 305cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 3</sup>	No entry: None Nt: OP.DIO24/16 (NPN) <sup>Note 1</sup> Pt: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
Axis construction <sup>Note 1</sup>	B14H	F10-BK equivalent guide-reinforced model
AC servo motor output (W)	200	200
Repeatability <sup>Note 2</sup> (mm)	+/-0.04	+/-0.01
Drive system	Timing belt	Ball screw (Class C7)
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	Equivalent to lead 25	20
Maximum speed (mm/sec)	1875	1200
Moving range (mm)	150 to 3050	150 to 350
Robot cable length (m)	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.


## Maximum payload (kg)

X stroke (mm)	Z stroke (mm)
150 to 3050	150 to 350
	8

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYBx 2 axes / ZFL20 F1




Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates an user cable extraction port.  
 Note 3. LU specification should be used for installation of the X axis motor.

X stroke	150	250	350	450	550	650	750	850	950	1050	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050	2150	2250	2350	2450	2550	2650	2750	2850	2950	3050	
L	538	638	738	838	938	1038	1138	1238	1338	1438	1538	1638	1738	1838	1938	2038	2138	2238	2338	2438	2538	2638	2738	2838	2938	3038	3138	3238	3338	3438	
K	-	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	200	100	
C	240	420	420	600	600	780	780	960	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140	1140
D	-	-	-	-	-	-	-	-	-	-	-	240	240	420	600	600	780	780	960	960	960	960	1140	1140	1140	1140	1140	1140	1140	1140	1140
E	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	240	240	420	420	600	600	780	960	
F	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	4	4	4	4	4	4	4
M	1	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10	10	11	11	12	12	13	13	14	14	15	
N	6	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	28	28	30	30	32	32	34	34	36	
Z stroke	150	250	350																												

# MXYx

2 axes / ZFL10



● XZ type   ● Cable carrier   ● Z-axis: clamped base / moving table type (200W)

## Ordering method

**MXYx - C** - [ ] - [ ] - **ZFL10** - [ ] - [ ] - **RCX222** - [ ] - **R** - [ ] - [ ]

Model	Cable	Combination	X-axis stroke	ZR-axis	Z-axis stroke	Cable	Controller	Usable for CE	Regenerative unit	Input/Output selection 1	Input/Output selection 2
F1			15 to 105cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None Nt: OP.DIO24/16 (NPN) <sup>Note 1</sup> Pt: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	200	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	600
<b>Moving range (mm)</b>	150 to 1050	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5   Option: 5, 10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

X stroke (mm)	Z stroke (mm)
150 to 1050	150 to 350
	15

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication


## MXYx 2 axes / ZFL10 (F1)



X stroke	150	250	350	450	550	650	750	850	950	1050
<b>L</b>	470	570	670	770	870	970	1070	1170	1270	1370
<b>K</b>	200	100	200	100	200	100	200	100	200	100
<b>C</b>	240	240	420	420	600	600	780	960	960	1140
<b>M</b>	0	1	1	2	2	3	3	4	4	5
<b>N</b>	4	6	6	8	8	10	10	12	12	14
<b>Z stroke</b>	150	250	350							
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>		1200				960	780	600	540
<b>Speed setting</b>			-				80%	65%	50%	45%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



### Ordering method

<b>MXYx - C</b>			<b>ZFH</b>			<b>RCX222</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>ZR-axis</b>	<b>Z-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
F1		F1	15 to 105cm		15 to 35cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

### Specification

	X-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F14H	F10-BK equivalent guide-reinforced model
<b>AC servo motor output (W)</b>	200	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	600
<b>Moving range (mm)</b>	150 to 1050	150 to 350
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


### Maximum payload (kg)

X stroke (mm)	Z stroke (mm)		
	150	250	350
150 to 1050	14	13	12

### Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

### MXYx 2 axes / ZFH (F1)



X stroke	150	250	350	450	550	650	750	850	950	1050	
	<b>L</b>	470	570	670	770	870	970	1070	1170	1270	1370
<b>K</b>	200	100	200	100	200	100	200	100	200	100	
<b>C</b>	240	240	420	420	600	600	780	960	960	1140	
<b>M</b>	0	1	1	2	2	3	3	4	4	5	
<b>N</b>	4	6	6	8	8	10	10	12	12	14	
<b>Z stroke</b>	150	250	350								
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	<b>X-axis</b>		1200				960	780	600	540	
	<b>Speed setting</b>		-				80%	65%	50%	45%	

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. The shaded position indicates a user cable extraction port.

Note 3. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Arm type

Gantry type


Moving arm type

Pole type

XZ type

# HXYx 2 axes / ZL

● XZ type ● Cable carrier ● Z-axis: clamped base / moving table type (200W)



## Ordering method

<b>HXYx - C</b>			<b>ZL</b>			<b>RCX222</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>ZR-axis</b>	<b>Z-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
F1			25 to 125cm		25 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OPDIO24/16 (NPN) <sup>Note 1</sup> P1: OPDIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>
F3											

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H-BK
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	10
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	600
<b>Moving range (mm)</b>	250 to 1250	250 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

X stroke (mm)	Z stroke (mm)
250 to 1250	250 to 550
	20


## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 2 axes / ZL (F1)





Detail of section A






Detail of section B

Use M8 x 1.25 hex socket head bolt with length head bolt with length (under head) of 40mm or more.



Cross-section of cable carrier




X stroke	250	350	450	550	650	750	850	950	1050	1150	1250	
<b>L</b>	615	715	815	915	1015	1115	1215	1315	1415	1515	1615	
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100	
<b>C</b>	240	420	600	600	780	780	960	960	1140	1140	1320	
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7	
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18	
<b>Z stroke</b>	250	350	450	550								
<b>Maximum speed for each stroke (mm/sec)</b> <sup>Note 3</sup>	X-axis		1200				960		840	720	600	480
<b>Speed setting</b>			-				80%		70%	60%	50%	40%

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# HXYx 2 axes / ZH

● XZ type ● Cable carrier ● Z-axis: clamped table / moving base type (200W)



## Ordering method

<b>HXYx - C</b>			<b>ZH</b>			<b>RCX222</b>		<b>R</b>			
<b>Model</b>	<b>Cable</b>	<b>Combination</b>	<b>X-axis stroke</b>	<b>ZR-axis</b>	<b>Z-axis stroke</b>	<b>Cable</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Regenerative unit</b>	<b>Input/Output selection 1</b>	<b>Input/Output selection 2</b>
F1		F1	25 to 125cm		25 to 55cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	R: RG2	N: NPN <sup>Note 1</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 2</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 1</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>
F3		F3									

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above. EN can be selected in I/O select 2.

## Specification

	X-axis	Z-axis
<b>Axis construction</b> <sup>Note 1</sup>	F17	F14H-BK
<b>AC servo motor output (W)</b>	400	200
<b>Repeatability</b> <sup>Note 2</sup> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <sup>Note 3</sup> (Deceleration ratio) (mm)	20	5
<b>Maximum speed</b> <sup>Note 4</sup> (mm/sec)	1200	300
<b>Moving range (mm)</b>	250 to 1250	250 to 550
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5,10	

Note 1. Use caution that the flange machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.


## Maximum payload (kg)

X stroke (mm)	Z stroke (mm)
250 to 1250	250 to 550
	30

## Controller

Controller	Operation method
RCX222-R	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## HXYx 2 axes / ZH (F1)



X stroke	250	350	450	550	650	750	850	950	1050	1150	1250
<b>L</b>	615	715	815	915	1015	1115	1215	1315	1415	1515	1615
<b>K</b>	100	200	100	200	100	200	100	200	100	200	100
<b>C</b>	240	420	600	600	780	780	960	960	1140	1140	1320
<b>M</b>	2	2	3	3	4	4	5	5	6	6	7
<b>N</b>	8	8	10	10	12	12	14	14	16	16	18

Z stroke	250	350	450	550
<b>ZK</b>	100	200	100	200
<b>ZM</b>	1	1	2	2
<b>ZN</b>	10	10	12	12

Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical stopper.  
 Note 2. User cable extraction port.

Note 3. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Maximum speed for each stroke (mm/sec)	X-axis	1200	960	840	720	600	480
<b>Speed setting</b>		-	80%	70%	60%	50%	40%

# MEMO

---

---

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Arm type

Gantry type

Moving arm  
type

Pole type

XZ type



# SCARA ROBOTS

# YK-X

## SERIES

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEKVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER
- INFORMATION
- Orbit / Tiny type
- Small / Medium type
- Large type
- Wall-mount / Inverse type
- Dust-proof & drip-proof type

## CONTENTS

<p>■ <b>YK-X SPECIFICATION SHEET</b> ..... 368</p> <p>■ <b>Robot ordering method description</b> ..... 369</p> <p>■ <b>Robot ordering method terminology</b> ..... 369</p> <p><b>ORBIT TYPE</b></p> <p>YK350TW ..... 370</p> <p>YK500TW ..... 372</p> <p><b>TINY TYPE</b></p> <p>YK120XG ..... 374</p> <p>YK150XG ..... 375</p> <p>YK180XG ..... 376</p> <p>YK180X ..... 377</p> <p>YK220X ..... 378</p> <p><b>SMALL TYPE</b></p> <p>YK250XG ..... 379</p> <p>YK350XG ..... 381</p> <p>YK400XG ..... 383</p> <p>YK400XR ..... 385</p> <p><b>MEDIUM TYPE</b></p> <p>YK500XGL ..... 386</p> <p>YK500XG ..... 388</p> <p>YK600XGL ..... 389</p> <p>YK600XG ..... 391</p>	<p>YK600XGH ..... 392</p> <p><b>LARGE TYPE</b></p> <p>YK700XGL ..... 393</p> <p>YK700XG ..... 394</p> <p>YK800XG ..... 395</p> <p>YK900XG ..... 396</p> <p>YK1000XG ..... 397</p> <p>YK1200X ..... 398</p> <p><b>WALL-MOUNT / INVERSE TYPE</b></p> <p>YK300XGS ..... 399</p> <p>YK400XGS ..... 401</p> <p>YK500XGS ..... 403</p> <p>YK600XGS ..... 404</p> <p>YK700XGS ..... 405</p> <p>YK800XGS ..... 406</p> <p>YK900XGS ..... 407</p> <p>YK1000XGS ..... 408</p> <p><b>DUST-PROOF &amp; DRIP-PROOF TYPE</b></p> <p>YK250XGP ..... 409</p> <p>YK350XGP ..... 411</p> <p>YK400XGP ..... 413</p> <p>YK500XGLP ..... 415</p> <p>YK500XGP ..... 417</p> <p>YK600XGLP ..... 418</p> <p>YK600XGP ..... 420</p> <p>YK600XGHP ..... 421</p>	<p>YK700XGP ..... 422</p> <p>YK800XGP ..... 423</p> <p>YK900XGP ..... 424</p> <p>YK1000XGP ..... 425</p>
---	---	--

# YK-X SPECIFICATION SHEET

Type	Model	Arm length (mm) and XY axis resultant maximum speed (m/s)												Standard cycle time (sec) <sup>Note 1</sup>	Maximum payload (kg)	R-axis tolerable moment of inertia (kgm <sup>2</sup> )	Completely beltless structure <sup>Note 2</sup>	R-axis harmonic drive <sup>Note 3</sup>	Detailed info page				
		120	150	180	220	250	300	350	400	500	600	700	800							900	1000	1200	
Orbit type	YK350TW	5.6												0.32 (RCX340) 0.38 (RCX240)	5	0.005 (Rated) 0.05 (Maximum)			<a href="#">P.370</a>				
	YK500TW	6.8												0.29	5 (RCX340) 4 (RCX240)	0.005 (Rated) 0.05 (Maximum)			<a href="#">P.372</a>				
Standard	Tiny type	YK120XG	3.3														0.33	1	0.01	●	●	<a href="#">P.374</a>	
		YK150XG	3.4															0.33	1	0.01	●	●	<a href="#">P.375</a>
		YK180XG	3.3															0.33	1	0.01	●	●	<a href="#">P.376</a>
		YK180X	3.3															0.39	1	0.01	●	●	<a href="#">P.377</a>
		YK220X	3.4															0.42	1	0.01	●	●	<a href="#">P.378</a>
	Small type	YK250XG	4.5															0.49	5	0.05	●	●	<a href="#">P.379</a>
		YK350XG	5.6															0.49	5	0.05	●	●	<a href="#">P.381</a>
		YK400XG	6.1															0.49	5	0.05	●	●	<a href="#">P.383</a>
		YK400XR	6															0.45	3	0.05			<a href="#">P.385</a>
		YK500XGL	5.1															0.59	5	0.05	●	●	<a href="#">P.386</a>
Medium type	YK500XG	7.6															0.45	10	0.30	●	●	<a href="#">P.388</a>	
	YK600XGL	4.9															0.63	5	0.05	●	●	<a href="#">P.389</a>	
	YK600XG	8.4															0.46	10	0.30	●	●	<a href="#">P.391</a>	
	YK600XGH	7.7															0.47	20	1.0	●	●	<a href="#">P.392</a>	
Large type	YK700XGL	9.2															0.50	10	0.30	●	●	<a href="#">P.393</a>	
	YK700XG	8.4															0.42	20	1.0	●	●	<a href="#">P.394</a>	
	YK800XG	9.2															0.48	20	1.0	●	●	<a href="#">P.395</a>	
	YK900XG	9.9															0.49	20	1.0	●	●	<a href="#">P.396</a>	
	YK1000XG	10.6															0.49	20	1.0	●	●	<a href="#">P.397</a>	
	YK1200X	7.4															0.91	50	2.45		●	<a href="#">P.398</a>	
Wall-mount / inverse type	YK300XGS	4.4															0.49	5	0.05	●	●	<a href="#">P.399</a>	
	YK400XGS	6.1															0.49	5	0.05	●	●	<a href="#">P.401</a>	
	YK500XGS	7.6															0.45	10	0.3	●	●	<a href="#">P.403</a>	
	YK600XGS	8.4															0.46	10	0.3	●	●	<a href="#">P.404</a>	
	YK700XGS	8.4															0.42	20	1.0	●	●	<a href="#">P.405</a>	
	YK800XGS	9.2															0.48	20	1.0	●	●	<a href="#">P.406</a>	
	YK900XGS	9.9															0.49	20	1.0	●	●	<a href="#">P.407</a>	
	YK1000XGS	10.6															0.49	20	1.0	●	●	<a href="#">P.408</a>	
Dust-proof & drip-proof type	YK250XGP	4.5															0.57	4	0.05	●	●	<a href="#">P.409</a>	
	YK350XGP	5.6															0.57	4	0.05	●	●	<a href="#">P.411</a>	
	YK400XGP	6.1															0.57	4	0.05	●	●	<a href="#">P.413</a>	
	YK500XGLP	5.1															0.74	4	0.05	●	●	<a href="#">P.415</a>	
	YK500XGP	7.6															0.55	8	0.3	●	●	<a href="#">P.417</a>	
	YK600XGLP	4.9															0.74	4	0.05	●	●	<a href="#">P.418</a>	
	YK600XGP	8.4															0.56	8	0.3	●	●	<a href="#">P.420</a>	
	YK600XGHP	7.7															0.57	18	1.0	●	●	<a href="#">P.421</a>	
	YK700XGP	8.4															0.52	18	1.0	●	●	<a href="#">P.422</a>	
	YK800XGP	9.2															0.58	18	1.0	●	●	<a href="#">P.423</a>	
	YK900XGP	9.9															0.59	18	1.0	●	●	<a href="#">P.424</a>	
YK1000XGP	10.6															0.59	18	1.0	●	●	<a href="#">P.425</a>		

Note 1. The standard cycle time is measured under the following conditions.

- During back and forth movement 25mm vertically and 100mm horizontally (TINY)
- During back and forth movement 25mm vertically and 300mm horizontally (small type / medium type / large type)

Note 2. Maintains high accuracy over long periods because the beltless structure drastically cuts down on wasted motion.

Operation is also nearly maintenance-free for long periods with no worries about belt breakage, stretching or deterioration over time.

Note 3. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.



# Robot ordering method description

In the order format for the YAMAHA SCARA robots YK-X series, the notation (letters/numbers) for the mechanical section is shown linked to the controller section notation.

## [Example]

- **Mechanical ▶ YK250XG**
  - Z-axis stroke ▶ 150mm
  - Tool flange ▶ With tool flange
  - Hollow shaft ▶ With hollow shaft
  - Cable length ▶ 3.5m
- **Controller ▶ RCX240S**

### ● Ordering method

**YK250XG-150-F-S-3L-RCX240S**

Mechanical section

Controller section

To find detailed controller information see the controller page.

**RCX240 ▶ P.532**, **RCX340 ▶ P.542**

① Model	② Z-axis stroke		③ Tool flange		④ Hollow shaft		⑤ Cable		⑥ Controller
YK***	50	50mm	No entry	None	No entry	None	2L	2m	RCX240
	100	100mm	F	With tool flange	S	With hollow shaft	3L	3.5m	RCX240S
	150	150mm					5L	5m	RCX340
	200	200mm					10L	10m	
	300	300mm							
	400	400mm							

Note 1. Available only for the master.

# Robot ordering method terminology

① <b>Model</b>	Enter the robot unit model.
② <b>Z-axis stroke</b>	Select the Z axis stroke. The stroke varies with the model you select so see that model's page to confirm the specifications.
③ <b>Tool flange</b>	Tool flange option for easy mounting of a tool to the tip. <b>No entry:</b> None <b>F:</b> With tool flange
④ <b>Hollow shaft</b>	Hollow shaft option for easy routing of air tubes and harness wires. <b>No entry:</b> None <b>S:</b> With hollow shaft
⑤ <b>Cable</b>	Select the length of the robot cable connecting the robot and controller. <b>2L:</b> 2m <sup>(Note 1)</sup> <b>3L:</b> 3.5m <b>5L:</b> 5m <b>10L:</b> 10m <small>Note 1. Only selectable for YK120XG, YK150XG, YK180XG.</small>
⑥ <b>Controller</b>	Select either the RCX240 (RCX240S) or RCX340.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / Tray type

Small / Medium type

Large type

Wall-mount / Inverse type

Dust-proof & drip-proof type

# YK350TW

Orbit type



- Arm length 350mm
- Maximum payload 5kg

## Ordering method

**YK350TW-130**

<b>Model</b>	<b>Z axis stroke</b> 130: 130mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	------------------------------------	---	---	--

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

<b>Controller</b>	<b>CE Marking</b>	<b>Regenerative unit</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	--------------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications


Axis specifications	Arm length	X-axis	Y-axis	Z-axis	R-axis
	175 mm	175 mm	175 mm	130 mm	-
	Rotation angle	+/-225 °	+/-225 °	-	+/-720 °
<b>AC servo motor output</b>		750 W	400 W	200 W	105 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Belt speed reduction
	<b>Transmission method</b>	Timing belt	Direct-coupled	Timing belt	Timing belt
	<b>Motor to speed reducer</b>	Direct-coupled			
	<b>Speed reducer to output</b>				
<b>Repeatability</b> <small>Note 1</small>		+/-0.01 mm		+/-0.01 mm	+/-0.01 °
<b>Maximum speed</b>		5.6 m/sec		1.5 m/sec	3000 °/sec
<b>Maximum payload</b> <small>Note 2</small>		5 kg			
<b>Standard cycle time: with 1kg payload</b> <small>Note 3</small>		0.32 sec (RCX340) / 0.38 sec (RCX240)			
<b>R-axis tolerable moment of inertia</b> <small>Note 4</small>	<b>Rated</b>	0.005 kgm <sup>2</sup>			
	<b>Maximum</b>	0.05 kgm <sup>2</sup>			
<b>User wiring</b>		0.15 sq × 8 wires			
<b>User tubing (Outer diameter)</b>		φ 6 × 2			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		26 kg			

Note 1. This is the value at a constant ambient temperature.  
 Note 2. Tool flange specifications (option) are 4 kg.  
 Note 3. When moving a 1 kg load back and forth 300mm horizontally and 25mm vertically (rough positioning arch motion).  
 Note 4. Limits must be placed on parameters such as acceleration according to the moment of inertia being used. See P.606.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

**R-axis moment of inertia (load inertia)**  
 Recommended positional relationship between the load weight and the offset amount from the center of the R-axis (center of gravity position)




Note. When the payload exceeds 4kg, it is predicted that the R-axis moment of inertia may exceed the rated value. So, make proper parameter setting.


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK350TW



YK350TW Tool flange mount type



# YK500TW

Orbit type



- Arm length 500mm
- Maximum payload 5kg

## Ordering method

**YK500TW-130**

<b>Model</b>	<b>Z axis stroke</b> 130: 130mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	------------------------------------	---	---	--

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

<b>Controller</b>	<b>CE Marking</b>	<b>Regenerative unit</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	--------------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications


		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	250 mm	250 mm	130 mm	-
	<b>Rotation angle</b>	+/-225 °	+/-225 °	-	+/-720 °
<b>AC servo motor output</b>		750 W	400 W	200 W	105 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Belt speed reduction
	<b>Transmission method</b>	Timing belt	Direct-coupled	Timing belt	Timing belt
	<b>Motor to speed reducer</b>	Timing belt	Direct-coupled	Timing belt	
<b>Speed reducer to output</b>	Direct-coupled				
<b>Repeatability</b> <small>Note 1</small>		+/-0.015 mm		+/-0.01 mm	+/-0.01 °
<b>Maximum speed</b>		6.8 m/sec		1.5 m/sec	3000 °/sec
<b>Maximum payload</b> <small>Note 2</small>		5 kg (RCX340), 4 kg (RCX240)			
<b>Standard cycle time: with 1kg payload</b> <small>Note 3</small>		0.29 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 4</small>	<b>Rated</b>	0.005 kgm <sup>2</sup>			
	<b>Maximum</b>	0.05 kgm <sup>2</sup>			
<b>User wiring</b>		0.15 sq × 8 wires			
<b>User tubing (Outer diameter)</b>		φ 6 × 2			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		27 kg			

Note 1. This is the value at a constant ambient temperature.  
 Note 2. For the option specifications (tool flange mount type), the maximum payload becomes 4 kg (RCX340) or 3 kg (RCX240).  
 Note 3. When moving a 1 kg load back and forth 300 mm horizontally and 25 mm vertically (rough positioning arch motion).  
 Note 4. Limits must be placed on parameters such as acceleration according to the moment of inertia being used. See P.606.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication


**R-axis moment of inertia (load inertia)**  
 Recommended positional relationship between the load weight and the offset amount from the center of the R-axis (center of gravity position)



Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>




## YK500TW



Keep enough space for the maintenance 4-φ9 work on the top face of the base.


Note: Upper section requires a space of at least 250mm for detaching/attaching cover.

R27 (Min. cable bending radius) Do not move the cable.



\* Tube (φ4) through hollow shaft protrudes about 300mm from the spline tip.  
 \* Tube through hollow shaft does not rotate with spline during R-axis rotation.





YK500TW Tool flange mount type





Keep enough space for the maintenance work on the top face of the base.

Note: Upper section requires a space of at least 250mm for detaching/attaching cover.

R27 (Min. cable bending radius) Do not move the cable.



\* Tube (φ4) through hollow shaft protrudes about 300mm from the spline tip.  
\* Tube through hollow shaft does not rotate with spline during R-axis rotation.



# YK120XG

Standard type: Tiny type

- Arm length 120mm
- Maximum payload 1kg

## Ordering method

**YK120XG - 50**

<b>Model</b>	<b>Z axis stroke</b>	<b>Cable</b>
	50: 50mm	2L: 2m
		3L: 3.5m
		5L: 5m
		10L: 10m

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>iVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	45 mm	75 mm	50 mm	-
	<b>Rotation angle</b>	+/-125 °	+/-145 °	-	+/-360 °
<b>AC servo motor output</b>		30 W	30 W	30 W	30 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b>	Direct-coupled			
<b>Repeatability</b> <small>Note 1</small>		+/-0.01 mm		+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>		3.3 m/sec		0.9 m/sec	1700 °/sec
<b>Maximum payload</b>		1.0 kg			
<b>Standard cycle time: with 0.1kg payload</b> <small>Note 2</small>		0.33 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>		0.01 kgm <sup>2</sup>			
<b>User wiring</b>		0.1 sq × 8 wires			
<b>User tubing (Outer diameter)</b>		φ 4 × 2			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 2 m Option: 3.5 m, 5 m, 10 m			
<b>Weight (Excluding robot cable)</b> <small>Note 4</small>		3.9 kg			
<b>Robot cable weight</b>		0.9 kg (2 m)	1.5 kg (3.5 m)	2.1 kg (5 m)	4.2 kg (10 m)

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When moving 25mm in vertical direction and 100mm in horizontal direction reciprocally.  
 Note 3. There are limits to acceleration coefficient settings. See P.606.  
 Note 4. The total robot weight is the sum of the robot body weight and the cable weight.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	300	Programming / I/O point trace / Remote command / Operation using RS-232C communication





Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK120XG



If the robot enters the inside of R12, the Z-axis upper end stopper may be in contact with the base. So, do not perform such motion.



# YK150XG

Standard type: Tiny type

- Arm length 150mm
- Maximum payload 1kg

## Ordering method

**YK150XG - 50**

Model	Z axis stroke	Cable
	50: 50mm	2L: 2m
		3L: 3.5m
		5L: 5m
		10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	iVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	75 mm	75 mm	50 mm	-
	Rotation angle	+/-125 °	+/-145 °	-	+/-360 °
AC servo motor output		30 W	30 W	30 W	30 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm		+/-0.004 °
Maximum speed		3.4 m/sec	0.9 m/sec		1700 °/sec
Maximum payload		1.0 kg			
Standard cycle time: with 0.1kg payload <sup>Note 2</sup>		0.33 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.01 kgm <sup>2</sup>			
User wiring		0.1 sq × 8 wires			
User tubing (Outer diameter)		φ 4 × 2			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 2 m Option: 3.5 m, 5 m, 10 m			
Weight (Excluding robot cable) <sup>Note 4</sup>		4.0 kg			
Robot cable weight		0.9 kg (2 m)	1.5 kg (3.5 m)	2.1 kg (5 m)	4.2 kg (10 m)

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When moving 25mm in vertical direction and 100mm in horizontal direction reciprocally.  
 Note 3. There are limits to acceleration coefficient settings. See P.606.  
 Note 4. The total robot weight is the sum of the robot body weight and the cable weight.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	300	Programming / I/O point trace / Remote command / Operation using RS-232C communication



Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.

Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK150XG

Connector for user wiring (No. 1 to 8 usable, socket contact)  
 J.S.T. Mfg Co., Ltd. SM connector SMR-8V-B, pin SYM-001T-P0.6 (supplied)  
 Use the YC12 crimping tool.




If the robot enters the inside of R12, the Z-axis upper end stopper may be in contact with the base. So, do not perform such motion.




### Working envelope

X, Y-axis origin is at ±5° with respect to front of robot base

When performing return-to-origin, move the axes counterclockwise in advance from the position shown above.



No phase relation between flat spot and R-axis origin  
 User tool installation range



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Tiny type

Small / Medium type


Large type

Walk-mount / Inverse type

Dust-proof & drip-proof type

# YK180XG

Standard type: Tiny type



- Arm length 180mm
- Maximum payload 1kg

## Ordering method

**YK180XG - 50**

Model	Z axis stroke	Cable
	50: 50mm	2L: 2m
		3L: 3.5m
		5L: 5m
		10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	iVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	105 mm	75 mm	50 mm	-
	Rotation angle	+/-125 °	+/-145 °	-	+/-360 °
AC servo motor output		30 W	30 W	30 W	30 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm		+/-0.01 mm	+/-0.004 °
Maximum speed		3.3 m/sec		0.9 m/sec	1700 °/sec
Maximum payload		1.0 kg			
Standard cycle time: with 0.1kg payload <sup>Note 2</sup>		0.33 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.01 kgm <sup>2</sup>			
User wiring		0.1 sq × 8 wires			
User tubing (Outer diameter)		φ 4 × 2			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 2 m Option: 3.5 m, 5 m, 10 m			
Weight (Excluding robot cable) <sup>Note 4</sup>		4.1 kg			
Robot cable weight		0.9 kg (2 m)	1.5 kg (3.5 m)	2.1 kg (5 m)	4.2 kg (10 m)

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When moving 25mm in vertical direction and 100mm in horizontal direction reciprocally.  
 Note 3. There are limits to acceleration coefficient settings. See P.606.  
 Note 4. The total robot weight is the sum of the robot body weight and the cable weight.

## Controller


Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK180XG

Connector for user wiring (No. 1 to 8 usable, socket contact)  
 J.S.T. Mfg Co., Ltd. SM connector SMR-8V-B, pin SYM-001T-P0.6 (supplied)  
 Use the YC12 crimping tool.



Do not attach any wire or tube to self-supporting cable. Doing so may degrade positioning accuracy.

If attaching wire or tube, make use of these air tubes. For details, refer to "10 When attaching a new user wire or tube" in Chapter 3.

316 (Maximum 322 during arm rotation)

10 (Maximum 120 during arm rotation)

239

146

104

R-axis dog

119

105

80

67

47+/-2 (Z-axis origin position)

50

41.5 90.5 32

Bas. firm turning radius location on Z-axis

Z-axis upper end stopper

φ26

No phase relation between flat spot and R-axis origin

User tool installation range

φ10h 7<sup>0</sup><sub>-0.015</sub>

Hollow diameter : φ4

Width across flats

22.5

27 20

4.5

123

32

2-φ5.5 through-hole (Use four M5 mounting bolts.)

R27 (Min. cable bending radius) Do not move the cable.

2-φ5.5

14


14

4-φ9

Keep enough space for the maintenance work at the rear of the base.

Tapped hole for user 4-M3 x 0.5, depth: 7

Details of B



The Z-axis upper end stopper is in contact with the base in an area inside from the inner limit of this working envelope. So, do not perform any motion in this area.

Working envelope

X, Y-axis origin is at ±5° with respect to front of robot base

When performing return-to-origin, move the axes counterclockwise in advance from the position shown above.

User tubing 2 (φ4)

User tubing 1 (φ4)

Cross section A-A

User tubing 2 (φ4)

M3 ground terminal


User tubing 1 (φ4)

35 74

(43)

47

53





# YK180X

Standard type: Tiny type

- Arm length 180mm
- Maximum payload 1kg

## Ordering method

**YK180X - 100**

Model	Z axis stroke	Cable
	100: 100mm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	iVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	71 mm	109 mm	100 mm	-
	Rotation angle	+/-120 °	+/-140 °	-	+/-360 °
AC servo motor output		50 W	30 W	30 W	30 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
Maximum speed		3.3 m/sec		0.7 m/sec	1700 °/sec
Maximum payload		1.0 kg			
Standard cycle time: with 0.1kg payload <sup>Note 2</sup>		0.39 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.01 kgm <sup>2</sup>			
User wiring		0.1 sq x 6 wires			
User tubing (Outer diameter)		φ 3 x 2			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight (Excluding robot cable) <sup>Note 4</sup>		5.5 kg			
Robot cable weight		1.5 kg (3.5 m)	2.1 kg (5 m)	4.2 kg (10 m)	

Note 1. This is the value at a constant ambient temperature.  
 Note 2. When reciprocating 100mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.607.  
 Note 4. The total robot weight is the sum of the robot body weight and the cable weight.

## Controller




Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK180X



Connector for user wiring (No. 1 to 6 usable, socket contact)  
 J.S.T. Mfg Co., Ltd. SM connector SMR-6VB, pin SYM-001T-P0.6 (supplied)  
 Use the YC12 crimping tool.



**Working envelope**  
 X-axis origin is at 0°±5° with respect to front of robot base



**X, Y-axis origin position**  
 When performing return-to-origin, move the axes counterclockwise in advance from the position shown above.



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Tiny type

Small / Medium type

Large type

Walk-mount / Inverse type

Dust-proof & drip-proof type

# YK220X

Standard type: Tiny type



- Arm length 220mm
- Maximum payload 1kg

## Ordering method

**YK220X - 100**

Model	Z axis stroke	Cable
	100: 100mm	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	111 mm	109 mm	100 mm	-
	Rotation angle	+/-120 °	+/-140 °	-	+/-360 °
AC servo motor output		50 W	30 W	30 W	30 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
Maximum speed		3.4 m/sec	0.7 m/sec		1700 °/sec
Maximum payload		1.0 kg			
Standard cycle time: with 0.1kg payload <sup>Note 2</sup>		0.42 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.01 kgm <sup>2</sup>			
User wiring		0.1 sq × 6 wires			
User tubing (Outer diameter)		φ 3 × 2			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight (Excluding robot cable) <sup>Note 4</sup>		5.5 kg			
Robot cable weight		1.5 kg (3.5 m)	2.1 kg (5 m)	4.2 kg (10 m)	

Note 1. This is the value at a constant ambient temperature.  
 Note 2. When reciprocating 100mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.607.  
 Note 4. The total robot weight is the sum of the robot body weight and the cable weight.

## Controller


Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>


## YK220X

Connector for user wiring  
 (No. 1 to 6 usable, socket contact)  
 J.S.T. Mfg Co., Ltd. SM connector  
 SMR-6VB, pin SYM-001T-P0.6 (supplied)  
 Use the YC12 crimping tool.




Do not attach any wire or tube to self-supporting cable. Doing so may degrade positioning accuracy.

If attaching wire or tube, make use of these air tubes. For details, refer to "10 When attaching a new user wire or tube" in Chapter 3.




Cross section A-A

Connector for user wiring  
 (No. 1 to 6 usable, socket contact)  
 J.S.T. Mfg Co., Ltd. SM connector SMR-6VB,  
 pin SYM-001T-P0.6 (supplied)  
 Use the YC12 crimping machine.




Working envelope

X-axis origin is at 0°±5° with respect to front of robot base





X, Y-axis origin position


When performing return-to-origin, move the axes counterclockwise in advance from the position shown above.



No phase relation between flat spot and R-axis origin  
 User tool installation range



R27 (Min. cable bending radius)  
 Do not move the cable.  
 Keep enough space for the maintenance work at the rear of the base.



# YK250XG

Standard type: Small type

- Arm length 250mm
- Maximum payload 5kg

## Ordering method

**YK250XG - 150**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	------------------------------------	---	---	--

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX340 ▶ **P.542**

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	100 mm	150 mm	150 mm	-
	<b>Rotation angle</b>	+/-140 °	+/-144 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <small>Note 1</small>	+/-0.01 mm		+/-0.01 mm	+/-0.004 °	
<b>Maximum speed</b>		4.5 m/sec		1.1 m/sec	1020 °/sec
<b>Maximum payload</b>		5 kg (Standard specification), 4 kg (Option specifications <small>Note 4</small> )			
<b>Standard cycle time: with 2kg payload</b> <small>Note 2</small>		0.49 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>		0.05 kgm <sup>2</sup> (0.5 kgfcm <sup>2</sup> )			
<b>User wiring</b>		0.2 sq × 10 wires			
<b>User tubing (Outer diameter)</b>		φ 4 × 3			
<b>Travel limit</b>		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		18.5 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.607.  
 Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK250XG



- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- Orbit / Turn type
- Small type
- Large type
- Inverse type
- Dust-proof & drip-proof type

## YK250XG Tool flange mount type



# YK350XG

Standard type: Small type

- Arm length 350mm
- Maximum payload 5kg

## Ordering method

**YK350XG - 150**

<b>Model</b>	Z axis stroke 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	-----------------------------	---	---	--

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>iVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	200 mm	150 mm	150 mm	-
	<b>Rotation angle</b>	+/-140 °	+/-144 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>	+/-0.01 mm		+/-0.01 mm	+/-0.004 °	
<b>Maximum speed</b>		5.6 m/sec		1.1 m/sec	1020 °/sec
<b>Maximum payload</b>		5 kg (Standard specification), 4 kg (Option specifications <sup>Note 4</sup> )			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>		0.49 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>		0.05 kgm <sup>2</sup> (0.5 kgfcm <sup>2</sup> )			
<b>User wiring</b>		0.2 sq × 10 wires			
<b>User tubing (Outer diameter)</b>		φ 4 × 3			
<b>Travel limit</b>		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		19 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.607.  
 Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK350XG



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / T/T type

Small type

Large type


Inverse type

Walk-mount / Inverse type

Dust-proof & drip-proof type

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- Orbit/Tilt type
- Small type
- Large type
- Wall-mount / Inverse type
- Dust-proof & drip-proof type

## YK350XG Tool flange mount type



# YK400XG

Standard type: Small type

- Arm length 400mm
- Maximum payload 5kg

## Ordering method

**YK400XG - 150**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	------------------------------------	---	---	--

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>				
<b>Arm length</b>	250 mm	150 mm	150 mm	-
<b>Rotation angle</b>	+/-140 °	+/-144 °	-	+/-360 °
<b>AC servo motor output</b>	200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw
	<b>Transmission method</b>	Direct-coupled		
	<b>Motor to speed reducer</b>	Direct-coupled		
<b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>	+/-0.01 mm		+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>	6.1 m/sec		1.1 m/sec	1020 °/sec
<b>Maximum payload</b>	5 kg (Standard specification), 4 kg (Option specifications <sup>Note 4</sup> )			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>	0.49 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>	0.05 kgm <sup>2</sup> (0.5 kgfcm <sup>2</sup> )			
<b>User wiring</b>	0.2 sq x 10 wires			
<b>User tubing (Outer diameter)</b>	φ 4 x 3			
<b>Travel limit</b>	1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>	Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>	19.5 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK400XG



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / T/Tv type

Small type


Large type

Walk-mount / Inverse type


Dust-proof & drip-proof type

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- Orbit/Tiny
- Small type
- Large type
- Wall-mount / Inverse type
- Dust-proof & drip-proof type



## YK400XG Tool flange mount type






If the robot enters the inside of the corner of R190 and dimension 148, the tool flange may be in contact with the base or the arm may be in contact with the machine harness. So, do not perform such motion.




- Note that the robot cannot be used at a position where the base flange or robot cable interferes with the tool flange in the working envelope shown above.
- X-axis mechanical stopper position : 142°
- Y-axis mechanical stopper position : 146°



4-M3 × 0.5 through-hole (No phase relation to R-axis origin.)  
As this hole is intended for the wiring/tubing clamp, do not attach a large load to it.



Detailed drawing D



View of E

Option:  
User wiring/tubing through spline type



# YK400XR

Standard type: Small type

● LOW COST HIGH PERFORMANCE MODEL

● Arm length 400mm ● Maximum payload 3kg



## Ordering method

<b>YK400XR</b>		<b>150</b>			<b>RCX340-4</b>														
<b>Model</b>	<b>Return-to-origin method</b> S: Sensor T: Stroke end	<b>Z axis stroke</b>	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m	<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b> 4: 4 pcs. 3: 3 pcs. 2: 2 pcs. 1: 1 pc. 0: 0 pc.							

Specify various controller setting items. RCX340 ▶ **P.542**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	225 mm	175 mm	150 mm	-
	<b>Rotation angle</b>	+/-132 °	+/-150 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	100 W	100 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Belt speed reduction
	<b>Transmission method</b>	Direct-coupled		Timing belt	
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled		Timing belt	
<b>Repeatability</b> <sup>Note 1</sup>		+/-0.01 mm		+/-0.01 mm	+/-0.01 °
<b>Maximum speed</b>		6 m/sec		1.1 m/sec	2600 °/sec
<b>Maximum payload</b>		3 kg (Standard specification), 2 kg (Option specifications <sup>Note 4</sup> )			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>		0.45 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>		0.05 kgm <sup>2</sup> (0.5 kgfcm <sup>2</sup> )			
<b>User wiring</b>		0.2 sq × 10 wires			
<b>User tubing (Outer diameter)</b>		φ 4 × 3			
<b>Travel limit</b>		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		17 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions and performing the coarse positioning arch operation.  
 Note 3. It is necessary to input the moment of inertia in the actual operating environment.  
 Note 4. Maximum payload of option specifications (with user wiring/tubing through spline type) is 2kg.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340	1000	Programming / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be restricted by adding the X- and Y-axis mechanical stoppers. (The maximum movement range was set at shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK400XR



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / Triv type

Small type

Large type

Walk-mount / Inverse type

Dust-proof & drip-proof type

# YK500XGL

Standard type: Medium type



- Arm length 500mm
- Maximum payload 5kg

## Ordering method

**YK500XGL - 150**

Model	Z axis stroke	Tool flange	Hollow shaft	Cable
	150: 150mm	No entry: None F: With tool flange	No entry: None S: With hollow shaft	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	250 mm	250 mm	150 mm	-
	Rotation angle	+/-140 °	+/-144 °	-	+/-360 °
AC servo motor output		200 W	150 W	50 W	100 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.004 °	
Maximum speed		5.1 m/sec		1.1 m/sec	1020 °/sec
Maximum payload		5 kg (Standard specification), 4 kg (Option specifications <sup>Note 4</sup> )			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.59 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.05 kgm <sup>2</sup> (0.5 kgfcm <sup>2</sup> )			
User wiring		0.2 sq x 10 wires			
User tubing (Outer diameter)		φ 4 x 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		21 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.) See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>


## YK500XGL



YK500XGL Tool flange mount type







If the robot enters the inside of corners of R200 and R250, the arm may be in contact with the machine harness. So, do not perform such motion.



- Note that the robot cannot be used at a position where the base flange or robot cable interferes with the tool flange in the working envelope shown above.
- X-axis mechanical stopper position : 142°
- Y-axis mechanical stopper position : 146°


4-M3 × 0.5 through-hole  
(No phase relation to R-axis origin.)

As this hole is intended for the wiring/tubing clamp, do not attach a large load to it.



# YK500XG

Standard type: Medium type



- Arm length 500mm
- Maximum payload 10kg

## Ordering method

**YK500XG**

Model	Z axis stroke	Tool flange	Cable
	200: 200mm 300: 300mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	200 mm	300 mm	200 mm / 300 mm	—
	Rotation angle	+/-130 °	+/-145 °	—	+/-360 °
AC servo motor output		400 W	200 W	200 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
		Motor to speed reducer			
		Direct-coupled			
		Speed reducer to output			
		Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
Maximum speed		7.6 m/sec	2.3 m/sec	1.7 m/sec	1700 °/sec
Maximum payload		10 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.45 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.30 kgm <sup>2</sup>			
User wiring		0.2 sq x 20 wires			
User tubing (Outer diameter)		φ 6 x 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		30 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.609.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	1700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.


Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)

See our robot manuals (installation manuals) for detailed information.

Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK500XG



# YK600XGL

Standard type: Medium type

- Arm length 600mm
- Maximum payload 5kg



## Ordering method

**YK600XGL - 150**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	------------------------------------	---	---	--

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	350 mm	250 mm	150 mm	-
	<b>Rotation angle</b>	+/-140 °	+/-144 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>	+/-0.01 mm		+/-0.01 mm		+/-0.004 °
<b>Maximum speed</b>		4.9 m/sec		1.1 m/sec	1020 °/sec
<b>Maximum payload</b>		5 kg (Standard specification), 4 kg (Option specifications <sup>Note 4</sup> )			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>		0.63 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>		0.05 kgm <sup>2</sup> (0.5 kgfcm <sup>2</sup> )			
<b>User wiring</b>		0.2 sq x 10 wires			
<b>User tubing (Outer diameter)</b>		φ 4 × 3			
<b>Travel limit</b>		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		22 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>



## YK600XGL









Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Orbit / T/Ty type  
Medium type  
Large type  
Walk-mount / Inverse type  
Dust-proof & drip-proof type

- Articulated robots  
**YA**
- Linear conveyor modules  
**LCM100**
- Compact single-axis robots  
**TRANSEVO**
- Single-axis robots  
**FLIP-X**
- Linear motor single-axis robots  
**PHASER**
- Cartesian robots  
**XY-X**
- SCARA robots  
**YK-X**
- Pick & place robots  
**YP-X**
- CLEAN
- CONTROLLER INFORMATION
- Orbit / Turn type
- Medium type
- Large type
- Walk-mount / Inverse type
- Dust-proof

## YK600XGL Tool flange mount type



- Note that the robot cannot be used at a position where the base flange or robot cable interferes with the tool flange in the working envelope shown above.
- X-axis mechanical stopper position : 142°
- Y-axis mechanical stopper position : 146°



# YK600XG

Standard type: Medium type

- Arm length 600mm
- Maximum payload 10kg



## Ordering method

**YK600XG**

Model	Z axis stroke	Tool flange	Cable
	200: 200mm 300: 300mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

**R3**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	iVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	300 mm	300 mm	200 mm	300 mm
	Rotation angle	+/-130 °	+/-145 °	-	+/-360 °
AC servo motor output		400 W	200 W	200 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm		+/-0.01 mm	+/-0.004 °
Maximum speed		8.4 m/sec		2.3 m/sec	1.7 m/sec
Maximum payload		10 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.46 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.30 kgm <sup>2</sup>			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		31 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.609.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	1700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.


Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)

See our robot manuals (installation manuals) for detailed information.

Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK600XG



# YK600XGH

Standard type: Medium type



● Arm length 600mm ● Maximum payload 20kg

## Ordering method

<b>YK600XGH</b>				<b>RCX340-4</b>								
<b>Model</b>	<b>Z axis stroke</b> 200: 200mm 400: 400mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m	<b>Controller /</b> Number of controllable axes	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>	
Specify various controller setting items. RCX340 ▶ <b>P.542</b>												
				<b>RCX240</b>		<b>R3</b>						
				<b>Controller</b>	<b>CE Marking</b>	<b>Regenerative unit</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>	
Specify various controller setting items. RCX240/RCX240S ▶ <b>P.532</b>												

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	200 mm	400 mm	200 mm 400 mm	-
	<b>Rotation angle</b>	+/-130 °	+/-150 °	-	+/-360 °
<b>AC servo motor output</b>		750 W	400 W	400 W	200 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>		7.7 m/sec	2.3 m/sec 1.7 m/sec		920 °/sec
<b>Maximum payload</b>		20 kg			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>		0.47 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
<b>User wiring</b>		0.2 sq × 20 wires			
<b>User tubing (Outer diameter)</b>		φ 6 × 3			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		Z axis 200 mm: 48 kg Z axis 400 mm: 50 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.






## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK600XGH





# YK700XGL

Standard type: Large type

● Arm length 700mm ● Maximum payload 10kg

Note. This model is a special order product. Please consult us for delivery time.

## Ordering method

**YK700XGL** **RCX340-4**

Model	Z axis stroke 200: 200mm 300: 300mm	Tool flange No entry: None F: With tool flange	Cable 3L: 3.5m 5L: 5m 10L: 10m	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
-------	---	--	---	---	--------------------	--------------------	--------------------	--------------------	--------------------	--------------------	---------------------

Specify various controller setting items. RCX340 ▶ **P.542**

## Specifications

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>				
Arm length	400 mm	300 mm	200 mm	300 mm
Rotation angle	+/-130 °	+/-145 °	-	+/-360 °
<b>AC servo motor output</b>	400 W	200 W	200 W	200 W
<b>Deceleration mechanism</b>	Speed reducer	Harmonic drive	Harmonic drive	Ball screw
	Transmission method	Direct-coupled		
	Motor to speed reducer	Direct-coupled		
	Speed reducer to output	Direct-coupled		
<b>Repeatability</b> <sup>Note 1</sup>	+/-0.01 mm		+/-0.01 mm	+/-0.005 °
<b>Maximum speed</b>	9.2 m/sec		2.3 m/sec	1.7 m/sec
<b>Maximum payload</b>	10 kg (Standard type), 9 kg (Option: Tool flange mount type)			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>	0.50 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>	0.30 kgm <sup>2</sup>			
<b>User wiring</b>	0.2 sq x 20 wires			
<b>User tubing (Outer diameter)</b>	φ6 × 3			
<b>Travel limit</b>	1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>	Standard: 3.5 m Option: 5, 10 m			
<b>Weight</b>	32 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)

Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.

Note 3. There are limits to acceleration coefficient settings.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340	1700	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.

Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK700XGL



# YK700XG

Standard type: Large type



- Arm length 700mm
- Maximum payload 20kg

## Ordering method

**YK700XG** [ ] [ ] [ ] **RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model	Z axis stroke	Tool flange	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m								

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** [ ] [ ] **R3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	iVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	300 mm	400 mm	200 mm 400 mm	—
	<b>Rotation angle</b>	+/-130 °	+/-150 °	—	+/-360 °
<b>AC servo motor output</b>		750 W	400 W	400 W	200 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <small>Note 1</small>		+/-0.02 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>		8.4 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec
<b>Maximum payload</b>		20 kg			
<b>Standard cycle time: with 2kg payload</b> <small>Note 2</small>		0.42 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>		1.0 kgm <sup>2</sup>			
<b>User wiring</b>		0.2 sq × 20 wires			
<b>User tubing (Outer diameter)</b>		φ 6 × 3			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		Z axis 200 mm: 50 kg Z axis 400 mm: 52 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.





## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>


## YK700XG




If the robot enters the inside of R30 and corner of dimensions 100 and 300, the Z-axis upper end stopper or tool flange may be in contact with the base or the arm may be in contact with the machine harness. So, do not perform such motion.



If the robot enters the inside of R30 and corner of dimensions 100 and 300, the Z-axis upper end stopper or tool flange may be in contact with the base or the arm may be in contact with the machine harness. So, do not perform such motion.




X-axis mechanical stopper position: 132°  
 Y-axis mechanical stopper position: 152°



# YK800XG

Standard type: Large type

- Arm length 800mm
- Maximum payload 20kg



## Ordering method

**YK800XG**

Model	Z axis stroke	Tool flange	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m	<b>RCX340-4</b>							

Specify various controller setting items. RCX340 ▶ **P.542**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
<b>RCX240</b>							

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	400 mm	400 mm	200 mm	400 mm
	Rotation angle	+/-130 °	+/-150 °	-	+/-360 °
AC servo motor output		750 W	400 W	400 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm		+/-0.01 mm	+/-0.004 °
Maximum speed		9.2 m/sec		2.3 m/sec 1.7 m/sec	920 °/sec
Maximum payload		20 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.48 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
User wiring		0.2 sq x 20 wires			
User tubing (Outer diameter)		φ 6 x 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 52 kg Z axis 400 mm: 54 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK800XG

**Working envelope of left-handed system**

**Working envelope of right-handed system**

**Option: Tool flange mount type**

**YK800XG 2200mm Stroke specification**

**YK800XG 2400mm Stroke specification**

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / Tray type

Small / Medium types


Large type

Walk-mount / Inverse type

Dust-proof & drip-proof type

# YK900XG

Standard type: Large type



- Arm length 900mm
- Maximum payload 20kg

## Ordering method

**YK900XG** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model	Z axis stroke	Tool flange	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m	<b>RCX340-4</b>							

Specify various controller setting items. **RCX340 ▶ P.542**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
<b>RCX240</b>		<b>R3</b>					

Specify various controller setting items. **RCX240/RCX240S ▶ P.532**

## Specifications

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>				
<b>Arm length</b>	500 mm	400 mm	200 mm / 400 mm	-
<b>Rotation angle</b>	+/-130 °	+/-150 °	-	+/-360 °
<b>AC servo motor output</b>	750 W	400 W	400 W	200 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw
	<b>Transmission method</b>	Direct-coupled		
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled		
<b>Repeatability</b> <small>Note 1</small>	+/-0.02 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>	9.9 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec
<b>Maximum payload</b>	20 kg			
<b>Standard cycle time: with 2kg payload</b> <small>Note 2</small>	0.49 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>	1.0 kg <sup>2</sup>			
<b>User wiring</b>	0.2 sq x 20 wires			
<b>User tubing (Outer diameter)</b>	φ 6 x 3			
<b>Travel limit</b>	1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>	Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>	Z axis 200 mm: 54 kg Z axis 400 mm: 56 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>


## YK900XG



# YK1000XG

Standard type: Large type

- Arm length 1000mm
- Maximum payload 20kg



## Ordering method

**YK1000XG**

<b>Model</b>	<b>Z axis stroke</b>	<b>Tool flange</b>	<b>Cable</b>	<b>RCX340-4</b>							
	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m	<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>

Specify various controller setting items. RCX340 ▶ **P.542**

<b>RCX240</b>	<b>R3</b>										
<b>Controller</b>	<b>CE Marking</b>	<b>Regenerative unit</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>				

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	600 mm	400 mm	200 mm	400 mm
	<b>Rotation angle</b>	+/-130 °	+/-150 °	-	+/-360 °
<b>AC servo motor output</b>		750 W	400 W	400 W	200 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <small>Note 1</small>	+/-0.02 mm		+/-0.01 mm		+/-0.004 °
<b>Maximum speed</b>		10.6 m/sec	2.3 m/sec 1.7 m/sec		920 °/sec
<b>Maximum payload</b>		20 kg			
<b>Standard cycle time: with 2kg payload</b> <small>Note 2</small>		0.49 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>		1.0 kgm <sup>2</sup>			
<b>User wiring</b>		0.2 sq × 20 wires			
<b>User tubing (Outer diameter)</b>		φ 6 × 3			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		Z axis 200 mm: 56 kg Z axis 400 mm: 58 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK1000XG

**Dimensions:** 80, 400, 600, 220, 161, 189, 99, 220, 150, 145, 75, 170, 245, 120, 128, 63, 990, 790, 440, 368, 333.5, 319.5, 278, 273, 208.7±2, 45, 14, 46, 711, 476, 268, 219, 202.2, 339.5, 254.5, 219, 74, 54, 47, 34, 19, 0, 21, 25, 46, 153, 48.48, 15, 36, 54, 4-φ9.

**Stroke:** Z400mm, Z200mm

**Working envelope of left-handed system:** R1000, R323, R400, R400, R400

**Working envelope of right-handed system:** R1000, R323, R400, R400

**X-axis mechanical stopper position: 132°**  
**Y-axis mechanical stopper position: 152°**

**Option: Tool flange mount type**

**Standard type:** Z-axis lower end mechanical stopper position

**Cross section A-A:** Hollow diameter: φ18, Width across flats: 24

**View of B:** Maximum 770 during arm rotation, φ65, φ50 h7-0.025, φ95, φ50 h7-0.025, φ65, 4-φ6.6 through-hole, Hollow diameter φ18, 4-φ14 M12 M12 bolt for installation, 4bolts used

**4-M4 x 0.7 through-hole for tool attachment:** Four M4 x 10L binding screws are supplied. Do not screw the screws in deeper than 10mm from bottom surface of arm.

**R27 (Min. cable bending radius):** Do not move the cable.

**Keep enough space for the maintenance work at the rear of the base.**

**M4 ground terminal**


**D-sub connector for user wiring (No.1 to 20 usable)**

**User tubing 1 (φ6 Black)**  
**User tubing 2 (φ6 Red)**  
**User tubing 3 (φ6 Blue)**

**YK1000XG Z200mm Stroke specification**  
**YK1000XG Z400mm Stroke specification**

# YK1200X

Standard type: Large type



- Arm length 1200mm
- Maximum payload 50kg

## Ordering method

**YK1200X - 400** **RCX340-4**

Model	Z axis stroke	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
		3L: 3.5m 5L: 5m 10L: 10m								

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** **R**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	600 mm	600 mm	400 mm	-
	Rotation angle	+/-125 °	+/-150 °	-	+/-180 °
AC servo motor output		900 W	800 W	600 W	400 W
Deceleration mechanism	Speed reducer	Planetary gear	Planetary gear	Ball screw	Harmonic drive
	Transmission method	Motor to speed reducer	Direct-coupled	Timing belt transmission	Timing belt transmission
		Speed reducer to output	Direct-coupled	Direct-coupled	Direct-coupled
Repeatability <sup>Note 1</sup>		+/-0.05 mm	+/-0.02 mm	+/-0.005 °	
Maximum speed		7.4 m/sec	0.75 m/sec	600 °/sec	
Maximum payload		50 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.91 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		2.45 kgm <sup>2</sup>			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		124 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings. See P.610.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK1200X



# YK300XGS

Wall-mount / inverse type

● Arm length 300mm ● Maximum payload 5kg Note. Built-to-order product. Contact us for the delivery period.

## Ordering method

**YK300XGS** **150** **RCX340-4**

<b>Model</b>	<b>Installation method</b> W: Wall-mount (same as per external view) U: Inverse wall-mount (upside down)	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> No entry: None S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m	<b>Controller / Number of controllable axes</b> RCX340-4	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
--------------	--	------------------------------------	---	---	--	---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	150 mm	150 mm	150 mm	-
	<b>Rotation angle</b>	+/-120 °	+/-130 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b>	Direct-coupled			
	<b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>		4.4 m/sec	1.0 m/sec	1020 °/sec (wall-mount) 720 °/sec (inverse wall-mount)	
<b>Maximum payload</b>		5 kg (Standard specification), 4 kg (Option specifications <sup>Note 4</sup> )			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>		0.49 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>		0.05 kgm <sup>2</sup>			
<b>User wiring</b>		0.2 sq x 10 wires			
<b>User tubing (Outer diameter)</b>		φ 4 x 3			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		19.5 kg			

Note 1. This is the value at a constant ambient temperature.  
Note 2. When reciprocating 25mm horizontally and 300mm horizontally (with a 2kg payload in rough-positioning arch motion).  
Note 3. There are limits to acceleration coefficient settings. See P.607.  
Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the position of Y axis mechanical stopper. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK300XGS

**D-sub connector for user wiring (No. 1 to 10 usable)**

**Cross section B-B**

**Working envelope**  
X-axis mechanical stopper position: 122°  
Y-axis mechanical stopper position: 132°


**(Option)**

- Additional Z-axis upper limit stopper: Allows changing the Z-axis origin position to a point 12mm, 15mm or 18mm (in 3mm steps) lower than the standard position.
- Additional Z-axis lower limit stopper: Allows changing the Z-axis stopper position to a point 17mm or more higher than the standard position. (Lower limit of working envelope: 4mm from additional stopper) (Cannot be used when user wiring and tubing are set through spline shaft.)

**Option: User wiring/tubing through spline type**  
Note. Inverse type is installed upside down.

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- Orbit/Tiny type
- Small / Medium type
- Large type
- Wall-mount / Inverse type
- Dust-proof & drip-proof type

## YK300XGS Tool flange mount type





# YK400XGS

Wall-mount / inverse type

● Arm length 400mm ● Maximum payload 5kg Note. Built-to-order product. Contact us for the delivery period.

## Ordering method

**YK400XGS** 150 RCX340-4

Model	Installation method <sup>Note1</sup>	Z axis stroke	Tool flange	Hollow shaft	Cable	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
	W: Wall-mount (same as per external view) U: Inverse wall-mount (upside down)	150: 150mm	No entry: None F: With tool flange	No entry: None S: With hollow shaft	3L: 3.5m 5L: 5m 10L: 10m	Specify various controller setting items. RCX340 ▶ <b>P.542</b>							

**RCX240S** Controller CE Marking Expansion I/O Network option IVY System Gripper Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>				
Arm length	250 mm	150 mm	150 mm	-
Rotation angle	+/-125 °	+/-144 °	-	+/-360 °
<b>AC servo motor output</b>	200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
<b>Speed reducer</b>	Direct-coupled			
<b>Transmission method</b>	Direct-coupled			
<b>Motor to speed reducer</b>	Direct-coupled			
<b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>	+/-0.01 mm	+/-0.01 mm	+/-0.004 °	
<b>Maximum speed</b>	6.1 m/sec	1.1 m/sec	1020 °/sec (wall-mount) 720 °/sec (inverse wall-mount)	
<b>Maximum payload</b>	5 kg (Standard specification), 4 kg (Option specifications <sup>Note 4</sup> )			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>	0.49 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>	0.05 kgm <sup>2</sup>			
<b>User wiring</b>	0.2 sq x 10 wires			
<b>User tubing (Outer diameter)</b>	φ 4 x 3			
<b>Travel limit</b>	1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>	Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>	20 kg			

Note 1. This is the value at a constant ambient temperature.  
Note 2. When reciprocating 25mm horizontally and 300mm horizontally (with a 2kg payload in rough-positioning arch motion).  
Note 3. There are limits to acceleration coefficient settings. See P.608.  
Note 4. Maximum payload of option specifications (with tool flange attached or with user wiring and tubing routed through spline shaft) is 4kg.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the position of Y axis mechanical stopper. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK400XGS



- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- Orbit/Tiny
- Small / Medium type
- Large type
- Wall-mount / Inverse type
- Dust-proof & drip-proof type


## YK400XGS Tool flange mount type



# YK500XGS

Wall-mount / inverse type

- Arm length 500mm
- Maximum payload 10kg



## Ordering method

### YK500XGS

Model	Installation method <sup>Note 1</sup>	Z axis stroke	Tool flange	Cable
	W: Wall-mount (same as per external view) U: Inverse wall-mount (upside down)	200: 200mm 300: 300mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

### RCX340-4

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ P.542

### RCX240

### R3

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	I/V System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ P.532

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

Axis specifications	Arm length	X-axis	Y-axis	Z-axis	R-axis
Rotation angle		200 mm	300 mm	200 mm/300 mm	-
AC servo motor output		+/-105 °	+/-125 °	-	+/-360 °
Speed reducer		400 W	200 W	200 W	200 W
Transmission method		Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
Motor to speed reducer		Direct-coupled			
Speed reducer to output		Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.004 °	
Maximum speed		7.6 m/sec	2.3 m/sec	1.7 m/sec	1700 °/sec (wall-mount) 800 °/sec (inverse wall-mount)
Maximum payload		10 kg (Standard specification), 9 kg (Option specifications)			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.45 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.30 kgm <sup>2</sup>			
User wiring		0.2 sq x 20 wires			
User tubing (Outer diameter)		φ 6 x 3			
Travel limit		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		30 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
Note 3. There are limits to acceleration coefficient settings. See P.609.  
Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	1700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>


## YK500XGS



# YK600XGS

Wall-mount / inverse type

- Arm length 600mm
- Maximum payload 10kg



## Ordering method

### YK600XGS

Model	Installation method <sup>Note 1</sup>	Z axis stroke	Tool flange	Cable
	W: Wall-mount (same as per external view) U: Inverse wall-mount (upside down)	200: 200mm 300: 300mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

### RCX340-4

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ P.542

### RCX240

### R3

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ P.532

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

Axis specifications	Arm length	X-axis	Y-axis	Z-axis	R-axis
	300 mm	300 mm	300 mm	200 mm/300 mm	-
	Rotation angle	+/-130 °	+/-145 °	-	+/-360 °
AC servo motor output		400 W	200 W	200 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm		+/-0.004 °
Maximum speed		8.4 m/sec		2.3 m/sec 1.7 m/sec	1700 °/sec (wall-mount) 800 °/sec (inverse wall-mount)
Maximum payload		10 kg (Standard specification), 9 kg (Option specifications)			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.46 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.30 kgm <sup>2</sup>			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		31 kg			

## Controller


Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	1700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
Note 3. There are limits to acceleration coefficient settings. See P.609.  
Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.

## YK600XGS



# YK700XGS

Wall-mount / inverse type

● Arm length 700mm ● Maximum payload 20kg

## Ordering method

### YK700XGS

Model	Installation method <sup>Note 1</sup>	Z axis stroke	Tool flange	Cable
	W: Wall-mount (same as per external view) I: Inverse wall-mount (upside down)	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

### RCX340-4

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ P.542

### RCX240

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ P.532

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	300 mm	400 mm	200 mm/400 mm	—
	Rotation angle	+/-130 °	+/-130 °	—	+/-360 °
AC servo motor output		750 W	400 W	400 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm	+/-0.004 °	
Maximum speed		8.4 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec (wall-mount) 480 °/sec (inverse wall-mount)
Maximum payload		20 kg (Standard specification), 19 kg (Option specifications)			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.42 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 50 kg Z axis 400 mm: 52 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
Note 3. There are limits to acceleration coefficient settings. See P.609.  
Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK700XGS



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / Triy type

Small / Medium type

Large type

Wall-mount / Inverse type

Dust-proof & drip-proof type

# YK800XGS

Wall-mount / inverse type

● Arm length 800mm ● Maximum payload 20kg

## Ordering method

### YK800XGS

Model	Installation method <sup>Note 1</sup>	Z axis stroke	Tool flange	Cable
	W: Wall-mount (same as per external view) U: Inverse wall-mount (upside down)	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

### RCX340-4

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

### RCX240

### R3

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

Axis specifications	Arm length	X-axis	Y-axis	Z-axis	R-axis
Rotation angle		400 mm	400 mm	200 mm/400 mm	—
AC servo motor output		+/-130 °	+/-145 °	—	+/-360 °
Speed reducer		750 W	400 W	400 W	200 W
Transmission method		Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
Motor to speed reducer		Direct-coupled			
Speed reducer to output		Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm	+/-0.004 °	
Maximum speed		9.2 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec (wall-mount) 480 °/sec (inverse wall-mount)
Maximum payload		20 kg (Standard specification), 19 kg (Option specifications)			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.48 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 52 kg Z axis 400 mm: 54 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
Note 3. There are limits to acceleration coefficient settings. See P.609.  
Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.



## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK800XGS



# YK900XGS

Wall-mount / inverse type

- Arm length 900mm
- Maximum payload 20kg

## Ordering method

**YK900XGS**

Model	Installation method <sup>Note 1</sup>	Z axis stroke	Tool flange	Cable
	W: Wall-mount (same as per external view) I: Inverse wall-mount (upside down)	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

	X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>				
Arm length	500 mm	400 mm	200 mm/400 mm	-
Rotation angle	+/-130 °	+/-150 °	-	+/-360 °
<b>AC servo motor output</b>	750 W	400 W	400 W	200 W
<b>Deceleration mechanism</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
Speed reducer	Harmonic drive			
Transmission method	Direct-coupled			
Motor to speed reducer	Direct-coupled			
Speed reducer to output	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>	+/-0.02 mm	+/-0.01 mm	+/-0.004 °	
<b>Maximum speed</b>	9.9 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec (wall-mount) 480 °/sec (inverse wall-mount)
<b>Maximum payload</b>	20 kg (Standard specification), 19 kg (Option specifications)			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>	0.49 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>	1.0 kgm <sup>2</sup>			
<b>User wiring</b>	0.2 sq × 20 wires			
<b>User tubing (Outer diameter)</b>	φ 6 × 3			
<b>Travel limit</b>	1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>	Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>	Z axis 200 mm: 54 kg Z axis 400 mm: 56 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
Note 3. There are limits to acceleration coefficient settings. See P.609.  
Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK900XGS



# YK1000XGS

Wall-mount / inverse type

- Arm length 1000mm
- Maximum payload 20kg

## Ordering method

**YK1000XGS**

Model	Installation method <sup>Note 1</sup>	Z axis stroke	Tool flange	Cable
	W: Wall-mount (same as per external view) U: Inverse wall-mount (upside down)	200: 200mm 400: 400mm	No entry: None F: With tool flange	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

Note 1. When installing the robot, always follow the specifications.  
Do not install the ceiling-mount robot upside down or do not install the inverse type robot to a ceiling.  
Incorrect installation can cause trouble or malfunction.

## Specifications

Axis specifications	Arm length	X-axis	Y-axis	Z-axis	R-axis
	Rotation angle	600 mm	400 mm	200 mm/400 mm	-
	AC servo motor output	+/-130 °	+/-150 °	-	+/-360 °
	Speed reducer	750 W	400 W	400 W	200 W
Deceleration mechanism	Transmission method	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm	+/-0.004 °	
Maximum speed		10.6 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec (wall-mount) 480 °/sec (inverse wall-mount)
Maximum payload		20 kg (Standard specification), 19 kg (Option specifications)			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.49 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 56 kg Z axis 400 mm: 58 kg			

## Controller


Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
Note 2. When reciprocating 300mm in horizontal and 25mm in vertical directions.  
Note 3. There are limits to acceleration coefficient settings. See P.609.  
Note. Please consult YAMAHA when connecting other tubes and cables to the self-supporting machine harness.

## YK1000XGS





# YK250XGP

Dust-proof & drip-proof type

- Arm length 250mm
- Maximum payload 4kg

## Ordering method

**YK250XGP - 150** **S** **RCX340-4**

Model: YK250XGP-150, Z axis stroke: 150: 150mm, Tool flange: No entry: None, F: With tool flange, Hollow shaft: S: With hollow shaft, Cable: 3L: 3.5m, 5L: 5m, 10L: 10m

Controller / Number of controllable axes: RCX340-4, Safety standard, Option A (OP.A), Option B (OP.B), Option C (OP.C), Option D (OP.D), Option E (OP.E), Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller, CE Marking, Expansion I/O, Network option, IVY System, Gripper, Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	100 mm	150 mm	150 mm	-
	Rotation angle	+/-129°	+/-134°	-	+/-360°
AC servo motor output (W)		200	150	50	100
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004°
Maximum speed		4.5 m/sec	1.1 m/sec		1020 °/sec
Maximum payload		4 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.57 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.05 kg <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring		0.2 sq × 10 wires			
User tubing (Outer diameter)		φ 4 × 4			
Travel limit		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		21.5 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.607.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK250XGP



Articulated robots YA
Linear conveyor modules LCM100
Compact single-axis robots TRANSEURO
Single-axis robots FLIP-X
Linear motor single-axis robots PHASER
Cartesian robots XY-X
SCARA robots YK-X
Pick & place robots YP-X
CLEAN
CONTROLLER INFORMATION
Orbit / Turn type
Small / Medium type
Large type
Wall-mount / Inverse type
Dust-proof & drip-proof type

### YK250XGP Tool flange mount type



# YK350XGP

Dust-proof & drip-proof type

- Arm length 350mm
- Maximum payload 4kg

## Ordering method

**YK350XGP - 150**

<b>Model</b>	<b>Z axis stroke</b>	<b>Tool flange</b>	<b>Hollow shaft</b>	<b>Cable</b>
	150: 150mm	No entry: None F: With tool flange	S: With hollow shaft	3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>iVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	200 mm	150 mm	150 mm	-
	<b>Rotation angle</b>	+/-129 °	+/-134 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <small>Note 1</small>	+/-0.01 mm		+/-0.01 mm	+/-0.004 °	
<b>Maximum speed</b>		5.6 m/sec	1.1 m/sec	1020 °/sec	
<b>Maximum payload</b>		4 kg			
<b>Standard cycle time: with 2kg payload</b> <small>Note 2</small>		0.57 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>		0.05 kgm <sup>2</sup>			
<b>Protection class</b> <small>Note 4</small>		Equivalent to IP65 (IEC 60529)			
<b>User wiring</b>		0.2 sq × 10 wires			
<b>User tubing (Outer diameter)</b>		φ 4 × 4			
<b>Travel limit</b>		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		22 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)

Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).

Note 3. There are limits to acceleration coefficient settings. See P.607.

Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.

Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.) See our robot manuals (installation manuals) for detailed information.


Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK350XGP



## YK350XGP Tool flange mount type



# YK400XGP

Dust-proof & drip-proof type



- Arm length 400mm
- Maximum payload 4kg

## Ordering method

**YK400XGP - 150** **S** **RCX340-4**

Model	Z axis stroke 150: 150mm	Tool flange No entry: None F: With tool flange	Hollow shaft S: With hollow shaft	Cable 3L: 3.5m 5L: 5m 10L: 10m	Controller / Number of controllable axes <b>RCX340-4</b>	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
-------	-----------------------------	--	--------------------------------------	---	---	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	250 mm	150 mm	150 mm	-
	Rotation angle	+/-129 °	+/-144 °	-	+/-360 °
AC servo motor output		200 W	150 W	50 W	100 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
Maximum speed		6.1 m/sec		1.1 m/sec	1020 °/sec
Maximum payload		4 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.57 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.05 kgm <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring		0.2 sq × 10 wires			
User tubing (Outer diameter)		φ 4 × 4			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		22.5 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK400XGP



## YK400XGP Tool flange mount type



# YK500XGLP

Dust-proof & drip-proof type

● Arm length 500mm ● Maximum payload 4kg

## Ordering method

**YK500XGLP - 150** **S** **RCX340-4**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m	<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
--------------	------------------------------------	---	---	--	---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	250 mm	250 mm	150 mm	-
	<b>Rotation angle</b>	+/-129 °	+/-144 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b>	Direct-coupled			
	<b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>		5.1 m/sec		1.1 m/sec	1020 °/sec
<b>Maximum payload</b>		4 kg			
<b>Standard cycle time: with 2kg payload</b> <sup>Note 2</sup>		0.74 sec			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup>		0.05 kgm <sup>2</sup>			
<b>Protection class</b> <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
<b>User wiring</b>		0.2 sq × 10 wires			
<b>User tubing (Outer diameter)</b>		φ 4 × 4			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		25 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK500XGLP



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / T/Try type



Small / Medium type

Large type

Walk-mount / Inverse type



Dust-proof & drip-proof type

## YK500XGLP Tool flange mount type



If the robot enters the inside from the inner limit of the working envelope, the Z-axis bellows may be in contact with the base or the arm may be in contact with the machine harness. So, do not perform such motion.

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position :  $131^\circ$
- Y-axis mechanical stopper position :  $146^\circ$



Tapped hole for user wiring 6-M3 x 0.5 Depth 6  
The weight of the tool attached here should be added to the tip mass.

R32 (Min. cable bending radius)  
Do not move the cable.

4- $\phi 11$

Keep enough space for the maintenance work at the rear of the base.



# YK500XGP

Dust-proof & drip-proof type

- Arm length 500mm
- Maximum payload 8kg

## Ordering method

**YK500XGP** **F** **RCX340-4**

Model      Z axis stroke      Tool flange      Cable

200: 200mm      F: With tool flange      3L: 3.5m

300: 300mm      5L: 5m

10L: 10m

Controller / Number of controllable axes      Safety standard      Option A (OP.A)      Option B (OP.B)      Option C (OP.C)      Option D (OP.D)      Option E (OP.E)      Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** **R3**

Controller      CE Marking      Regenerative unit      Expansion I/O      Network option      iVY System      Gripper      Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	200 mm	300 mm	200 mm/300 mm	—
	Rotation angle	+/-130 °	+/-145 °	—	+/-360 °
AC servo motor output		400 W	200 W	200 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
Maximum speed		7.6 m/sec	2.3 m/sec	1.7 m/sec	1700 °/sec
Maximum payload		8 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.55 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		0.3 kgm <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 32 kg Z axis 300 mm: 33 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.

## Controller





Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	1700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK500XGP


Connector for user wiring (No.1 to 20 usable, cable clamp size: φ16 to 18)  
 Cover with the caps provided when not used.



If the robot enters the inside of the corner of dimensions 135 and 292, the Z-axis tip flange may be in contact with the base or the arm may be in contact with the machine harness. So, do not perform such motion.



Working envelope of left-handed system



Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 147°

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YF-X

CLEAN

CONTROLLER INFORMATION

Orbit / Tray type

Small / Medium type

Large type

Inverse type

Walk-mount / Inverse type

Dust-proof & drip-proof type

# YK600XGLP

Dust-proof & drip-proof type

- Arm length 600mm
- Maximum payload 4kg

## Ordering method

**YK600XGLP-150** **S** **RCX340-4**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> S: With hollow shaft	<b>Cable</b> 3L: 3.5m 5L: 5m 10L: 10m	<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
--------------	------------------------------------	---	---	--	---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	350 mm	250 mm	150 mm	-
	<b>Rotation angle</b>	+/-129 °	+/-144 °	-	+/-360 °
<b>AC servo motor output</b>		200 W	150 W	50 W	100 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b>	Direct-coupled			
	<b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <small>Note 1</small>		+/-0.01 mm	+/-0.01 mm		+/-0.004 °
<b>Maximum speed</b>		4.9 m/sec		1.1 m/sec	1020 °/sec
<b>Maximum payload</b>		4 kg			
<b>Standard cycle time: with 2kg payload</b> <small>Note 2</small>		0.74 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>		0.05 kgm <sup>2</sup>			
<b>Protection class</b> <small>Note 4</small>		Equivalent to IP65 (IEC 60529)			
<b>User wiring (sq × wires)</b>		0.2 × 10			
<b>User tubing (Outer diameter)</b>		φ 4 × 4			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		26 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK600XGLP



The arm may be in contact with the machine harness in an area inside from the inner limit of this working envelope. So, do not operate the arm in this area.


- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 146°

User tubing 1 (φ4 black)  
 User tubing 2 (φ4 red)  
 Insert the plug provided when not used.  
 Since this port is not used, cover it with the cap supplied with the joint.  
 Connector for user wiring (No.1 to 10 usable, cable clamp size: φ13.1 to 15)  
 Cover with the caps provided when not used.

Tapped hole for user wiring 6-M3 × 0.5 Depth 6  
 The weight of the tool attached here should be added to the tip mass.

R32 (Min. cable bending radius)  
 Do not move the cable.

## YK600XGLP Tool flange mount type



# YK600XGP

Dust-proof & drip-proof type

- Arm length 600mm
- Maximum payload 8kg

## Ordering method

**YK600XGP** [ ] **F** [ ] **RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model**      **Z axis stroke**      **Tool flange**      **Cable**      **Controller / Number of controllable axes**      **Safety standard**      **Option A (OP.A)**      **Option B (OP.B)**      **Option C (OP.C)**      **Option D (OP.D)**      **Option E (OP.E)**      **Absolute battery**

Z axis stroke: 200: 200mm, 300: 300mm  
 Tool flange: F: With tool flange  
 Cable: 3L: 3.5m, 5L: 5m, 10L: 10m

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240** [ ] **R3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Controller**      **CE Marking**      **Regenerative unit**      **Expansion I/O**      **Network option**      **iVY System**      **Gripper**      **Battery**

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
<b>Axis specifications</b>	<b>Arm length</b>	300 mm	300 mm	200 mm 300 mm	—
	<b>Rotation angle</b>	+/-130 °	+/-145 °	—	+/-360 °
<b>AC servo motor output</b>		400 W	200 W	200 W	200 W
<b>Deceleration mechanism</b>	<b>Speed reducer</b>	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	<b>Transmission method</b>	Direct-coupled			
	<b>Motor to speed reducer</b> <b>Speed reducer to output</b>	Direct-coupled			
<b>Repeatability</b> <small>Note 1</small>		+/-0.01 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
<b>Maximum speed</b>		8.4 m/sec	2.3 m/sec	1.7 m/sec	1700 °/sec
<b>Maximum payload</b>		8 kg			
<b>Standard cycle time: with 2kg payload</b> <small>Note 2</small>		0.56 sec			
<b>R-axis tolerable moment of inertia</b> <small>Note 3</small>		0.3 kgm <sup>2</sup>			
<b>Protection class</b> <small>Note 4</small>		Equivalent to IP65 (IEC 60529)			
<b>User wiring (sq × wires)</b>		0.2 × 20			
<b>User tubing (Outer diameter)</b>		φ 6 × 3			
<b>Travel limit</b>		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
<b>Robot cable length</b>		Standard: 3.5 m Option: 5 m, 10 m			
<b>Weight</b>		Z axis 200 mm: 33 kg Z axis 300 mm: 34 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.





## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	1700	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK600XGP



Working envelope of left-handed system



Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 147°

# YK600XGHP

Dust-proof & drip-proof type

- Arm length 600mm
- Maximum payload 18kg

## Ordering method

**YK600XGHP** **F** **RCX340-4**

Model      Z axis stroke      Tool flange      Cable      Controller / Number of controllable axes      Safety standard      Option A (OP.A)      Option B (OP.B)      Option C (OP.C)      Option D (OP.D)      Option E (OP.E)      Absolute battery

200: 200mm      F: With tool flange      3L: 3.5m      RCX340

400: 400mm      5L: 5m      10L: 10m

**RCX240** **R3**

Controller      CE Marking      Regenerative unit      Expansion I/O      Network option      IVY System      Gripper      Battery

Specify various controller setting items. RCX340 ▶ **P.542**

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	200 mm	400 mm	200 mm / 400 mm	—
	Rotation angle	+/-130 °	+/-150 °	—	+/-360 °
AC servo motor output		750 W	400 W	400 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
Maximum speed		7.7 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec
Maximum payload		18 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.57 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring (sq × wires)		0.2 × 20			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1. Soft limit    2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m    Option: 5 m, 10 m			
Weight		Z axis 200 mm: 52 kg    Z axis 400 mm: 54 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.

## Controller






Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.) See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.



Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK600XGHP

Connector for user wiring (No.1 to 20 usable, cable clamp size: φ16 to 18)  
 Cover with the caps provided when not used.



- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / T/Try type

Small / Medium type

Large type

Walk-mount / Inverse type

Dust-proof & drip-proof type

# YK700XGP

Dust-proof & drip-proof type



- Arm length 700mm
- Maximum payload 18kg

## Ordering method

**YK700XGP** **F** **RCX340-4**

Model      Z axis stroke      Tool flange      Cable

200: 200mm      F: With tool flange      3L: 3.5m      Controller / Number of controllable axes

400: 400mm      5L: 5m      10L: 10m      Safety standard      Option A (OP.A)      Option B (OP.B)      Option C (OP.C)      Option D (OP.D)      Option E (OP.E)      Absolute battery

**RCX240** **R3**

Controller      CE Marking      Regenerative unit      Expansion I/O      Network option      iVY System      Gripper      Battery

Specify various controller setting items. RCX340 ▶ **P.542**

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	300 mm	400 mm	200 mm	400 mm
	Rotation angle	+/-130 °	+/-150 °	-	+/-360 °
AC servo motor output		750 W	400 W	400 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
Speed reducer to output		Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004 °
Maximum speed		8.4 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec
Maximum payload		18 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.52 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring		0.2 sq × 20 wires			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 54 kg Z axis 400 mm: 56 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.




## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK700XGP





Working envelope of left-handed system



Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°



Z axis tip shape

# YK800XGP

Dust-proof & drip-proof type

● Arm length 800mm ● Maximum payload 18kg

## Ordering method

**YK800XGP** **F** **RCX340-4**

Model	Z axis stroke 200: 200mm 400: 400mm	Tool flange F: With tool flange	Cable 3L: 3.5m 5L: 5m 10L: 10m	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
-------	---	------------------------------------	---	--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** **R3**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	iVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

Axis specifications	Arm length	X-axis	Y-axis	Z-axis	R-axis
Arm length	400 mm	400 mm	400 mm	200 mm	400 mm
Rotation angle	+/-130°	+/-130°	+/-150°	-	+/-360°
AC servo motor output	750 W	400 W	400 W	400 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm	+/-0.01 mm	+/-0.004°
Maximum speed		9.2 m/sec	2.3 m/sec	1.7 m/sec	920°/sec
Maximum payload		18 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.58 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring		0.2 sq x 20 wires			
User tubing (Outer diameter)		φ 6 x 3			
Travel limit		1. Soft limit 2. Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 56 kg Z axis 400 mm: 58 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)

Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).

Note 3. There are limits to acceleration coefficient settings. See P.609.

Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication





Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.

Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.) See our robot manuals (installation manuals) for detailed information.


Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK800XGP




Z axis tip shape



Working envelope of left-handed system

If the robot enters the inside of R265 and corner of dimensions 98 and 400, the Z-axis tip flange may be in contact with the base or the arm may be in contact with the machine harness. So, do not perform such motion.



Working envelope of right-handed system

Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.  
• X-axis mechanical stopper position : 132°  
• Y-axis mechanical stopper position : 152°

\* There is no phase relation between each position of M5 tapped holes and R-axis origin position.

# YK900XGP

Dust-proof & drip-proof type

- Arm length 900mm
- Maximum payload 18kg

## Ordering method

**YK900XGP** **F** **RCX340-4**

Model      Z axis stroke      Tool flange      Cable      Controller / Number of controllable axes      Safety standard      Option A (OP.A)      Option B (OP.B)      Option C (OP.C)      Option D (OP.D)      Option E (OP.E)      Absolute battery

Z axis stroke: 200: 200mm, 400: 400mm  
 Tool flange: F: With tool flange  
 Cable: 3L: 3.5m, 5L: 5m, 10L: 10m

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240** **R3**

Controller      CE Marking      Regenerative unit      Expansion I/O      Network option      iVY System      Gripper      Battery

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	500 mm	400 mm	200 mm 400 mm	-
	Rotation angle	+/-130 °	+/-150 °	-	+/-360 °
AC servo motor output		750 W	400 W	400 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm		+/-0.004 °
Maximum speed		9.9 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec
Maximum payload		18 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.59 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring (sq x wires)		0.2 x 20			
User tubing (Outer diameter)		φ 6 x 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 58 kg Z axis 400 mm: 60 kg			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.



## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication




Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK900XGP





Working envelope of left-handed system



Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°





# YK1000XGP

Dust-proof & drip-proof type

- Arm length 1000mm
- Maximum payload 18kg

## Ordering method

**YK1000XGP** [ ] **F** [ ] **RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model      Z axis stroke      Tool flange      Cable      Controller / Number of controllable axes      Safety standard      Option A (OP.A)      Option B (OP.B)      Option C (OP.C)      Option D (OP.D)      Option E (OP.E)      Absolute battery

Z axis stroke: 200: 200mm, 400: 400mm  
 Tool flange: F: With tool flange  
 Cable: 3L: 3.5m, 5L: 5m, 10L: 10m

**RCX340-4** Controller / Number of controllable axes      Safety standard      Option A (OP.A)      Option B (OP.B)      Option C (OP.C)      Option D (OP.D)      Option E (OP.E)      Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240** [ ] **R3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller      CE Marking      Regenerative unit      Expansion I/O      Network option      I/V System      Gripper      Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications

		X-axis	Y-axis	Z-axis	R-axis
Axis specifications	Arm length	600 mm	400 mm	200 mm	400 mm
	Rotation angle	+/-130 °	+/-150 °	-	+/-360 °
AC servo motor output		750 W	400 W	400 W	200 W
Deceleration mechanism	Speed reducer	Harmonic drive	Harmonic drive	Ball screw	Harmonic drive
	Transmission method	Direct-coupled			
	Motor to speed reducer	Direct-coupled			
	Speed reducer to output	Direct-coupled			
Repeatability <sup>Note 1</sup>		+/-0.02 mm	+/-0.01 mm		+/-0.004 °
Maximum speed		10.6 m/sec	2.3 m/sec	1.7 m/sec	920 °/sec
Maximum payload		18 kg			
Standard cycle time: with 2kg payload <sup>Note 2</sup>		0.59 sec			
R-axis tolerable moment of inertia <sup>Note 3</sup>		1.0 kgm <sup>2</sup>			
Protection class <sup>Note 4</sup>		Equivalent to IP65 (IEC 60529)			
User wiring (sq × wires)		0.2 × 20			
User tubing (Outer diameter)		φ 6 × 3			
Travel limit		1.Soft limit 2.Mechanical stopper (X,Y,Z axis)			
Robot cable length		Standard: 3.5 m Option: 5 m, 10 m			
Weight		Z axis 200 mm: 60 kg Z axis 400 mm: 62 kg			

- Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.609.  
 Note 4. Do not use robots where the bellows section is directly exposed to water jet. Contact our distributor for information on drip-proof structure preventing liquid other than water.



## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R3	2500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

- Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.


Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK1000XGP



If the robot enters the inside of the corner of dimensions 98 and 400, the Z-axis tip flange may be in contact with the base of the arm or may be in contact with the machine harness. So, do not perform such motion.



### Working envelope of left-handed system



If the robot enters the inside of the corner of dimensions 98 and 400, the Z-axis tip flange may be in contact with the base of the arm or may be in contact with the machine harness. So, do not perform such motion.

### Working envelope of right-handed system

- Note that the robot cannot be used at a position where the base flange, robot cable, spline, and bellows interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 132°
- Y-axis mechanical stopper position : 152°



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Orbit / Tray type

Small / Medium type

Large type

Walk-mount / Inverse type

Dust-proof & drip-proof type

# MEMO

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION


Orbit / Tiny  
type

Small /  
Medium type

Large type

Wall-mount /  
Inverse type

Dust-proof  
& drip-proof  
type



## PICK & PLACE ROBOTS

# YP-X SERIES

## CONTENTS

■ YP-X SPECIFICATION SHEET .....	428
■ Robot ordering method description .....	428
■ Robot ordering method terminology .....	428
<b>2 AXES</b>	
YP220BX .....	429
YP320X .....	430
<b>3 AXES</b>	
YP220BXR .....	431
YP320XR .....	432
YP330X .....	433
<b>4 AXES</b>	
YP340X .....	434

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

2-axes

3-axes

4-axes

# YP-X SPECIFICATION SHEET

Type	Model	Maximum payload (kg)	Cycle time (sec) <sup>Note 1</sup>	Structure	Moving range	Detailed info page
2-axes	YP220BX	3	0.45	X-axis: Belt Z-axis: Belt	200mm 100mm	<a href="#">P.429</a>
	YP320X	3	0.57	X-axis: Ball screw Z-axis: Belt	330mm 100mm	<a href="#">P.430</a>
3-axes	YP220BXR	1	0.62	X-axis: Belt Z-axis: Belt	200mm 100mm	<a href="#">P.431</a>
				R-axis: Rotation axis	+/-180°	
	YP320XR	1	0.67	X-axis: Ball screw Z-axis: Belt	330mm 100mm	<a href="#">P.432</a>
				R-axis: Rotation axis	+/-180°	
YP330X	3	0.57	X-axis: Ball screw Y-axis: Ball screw Z-axis: Belt	330mm 150mm 100mm	<a href="#">P.433</a>	
			R-axis: Rotation axis	+/-180°		
4-axes	YP340X	1	0.67	X-axis: Ball screw Y-axis: Ball screw Z-axis: Belt R-axis: Rotation axis	330mm 150mm 100mm +/-180°	<a href="#">P.434</a>

Note 1. Cycle time is the time required for moving back and forth 150mm (arch 50) and vertically 50mm (during rough-positioning motion with 1kg load).

## Robot ordering method description

In the order format for the YAMAHA pick & place robots YP-X series, the notation (letters/numbers) for the mechanical section is shown linked to the controller section notation.

### [Example]

#### ■ 2-axis specifications

##### ● Mechanical ▶ YP220BX

- Robot cable length ▶ 3.5m

##### ● Controller ▶ RCX222

- Usable for CE ▶ Not required
- Input/Output selection 1 ▶ NPN
- Input/Output selection 2 ▶ None

#### ● Ordering method

## YP220BX-3L-RCX222-N

Mechanical section

Controller section

① Model	② Cable length	③ Controller	④ Usable for CE	⑤ Input/Output selection 1	⑥ Input/Output selection 2
YP220BX YP320X	3L 3.5m 5L 5m 10L 10m	RCX222	No entry E Standard CE marking	N NPN <sup>Note 1</sup> P PNP CC CC-Link DN DeviceNet™ PB PROFIBUS EN Ethernet YC YC-Link <sup>Note 2</sup>	No entry None N1 OP.DIO 24/16 (NPN) <sup>Note 1</sup> P1 OP.DIO 24/17 (PNP) EN Ethernet <sup>Note 3</sup>

Note 1. With the CE marking, it is not possible to select NPN or Ethernet.

Note 2. Available only for the master.

Note 3. Only when CC-Link or DeviceNet™ or PROFIBUS was selected for I/O select 1 above. Ethernet can be selected in I/O select 2.

#### ■ 3 / 4 axis specifications

##### ● Mechanical ▶ YP340X

- Robot cable length ▶ 5m

##### ● Controller ▶ RCX240S

#### ● Ordering method

## YP340X-5L-RCX240S

Mechanical section

Controller section

① Model	② Cable length	③ Controller
YP220BXR YP320XR YP330X YP340X	3L 3.5m 5L 5m 10L 10m	RCX240S RCX340

To find detailed controller information see the controller page. [RCX222 ▶ P.524](#), [RCX240S ▶ P.532](#), [RCX340 ▶ P.542](#)

## Robot ordering method terminology

① Model	Enter the robot unit model.
② Cable length	Select the length of the robot cable connecting the robot and controller. 3L: 3.5m      5L: 5m      10L: 10m
③ Controller	<b>2-axis specifications:</b> Select the RCX222. <b>3 / 4 axis specifications:</b> Select either the RCX240S or RCX340.

# YP220BX 2 axes



## Ordering method

<b>YP220BX</b>		<b>RCX222</b>			
<b>Model</b>	<b>Cable length</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Inputs/Outputs selection 1</b>	<b>Inputs/Outputs selection 2</b>
	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 2</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 1</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 2</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. Available only for the master.

Note 2. NPN cannot be selected if using CE marking.

Note 3. Only when you have selected CC, DN or PB for Input/Output selection 1, you can select EN for Input/Output selection 2.

## Specifications

	X axis	Z axis
AC servo motor output (W)	200	200
Repeatability <sup>Note 1</sup> (mm)	+/-0.05	+/-0.05
Drive system	Timing belt	Timing belt
Deceleration ratio (mm)	Equivalent to lead 24	Equivalent to lead 20
Maximum speed <sup>Note 2</sup> (mm/sec)	1440	1200
Moving range (mm)	200	100
Cycle time (sec)	0.45 <sup>Note 3</sup>	
Maximum payload (kg)	3	
Robot cable length (m)	Standard: 3.5 Option: 5,10	
Weight (kg)	17	

Note 1. Positioning repeatability precision in a single swing when residual vibration is stabilized (variable depending on the load and stroke).


Note 2. When the moving stroke is short, the maximum speed may not be reached.

Note 3. Reciprocating time in vertical direction (50mm) and longitudinal direction (150mm) with the arch amount of 50 (when executing rough-positioning arch motion with 1kg load).

## Controller

Controller	Power consumption (VA)	Operating method
RCX222	500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## YP220BX



Note 1. Distance to mechanical stopper.

Note 2. Return-to-origin on the YP220BX is by absolute reset. So the origin position must be set the first time (making initial settings) but after that is not required.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN


CONTROLLER INFORMATION

2-axes

3-axes

4-axes

# YP320X 2 axes



## Ordering method

<b>YP320X</b>		<b>RCX222</b>			
<b>Model</b>	<b>Cable length</b>	<b>Controller</b>	<b>Usable for CE</b>	<b>Inputs/Outputs selection 1</b>	<b>Inputs/Outputs selection 2</b>
	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN <sup>Note 2</sup> P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note 1</sup>	No entry: None N1: OP.DIO24/16 (NPN) <sup>Note 2</sup> P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note 3</sup>

Note 1. Available only for the master.  
 Note 2. NPN cannot be selected if using CE marking.  
 Note 3. Only when you have selected CC, DN or PB for Input/Output selection 1, you can select EN for Input/Output selection 2.

## Specifications


	X axis	Z axis
AC servo motor output (W)	200	200
Repeatability <sup>Note 1</sup> (mm)	+/-0.02	+/-0.05
Drive system	Ball screw (C7 class)	Timing belt
Deceleration ratio (mm)	Equivalent to lead 20	Equivalent to lead 25
Maximum speed <sup>Note 2</sup> (mm/sec)	1500	1500
Moving range (mm)	330	100
Cycle time (sec)	0.57 <sup>Note 3</sup> , 0.78 <sup>Note 4</sup>	
Maximum payload (kg)	3	
Robot cable length (m)	Standard: 3.5 Option: 5,10	
Weight (kg)	21	

Note 1. Positioning repeatability precision in a single swing when residual vibration is stabilized (variable depending on the load and stroke).  
 Note 2. When the moving stroke is short, the maximum speed may not be reached.  
 Note 3. Reciprocating time in vertical direction (50mm) and longitudinal direction (150mm) with the arch amount of 50 (when executing rough-positioning arch motion with 1kg load).  
 Note 4. Reciprocating time in vertical direction (25mm) and longitudinal direction (300mm) with the arch amount of 25 (when executing rough-positioning arch motion with 1kg load).

## Controller

Controller	Power consumption (VA)	Operating method
RCX222	500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## YP320X



Note 1. Distance to mechanical stopper.  
 Note 2. Return-to-origin on the YP320X is by absolute reset. So the origin position must be set the first time (making initial settings) but after that is not required.  
 Note 3. Do not use bolts longer than 20mm (robot bottom plate thickness).

# YP220BXR 3 axes



## Ordering method

**YP220BXR**

Model	Cable length
	3L: 3.5m
	5L: 5m
	10L: 10m

**RCX340-3**

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	iVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications


	X axis	Z axis	R axis
AC servo motor output (W)	200	200	60
Repeatability <sup>Note 1</sup> (mm)	+/-0.05	+/-0.05	+/-0.1
Drive system	Timing belt	Timing belt	Ball Reducer
Deceleration ratio (mm)	Equivalent to lead 24	Equivalent to lead 20	1/18
Maximum speed <sup>Note 2</sup> (XZ: mm/sec) (R: °/sec)	1440	1200	1000
Moving range (XZ: mm) (R: °)	200	100	+/-180
Cycle time (sec)	0.62 <sup>Note 3</sup>		
Maximum payload (kg)	1		
R-axis allowable moment inertia (kgm <sup>2</sup> [kgfcm <sup>2</sup> ])	0.00098 [0.01]		
Robot cable length (m)	Standard: 3.5 Option: 5,10		
Weight (kg)	19		

Note 1. Positioning repeatability precision in a single swing when residual vibration is stabilized (variable depending on the load and stroke).  
 Note 2. When the moving stroke is short, the maximum speed may not be reached.  
 Note 3. Reciprocating time in vertical direction (50mm) and longitudinal direction (150mm) with the arch amount of 50 (when executing rough-positioning arch motion with 1kg load).

## Controller

Controller	Power consumption (VA)	Operating method
RCX340 RCX240S	700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## YP220BXR



Note 1. Distance to mechanical stopper.  
 Note 2. Return-to-origin on the YP220BXR is by absolute reset. So the origin position must be set the first time (making initial settings) but after that is not required.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN


CONTROLLER INFORMATION

2-axes

3-axes

4-axes

# YP320XR 3 axes



## Ordering method

**YP320XR**   **RCX340-3**                

**Model** **Cable length** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

3L: 3.5m  
5L: 5m  
10L: 10m

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240S**                  

**Controller** **CE Marking** **Expansion I/O** **Network option** **iVY System** **Gripper** **Battery**

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Specifications


	X axis	Z axis	R axis
AC servo motor output (W)	200	200	60
Repeatability <sup>Note 1</sup> (XZ: mm) (R: °)	+/-0.02	+/-0.05	+/-0.1
Drive system	Ball screw (C7 class)	Timing belt	Ball Reducer
Deceleration ratio (mm)	Equivalent to lead 20	Equivalent to lead 25	1/18
Maximum speed <sup>Note 2</sup> (XZ: mm/sec) (R: °/sec)	1500	1500	1000
Moving range (XZ: mm) (R: °)	330	100	+/-180
Cycle time (sec)	0.67 <sup>Note 3</sup> , 0.87 <sup>Note 4</sup>		
Maximum payload (kg)	1		
R-axis allowable moment inertia (kgm <sup>2</sup> [kgfcm <sup>2</sup> ])	0.00098 [0.01]		
Robot cable length (m)	Standard: 3.5 Option: 5,10		
Weight (kg)	23		

Note 1. Positioning repeatability precision in a single swing when residual vibration is stabilized (variable depending on the load and stroke).  
 Note 2. When the moving stroke is short, the maximum speed may not be reached.  
 Note 3. Reciprocating time in vertical direction (50mm) and longitudinal direction (150mm) with the arch amount of 50 (when executing rough-positioning arch motion with 1kg load).  
 Note 4. Reciprocating time in vertical direction (25mm) and longitudinal direction (300mm) with the arch amount of 25 (when executing rough-positioning arch motion with 1kg load).

## Controller

Controller	Power consumption (VA)	Operating method
RCX340 RCX240S	700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## YP320XR



Note 1. Distance to mechanical stopper.  
 Note 2. Return-to-origin on the YP320XR is by absolute reset. So the origin position must be set the first time (making initial settings) but after that is not required.  
 Note 3. Do not use bolts longer than 20mm (robot bottom plate thickness).



# YP330X 3 axes



## Ordering method

### YP330X

Model

Cable length  
 3L: 3.5m  
 5L: 5m  
 10L: 10m

### RCX340-3

Controller / Number of controllable axes

Safety standard

Option A (OP.A)

Option B (OP.B)

Option C (OP.C)

Option D (OP.D)

Option E (OP.E)

Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

### RCX240S

Controller

CE Marking

Expansion I/O

Network option

iVY System

Gripper

Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications


	X axis	Y axis	Z axis
AC servo motor output (W)	200	200	200
Repeatability <sup>Note 1</sup> (mm)	+/-0.02	+/-0.02	+/-0.05
Drive system	Ball screw (C7 class)	Ball screw (C7 class)	Timing belt
Deceleration ratio (mm)	Equivalent to lead 20	Equivalent to lead 20	Equivalent to lead 25
Maximum speed <sup>Note 2</sup> (mm/sec)	1500	1000	1500
Moving range (mm)	330	150	100
Cycle time (sec)	0.57 <sup>Note 3</sup> , 0.78 <sup>Note 4</sup>		
Maximum payload (kg)	3		
Robot cable length (m)	Standard: 3.5 Option: 5,10		
Weight (kg)	32		

Note 1. Positioning repeatability precision in a single swing when residual vibration is stabilized (variable depending on the load and stroke).  
 Note 2. When the moving stroke is short, the maximum speed may not be reached.  
 Note 3. Reciprocating time in vertical direction (50mm) and longitudinal direction (150mm) with the arch amount of 50 (when executing rough-positioning arch motion with 1kg load).  
 Note 4. Reciprocating time in vertical direction (25mm) and longitudinal direction (300mm) with the arch amount of 25 (when executing rough-positioning arch motion with 1kg load).

## Controller

Controller	Power consumption (VA)	Operating method
RCX340 RCX240S	700	Programming / I/O point trace / Remote command / Operation using RS-232C communication

YP330X



Note 1. Distance to mechanical stopper.  
 Note 2. Return-to-origin on the YP330X is by absolute reset. So the origin position must be set the first time (making initial settings) but after that is not required.  
 Note 3. Do not use bolts longer than 20mm (robot bottom plate thickness).

Controller

**RCX340 ▶ 542 RCX240S ▶ 532**

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN


CONTROLLER INFORMATION

2-axes

3-axes

4-axes

# YP340X 4 axes



## Ordering method

**YP340X**

Model

Cable length  
3L: 3.5m  
5L: 5m  
10L: 10m

**RCX340-4**

Controller /  
Number of controllable axes

Safety  
standard

Option A  
(OP.A)

Option B  
(OP.B)

Option C  
(OP.C)

Option D  
(OP.D)

Option E  
(OP.E)

Absolute  
battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller

CE Marking

Expansion I/O

Network option

iVY System

Gripper

Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Specifications



	X axis	Y axis	Z axis	R axis
AC servo motor output (W)	200	200	200	60
Repeatability <sup>Note 1</sup> (XYZ: mm)(R: °)	+/-0.02	+/-0.02	+/-0.05	+/-0.1
Drive system	Ball screw (C7 class)	Ball screw (C7 class)	Timing belt	Ball Reducer
Deceleration ratio (mm)	Equivalent to lead 20	Equivalent to lead 20	Equivalent to lead 25	1/18
Maximum speed <sup>Note 2</sup> (XYZ: mm/sec) (R: °/sec)	1500	1000	1500	1000
Moving range (XYZ: mm) (R: °)	330	150	100	+/-180
Cycle time (sec)	0.67 <sup>Note 3</sup> , 0.87 <sup>Note 4</sup>			
Maximum payload (kg)	1			
R-axis allowable moment inertia (kgm <sup>2</sup> [kgfcm <sup>2</sup> ])	0.00098 [0.01]			
Robot cable length (m)	Standard: 3.5 Option: 5,10			
Weight (kg)	34			

Note 1. Positioning repeatability precision in a single swing when residual vibration is stabilized (variable depending on the load and stroke).  
 Note 2. When the moving stroke is short, the maximum speed may not be reached.  
 Note 3. Reciprocating time in vertical direction (50mm) and longitudinal direction (150mm) with the arch amount of 50 (when executing rough-positioning arch motion with 1kg load).  
 Note 4. Reciprocating time in vertical direction (25mm) and longitudinal direction (300mm) with the arch amount of 25 (when executing rough-positioning arch motion with 1kg load).

## Controller

Controller	Power consumption (VA)	Operating method
RCX340 RCX240S	800	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## YP340X



Note 1. Distance to mechanical stopper.  
 Note 2. Return-to-origin on the YP340X is by absolute reset. So the origin position must be set the first time (making initial settings) but after that is not required.  
 Note 3. Do not use bolts longer than 20mm (robot bottom plate thickness).



# CLEAN ROBOTS

# CLEAN

# TYPE

## CONTENTS

### ■ CLEAN ROBOTS SPECIFICATION SHEET ..... 436

#### SINGLE-AXIS

##### ● TRANSERVO

SSC04 .....	439
SSC05 .....	440
SSC05H .....	441

##### ● FLIP-XC

C4L .....	442
C4LH .....	443
C5L .....	444
C5LH .....	445
C6L .....	446
C8 .....	447
C8L .....	448
C8LH .....	449
C10 .....	450
C14 .....	451
C14H .....	452
C17 .....	453
C17L .....	454
C20 .....	455

#### CARTESIAN XY-XC

##### ● 2 axes

SXYxC .....	456
-------------	-----

##### ● 3 axes / ZSC

SXYxC .....	458
-------------	-----

##### ● 4 axes / ZRSC

SXYxC .....	460
-------------	-----

#### SCARA YK-XC

YK180XC .....	462
YK220XC .....	463
YK250XGC .....	464
YK350XGC .....	466
YK400XGC .....	468
YK500XGLC .....	470
YK500XC .....	472
YK600XGLC .....	473
YK600XC .....	475
YK700XC .....	476
YK800XC .....	477
YK1000XC .....	478

# CLEAN ROBOTS SPECIFICATION SHEET

## Clean single-axis robots

### ●TRANSERVO

- Degree of cleanliness CLASS 10
- Intake air 15 to 80Nℓ/min

Model	Lead (mm)	Payload (kg)		Stroke (mm) and maximum speed (mm/sec)																Detailed info page		
		Horizontal	Vertical	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800			
SSC04	12	2	1	600																		P.439
	6	4	2	300																		
	2	6	4	100																		
SSC05	20	4	–	1000						933	833	733	633									P.440
	12	6	1	600						560	500	440	380									
	6	10	2	300						280	250	220	190									
SSC05H	20	6	–	1000						933	833	733	633									P.441
	12	8	–	600						560	500	440	380									
		–	2	500										440	380							
	6	12	–	300						280	250	220	190									
		–	4	250										220	190							

### ●FLIP-XC

- Degree of cleanliness C4L/C4LH/C5L/C5LH/C6L ..... ISO CLASS 3 (ISO14644-1) <sup>Note</sup>  
Models other than those shown above .... CLASS 10  
Note. Class 10 (0.1µm) equivalent to FED-STD-209D
- Intake air 20 to 90Nℓ/min

Model	AC servo motor output (W)	Repeatability (mm)	Lead (mm)	Payload (kg)		Stroke (mm) and maximum speed (mm/sec)																									
				Horizontal	Vertical	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950							
C4L / C4LH	30	+/-0.02	12	4.5	1.2	720																									
			6	6	2.4	360																									
			2	6	7.2	120																									
C5L / C5LH	30	+/-0.02	20	3	–	1000																									
			12	5	1.2	800																									
			6	9	2.4	400																									
C6L	60	+/-0.02	20	10	–	1000																									
			12	12	4	800																									
			6	30	8	400																									
C8	100	+/-0.02	20	12	–	1000						900	800	700	650																
			12	20	4	720						648	540	468	432	360															
			6	40	8	360						324	270	234	216	180															
C8L	100	+/-0.01	20	20	4	1000										900	800	700	650	600											
			10	40	8	600										510	450	390	360	330	300										
			5	50	16	300										255	225	195	180	165	150										
C8LH	100	+/-0.01	20	30	–	1000										900	800	700	650	600	550										
			10	60	–	600										510	450	390	360	330	300	270									
			5	80	–	300										255	225	195	180	165	150	135									
C10	100	+/-0.01	20	20	4	1000										950	750	600													
			10	40	10	500										475	375	300													
			5	60	20	250										237	187	150													
C14	100	+/-0.01	20	30	4	1000										950	750	600													
			10	55	10	500										475	375	300													
			5	80	20	250										237	187	150													
C14H	200	+/-0.01	20	40	8	1000										950	750	600													
			10	80	20	500										475	375	300													
			5	100	30	250										237	187	150													
C17	400	+/-0.01	20	80	15	1000																		800							
			10	120	35	500																		400							
C17L	600	+/-0.02	50	50	10																										
C20	600	+/-0.01	20	120	25	1000																			800						
			10	–	45	500																			400						

																					Detailed info page				
	1000	1050	1100	1150	1200	1250	1300	1350	1400	1450	1500	1550	1600	1650	1700	1750	1800	1850	1900	1950	2000	2050			
																								C4L : <b>P.442</b> C4LH : <b>P.443</b>	
																									C5L : <b>P.444</b> C5LH : <b>P.445</b>
																									<b>P.446</b>
																									<b>P.447</b>
	550	500																							<b>P.448</b>
	270	240																							<b>P.449</b>
	135	120																							<b>P.449</b>
	500	450																							<b>P.450</b>
	240	210																							<b>P.451</b>
	120	105																							<b>P.452</b>
	600	500																							<b>P.453</b>
	300	250																							<b>P.454</b>
	150	125																							<b>P.455</b>
	600	500																							<b>P.453</b>
	300	250																							<b>P.454</b>
	150	125																							<b>P.455</b>
	800	700	600	500																					<b>P.454</b>
	400	350	300	250																					<b>P.455</b>
			1000	1000	1000	1000	1000	1000	1000	1000	900	800	800												<b>P.454</b>
	800	700	600	500																					<b>P.455</b>
	400	350	300	250																					<b>P.455</b>

Clean cartesian robots

● XY-XC

- Degree of cleanliness CLASS 10
- Intake air 60 to 90Nℓ/min
- Aperture designed to minimal dimensions by use of stainless steel sheet
- Installed clean robot dedicated cable duct




Type	Model	Axis	Moving range	Maximum speed (mm/sec)	Maximum payload (kg)	Detailed info page
2 axes	SXYXC	X	150 to 1050mm	1000	20	P.456
		Y	150 to 650mm	1000		
3 axes	SXYXC (ZSC12)	X	150 to 1050mm	1000	3	P.458
		Y	150 to 650mm	1000		
		Z	150mm	1000		
	SXYXC (ZSC6)	X	150 to 1050mm	1000	5	P.458
		Y	150 to 650mm	1000		
		Z	150mm	500		
4 axes	SXYXC (ZRSC12)	X	150 to 1050mm	1000	3	P.460
		Y	150 to 650mm	1000		
		Z	150mm	1000		
		R	360°	1020°/sec		
	SXYXC (ZRSC6)	X	150 to 1050mm	1000	5	P.460
		Y	150 to 650mm	1000		
		Z	150mm	500		
		R	360°	1020°/sec		

Arm variations



Special model for clean rooms with moving Y-axis carriage installed upward.



Clean SCARA robots

● YK-XC/YK-XGC/YK-XGLC

- Degree of cleanliness YK-XC ..... CLASS 10  
YK-XGC/YK-XGLC... ISO CLASS 3 (ISO14644-1) <sup>Note</sup>  
Note. Class 10 (0.1μm) equivalent to FED-STD-209D

- Intake air 30 to 60Nℓ/min
- Harness placed completely on inside

- Bellows cover fitted in axial tip



Passed 20 million stroke durability test

Type	Model	Arm length (mm) and XY axis combined maximum speed (m/s)														Standard cycle time (sec)	Maximum payload (kg)	R axis tolerable moment of inertia (kgm <sup>2</sup> )	Detailed info page		
		120	150	180	220	250	300	350	400	500	600	700	800	900	1000					1200	
Tiny type	YK180XC	3.3m/s														0.42	1	0.01	P.462		
	YK220XC	3.4m/s															0.45	1	0.01	P.463	
Small type	YK250XGC	4.5m/s															0.57	4	0.05	P.464	
	YK350XGC	5.6m/s															0.57	4	0.05	P.466	
	YK400XGC	6.1m/s															0.57	4	0.05	P.468	
Medium type	YK500XGLC	5.1m/s															0.74	4	0.05	P.470	
	YK500XC	4.9m/s															0.53	10	0.12	P.472	
	YK600XGLC	4.9m/s															0.74	4	0.05	P.473	
	YK600XC	5.6m/s															0.56	10	0.12	P.475	
Large type	YK700XC	6.7m/s															0.57	20	0.32	P.476	
	YK800XC	7.3m/s																0.57	20	0.32	P.477
	YK1000XC	8.0m/s																0.60	20	0.32	P.478

# SSC04

- CE compliance
- Origin on the non-motor side is selectable

## Ordering method

<b>SSC04</b>		<b>S</b>						
<b>Model</b>	<b>Lead</b>	<b>Type</b>	<b>Brake</b>	<b>Direction of air coupler installation</b>	<b>Origin position</b>	<b>Stroke</b>	<b>Cable length</b> <sup>Note 2</sup>	
	12: 12mm 6: 6mm 2: 2mm	S: Straight	N: With no brake B: With brake	RJ: Right (Standard) LJ: Left	N: Standard <sup>Note 1</sup> Z: Non-motor side	50 to 400 (50mm pitch)	1L: 1m 3L: 3m 5L: 5m 10L: 10m	

Note 1. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 2. The robot cable is flexible and resists bending.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>Motor</b>	42 □ Step motor
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.02
<b>Deceleration mechanism</b>	Ball screw φ8 (Class C10)
<b>Maximum motor torque (N-m)</b>	0.27
<b>Ball screw lead (mm)</b>	12    6    2
<b>Maximum speed (mm/sec)</b>	600    300    100
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 2    4    6 <b>Vertical</b> 1    2    4
<b>Max. pressing force (N)</b>	45    90    150
<b>Stroke (mm)</b>	50 to 400 (50mm pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+216 <b>Vertical</b> Stroke+261
<b>Maximum outside dimension of body cross-section (mm)</b>	W49 × H59
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10
<b>Degree of cleanliness</b>	CLASS 10 <sup>Note 2</sup>
<b>Intake air (Nl/min)</b>	<b>Lead 12</b> <b>Lead 6</b> <b>Lead 2</b> 50    30    15

Note 1. Positioning repeatability in one direction.  
 Note 2. Per 1cf (0.1µm base), when suction blower is used.

<b>S2</b>	<b>S2</b>	<b>I/O</b>
<b>Robot positioner</b>	S2: TS-S2 <sup>Note 3</sup>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 4</sup>
<b>SH</b>	<b>SH</b>	<b>Battery</b>
<b>Robot positioner</b>	SH: TS-SH	B: With battery (Absolute) N: None (Incremental)
<b>SD</b>	<b>SD</b>	<b>1</b>
<b>Robot driver</b>	SD: TS-SD	I/O cable 1: 1m

## Allowable overhang

Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				Vertical installation (Unit: mm)				
	A	B	C		A	B	C		A	C		
<b>Lead 12</b>	1kg	807	218	292	1kg	274	204	776	<b>Lead 12</b>	0.5kg	407	408
	2kg	667	107	152	2kg	133	93	611		1kg	204	204
<b>Lead 6</b>	2kg	687	116	169	2kg	149	102	656	<b>Lead 6</b>	1kg	223	223
	3kg	556	76	112	3kg	92	62	516		2kg	107	107
	4kg	567	56	84	4kg	63	43	507	<b>Lead 2</b>	2kg	118	118
<b>Lead 2</b>	4kg	869	61	92	4kg	72	48	829		4kg	53	53
	6kg	863	40	60	6kg	39	29	789				

Note. Distance from center of slider upper surface to conveyor center-of-gravity at a guide service life of 10,000 km (Service life is calculated for 400mm stroke models).


## Static loading moment

(Unit: N-m)		
MY	MP	MR
16	19	17

## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control

## SSC04



Effective stroke	50	100	150	200	250	300	350	400
<b>L</b>	266	316	366	416	466	516	566	616
<b>A</b>	2	3	4	5	6	7	8	9
<b>B</b>	3	4	5	6	7	8	9	10
<b>C</b>	50	100	150	200	250	300	350	400
<b>Weight (kg)</b> <sup>Note 5</sup>	1.5	1.6	1.7	1.8	2.0	2.1	2.2	2.3

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Either right or left can be selected for the suction air joint mounting direction. This drawing shows the RJ (standard) direction.  
 Note 3. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 4. The cable's minimum bend radius is R30.  
 Note 5. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.

# SSC05



- High lead: Lead 20
- CE compliance
- Origin on the non-motor side is selectable

## Ordering method

<b>SSC05</b>	<b>S</b>						
Model	Lead	Type	Brake <sup>Note 1</sup>	Direction of air coupler installation	Origin position	Stroke	Cable length <sup>Note 3</sup>
	20: 20mm 12: 12mm 6: 6mm	S: Straight	N: With no brake B: With brake	RJ: Right (Standard) LJ: Left	N: Standard <sup>Note 2</sup> Z: Non-motor side	50 to 800 (50mm pitch)	1L: 1m 3L: 3m 5L: 5m 10L: 10m

<b>S2</b>		
Robot positioner	I/O	Battery
S2: TS-S2 <sup>Note 4</sup>	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>	B: With battery (Absolute) N: None (Incremental)
<b>SH</b>		
Robot positioner	I/O	Battery
SH: TS-SH	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 5</sup>	B: With battery (Absolute) N: None (Incremental)
<b>SD</b>	<b>1</b>	
Robot driver	I/O cable	
SD: TS-SD	t: 1m	

Note 1. Only the model with a lead of 12mm or 6mm can select specifications with brake.  
 Note 2. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 3. The robot cable is flexible and resists bending.  
 Note 4. See P.498 for DIN rail mounting bracket.  
 Note 5. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>Motor</b>	42 □ Step motor
<b>Repeatability <sup>Note 1</sup> (mm)</b>	+/-0.02
<b>Deceleration mechanism</b>	Ball screw φ12 (Class C10)
<b>Maximum motor torque (N·m)</b>	0.27
<b>Ball screw lead (mm)</b>	20    12    6
<b>Maximum speed (mm/sec) <sup>Note 2</sup></b>	1000    600    300
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 4    6    10 <b>Vertical</b> —    1    2
<b>Max. pressing force (N)</b>	27    45    90
<b>Stroke (mm)</b>	50 to 800 (50mm pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+230 <b>Vertical</b> Stroke+270
<b>Maximum outside dimension of body cross-section (mm)</b>	W55 × H56
<b>Cable length (m)</b>	Standard: 1 / Option: 3, 5, 10
<b>Degree of cleanliness</b>	CLASS 10 <sup>Note 3</sup>
<b>Intake air (Nl/min)</b>	Lead 20    Lead 12    Lead 6 80    50    30

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1µm base), when suction blower is used.

## Allowable overhang <sup>Note</sup>

Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				
	A	B	C		A	B	C	
Lead 20	2kg	413	139	218	2kg	192	123	372
Lead 12	4kg	334	67	120	4kg	92	51	265
Lead 6	4kg	347	72	139	4kg	109	57	300
Lead 20	6kg	335	47	95	6kg	63	31	263
Lead 12	4kg	503	78	165	4kg	134	63	496
Lead 6	8kg	332	37	79	6kg	76	35	377
Lead 20	10kg	344	29	62	8kg	47	22	355

## Static loading moment


Static loading moment (Unit: N·m)		
MY	MP	MR
25	33	30

## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	Remote command
TS-SD	Pulse train control

Note. Distance from center of slider upper surface to conveyor center-of-gravity at a guide service life of 10,000 km (Service life is calculated for 600mm stroke models).

## SSC05



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Either right or left can be selected for suction air joint mounting direction. This drawing shows the RJ (standard) direction.  
 Note 3. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 4. The cable's minimum bend radius is R30.  
 Note 5. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.  
 Note 6. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	280	330	380	430	480	530	580	630	680	730	780	830	880	930	980	1030
A	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
B	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
C	100	150	200	250	300	350	400	450	500	500	500	500	500	500	500	500
Weight (kg) <sup>Note 5</sup>	2.1	2.3	2.5	2.7	2.8	3.0	3.2	3.4	3.6	3.8	4.0	4.2	4.4	4.6	4.8	5.0
Maximum speed for each stroke (mm/sec) <sup>Note 6</sup>	1000															
Lead 20	933															
Lead 12	560															
Lead 6	280															




# SSC05H



- High lead: Lead 20
- CE compliance
- Origin on the non-motor side is selectable

## Ordering method




Note 1. Only the model with a lead of 12mm or 6mm can select specifications with brake.  
 Note 2. If changing from the origin position at the time of purchase, the machine reference amount must be reset. For details, refer to the manual.  
 Note 3. The robot cable is flexible and resists bending.  
 Note 4. See P.498 for DIN rail mounting bracket.  
 Note 5. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications


Motor	42 Step motor		
Repeatability	Note 1 (mm) +/-0.02		
Deceleration mechanism	Ball screw φ12 (Class C10)		
Maximum motor torque (N·m)	0.47		
Ball screw lead (mm)	20	12	6
Maximum speed (mm/sec)	Horizontal	1000	600 300
	Vertical	-	500 250
Maximum payload (kg)	Horizontal	6	8 12
	Vertical	-	2 4
Max. pressing force (N)	36	60	120
Stroke (mm)	50 to 800 (50mm pitch)		
Overall length (mm)	Horizontal	Stroke+286	
	Vertical	Stroke+306	
Maximum outside dimension of body cross-section (mm)	W55 × H56		
Cable length (m)	Standard: 1 / Option: 3, 5, 10		
Degree of cleanliness	CLASS 10		
Intake air (Nl/min)	Lead 20	Lead 12	Lead 6
	80	50	30

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1μm base), when suction blower is used.


## Allowable overhang



Horizontal installation (Unit: mm)	A B C		
	A	B	C
Lead 20	2kg 599	225	291
	4kg 366	109	148
	6kg 352	71	104
Lead 12	4kg 500	118	179
	6kg 399	79	118
Lead 6	6kg 573	83	136
	8kg 480	61	100
	10kg 442	47	78
	12kg 465	39	64




Wall installation (Unit: mm)	A B C		
	A	B	C
Lead 20	2kg 262	203	554
	4kg 118	88	309
	6kg 71	49	262
Lead 12	4kg 146	96	449
	6kg 85	55	334
Lead 6	6kg 101	62	519
	8kg 64	39	413
	10kg 43	26	355
	12kg 28	17	338



Vertical installation (Unit: mm)	A C	
	A	C
Lead 12	1kg 458	459
	2kg 224	224
Lead 6	2kg 244	245
	4kg 113	113

## Static loading moment




(Unit: N·m)		
MY	MP	MR
32	38	34

## Controller

Controller	Operation method
TS-S2	I/O point trace / Remote command
TS-SH	I/O point trace / Remote command
TS-SD	Pulse train control

## SSC05H



Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Either right or left can be selected for the suction air joint mounting direction. This drawing shows the RJ (standard) direction.  
 Note 3. Secure the cable with a tie-band 100mm or less from unit's end face to prevent the cable from being subjected to excessive loads.  
 Note 4. The cable's minimum bend radius is R30.  
 Note 5. These are the weights without a brake. The weights are 0.2kg heavier when equipped with a brake.  
 Note 6. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
	L	336	386	436	486	536	586	636	686	736	786	836	886	936	986	1036
A	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
B	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
C	100	150	200	250	300	350	400	450	500	500	500	500	500	500	500	500
Weight (kg)	2.4	2.6	2.8	3.0	3.2	3.4	3.6	3.8	4.0	4.2	4.4	4.5	4.7	4.9	5.1	5.3
Maximum speed for each stroke (mm/sec)	Lead 20															
	Lead 12 (Horizontal)															
	Lead 12 (Vertical)															
	Lead 6 (Horizontal)															
Lead 6 (Vertical)																

Controller

**TS-S2 ▶ 490 TS-SH ▶ 490 TS-SD ▶ 500**

# C4L

Origin on the non-motor side is selectable



## Ordering method

### C4L

Model	Lead designation	Brake	Direction of air coupler installation	Origin position change	Stroke	Cable length <sup>Note 1</sup>	Controller	I/O connector specification
	12: 12mm 6: 6mm 2: 2mm	No entry: With no brake BK: With brake	L: Left (Standard) R: Right	None: Standard Z: Non-motor side	50 to 400 (50mm pitch)	1L: 1m 3L: 3.5m 5L: 5m 10L: 10m 1K/3K/5K/10K (Flexible cable)	ERCD	CN1: I/O flat cable 1m (Standard) CN2: Twisted-pair cable 2m (pulse train function)

Note 1. The robot cable is standard cable (1L/3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.

## Basic specifications

AC servo motor output (W)	30	
Repeatability <sup>Note 1</sup> (mm)	±0.02	
Deceleration mechanism	Ball screw $\phi 8$ (Class C10)	
Ball screw lead (mm)	12	6
Maximum speed (mm/sec)	720	360
Maximum payload (kg)	Horizontal	4.5
	Vertical	1.2
Rated thrust (N)	32	64
	153	
Stroke (mm)	50 to 400 (50mm pitch)	
Overall length (mm)	Horizontal	Stroke+205
	Vertical	Stroke+240
Maximum outside dimension of body cross-section (mm)	W45×H55	
Cable length (m)	Standard: 3.5 / Option: 1.5, 10	
Degree of cleanliness	ISO CLASS 3 (ISO14644-1) <sup>Note 2</sup>	
Intake air (N <sub>l</sub> /min) <sup>Note 3</sup>	50	30

Note 1. Positioning repeatability in one direction.  
 Note 2. CLASS 10 (0.1 $\mu$ m) FED-STD-209D or equivalent when a suction blower is used.  
 Note 3. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang <sup>Note</sup>

	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C	A	C	
Lead 12	2kg	429	87	179	2kg	145	52	368	
	4.5kg	219	32	74	4.5kg	46	0	139	
Lead 6	3kg	511	58	135	3kg	103	22	370	
	6kg	336	26	62	6kg	27	0	185	
Lead 2	3kg	1571	58	142	3kg	109	23	1150	
	6kg	751	27	66	6kg	27	0	420	

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.  
 Note. Service life is calculated for 300mm stroke models.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
15	19	18

## Controller

Controller	Operation method
ERCD	Pulse train control / Programming / I/O point trace / Remote command / Operation using RS-232C communication

## C4L



Effective stroke	50	100	150	200	250	300	350	400
L	255	305	355	405	455	505	555	605
A	4	6	6	8	8	10	10	10
B	1	2	2	2	2	3	3	4
C	150	100	125	125	125	125	125	125
E	0	0	0	50	100	25	75	0
S	70	120	170	220	270	320	370	420
Weight (kg) <sup>Note 3</sup>	1.4	1.5	1.7	1.8	2	2.1	2.3	2.4
Maximum speed for each stroke (mm/sec)	Lead 12	720						
	Lead 6	360						
	Lead 2	120						

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R30.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.  
 Note 4. Either right or left can be selected for the installation direction for the  $\phi 6$  intake air joint. (The left side is the standard.)  
 Note 5. External view of C4LH is identical to C4L.

# C4LH

Origin on the non-motor side is selectable



## Ordering method

### C4LH

<b>Model</b>	<b>Lead designation</b> 12: 12mm 6: 6mm 2: 2mm	<b>Brake</b> No entry: With no brake BK: With brake	<b>Direction of air coupler installation</b> L: Left (Standard) R: Right	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Stroke</b> 50 to 400 (50mm pitch)	<b>Cable length</b> <small>Note 1</small> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>TSX</b> <b>Positioner</b> <small>Note 2</small> TS-X Driver: Power supply voltage / Power capacity 10S: 100V/100W or less 20S: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <small>Note 3</small>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
<b>SR1-X</b> <b>Controller</b>	<b>05</b> Driver: Power capacity 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)	<b>RDV-X</b> <b>Driver</b>	<b>2</b> Power-supply voltage 2: AC200V	<b>05</b> Driver: Power capacity 05: 100W or less			




Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	30
Repeatability <small>Note 1</small> (mm)	+/-0.02
Deceleration mechanism	Ball screw $\phi 8$ (Class C10)
Ball screw lead (mm)	12 6 2
Maximum speed (mm/sec)	720 360 120
Maximum payload (kg)	Horizontal 4.5 6 6 Vertical 1.2 2.4 7.2
Rated thrust (N)	32 64 153
Stroke (mm)	50 to 400 (50mm pitch)
Overall length (mm)	Horizontal Stroke+205 Vertical Stroke+240
Maximum outside dimension of body cross-section (mm)	W45×H55
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	ISO CLASS 3 (ISO14644-1) <small>Note 2</small>
Intake air (Nl/min) <small>Note 3</small>	50 30 15

Note 1. Positioning repeatability in one direction.  
Note 2. CLASS 10 (0.1 $\mu$ m) FED-STD-209D or equivalent when a suction blower is used.  
Note 3. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang Note

Horizontal installation (Unit: mm)				Wall installation (Unit: mm)				Vertical installation (Unit: mm)			
	A	B	C		A	B	C	Lead 12	A	C	
Lead 12	2kg 339	90	174	Lead 12	2kg 136	72	295	Lead 12	1.2kg	118	118
Lead 6	4.5kg 169	37	72	Lead 6	4.5kg 44	20	111	Lead 6	2.4kg	52	54
Lead 2	3kg 234	27	62	Lead 2	3kg 101	41	254	Lead 2	3kg	38	39
Lead 2	6kg 1105	59	142	Lead 2	6kg 27	10	127	Lead 2	7.2kg	0	0
Lead 2	6kg 520	27	66	Lead 2	6kg 110	41	805				
				Lead 2	6kg 28	10	290				

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

Note. Service life is calculated for 300mm stroke models.


## Static loading moment

			(Unit: N·m)		
MY	MP	MR			
15	19	18			

## Controller


Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105	I/O point trace / Remote command
TS-X205	Remote command
RDV-X205	Pulse train control

## C4LH



Effective stroke	50	100	150	200	250	300	350	400
L	255	305	355	405	455	505	555	605
A	4	6	6	8	8	10	10	10
B	1	2	2	2	2	3	3	4
C	150	100	125	125	125	125	125	125
E	0	0	0	50	100	25	75	0
S	70	120	170	220	270	320	370	420
Weight (kg) <small>Note 3</small>	1.4	1.5	1.7	1.8	2	2.1	2.3	2.4
Maximum speed for each stroke (mm/sec)	Lead 12	720						
	Lead 6	360						
	Lead 2	120						

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Minimum bend radius of motor cable is R30.  
Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.  
Note 4. Either right or left can be selected for the installation direction for the  $\phi 6$  intake air joint. (The left side is the standard.)  
Note 5. External view of C4LH is identical to C4L.



# C5L

- High lead: Lead 20
- Origin on the non-motor side is selectable

## Ordering method

<b>C5L</b>							<b>ERCD</b>	
<b>Model</b>	<b>Lead designation</b> 20: 20mm 12: 12mm 6: 6mm	<b>Brake</b> <sup>Note 1</sup> No entry: With no brake BK: With brake	<b>Direction of air coupler installation</b> L: Left (Standard) R: Right	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Stroke</b> 50 to 800 (50mm pitch)	<b>Cable length</b> <sup>Note 2</sup> 1L: 1m 3L: 3.5m 5L: 5m 10L: 10m 1K/3K/5K/10K (Flexible cable)	<b>Controller</b>	<b>I/O connector specification</b> CN1: I/O flat cable 1m (Standard) CN2: Twisted-pair cable 2m (pulse train function)

Note 1. The model with a lead of 20mm cannot select specifications with brake (vertical specifications).  
 Note 2. The robot cable is standard cable (1L/3L/5L/10L), but can be changed to flexible cable.  
 See P.594 for details on robot cable.

## Basic specifications

<b>AC servo motor output (W)</b>	30
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/- 0.02
<b>Deceleration mechanism</b>	Ball screw $\phi 12$ (Class C10)
<b>Ball screw lead (mm)</b>	20 12 6
<b>Maximum speed (mm/sec)</b>	1000 800 400
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 3 5 9 <b>Vertical</b> - 1.2 2.4
<b>Rated thrust (N)</b>	19 32 64
<b>Stroke (mm)</b>	50 to 800 (50mm pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+201.5 <b>Vertical</b> Stroke+236.5
<b>Maximum outside dimension of body cross-section (mm)</b>	W55×H65
<b>Cable length (m)</b>	Standard: 3.5 / Option: 1.5, 10
<b>Degree of cleanliness</b>	ISO CLASS 3 (ISO14644-1) <sup>Note 2</sup>
<b>Intake air (N<math>\ell</math>/min)</b> <sup>Note 3</sup>	80 50 30

Note 1. Positioning repeatability in one direction.  
 Note 2. CLASS 10 (0.1 $\mu$ m) FED-STD-209D or equivalent when a suction blower is used.  
 Note 3. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang

Lead	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)	
	A	B	C	A	B	C	A	C
Lead 20	1584	324	745	679	303	1505	1.2kg	245
Lead 12	699	104	251	215	87	605	2.4kg	110
Lead 6	1166	159	406	364	126	1073		
Lead 20	551	59	155	123	28	438		
Lead 12	1194	104	294	3kg	259	72	354	
Lead 6	624	31	89	9kg	50	0	154	

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.  
 Note. Service life is calculated for 600mm stroke models.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
30	34	40

## Controller

Controller	Operation method
ERCD	Pulse train control / Programming / I/O point trace / Remote command / Operation using RS-232C communication

## C5L



Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	251.5	301.5	351.5	401.5	451.5	501.5	551.5	601.5	651.5	701.5	751.5	801.5	851.5	901.5	951.5	1001.5
A	4	4	4	6	6	6	6	8	8	8	8	10	10	10	10	12
B	0	0	0	1	1	1	1	2	2	2	2	3	3	3	3	4
E	100	200	200	100	100	200	200	100	100	200	200	100	100	200	200	100
S	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
Weight (kg) <sup>Note 3</sup>	1.7	2.0	2.2	2.5	2.7	3.0	3.2	3.4	3.7	3.9	4.2	4.4	4.7	4.9	5.1	5.4
Maximum speed for each stroke (mm/sec) <sup>Note 5</sup>	1000															
Speed setting	-															
Lead 20	90%															
Lead 12	80%															
Lead 6	70%															
Speed setting	-															
	80%															
	70%															
	60%															
	55%															

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R30.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.  
 Note 4. Either right or left can be selected for the installation direction for the  $\phi 6$  intake air joint. (The left side is the standard.)  
 Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.  
 Note 6. External view of C5LH is identical to C5L.

# C5LH

- High lead: Lead 20
- Origin on the non-motor side is selectable



## Ordering method

<b>C5LH</b>	<b>Model</b>	<b>Lead designation</b> 20: 20mm 12: 12mm 6: 6mm	<b>Brake</b> <sup>Note 1</sup> No entry: With no brake BK: With brake	<b>Direction of air coupler installation</b> L: Left (Standard) R: Right	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Stroke</b> 50 to 800 (50mm pitch)	<b>Cable length</b> <sup>Note 2</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>TSX</b>	<b>Positioner</b> <sup>Note 3</sup> TS-X	<b>Driver: Power supply voltage / Power capacity</b> 105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 4</sup>	<b>Battery</b> No entry: None N: None (Incremental)
	<b>SR1-X</b>	<b>Controller</b>	<b>Driver: Power capacity</b> 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)							
	<b>RDV-X</b>	<b>Driver</b>	<b>Power supply voltage</b> 2: AC200V	<b>Driver: Power capacity</b> 05: 100W or less									

Note 1. The model with a lead of 20mm cannot select specifications with brake (vertical specifications).  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	30
Repeatability <sup>Note 1</sup> (mm)	+/-0.02
Deceleration mechanism	Ball screw $\phi 12$ (Class C10)
Ball screw lead (mm)	20 12 6
Maximum speed (mm/sec)	1000 800 400
Maximum payload (kg)	Horizontal: 3 5 9 Vertical: - 1.2 2.4
Rated thrust (N)	19 32 64
Stroke (mm)	50 to 800 (50mm pitch)
Overall length (mm)	Horizontal: Stroke+201.5 Vertical: Stroke+236.5
Maximum outside dimension of body cross-section (mm)	W55×H65
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	ISO CLASS 3 (ISO14644-1) <sup>Note 2</sup>
Intake air (Nl/min) <sup>Note 3</sup>	80 50 30

Note 1. Positioning repeatability in one direction.  
 Note 2. CLASS 10 (0.1 $\mu$ m) FED-STD-209D or equivalent when a suction blower is used.  
 Note 3. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang <sup>Note</sup>

Horizontal installation (Unit: mm)	Wall installation (Unit: mm)			Vertical installation (Unit: mm)	
	A	B	C	A	C
<b>Lead 20</b>	1099	324	645	1kg	602 303 950
<b>Lead 12</b>	916	159	398	2kg	347 141 800
<b>Lead 6</b>	436	60	152	5kg	119 44 355
	1194	105	294	3kg	259 87 950
	624	31	89	9kg	50 15 385

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.  
 Note. Service life is calculated for 600mm stroke models.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
30	34	40

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105	I/O point trace / Remote command
TS-X205	
RDV-X205	Pulse train control

## C5LH




Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
L	251.5	301.5	351.5	401.5	451.5	501.5	551.5	601.5	651.5	701.5	751.5	801.5	851.5	901.5	951.5	1001.5
A	4	4	4	6	6	6	6	8	8	8	8	10	10	10	10	12
B	0	0	0	1	1	1	1	2	2	2	2	3	3	3	3	4
E	100	200	200	100	100	200	200	100	100	200	200	100	100	200	200	100
S	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800
Weight (kg) <sup>Note 3</sup>	1.7	2.0	2.2	2.5	2.7	3.0	3.2	3.4	3.7	3.9	4.2	4.4	4.7	4.9	5.1	5.4
Maximum speed for each stroke <sup>Note 5</sup> (mm/sec)	1000															
Speed setting	90% 80% 70%															
Lead 20	900 800 700															
Lead 12	800															
Lead 6	400															
Speed setting	80% 70% 60% 55%															

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R30.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.  
 Note 4. Either right or left can be selected for the installation direction for the  $\phi 6$  intake air joint. (The left side is the standard.)  
 Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.  
 Note 6. External view of C5LH is identical to C5L.

# C6L

- High lead: Lead 20
- Origin on the non-motor side is selectable



## Ordering method

### C6L

<b>Model</b>	<b>Lead designation</b> 20: 20mm 12: 12mm 6: 6mm	<b>Brake</b> <sup>Note 1</sup> No entry: With no brake BK: With brake	<b>Direction of air coupler installation</b> L: Left (Standard) R: Right	<b>Origin position change</b> None: Standard Z: Non-motor side	<b>Stroke</b> 50 to 800 (50mm pitch)	<b>Cable length</b> <sup>Note 2</sup> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)
--------------	---	---	--	--	---	---

### TSX

<b>Positioner</b> <sup>Note 3</sup> TS-X	<b>Driver: Power supply voltage / Power capacity</b> 105: 100V/100W or less 205: 200V/100W or less	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 4</sup>	<b>Battery</b> 3: With battery (Absolute) N: None (Incremental)
---	--	---	---	---

### SR1-X

<b>Controller</b> 05	<b>Driver: Power capacity</b> 05: 100W or less	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> 3: With battery (Absolute) N: None (Incremental)
-------------------------	---	---	---	---

### RDV-X

<b>Driver</b> 2	<b>Power supply voltage</b> 2: AC200V	<b>Driver: Power capacity</b> 05: 100W or less	<b>Regenerative unit</b> RBR1
--------------------	--	---	----------------------------------

- Note 1. The model with a lead of 20mm cannot select specifications with brake (vertical specifications).
- Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.
- Note 3. See P.498 for DIN rail mounting bracket.
- Note 4. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>AC servo motor output (W)</b>	60
<b>Repeatability</b> <sup>Note 1</sup> (mm)	+/-0.02
<b>Deceleration mechanism</b>	Ball screw $\phi 12$ (Class C10)
<b>Ball screw lead (mm)</b>	20 12 6
<b>Maximum speed (mm/sec)</b>	1000 800 400
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 10 12 30 <b>Vertical</b> - 4 8
<b>Rated thrust (N)</b>	51 85 170
<b>Stroke (mm)</b>	50 to 800 (50mm pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+247.5 <b>Vertical</b> Stroke+282.5
<b>Maximum outside dimension of body cross-section (mm)</b>	W65×H65
<b>Cable length (m)</b>	Standard: 3.5 / Option: 5, 10
<b>Degree of cleanliness</b>	ISO CLASS 3 (ISO14644-1) <sup>Note 2</sup>
<b>Intake air (Nl/min)</b> <sup>Note 3</sup>	80 50 30

- Note 1. Positioning repeatability in one direction.
- Note 2. CLASS 10 (0.1 $\mu$ m) FED-STD-209D or equivalent when a suction blower is used.
- Note 3. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang

Horizontal installation (Unit: mm)	Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C
<b>Lead 20</b>	2kg 433	192	295	2kg 300	174	365
<b>6kg</b>	145	59	104	6kg 83	44	105
<b>10kg</b>	110	33	75	10kg 43	18	71
<b>Lead 12</b>	3kg 622	125	336	3kg 291	96	317
<b>8kg</b>	271	41	121	8kg 87	13	110
<b>12kg</b>	214	24	76	12kg 41	0	126
<b>Lead 6</b>	5kg 692	73	236	5kg 202	45	237
<b>10kg</b>	372	33	109	10kg 70	5	97
<b>30kg</b>	157	0	25	30kg 0	0	0

- Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.
- Note. Service life is calculated for 600mm stroke models.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
35	40	50

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105	I/O point trace / Remote command
TS-X205	I/O point trace / Remote command
RDV-X205-RBR1	Pulse train control

## C6L



Effective stroke	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800					
L	297.5	347.5	397.5	447.5	497.5	547.5	597.5	647.5	697.5	747.5	797.5	847.5	897.5	947.5	997.5	1047.5					
A	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18					
B	0	0	0	1	1	1	1	2	2	2	2	3	3	3	3	4					
E	150	200	200	100	100	200	200	100	100	200	200	100	100	200	200	100					
S	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800					
<b>Weight (kg)</b> <sup>Note 3</sup>	2.6	2.9	3.1	3.4	3.7	4.0	4.3	4.6	4.9	5.2	5.4	5.7	6.0	6.3	6.6	6.8					
<b>Maximum speed for each stroke</b> <sup>Note 5</sup> (mm/sec)	<b>Lead 20</b>	1000																			
	<b>Speed setting</b>	-																			
	<b>Lead 12</b>	800																			
	<b>Lead 6</b>	400																			
<b>Speed setting</b>		-																			
		680			600			520			480			340			260			240	
	85%			75%			65%			60%											

- Note 1. Stop positions are determined by the mechanical stoppers at both ends.
- Note 2. Minimum bend radius of motor cable is R30.
- Note 3. Weight of models with no brake. The weight of brake-attached models is 0.2 kg heavier than the models with no brake shown in the table.
- Note 4. Either right or left can be selected for the installation direction for the  $\phi 6$  intake air joint. (The left side is the standard.)
- Note 5. When the stroke is longer than 600mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



# C8L

Origin on the non-motor side is selectable

## Ordering method

<b>C8L</b>	<b>Model</b>	<b>Lead</b>	<b>Brake</b>	<b>Option</b>	<b>Stroke</b>	<b>Cable length</b> <sup>Note 1</sup>	<b>TSX</b>	<b>Positioner</b> <sup>Note 2</sup>	<b>Driver: Power-supply voltage / Power capacity</b>	<b>LCD monitor</b>	<b>I/O selection</b>	<b>Battery</b>
		20: 20mm 10: 10mm 5: 5mm	No entry: With no brake BK: With brake	Origin position change None: Standard Z: Non-motor side	150 to 1050 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)		TS-X	105: 100V/100W or less 205: 200V/100W or less	No entry: None L: With LCD	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	B: With battery (Absolute) N: None (Incremental)
							<b>SR1-X</b>	<b>Controller</b>	<b>05</b>	Usable for CE No entry: Standard E: CE marking	I/O selection N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	Battery B: With battery (Absolute) N: None (Incremental)
							<b>RDV-X</b>	<b>Driver</b>	<b>2</b>	Power-supply voltage 2: AC200V	<b>05</b>	<b>RBR1</b>
										Driver: Power capacity 05: 100W or less	Driver: Power capacity 05: 100W or less	Regenerative unit

Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	100
Repeatability <sup>Note 1</sup> (mm)	+/-0.01
Deceleration mechanism	Ball screw (Class C7)
Ball screw lead (mm)	20 10 5
Maximum speed (mm/sec)	1000 600 300
Maximum payload (kg)	Horizontal 20 40 50 Vertical 4 8 16
Rated thrust (N)	84 169 339
Stroke (mm)	150 to 1050 (50mm pitch)
Overall length (mm)	Horizontal Stroke+325 Vertical Stroke+360
Maximum outside dimension of body cross-section (mm)	W80 x H75
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	CLASS 10 <sup>Note 3</sup>
Intake air (Nl/min)	30 to 90 <sup>Note 4</sup>

Note 1. Positioning repeatability in one direction.  
Note 2. When the stroke is longer than 700mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
Note 3. Per 1cf (0.1um base), when suction blower is used.  
Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang<sup>Note</sup>

Lead	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C	A	C	
Lead 20	5kg	259	122	179	5kg	147	100	220	
	10kg	149	55	89	10kg	53	32	97	
	15kg	100	33	56	15kg	17	10	39	
	20kg	95	22	41	20kg	0	0	0	
Lead 10	10kg	251	61	130	10kg	87	41	197	
	20kg	127	25	55	20kg	10	4	37	
	30kg	90	14	31	30kg	0	0	0	
	40kg	69	8	18	40kg	0	0	0	
Lead 5	20kg	256	29	76	20kg	24	9	152	
	30kg	188	16	43	30kg	0	0	0	
	40kg	96	10	28	40kg	0	0	0	
	50kg	33	6	18	50kg	0	0	0	

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.


## Static loading moment

	(Unit: N·m)		
	MY	MP	MR
	70	95	110

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105	I/O point trace / Remote command
TS-X205	Remote command
RDV-X205-RBR1	Pulse train control

## C8L



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	
L	475	525	575	625	675	725	775	825	875	925	975	1025	1075	1125	1175	1225	1275	1325	1375	
A	0	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	
B	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	
C	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26	26	
D	280	330	380	430	480	530	580	630	680	730	780	830	880	930	980	1030	1080	1130	1180	
Weight (kg) <sup>Note 3</sup>	3.9	4.2	4.5	4.8	5.1	5.4	5.7	6.0	6.4	6.7	7.0	7.3	7.6	7.9	8.2	8.5	8.8	9.2	9.5	
Maximum speed (mm/sec) <sup>Note 4</sup>	1000																			
	Speed setting	-																		
	Lead 10	600																		
	Lead 5	300																		
Speed setting	-																			
	85% 75% 65% 60% 55% 50% 45% 40%																			

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Minimum bend radius of motor cable is R50.  
Note 3. Weight of models with no brake. The weight of brake-attached models is 0.3 kg heavier than the models with no brake shown in the table.  
Note 4. When the stroke is longer than 700mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



# C8LH

Origin on the non-motor side is selectable

## Ordering method

**C8LH**

Model	Lead	Option	Stroke	Cable length <sup>Note 1</sup>	TSX	SR1-X	RDV-X
	20: 20mm 10: 10mm 5: 5mm	Origin position change None: Standard Z: Non-motor side	150 to 1050 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>Positioner</b> <sup>Note 2</sup> TS-X Driver: Power supply voltage / Power capacity 105: 100V/100W or less 205: 200V/100W or less LCD monitor No entry: None L: With LCD	<b>Controller</b> SR1-X Driver: Power capacity 05: 100W or less Usable for CE No entry: Standard E: CE marking	<b>Driver</b> RDV-X Power supply voltage 2: AC200V Driver: Power capacity 05: 100W or less <b>Regenerative unit</b> RBR1
					<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)


Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
Note 2. See P.498 for DIN rail mounting bracket.  
Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	100
Repeatability <sup>Note 1</sup> (mm)	+/-0.01
Deceleration mechanism	Ball screw (Class C7)
Ball screw lead (mm)	20 10 5
Maximum speed <sup>Note 2</sup> (mm/sec)	1000 600 300
Maximum payload (kg)	Horizontal 30 60 80
Rated thrust (N)	84 169 339
Stroke (mm)	150 to 1050 (50mm pitch)
Overall length (mm)	Stroke+389
Maximum outside dimension of body cross-section (mm)	W80 x H75
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	CLASS 10 <sup>Note 3</sup>
Intake air (N <sub>2</sub> /min)	30 to 90 <sup>Note 4</sup>

Note 1. Positioning repeatability in one direction.  
Note 2. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
Note 3. Per 1cf (0.1um base), when suction blower is used.  
Note 4. The necessary intake amount varies depending on the use conditions and environment.


## Allowable overhang <sup>Note</sup>



	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)		
	A	B	C	A	B	C
Lead 20	10kg	687	274	200	163	225
	20kg	401	125	92	56	76
	30kg	338	76	57	20	27
Lead 10	20kg	622	137	111	74	90
	40kg	472	57	47	40kg	8
	60kg	375	30	25	60kg	-
Lead 5	20kg	1087	148	127	20kg	89
	40kg	844	63	54	40kg	15
	60kg	707	34	29	60kg	-
	80kg	594	20	17	80kg	-

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment




(Unit: N·m)		
MY	MP	MR
128	163	143

## Controller

Controller	Operation method
SR1-X05 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X105	I/O point trace / Remote command
TS-X205	
RDV-X205-RBR1	Pulse train control

## C8LH



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050
L	539	589	639	689	739	789	839	889	939	989	1039	1089	1139	1189	1239	1289	1339	1389	1439
A	1	1	2	2	3	3	4	4	5	5	6	6	7	7	8	8	9	9	10
B	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100	150	100
C	8	8	10	10	12	12	14	14	16	16	18	18	20	20	22	22	24	24	26
D	330	380	430	480	530	580	630	680	730	780	830	880	930	980	1030	1080	1130	1180	1230
Weight (kg)	4.7	5.0	5.3	5.6	5.9	6.2	6.6	6.9	7.2	7.5	7.8	8.1	8.4	8.7	9.0	9.3	9.7	10.0	10.3
Maximum speed <sup>Note 3</sup> (mm/sec)	Lead 20																		
	Speed setting																		
	Lead 10																		
	Lead 5																		
Speed setting																			

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
Note 2. Minimum bend radius of motor cable is R50.  
Note 3. When the stroke is longer than 650mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Single-axis  
Cartesian  
SCARA

# C10

Origin on the non-motor side is selectable: Lead 20 • 10



## Ordering method

<b>C10</b>	<b>Model</b>	<b>Lead</b>	<b>Brake</b>	<b>Option</b>	<b>Stroke</b>	<b>Cable length</b> <sup>Note 2</sup>	<b>TSX</b>	<b>SR1-X</b>	<b>RDV-X</b>	<b>I/O selection</b>	<b>Battery</b>
		20: 20mm 10: 10mm 5: 5mm	No entry: With no brake BK: With brake	Origin position change None: Standard Z: Non-motor side <sup>Note 1</sup>	150 to 1050 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>Positioner</b> <sup>Note 3</sup> TS-X Driver: Power-supply voltage / Power capacity 105: 100V/100W or less 205: 200V/100W or less Regenerative unit No entry: None R: With RGT LCD monitor No entry: None L: With LCD	<b>Controller</b> 05 Driver: Power capacity 05: 100W or less Usable for CE No entry: Standard E: CE marking Regenerative unit No entry: None R: With RGT	<b>Driver</b> 2 Power-supply voltage 2: AC200V 05 Driver: Power capacity 05: 100W or less	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 4</sup>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
										<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
										<b>Regenerative unit</b> RBR1	

- Note 1. If selecting 5mm lead specifications then the origin point cannot be changed to the non-motor side.  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	100
Repeatability <sup>Note 1</sup> (mm)	+/-0.01
Deceleration mechanism	Ball screw (Class C7)
Ball screw lead (mm)	20 10 5
Maximum speed (mm/sec)	1000 500 250
Maximum payload (kg)	Horizontal 20 40 60 Vertical 4 10 20
Rated thrust (N)	84 169 339
Stroke (mm)	150 to 1050 (50mm pitch)
Overall length (mm)	Horizontal Stroke+283 Vertical Stroke+313
Maximum outside dimension of body cross-section (mm)	W104 x H85
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	CLASS 10 <sup>Note 3</sup>
Intake air (Nl/min)	30 to 90 <sup>Note 4</sup>

- Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1um base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang

Installation	Lead	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)				
		A	B	C	A	B	C	A	C			
Horizontal	Lead 20	5kg	1875	530	510	5kg	496	451	1826	1kg	2461	2492
		10kg	1079	247	242	10kg	218	168	1002	2kg	1213	1244
		20kg	628	106	107	20kg	78	27	497	4kg	585	617
	Lead 10	15kg	765	156	164	10kg	230	170	1036	8kg	627	658
		30kg	425	62	66	20kg	80	29	506	10kg	280	312
Wall	Lead 10	15kg	350	38	42	10kg	30	0	311	10kg	210	242
		30kg	960	63	68	10kg	234	170	2716	10kg	213	244
	Lead 5	50kg	565	25	28	20kg	82	29	1206	15kg	119	151
		60kg	470	16	17	30kg	31	0	711	20kg	72	104

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


(Unit: N·m)		
MY	MP	MR
119	119	105

## Controller

Controller	Operation method
SR1-X05 <sup>Note</sup>	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221/222	
RCX240/340	
TS-X105 <sup>Note</sup>	I/O point trace / Remote command
TS-X205 <sup>Note</sup>	
RDV-X205-RBR1	Pulse train control

Note. Regenerative unit is required when the models used vertically and with 700mm or larger stroke.

## C10



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	
L	433	483	533	583	633	683	733	783	833	883	933	983	1033	1083	1133	1183	1233	1283	1333	
A	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	
M	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	
N	4	6	6	6	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	
Weight (kg) <sup>Note 3</sup>	4.4	5.0	5.5	6.1	6.7	7.3	7.8	8.4	9.0	9.6	10.1	10.7	11.3	11.9	12.4	13.0	13.6	14.2	14.7	
Maximum speed (mm/sec) <sup>Note 4</sup>	Lead 20	1000																		
	Lead 10	500																		
	Lead 5	250																		
Speed setting	95% 95% 75% 75% 60% 60% 50%																			

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R50.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 0.4 kg heavier than the models with no brake shown in the table.  
 Note 4. When the stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



## Ordering method

C14					TSX					SR1-X					RDV-X							
Model	Lead	Brake	Option	Stroke	Cable length	Positioner	Driver: Power-supply voltage / Power capacity	Regenerative unit	LCD monitor	I/O selection	Battery	Controller	Driver: Power capacity	Usable for CE	Regenerative unit	I/O selection	Battery	Driver	Power-supply voltage	Driver: Power capacity	Regenerative unit	
	20: 20mm 10: 10mm 5: 5mm	No entry: With no brake BK: With brake	Origin position change None: Standard Z: Non-motor side	150 to 1050 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	TS-X	105: 100V/100W or less 205: 200V/100W or less	No entry: None R: With RGT	No entry: None L: With LCD	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <sup>Note 3</sup>	B: With battery (Absolute) N: None (Incremental)	SR1-X	05: 100W or less	No entry: Standard E: CE marking	No entry: None R: With RG1	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	B: With battery (Absolute) N: None (Incremental)	RDV-X	2: AC200V	05: 100W or less	RBR1	

Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	100
Repeatability <sup>Note 1</sup> (mm)	+/-0.01
Deceleration mechanism	Ball screw (Class C7)
Ball screw lead (mm)	20    10    5
Maximum speed (mm/sec)	1000   500   250
Maximum payload (kg)	Horizontal: 30, 55, 80 Vertical: 4, 10, 20
Rated thrust (N)	84, 169, 339
Stroke (mm)	150 to 1050 (50mm pitch)
Overall length (mm)	Horizontal: Stroke+285 Vertical: Stroke+315
Maximum outside dimension of body cross-section (mm)	W136 x H96
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	CLASS 10 <sup>Note 3</sup>
Intake air (Nl/min)	30 to 90 <sup>Note 4</sup>

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1um base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang<sup>Note</sup>

	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C	A	C	
Lead 20	5kg: 2127	15kg: 1177	30kg: 1247	5kg: 1047	15kg: 387	30kg: 206	1kg: 600	2kg: 1200	
Lead 10	5kg: 1384	15kg: 459	30kg: 242	5kg: 968	15kg: 264	30kg: 97	4kg: 1141	8kg: 885	
Lead 5	5kg: 968	15kg: 323	30kg: 182	5kg: 658	15kg: 180	30kg: 127	10kg: 1216	20kg: 943	

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


	MY	MP	MR
(Unit: N·m)	232	233	204

## Controller

Controller	Operation method
SR1-X-05 <sup>Note</sup>	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX21/22/222 / RCX240/340	
TS-X105 <sup>Note</sup>	I/O point trace / Remote command
TS-X205 <sup>Note</sup>	
RDV-X205-RBR1	Pulse train control

Note. Regenerative unit is required when the models used vertically with 700mm or larger stroke.

## C14



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	
L	435	485	535	585	635	685	735	785	835	885	935	985	1035	1085	1135	1185	1235	1285	1335	
A	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	
M	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	
N	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	
Weight (kg) <sup>Note 3</sup>	9.2	9.9	10.5	11.2	11.7	12.4	13.0	13.7	14.3	15.0	15.5	16.2	16.8	17.5	18.1	18.8	19.3	20.0	20.6	
Maximum speed (mm/sec) <sup>Note 4</sup>	Lead 20	1000																		
	Lead 10	500																		
	Lead 5	250																		
	Speed setting	95%																		

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R50.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 0.4 kg heavier than the models with no brake shown in the table.  
 Note 4. When the stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# C14H

● Origin on the non-motor side is selectable: Lead 20 • 10



## Ordering method

**C14H**

Model	Lead	Brake	Option	Stroke	Cable length	TSX	SR1-X	RDV-X	Battery
	20: 20mm 10: 10mm 5: 5mm	No entry: With no brake BK: With brake	Origin position change None: Standard Z: Non-motor side	150 to 1050 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	Positioner TS-X Driver: Power-supply voltage / Power capacity 110: 100V/200W 210: 200V/200W Regenerative unit No entry: None R: With RGT LCD monitor No entry: None L: With LCD	Controller 10 Driver: Power capacity 10: 200W Usable for CE No entry: Standard E: CE marking Regenerative unit No entry: None R: With RG1	Driver 2 Power-supply voltage 2: AC200V 10 Driver: Power capacity 10: 200W or less	I/O selection N: NPN P: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board Battery B: With battery (Absolute) N: None (Incremental)

Note 1. If selecting 5mm lead specifications then the origin point cannot be changed to the non-motor side.  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	200
Repeatability (mm)	+/-0.01
Deceleration mechanism	Ball screw (Class C7)
Ball screw lead (mm)	20 10 5
Maximum speed (mm/sec)	1000 500 250
Maximum payload (kg)	Horizontal 40 80 100 Vertical 8 20 30
Rated thrust (N)	170 341 683
Stroke (mm)	150 to 1050 (50mm pitch)
Overall length (mm)	Horizontal Stroke+349 Vertical Stroke+379
Maximum outside dimension of body cross-section (mm)	W136 x H96
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	CLASS 10
Intake air (Nl/min)	30 to 90

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1um base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang

Lead	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)				
	A	B	C	A	B	C	Lead 20	A	C		
Lead 20	10kg	2247	1675	958	10kg	987	1210	1678	4kg	2400	2008
	20kg	1397	855	528	20kg	497	548	958	6kg	1687	1358
	40kg	1037	445	318	40kg	247	217	598	8kg	1287	1033
Lead 10	30kg	1937	583	478	30kg	402	328	1238	10kg	1347	1088
	50kg	1637	364	323	50kg	227	152	878	15kg	887	718
	80kg	1717	242	235	80kg	119	74	678	20kg	657	538
Lead 5	60kg	2443	311	313	60kg	197	108	1308	20kg	747	608
	80kg	2193	242	250	80kg	127	53	1008	25kg	663	484
	100kg	2000	202	213	100kg	85	20	788	30kg	491	396

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


(Unit: N·m)		
MY	MP	MR
293	294	258

## Controller

Controller	Operation method
SR1-X10	Programming / I/O point trace / Remote command
RCX221/222	Operation using RS-232C communication
RCX240/340	I/O point trace / Remote command
TS-X110	Pulse train control
TS-X210	
RDV-X210-RBR1	

Note. Regenerative unit is required when used vertically.

## C14H



Effective stroke	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050
	L	499	549	599	649	699	749	799	849	899	949	999	1049	1099	1149	1199	1249	1299	1349
A	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100
M	0	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5
N	6	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16
Weight (kg)	10.7	11.4	12.0	12.7	13.2	13.9	14.5	15.2	15.8	16.5	17.0	17.7	18.3	19.0	19.6	20.3	20.8	21.5	22.1
Maximum speed (mm/sec)	Lead 20	1000																	
	Lead 10	500																	
	Lead 5	250																	
	Speed setting	95% 95% 75% 75% 60% 60% 50%																	

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R50.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 0.4 kg heavier than the models with no brake shown in the table.

Note 4. When the stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# C17

Origin on the non-motor side is selectable



## Ordering method

<b>C17</b>	<b>Model</b>	<b>Lead</b>	<b>Brake</b>	<b>Option</b>	<b>Stroke</b>	<b>Cable length</b> <small>Note 1</small>	<b>TSX</b>	<b>220</b>			<b>I/O selection</b>	<b>Battery</b>
		20: 20mm 10: 10mm	No entry: With no brake BK: With brake	Origin position change None: Standard Z: Non-motor side	200 to 1250 (50mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>Positioner</b> <small>Note 2</small> TS-X	<b>Driver: Power supply voltage / Power capacity</b> 220: 200V/400 to 600W	<b>Regenerative unit</b> No entry: None R: With RGT	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board <small>Note 3</small>	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>SR1-X</b>	<b>20</b>			<b>I/O selection</b>	<b>Battery</b>
							<b>Controller</b>	<b>Driver: Power capacity</b> 20: 400 to 600W	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>Regenerative unit</b> No entry: None R: With RG1	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>RDV-X</b>	<b>2</b>		<b>20</b>		<b>Regenerative unit</b>
							<b>Driver</b>	<b>Power supply voltage</b> 2: AC200V		<b>Driver: Power capacity</b> 20: 400W or less		<b>Regenerative unit</b> RBR1 (Horizontal) RBR2 (Vertical)

Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

<b>AC servo motor output (W)</b>	400
<b>Repeatability</b> <small>Note 1</small> (mm)	+/-0.01
<b>Deceleration mechanism</b>	Ball screw (Class C7)
<b>Ball screw lead (mm)</b>	20 10
<b>Maximum speed</b> <small>Note 2</small> (mm/sec)	1000 600
<b>Maximum payload (kg)</b>	<b>Horizontal</b> 80 120 <b>Vertical</b> 15 35
<b>Rated thrust (N)</b>	339 678
<b>Stroke (mm)</b>	200 to 1250 (50mm pitch)
<b>Overall length (mm)</b>	<b>Horizontal</b> Stroke+395 <b>Vertical</b> Stroke+425
<b>Maximum outside dimension of body cross-section (mm)</b>	W168 x H114
<b>Cable length (m)</b>	Standard: 3.5 / OP: 5, 10
<b>Degree of cleanliness</b>	CLASS 10 <small>Note 3</small>
<b>Intake air (Nl/min)</b>	30 to 90 <small>Note 4</small>

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 950mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1um base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang

	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)		
	A	B	C	A	B	C	A	C	
<b>Lead 20</b>									
30kg	2660	871	1040	1017	789	2576	5kg	3000 3000	
50kg	1911	508	615	583	426	1808	10kg	2443 2443	
80kg	1541	303	377	338	221	1380	15kg	1633 1633	
<b>Lead 10</b>									
60kg	2443	418	580	525	336	2443	15kg	1728 1728	
100kg	2000	237	330	271	155	2000	25kg	1013 1013	
120kg	1841	192	268	207	109	1841	35kg	707 707	

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


(Unit: N·m)		
MY	MP	MR
1032	1034	908

## Controller

Controller	Operation method
SR1-X20 <small>Note</small>	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX221/222	Programming / I/O point trace / Remote command / Operation using RS-232C communication
RCX240/340	Programming / I/O point trace / Remote command
TS-X220 <small>Note</small>	I/O point trace / Remote command
RDV-X220-RBR1	Pulse train control (Horizontal)
RDV-X220-RBR2	Pulse train control (Vertical)

Note. Regenerative unit is required when used perpendicularly and moving at maximum speeds exceeding 1000mm/sec.

## C17



Effective stroke	L	Stroke (mm)																					
		200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250
<b>L</b>	595	645	695	745	795	845	895	945	995	1045	1095	1145	1195	1245	1295	1345	1395	1445	1495	1545	1595	1645	
<b>A</b>	50	100	150	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150
<b>M</b>	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	4	5	5	5	5	6	6	6
<b>N</b>	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	14	16	16	16	16	18	18	18
<b>Weight (kg)</b> <small>Note 3</small>	15.0	16.0	17.0	17.9	18.9	19.8	20.8	21.7	22.7	23.6	24.6	25.5	26.5	27.4	28.4	29.3	30.3	31.2	32.2	33.1	34.1	35.0	
<b>Maximum speed</b> <small>Note 4</small>																							
<b>Lead 20</b>																							
<b>Lead 10</b>																							
<b>Speed setting</b>																							

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R50.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 1.5 kg heavier than the models with no brake shown in the table.  
 Note 4. When the stroke is longer than 950mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# C17L

● Origin on the non-motor side is selectable

Note. Built-to-order product. Contact us for the delivery period.

## Ordering method

**C17L - 50**

Model	Lead	Brake	Option	Stroke	Cable length
		No entry: With no brake BK: With brake	Origin position change None: Standard Z: Non-motor side	1150 to 2050 (100mm pitch)	3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)

Positioner	220	R	LCD monitor	I/O selection	Battery
TS-X	Driver: Power-supply voltage / Power capacity 220: 200V/400 to 600W	Regenerative unit R: With RGT	No entry: None L: With LCD	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: No I/O board	B: With battery (Absolute) N: None (Incremental)

Controller	20	R	I/O selection	Battery
SR1-X	Driver: Power capacity 20: 400 to 600W	Usable for CE No entry: Standard E: CE marking	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	B: With battery (Absolute) N: None (Incremental)

Driver	2	20	Regenerative unit
RDV-X	Power-supply voltage 2: AC200V	Driver: Power capacity 20: 400W or less	RBR1 (Horizontal) RBR2 (Vertical)

Note 1. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 2. See P.498 for DIN rail mounting bracket.  
 Note 3. Acceleration / deceleration is different depending the Positioner or Controller or Driver.  
 Note 4. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	600
Repeatability (mm)	+/-0.02
Deceleration mechanism	Ball screw (Class C10)
Ball screw lead (mm)	50
Maximum speed (mm/sec)	1000
Maximum payload (kg)	Horizontal: 50 Vertical: 10
Rated thrust (N)	204
Stroke (mm)	1150 to 2050 (100 pitch)
Overall length (mm)	Horizontal: Stroke+485 Vertical: Stroke+515
Maximum outside dimension of body cross-section (mm)	W168 x H114
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	CLASS 10
Intake air (Nl/min)	30 to 90

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 1850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1um base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang

Lead 50	Horizontal installation (Unit: mm)			Wall installation (Unit: mm)			Vertical installation (Unit: mm)			
	A	B	C	A	B	C	A	C		
10kg	4000	2687	3327	10kg	3436	2605	4000	2kg	1200	1200
30kg	3045	872	929	30kg	1169	790	3045	5kg	3000	3000
50kg	2602	509	714	50kg	666	427	2602	10kg	2579	2579

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.


## Static loading moment

(Unit: N·m)		
MY	MP	MR
1032	1034	908

## Controller

Controller	Operation method
SR1-X20-R RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X220-R	I/O point trace / Remote command
RDV-X220-RBR1 (Horizontal) RDV-X220-RBR2 (Vertical)	Pulse train control

## C17L



Effective stroke	1150	1250	1350	1450	1550	1650	1750	1850	1950	2050
L	1635	1735	1835	1935	2035	2135	2235	2335	2435	2535
A	200	100	200	100	200	100	200	100	200	100
M	5	6	6	7	7	8	8	9	9	10
N	16	18	18	20	20	22	22	24	24	26
Weight (kg) Note 3	39.1	41.2	43.2	45.2	47.3	49.3	51.3	53.4	55.4	57.4
Maximum speed (mm/sec) Note 4	Lead 50					Speed setting				
	1000					-				
						90%				
						80%				

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R50.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 1.5 kg heavier than the models with no brake shown in the table.  
 Note 4. When the stroke is longer than 1850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# C20

● Origin on the non-motor side is selectable



## Ordering method

<b>C20</b>	<b>Model</b>	<b>Lead</b> 20: 20mm 10: 10mm	<b>Brake</b> No entry: With no brake BK: With brake	<b>Option</b> Origin position change None: Standard Z: Non-motor side	<b>Stroke</b> 200 to 1250 (50mm pitch)	<b>Cable length</b> 3L: 3.5m 5L: 5m 10L: 10m 3K/5K/10K (Flexible cable)	<b>TSX</b>	<b>220</b>	<b>I/O selection</b>	<b>Battery</b>		
							<b>Positioner</b> TS-X	<b>Driver: Power supply voltage / Power capacity</b> 220: 200V/400 to 600W	<b>Regenerative unit</b> No entry: None R: With RGT	<b>LCD monitor</b> No entry: None L: With LCD	<b>I/O selection</b> NP: NPN PN: PNP CC: CC-Link EP: EtherNet/IP™ DN: DeviceNet™ PT: PROFINET GW: No I/O board	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>SR1-X</b>	<b>20</b>	<b>Usable for CE</b> No entry: Standard E: CE marking	<b>Regenerative unit</b> No entry: None R: With RG1	<b>I/O selection</b> N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS	<b>Battery</b> B: With battery (Absolute) N: None (Incremental)
							<b>RDV-X</b>	<b>2</b>	<b>Power supply voltage</b> 2: AC200V	<b>20</b>	<b>Regenerative unit</b> RBR1 (Horizontal) RBR2 (Vertical)	

Note 1. Only the model with specifications with brake (vertical specifications) can select a lead of 10mm.  
 Note 2. The robot cable is standard cable (3L/5L/10L), but can be changed to flexible cable. See P.594 for details on robot cable.  
 Note 3. See P.498 for DIN rail mounting bracket.  
 Note 4. Acceleration / deceleration is different depending the Positioner or Controller or Driver.  
 Note 5. Select this selection when using the gateway function. For details, see P.60.

## Basic specifications

AC servo motor output (W)	600
Repeatability (mm)	+/-0.01
Deceleration mechanism	Ball screw (Class C7)
Ball screw lead (mm)	20 10
Maximum speed (mm/sec)	1000 500
Maximum payload (kg)	Horizontal 120 Vertical 25 45
Rated thrust (N)	510 1020
Stroke (mm)	200 to 1250 (50mm pitch)
Overall length (mm)	Horizontal Stroke+441 Vertical Stroke+471
Maximum outside dimension of body cross-section (mm)	W202 x H117
Cable length (m)	Standard: 3.5 / Option: 5, 10
Degree of cleanliness	CLASS 10
Intake air (Nl/min)	30 to 90

Note 1. Positioning repeatability in one direction.  
 Note 2. When the stroke is longer than 950mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 3. Per 1cf (0.1um base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Allowable overhang

Horizontal installation (Unit: mm)	Lead 20		
	50kg	2602	869 1145
Wall installation (Unit: mm)	Lead 20		
	50kg	1144	798 2602
Vertical installation (Unit: mm)	Lead 10		
	15kg	2711	2711
Horizontal installation (Unit: mm)	Lead 20		
	50kg	1144	798 2602
Wall installation (Unit: mm)	Lead 20		
	50kg	717	456 2193
Vertical installation (Unit: mm)	Lead 10		
	15kg	2711	2711
Horizontal installation (Unit: mm)	Lead 20		
	50kg	1144	798 2602
Wall installation (Unit: mm)	Lead 20		
	50kg	717	456 2193
Vertical installation (Unit: mm)	Lead 10		
	15kg	2711	2711

Note. Distance from center of slider top to center of gravity of object being carried at a guide service life of 10,000 km.

## Static loading moment


	(Unit: N·m)		
	MY	MP	MR
	1101	1103	968

## Controller

Controller	Operation method
SR1-X20 RCX221/222 RCX240/340	Programming / I/O point trace / Remote command / Operation using RS-232C communication
TS-X220	I/O point trace / Remote command
RDV-X220-RBR1 RDV-X220-RBR2	Pulse train control (Horizontal) Pulse train control (Vertical)

Note. Regenerative unit is required when used vertically and moving at maximum speeds exceeding 1000mm/sec.

## C20



Effective stroke	200	250	300	350	400	450	500	550	600	650	700	750	800	850	900	950	1000	1050	1100	1150	1200	1250		
L	641	691	741	791	841	891	941	991	1041	1091	1141	1191	1241	1291	1341	1391	1441	1491	1541	1591	1641	1691		
A	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100	150	200	50	100		
M	1	1	1	1	2	2	2	2	3	3	3	3	4	4	4	5	5	5	5	5	6	6		
N	8	8	8	8	10	10	10	10	12	12	12	12	14	14	14	16	16	16	16	16	18	18		
Weight (kg)	25.0	26.0	27.0	28.0	29.0	30.0	31.0	32.0	33.0	34.0	35.0	36.0	37.0	38.0	39.0	40.0	41.0	42.0	43.0	44.0	45.0	46.0		
Maximum speed (mm/sec)	Lead 20																							
	Lead 10																							
Speed setting																								

Note 1. Stop positions are determined by the mechanical stoppers at both ends.  
 Note 2. Minimum bend radius of motor cable is R50.  
 Note 3. Weight of models with no brake. The weight of brake-attached models is 2.0 kg heavier than the models with no brake shown in the table.  
 Note 4. When the stroke is longer than 950mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

Controller

**SR1-X ▶ 516 TS-X ▶ 490 RDV-X ▶ 504**

# SXYxC 2 axes

● Clean type ● Cable duct



## Ordering method

<b>SXYxC</b>	<b>D</b>					<b>RCX222</b>			
Model	Cable	Combination	X axis stroke	Y axis stroke	Cable length	Controller	Usable for CE	Input/Output selection 1	Input/Output selection 2
	D: Cable duct	T1 T2 T3	15 to 105cm	15 to 65cm	3L: 3.5m 5L: 5m 10L: 10m	RCX222	No entry: Standard E: CE marking	N: NPN P: PNP CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet YC: YC-Link	No entry: None N: OP.DIO24/16 (NPN) P: OP.DIO24/17 (PNP) EN: Ethernet

Note 1. NPN cannot be selected if using CE marking.  
 Note 2. Available only for the master. See P.66 for details on YC-Link system.  
 Note 3. Only when CC or DN or PB was selected for I/O select 1 above, EN can be selected in I/O select 2.

## Basic specifications

	X axis	Y axis
<b>Axis construction</b> <small>Note 1</small>	C14H	C14
<b>AC servo motor output (W)</b>	200	100
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1000	1000
<b>Moving range (mm)</b>	150 to 1050	150 to 650
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10	
<b>Degree of cleanliness</b>	CLASS 10 <small>Note 5</small>	
<b>Intake air (Nl/min)</b>	60 <small>Note 6</small>	

Note 1. Use caution that the frame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 5. Per 1cf (0.1µm base), when suction blower is used.  
 Note 6. The necessary intake amount varies depending on the use conditions and environment.


## Maximum payload (kg)

Y stroke (mm)	XY 2 axes
150	20
250	17
350	15
450	13
550	11
650	9

## Controller

Controller	Operation method
RCX222	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYxC 2 axes T1




X stroke	150	250	350	450	550	650	750	850	950	1050
	L	628	728	828	928	1028	1128	1228	1328	1428
K	200	100	200	100	200	100	200	100	200	100
M	0	1	1	2	2	3	3	4	4	5
N	6	8	8	10	10	12	12	14	14	16
Y stroke	150	250	350	450	550	650				
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 2</small>	X axis		1000			800		650	550	
<b>Speed setting</b>			-			80%		65%	55%	

Note 1. The moving range when returning to origin and the stop position when stopping by mechanical stopper.  
 Note 2. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.



SXYxC 2 axes T3



X stroke	150	250	350	450	550	650	750	850	950	1050	
L	628	728	828	928	1028	1128	1228	1328	1428	1528	
K	200	100	200	100	200	100	200	100	200	100	
M	0	1	1	2	2	3	3	4	4	5	
N	6	8	8	10	10	12	12	14	14	16	
Y stroke	150	250	350	450	550	650					
Maximum speed for each stroke (mm/sec) <sup>Note 2</sup>	X axis			1000			800	650	550		
Speed setting				-			80%	65%	55%		

Note 1. The moving range when returning to origin and the stop position when stopping by mechanical stopper.

Note 2. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYxC

3 axes / ZSC

- Clean type
- Cable duct
- Z-axis shaft vertical type

## Ordering method

**SXYxC - D** [ ] [ ] [ ] [ ] **15** [ ] **RCX340-3** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

**Model** **Cable** **Combination** **X axis stroke** **Y axis stroke** **ZR axis** **Z axis stroke** **Cable length** **Controller / Number of controllable axes** **Safety standard** **Option A (OP.A)** **Option B (OP.B)** **Option C (OP.C)** **Option D (OP.D)** **Option E (OP.E)** **Absolute battery**

**D:** Cable duct **T1** T3 **15 to 105cm** **15 to 65cm** **ZSC12** **ZSC6** **3L: 3.5m** **5L: 5m** **10L: 10m** **Specify various controller setting items. RCX340 ▶ P.542**

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] **Controller** **CE Marking** **Expansion I/O** **Network option** **iVY System** **Gripper** **Battery**

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Basic specifications

	X axis	Y axis	Z axis: ZSC12	Z axis: ZSC6
<b>Axis construction</b> <small>Note 1</small>	C14H	C14		-
<b>AC servo motor output (W)</b>	200	100		60
<b>Repeatability</b> <small>Note 2</small> (mm)	+/-0.01	+/-0.01		+/-0.02
<b>Drive system</b>	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C10)	
<b>Ball screw lead</b> <small>Note 3</small> (Deceleration ratio) (mm)	20	20	12	6
<b>Maximum speed</b> <small>Note 4</small> (mm/sec)	1000	1000	1000	500
<b>Moving range (mm)</b>	150 to 1050	150 to 650		150
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10			
<b>Degree of cleanliness</b>	CLASS 10 <small>Note 5</small>			
<b>Intake air (Nl/min)</b>	90 <small>Note 6</small>			

Note 1. Use caution that the frame machining (installation holes, tap holes) differs from single-axis robots.  
 Note 2. Positioning repeatability in one direction.  
 Note 3. Leads not listed in the catalog are also available. Contact us for details.  
 Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.  
 Note 5. Per 1cf (0.1µm base), when suction blower is used.  
 Note 6. The necessary intake amount varies depending on the use conditions and environment.


## Maximum payload (kg)

Y stroke (mm)	ZSC12	ZSC6
150 to 650	3	5

## Controller

Controller	Operation method
RCX340 RCX240S	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYxC 3 axes / ZSC (T1)




X stroke	150	250	350	450	550	650	750	850	950	1050	
<b>L</b>	628	728	828	928	1028	1128	1228	1328	1428	1528	
<b>K</b>	200	100	200	100	200	100	200	100	200	100	
<b>M</b>	0	1	1	2	2	3	3	4	4	5	
<b>N</b>	6	8	8	10	10	12	12	14	14	16	
<b>Y stroke</b>	150	250	350	450	550	650					
<b>Z stroke</b>	150										
<b>Maximum speed for each stroke (mm/sec)</b> <small>Note 2</small>	<b>X axis</b>	1000				800	650	550			
	<b>Speed setting</b>	-				80%	65%	55%			

Note 1. The moving range when returning to origin and the stop position when stopping by mechanical stopper.

Note 2. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

SXYxC 3 axes / ZSC T3



X stroke	150	250	350	450	550	650	750	850	950	1050	
L	628	728	828	928	1028	1128	1228	1328	1428	1528	
K	200	100	200	100	200	100	200	100	200	100	
M	0	1	1	2	2	3	3	4	4	5	
N	6	8	8	10	10	12	12	14	14	16	
Y stroke	150	250	350	450	550	650					
Z stroke	150										
Maximum speed for each stroke (mm/sec) Note 2	X axis	1000					800	650	550		
	Speed setting	-					80%	65%	55%		

Note 1. The moving range when returning to origin and the stop position when stopping by mechanical stopper.

Note 2. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# SXYxC

4 axes / ZRSC

- Clean type
- Cable duct
- ZR-axis integrated type



## Ordering method

**SXYxC - D** [ ] [ ] [ ] [ ] [ ] **15** [ ]

Model	Cable	Combination	X axis stroke	Y axis stroke	ZR axis	Z axis stroke	Cable length
	D: Cable duct	T1 T3	15 to 105cm	15 to 65cm	ZRSC12 ZRSC6		3L: 3.5m 5L: 5m 10L: 10m

**RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ P.542

**RCX240S** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller	CE Marking	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ P.532

## Basic specifications

	X axis	Y axis	Z axis ZRSC12	Z axis ZRSC6	R axis
Axis construction <sup>Note 1</sup>	C14H	C14			R5
AC servo motor output (W)	200	100	60		100
Repeatability <sup>Note 2</sup> (XYZ: mm) (R: °)	+/-0.01	+/-0.01	+/-0.02		+/-0.005
Drive system	Ball screw (Class C7)	Ball screw (Class C7)	Ball screw (Class C10)		Harmonic gear
Ball screw lead <sup>Note 3</sup> (Deceleration ratio) (mm)	20	20	12	6	(1/50)
Maximum speed <sup>Note 4</sup> (XYZ: mm/sec) (R: °/sec)	1000	1000	1000	500	1020
Moving range (XYZ: mm) (R: °)	150 to 1050	150 to 650	150		360
Robot cable length (m)	Standard: 3.5 Option: 5, 10				
Degree of cleanliness	CLASS 10 <sup>Note 5</sup>				
Intake air (Nl/min)	90 <sup>Note 6</sup>				

- Note 1. Use caution that the frame machining (installation holes, tap holes) differs from single-axis robots.
- Note 2. Positioning repeatability in one direction.
- Note 3. Leads not listed in the catalog are also available. Contact us for details.
- Note 4. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.
- Note 5. Per 1cf (0.1μm base), when suction blower is used.
- Note 6. The necessary intake amount varies depending on the use conditions and environment.



## Maximum payload (kg)

Y stroke (mm)	ZRSC12	ZRSC6
150	3	5
250		
350		
450		
550		
650		4


## Controller

Controller	Operation method
RCX340 RCX240S	Programming / I/O point trace / Remote command / Operation using RS-232C communication

## SXYxC 4 axes / ZRSC (T1)



Detail of section A








X stroke	150	250	350	450	550	650	750	850	950	1050	
	L	628	728	828	928	1028	1128	1228	1328	1428	1528
K	200	100	200	100	200	100	200	100	200	100	
M	0	1	1	2	2	3	3	4	4	5	
N	6	8	8	10	10	12	12	14	14	16	
Y stroke	150	250	350	450	550	650					
Z stroke	150										
Maximum speed for each stroke (mm/sec) <sup>Note 2</sup>	X axis	1000				800		650		550	
	Speed setting	-				80%		65%		55%	

Note 1. The moving range when returning to origin and the stop position when stopping by mechanical stopper.

Note 2. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

SXYxC 4 axes / ZRSC T3



X stroke	150	250	350	450	550	650	750	850	950	1050
L	628	728	828	928	1028	1128	1228	1328	1428	1528
K	200	100	200	100	200	100	200	100	200	100
M	0	1	1	2	2	3	3	4	4	5
N	6	8	8	10	10	12	12	14	14	16
Y stroke	150	250	350	450	550	650				
Z stroke	150									
Maximum speed for each stroke (mm/sec)	X axis			1000			800	650	550	
	Speed setting			-			80%	65%	55%	

Note 1. The moving range when returning to origin and the stop position when stopping by mechanical stopper.

Note 2. When the X-axis stroke is longer than 850mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.

# YK180XC

Note. Built-to-order product. Contact us for the delivery period.

- Arm length 180mm
- Maximum payload 1kg

## Ordering method

### YK180XC - 100

<b>Model</b>	<b>Z axis stroke</b>	<b>Cable length</b>
	100: 100mm	3L: 3.5m
		5L: 5m
		10L: 10m

### RCX340-4

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ P.542

### RCX240S

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>iVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ P.532

## Basic specifications

	X axis	Y axis	Z axis	R axis
<b>Axis specifications</b>				
<b>Arm length (mm)</b>	71	109	100	-
<b>Rotation angle (°)</b>	+/-120	+/-140	-	+/-360
<b>AC servo motor output (W)</b>	50	30	30	30
<b>Repeatability</b> <sup>Note 1</sup> (XYZ: mm) (R: °)	+/-0.01		+/-0.01	+/-0.004
<b>Maximum speed (XYZ: m/sec) (R: °/sec)</b>	3.3		0.7	1700
<b>Maximum payload (kg)</b>	1.0			
<b>Standard cycle time: with 0.1kg payload</b> <sup>Note 2</sup> (sec)	0.42			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup> (kgm <sup>2</sup> )	0.01			
<b>User wiring (sq x wires)</b>	0.1 x 8			
<b>User tubing (Outer diameter)</b>	φ3 x 2			
<b>Travel limit</b>	1.Soft limit, 2.Mechanical limit (X, Y, Zaxis)			
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10			
<b>Weight (kg) (Excluding robot cable)</b> <sup>Note 4</sup>	6.5			
<b>Robot cable weight</b>	1.5kg (3.5m) 2.1kg (5m) 4.2kg (10m)			
<b>Degree of cleanliness</b>	CLASS 10 (0.1 μm base)			
<b>Intake air (Nℓ/min)</b>	30			

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.




Note 1. This is the value at a constant ambient temperature. (X,Y axes)

Note 2. When moving 25mm in vertical direction and 100mm in horizontal direction reciprocally.


Note 3. There are limits to acceleration coefficient settings.

Note 4. The total robot weight is the sum of the robot body weight and the cable weight.


## YK180XC



Details of A




Details of B



X-axis and Y-axis origin positions

Move counterclockwise in advance from the above position when performing origin return.



# YK220XC

Note. Built-to-order product. Contact us for the delivery period.

- Arm length 220mm
- Maximum payload 1kg

## Ordering method

### YK220XC - 100

Model	Z axis stroke	Cable length
	100: 100mm	3L: 3.5m
		5L: 5m
		10L: 10m

### RCX340-4

Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
--	-----------------	-----------------	-----------------	-----------------	-----------------	-----------------	------------------

Specify various controller setting items. RCX340 ▶ **P.542**

### RCX240S

Controller	CE Marking	Expansion I/O	Network option	iVY System	Gripper	Battery
------------	------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

		X axis	Y axis	Z axis	R axis
Axis specifications	Arm length (mm)	111	109	100	-
	Rotation angle (°)	+/-120	+/-140	-	+/-360
AC servo motor output (W)		50	30	30	30
Repeatability <sup>Note 1</sup> (XYZ: mm) (R: °)		+/-0.01		+/-0.01	+/-0.004
Maximum speed (XYZ: m/sec) (R: °/sec)		3.4		0.7	1700
Maximum payload (kg)				1.0	
Standard cycle time: with 0.1kg payload <sup>Note 2</sup> (sec)				0.45	
R-axis tolerable moment of inertia <sup>Note 3</sup> (kgm <sup>2</sup> )				0.01	
User wiring (sq x wires)				0.1 x 8	
User tubing (Outer diameter)				φ3 x 2	
Travel limit		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
Robot cable length (m)		Standard: 3.5 Option: 5, 10			
Weight (kg) (Excluding robot cable) <sup>Note 4</sup>		6.5			
Robot cable weight		1.5kg (3.5m) 2.1kg (5m) 4.2kg (10m)			
Degree of cleanliness		CLASS 10 (0.1μm base)			
Intake air (Nℓ/min)		30			


Note 1. This is the value at a constant ambient temperature.  
 Note 2. When reciprocating 100mm in horizontal and 25mm in vertical directions.  
 Note 3. There are limits to acceleration coefficient settings.  
 Note 4. The total robot weight is the sum of the robot body weight and the cable weight.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.

## YK220XC



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Single-axis  
Cartesian  
SCARA

# YK250XGC

● Arm length 250mm ● Maximum payload 4kg



## Ordering method

**YK250XGC - 150** **S** **RCX340-4**

Model	Z axis stroke	Tool flange	Hollow shaft	Cable length	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
	150: 150mm	No entry: None F: With tool flange	S: With hollow shaft	3L: 3.5m 5L: 5m 10L: 10m								

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller	CE Marking	Expansion I/O	Network option	iVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

	X axis	Y axis	Z axis	R axis
<b>Axis specifications</b>				
Arm length (mm)	100	150	150	-
Rotation angle (°)	+/-129	+/-134	-	+/-360
<b>AC servo motor output (W)</b>	200	150	50	100
<b>Repeatability</b> <sup>Note 1</sup> (XYZ: mm) (R: °)	+/-0.01		+/-0.01	+/-0.004
<b>Maximum speed (XYZ: m/sec) (R: °/sec)</b>	4.5		1.1	1020
<b>Maximum payload (kg)</b>	4			
<b>Standard cycle time: with 2kg payload (sec)</b> <sup>Note 2</sup>	0.57			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup> (kgm <sup>2</sup> )	0.05			
<b>User wiring (sq x wires)</b>	0.2x10			
<b>User tubing (Outer diameter)</b>	φ4x4			
<b>Travel limit</b>	1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10			
<b>Weight (kg)</b>	21.5			
<b>Degree of cleanliness</b>	ISO CLASS 3 (ISO 14644-1) <sup>Note 4+ESD</sup> <sup>Note 5</sup>			
<b>Intake air (Nℓ/min)</b>	30 <sup>Note 6</sup>			

## Controller


Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>






Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.607.  
 Note 4. Class 10 (0.1μm) equivalent to FED-STD-209D  
 Note 5. ESD (ElectroStatic Discharge) prevention is an option. Please contact our distributor.  
 Note 6. The necessary intake amount varies depending on the use conditions and environment.

## YK250XGC





## YK250XGC Tool flange mount type



# YK350XGC

● Arm length 350mm ● Maximum payload 4kg

## Ordering method

**YK350XGC - 150**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> S: With hollow shaft	<b>Cable length</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	------------------------------------	---	---	---

**S**

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>iVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P532**

## Basic specifications

	X axis	Y axis	Z axis	R axis
<b>Axis specifications</b>				
<b>Arm length (mm)</b>	200	150	150	-
<b>Rotation angle (°)</b>	+/-129	+/-134	-	+/-360
<b>AC servo motor output (W)</b>	200	150	50	100
<b>Repeatability</b> <sup>Note 1</sup> (XYZ: mm) (R: °)	+/-0.01		+/-0.01	+/-0.004
<b>Maximum speed (XYZ: m/sec) (R: °/sec)</b>	5.6		1.1	1020
<b>Maximum payload (kg)</b>	4			
<b>Standard cycle time: with 2kg payload (sec)</b> <sup>Note 2</sup>	0.57			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup> (kgm <sup>2</sup> )	0.05			
<b>User wiring (sq x wires)</b>	0.2x10			
<b>User tubing (Outer diameter)</b>	φ4x4			
<b>Travel limit</b>	1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10			
<b>Weight (kg)</b>	22			
<b>Degree of cleanliness</b>	ISO CLASS 3 (ISO 14644-1) <sup>Note 4</sup> +ESD <sup>Note 5</sup>			
<b>Intake air (Nl/min)</b>	30 <sup>Note 6</sup>			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.607.  
 Note 4. Class 10 (0.1µm) equivalent to FED-STD-209D  
 Note 5. ESD (ElectroStatic Discharge) prevention is an option. Please contact our distributor.  
 Note 6. The necessary intake amount varies depending on the use conditions and environment.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK350XGC



## YK350XGC Tool flange mount type



# YK400XGC

● Arm length 400mm ● Maximum payload 4kg



## Ordering method

**YK400XGC-150** **S** **RCX340-4**

Model: YK400XGC-150  
 Z axis stroke: 150: 150mm  
 Tool flange: No entry: None, F: With tool flange  
 Hollow shaft: S: With hollow shaft  
 Cable length: 3L: 3.5m, 5L: 5m, 10L: 10m

Controller / Number of controllable axes: RCX340-4  
 Safety standard: [ ]  
 Option A (OP.A): [ ]  
 Option B (OP.B): [ ]  
 Option C (OP.C): [ ]  
 Option D (OP.D): [ ]  
 Option E (OP.E): [ ]  
 Absolute battery: [ ]

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

Controller: RCX240S  
 CE Marking: [ ]  
 Expansion I/O: [ ]  
 Network option: [ ]  
 IVY System: [ ]  
 Gripper: [ ]  
 Battery: [ ]

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

	X axis	Y axis	Z axis	R axis
<b>Axis specifications</b>				
Arm length (mm)	250	150	150	-
Rotation angle (°)	+/-129	+/-144	-	+/-360
<b>AC servo motor output (W)</b>	200	150	50	100
<b>Repeatability</b> <sup>Note 1</sup> (XYZ: mm) (R: °)	+/-0.01		+/-0.01	+/-0.004
<b>Maximum speed</b> (XYZ: m/sec) (R: °/sec)	6.1		1.1	1020
<b>Maximum payload (kg)</b>	4			
<b>Standard cycle time: with 2kg payload (sec)</b> <sup>Note 2</sup>	0.57			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup> (kgm <sup>2</sup> )	0.05			
<b>User wiring</b> (sq x wires)	0.2x10			
<b>User tubing</b> (Outer diameter)	φ4x4			
<b>Travel limit</b>	1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
<b>Robot cable length (m)</b>	Standard: 3.5 Option: 5, 10			
<b>Weight (kg)</b>	22.5			
<b>Degree of cleanliness</b>	ISO CLASS 3 (ISO 14644-1) <sup>Note 4+ESD</sup> <sup>Note 5</sup>			
<b>Intake air (Nl/min)</b>	30 <sup>Note 6</sup>			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Class 10 (0.1µm) equivalent to FED-STD-209D  
 Note 5. ESD (ElectroStatic Discharge) prevention is an option. Please contact our distributor.  
 Note 6. The necessary intake amount varies depending on the use conditions and environment.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>


## YK400XGC






**YK400XGC Tool flange mount type**





4-M3 × 0.5 Depth 5  
(No phase relation to R-axis origin.)  
As this hole is intended for the wiring/tubing clamp, do not attach a large load to it.



If the robot enters the inside from the inner limit of the working envelope, the Z-axis bellows may be in contact with the base or the arm may be in contact with the machine harness. So, do not perform such motion.



- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 146°



# YK500XGLC

● Arm length 500mm ● Maximum payload 4kg

## Ordering method

**YK500XGLC - 150** **S** **RCX340-4**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> S: With hollow shaft	<b>Cable length</b> 3L: 3.5m 5L: 5m 10L: 10m	<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
--------------	------------------------------------	---	---	---	---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

Axis specifications	Arm length (mm)	X axis	Y axis	Z axis	R axis
	Rotation angle (°)	+/-129	+/-144	-	+/-360
<b>AC servo motor output (W)</b>		200	150	50	100
<b>Repeatability</b> <sup>Note 1</sup> (XYZ: mm) (R: °)		+/-0.01		+/-0.01	+/-0.004
<b>Maximum speed</b> (XYZ: m/sec) (R: °/sec)		5.1		1.1	1020
<b>Maximum payload (kg)</b>		4			
<b>Standard cycle time: with 2kg payload (sec)</b> <sup>Note 2</sup>		0.74			
<b>R-axis tolerable moment of inertia</b> <sup>Note 3</sup> (kgm <sup>2</sup> )		0.05			
<b>User wiring</b> (sq x wires)		0.2x10			
<b>User tubing (Outer diameter)</b>		φ4x4			
<b>Travel limit</b>		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
<b>Robot cable length (m)</b>		Standard: 3.5 Option: 5, 10			
<b>Weight (kg)</b>		25			
<b>Degree of cleanliness</b>		ISO CLASS 3 (ISO 14644-1) <sup>Note 4, +ESD</sup> <sup>Note 5</sup>			
<b>Intake air (Nl/min)</b>		30 <sup>Note 6</sup>			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Class 10 (0.1µm) equivalent to FED-STD-209D  
 Note 5. ESD (ElectroStatic Discharge) prevention is an option. Please contact our distributor.  
 Note 6. The necessary intake amount varies depending on the use conditions and environment.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication



Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>




## YK500XGLC



YK500XGLC Tool flange mount type



- Note that the robot cannot be used at a position where the base flange, robot cable, spline, bellows, and tool flange interfere with each other in the working envelope shown above.
- X-axis mechanical stopper position : 131°
- Y-axis mechanical stopper position : 146°



# YK500XC

● Arm length 500mm ● Maximum payload 10kg



## Ordering method

**YK500XC**   **RCX340-4**

Model	Z axis stroke	Cable length	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
	200: 200mm 300: 300mm	3L: 3.5m 5L: 5m 10L: 10m								

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**  **R**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

Axis specifications	Arm length (mm)	X axis	Y axis	Z axis	R axis
Rotation angle (°)		+/-120	+/-142	-	+/-180
AC servo motor output (W)		400	200	200	100
Repeatability <sup>Note 1</sup> (XYZ: mm) (R: °)		+/-0.02		+/-0.01	+/-0.005
Maximum speed (XYZ: m/sec) (R: °/sec)		4.9		1.7	876
Maximum payload (kg)		10			
Standard cycle time: with 2kg payload (sec)		0.53			
R-axis tolerable moment of inertia <sup>Note 2</sup> (kgm <sup>2</sup> )		0.12			
User wiring (sq x wires)		0.2 x 20			
User tubing (Outer diameter)		φ6 x 3			
Travel limit		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
Robot cable length (m)		Standard: 3.5 Option: 5, 10			
Weight (kg)		31			
Degree of cleanliness		CLASS 10 <sup>Note 3</sup>			
Intake air (Nl/min)		60 <sup>Note 4</sup>			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. There are limits to acceleration coefficient settings.  
 Note 3. Per 1cf (0.1μm base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R	1500	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK500XC





# YK600XGLC

● Arm length 600mm ● Maximum payload 4kg

## Ordering method

**YK600XGLC - 150**

<b>Model</b>	<b>Z axis stroke</b> 150: 150mm	<b>Tool flange</b> No entry: None F: With tool flange	<b>Hollow shaft</b> S: With hollow shaft	<b>Cable length</b> 3L: 3.5m 5L: 5m 10L: 10m
--------------	------------------------------------	---	---	---

**S**

**RCX340-4**

<b>Controller / Number of controllable axes</b>	<b>Safety standard</b>	<b>Option A (OP.A)</b>	<b>Option B (OP.B)</b>	<b>Option C (OP.C)</b>	<b>Option D (OP.D)</b>	<b>Option E (OP.E)</b>	<b>Absolute battery</b>
---	------------------------	------------------------	------------------------	------------------------	------------------------	------------------------	-------------------------

**RCX240S**

<b>Controller</b>	<b>CE Marking</b>	<b>Expansion I/O</b>	<b>Network option</b>	<b>IVY System</b>	<b>Gripper</b>	<b>Battery</b>
-------------------	-------------------	----------------------	-----------------------	-------------------	----------------	----------------

Specify various controller setting items. RCX340 ▶ **P.542**

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

Axis specifications	Arm length (mm)	X axis	Y axis	Z axis	R axis
		350	250	150	-
	Rotation angle (°)	+/-129	+/-144	-	+/-360
<b>AC servo motor output (W)</b>		200	150	50	100
<b>Repeatability<sup>Note 1</sup> (XYZ: mm) (R: °)</b>		+/-0.01		+/-0.01	+/-0.004
<b>Maximum speed (XYZ: m/sec) (R: °/sec)</b>		4.9		1.1	1020
<b>Maximum payload (kg)</b>		4			
<b>Standard cycle time: with 2kg payload (sec)<sup>Note 2</sup></b>		0.74			
<b>R-axis tolerable moment of inertia<sup>Note 3</sup> (kgm<sup>2</sup>)</b>		0.05			
<b>User wiring (sq x wires)</b>		0.2x10			
<b>User tubing (Outer diameter)</b>		φ4x4			
<b>Travel limit</b>		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
<b>Robot cable length (m)</b>		Standard: 3.5 Option: 5, 10			
<b>Weight (kg)</b>		26			
<b>Degree of cleanliness</b>		ISO CLASS 3 (ISO 14644-1) <sup>Note 4</sup> +ESD <sup>Note 5</sup>			
<b>Intake air (Nl/min)</b>		30 <sup>Note 6</sup>			

- Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. When reciprocating 25mm in vertical direction and 300mm in horizontal direction (rough-positioning arch motion).  
 Note 3. There are limits to acceleration coefficient settings. See P.608.  
 Note 4. Class 10 (0.1µm) equivalent to FED-STD-209D  
 Note 5. ESD (ElectroStatic Discharge) prevention is an option. Please contact our distributor.  
 Note 6. The necessary intake amount varies depending on the use conditions and environment.


## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240S	1000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

- Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.  
 Note. To set the standard coordinates with high accuracy, use a standard coordinate setting jig (option). Refer to the user's manual (installation manual) for more details.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK600XGLC



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSERVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Single-axis  
Cartesian

SCARA

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN


CONTROLLER INFORMATION

Single-axis

Cartesian

SCARA

## YK600XGLC Tool flange mount type



# YK600XC

● Arm length 600mm ● Maximum payload 10kg



## Ordering method

**YK600XC**

**Model**     **Z axis stroke**     **Cable length**

Z axis stroke: 200: 200mm, 300: 300mm  
 Cable length: 3L: 3.5m, 5L: 5m, 10L: 10m

**RCX340-4**     **Option A (OP.A)**     **Option B (OP.B)**     **Option C (OP.C)**     **Option D (OP.D)**     **Option E (OP.E)**     **Absolute battery**

Controller / Number of controllable axes     Safety standard     Option A (OP.A)     Option B (OP.B)     Option C (OP.C)     Option D (OP.D)     Option E (OP.E)     Absolute battery

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240**     **R**

Controller     CE Marking     Regenerative unit     Expansion I/O     Network option     iVY System     Gripper     Battery

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Basic specifications

Axis specifications	Arm length (mm)	X axis	Y axis	Z axis	R axis
Rotation angle (°)	350	+/-120	+/-145	200 300	-
AC servo motor output (W)		400	200	200	100
Repeatability <sup>Note 1</sup> (XYZ: mm) (R: °)		+/-0.02		+/-0.01	+/-0.005
Maximum speed (XYZ: m/sec) (R: °/sec)		5.6		1.7	876
Maximum payload (kg)		10			
Standard cycle time: with 2kg payload (sec)		0.56			
R-axis tolerable moment of inertia <sup>Note 2</sup> (kgm <sup>2</sup> )		0.12			
User wiring (sq x wires)		0.2 x 20			
User tubing (Outer diameter)		φ6 x 3			
Travel limit		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
Robot cable length (m)		Standard: 3.5 Option: 5, 10			
Weight (kg)		33			
Degree of cleanliness		CLASS 10 <sup>Note 3</sup>			
Intake air (Nl/min)		60 <sup>Note 4</sup>			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. There are limits to acceleration coefficient settings.  
 Note 3. Per 1cf (0.1μm base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.



## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R	1500	Programming / I/O point trace / Remote command / Operation using RS-232C communication


Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>


## YK600XC



Working envelope



X,Y axis mechanical stopper position



Controller

**RCX340 ▶ 542** **RCX240 ▶ 532**

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Single-axis  
Cartesian

SCARA

# YK700XC

● Arm length 700mm ● Maximum payload 20kg



## Ordering method

**YK700XC** [ ] [ ] **RCX340-4** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Model      Z axis stroke      Cable length      Controller / Number of controllable axes      Safety standard      Option A (OP.A)      Option B (OP.B)      Option C (OP.C)      Option D (OP.D)      Option E (OP.E)      Absolute battery

Z axis stroke: 200: 200mm, 400: 400mm  
Cable length: 3L: 3.5m, 5L: 5m, 10L: 10m

**Specify various controller setting items. RCX340 ▶ P.542**

**RCX240** [ ] [ ] **R** [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ] [ ]

Controller      CE Marking      Regenerative unit      Expansion I/O      Network option      iVY System      Gripper      Battery

**Specify various controller setting items. RCX240/RCX240S ▶ P.532**

## Basic specifications

Axis specifications	Arm length (mm)	X axis	Y axis	Z axis	R axis
Rotation angle (°)		+/-120	+/-145	-	+/-180
AC servo motor output (W)		800	400	400	200
Repeatability <sup>Note 1</sup> (XYZ: mm) (R: °)		+/-0.02		+/-0.01	+/-0.005
Maximum speed (XYZ: m/sec) (R: °/sec)		6.7		1.7	600
Maximum payload (kg)		20			
Standard cycle time: with 2kg payload (sec)		0.57			
R-axis tolerable moment of inertia <sup>Note 2</sup> (kgm <sup>2</sup> )		0.32			
User wiring (sq x wires)		0.2 x 20			
User tubing (Outer diameter)		φ6 x 3			
Travel limit		1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
Robot cable length (m)		Standard: 3.5 Option: 5, 10			
Weight (kg)		57			
Degree of cleanliness		CLASS 10 <sup>Note 3</sup>			
Intake air (Nl/min)		60 <sup>Note 4</sup>			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. There are limits to acceleration coefficient settings.  
 Note 3. Per 1cf (0.1μm base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Controller





Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R	2000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.

Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.) See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK700XC



Note: For details about tubing work, refer to the User's Manual.

# YK800XC

● Arm length 800mm ● Maximum payload 20kg



## Ordering method

**YK800XC**

Model	Z axis stroke 200: 200mm 400: 400mm	Cable length 3L: 3.5m 5L: 5m 10L: 10m	<b>RCX340-4</b>							
			Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
------------	------------	-------------------	---------------	----------------	------------	---------	---------

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

	X axis	Y axis	Z axis	R axis
Axis specifications				
Arm length (mm)	450	350	200 400	-
Rotation angle (°)	+/-120	+/-145	-	+/-180
AC servo motor output (W)	800	400	400	200
Repeatability <sup>Note 1</sup> (XYZ: mm) (R: °)	+/-0.02		+/-0.01	+/-0.005
Maximum speed (XYZ: m/sec) (R: °/sec)	7.3		1.7	600
Maximum payload (kg)	20			
Standard cycle time: with 2kg payload (sec)	0.57			
R-axis tolerable moment of inertia <sup>Note 2</sup> (kgm <sup>2</sup> )	0.32			
User wiring (sq x wires)	0.2 x 20			
User tubing (Outer diameter)	φ6 x 3			
Travel limit	1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)			
Robot cable length (m)	Standard: 3.5 Option: 5, 10			
Weight (kg)	58			
Degree of cleanliness	CLASS 10 <sup>Note 3</sup>			
Intake air (Nl/min)	60 <sup>Note 4</sup>			

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. There are limits to acceleration coefficient settings.  
 Note 3. Per 1cf (0.1μm base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.





## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R	2000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.  
 Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)  
 See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>

## YK800XC



Note: For details about tubing work, refer to the User's Manual.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Single-axis  
Cartesian  
SCARA

# YK1000XC

- Arm length 1000mm
- Maximum payload 20kg



## Ordering method

**YK1000XC**

Model	Z axis stroke	Cable length	Controller / Number of controllable axes	Safety standard	Option A (OP.A)	Option B (OP.B)	Option C (OP.C)	Option D (OP.D)	Option E (OP.E)	Absolute battery
	200: 200mm 400: 400mm	3L: 3.5m 5L: 5m 10L: 10m	<b>RCX340-4</b>							

Specify various controller setting items. RCX340 ▶ **P.542**

**RCX240**

Controller	CE Marking	Regenerative unit	Expansion I/O	Network option	IVY System	Gripper	Battery
		<b>R</b>					

Specify various controller setting items. RCX240/RCX240S ▶ **P.532**

## Basic specifications

	X axis	Y axis	Z axis		R axis
<b>Axis specifications</b>					
Arm length (mm)	550	450	200	400	-
Rotation angle (°)	+/-120	+/-145	-	-	+/-180
<b>AC servo motor output (W)</b>	800	400	400	200	
Repeatability <sup>Note 1</sup> (XYZ: mm) (R: °)	+/-0.02		+/-0.01	+/-0.005	
Maximum speed (XYZ: m/sec) (R: °/sec)	8.0		1.7	600	
Maximum payload (kg)	20				
Standard cycle time: with 2kg payload (sec)	0.60				
R-axis tolerable moment of inertia <sup>Note 2</sup> (kgm <sup>2</sup> )	0.32				
User wiring (sq x wires)	0.2 x 20				
User tubing (Outer diameter)	φ6 x 3				
Travel limit	1.Soft limit, 2.Mechanical stopper (X, Y, Z axes)				
Robot cable length (m)	Standard: 3.5 Option: 5, 10				
Weight (kg)	59				
Degree of cleanliness	CLASS 10 <sup>Note 3</sup>				
Intake air (Nl/min)	60 <sup>Note 4</sup>				

Note 1. This is the value at a constant ambient temperature. (X,Y axes)  
 Note 2. There are limits to acceleration coefficient settings.  
 Note 3. Per 1cf (0.1μm base), when suction blower is used.  
 Note 4. The necessary intake amount varies depending on the use conditions and environment.

## Controller

Controller	Power capacity (VA)	Operation method
RCX340 RCX240-R	2000	Programming / I/O point trace / Remote command / Operation using RS-232C communication

Note. "Harmonic" and "Harmonic drive" are the registered trademarks of Harmonic Drive Systems Inc.

Note. The movement range can be limited by changing the positions of X and Y axis mechanical stoppers. (The movement range is set to the maximum at the time of shipment.)

See our robot manuals (installation manuals) for detailed information.

Our robot manuals (installation manuals) can be downloaded from our website at the address below:  
<http://global.yamaha-motor.com/business/robot/>



## YK1000XC

**Working envelope**

**Maximum working envelope**

**Joint (Note)**  
 (φ12 x 2 pcs.)  
 R27 (Min. cable bending radius)  
 Do not move the cable.  
 M4 grounding terminal  
 Joint (Note) (φ12)  
 User tubes 1 (φ6 Black)  
 User tubes 2 (φ6 Red)  
 User tubes 3 (φ6 Blue)  
 D-sub connector for user wiring (Adapted to No.1 to 20)

Note: For details about tubing work, refer to the User's Manual.



## YAMAHA ROBOT CONTROLLERS

# CONTROLLER

## CONTENTS

### CONTROLLER

LCC140 ..... 484

### POSITIONER

TS-S2/TS-SH/TS-X/TS-P ..... 490

### DRIVER

TS-SD ..... 500

RDV-X/RDV-P ..... 504

### CONTROLLER

ERCD ..... 510

SR1-X/SR1-P ..... 516

RCX221/RCX222 ..... 524

RCX240/RCX240S ..... 532

RCX340 ..... 542

### OPTION DETAILS

- Support software for PC
  - TS-Manager ..... 552
  - POPCOM+ ..... 554
  - VIP+ ..... 556
  - RDV-Manager ..... 558
  - RCX-Studio Pro ..... 559
- Handy terminal
  - HT1/HT1-D ..... 560
- Programming box
  - HPB/HPB-D ..... 561
  - RPB/RPB-E ..... 562

- PBX/PBX-E ..... 563
- LCD Monitor option
  - TS-Monitor ..... 564
- Touch operator interface
  - Pro-face ..... 565
- Field network system with minimal wiring (network)
  - LCC140 ..... 566
  - TS-S2/TS-SH/TS-X/TS-P ..... 567
  - SR1-X/SR1-P ..... 568
  - RCX221/RCX222/RCX240/RCX240S/  
RCX340 ..... 569
  - RCX240/RCX240S/RCX340 ..... 570
  - RCX340 ..... 571

### ROBOT VISION iVY SYSTEM

iVY System ..... 572

### ROBOT VISION iVY2 SYSTEM

iVY2 System ..... 576

### ELECTRIC GRIPPER

- YRG Series ..... 582
  - Compact single cam type
    - YRG-2005SS ..... 583
  - Single cam type
    - YRG-2010S/2815S/4225S ..... 584
  - Double cam type
    - YRG-2005W/2810W/4220W ..... 585

- Screw type strait style
  - YRG-2020FS/2840FS ..... 586
- Screw type "T" style
  - YRG-2020FT/2840FT ..... 587
- Three fingers type
  - YRG-2004T ..... 588
  - YRG-2013T/2820T/4230T ..... 589

Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEMO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

iVY/iVY2 Electric gripper

Option

# CONTROLLER FEATURE DESCRIPTION

## Single-axis

### Dedicated robot controller for the LCM100

#### Linear conveyor module **LCC140**

Linear conveyor module ..... LCM100

**P.484**



Operating method	Programming/I/O point tracing/ Remote command/Operation using RS-232C communication
Points	10,000 points
Input power	Single phase 200 to 230V AC +/-10% maximum (50/60Hz)
Origin search method	Incremental
Field networks	CC-Link, DeviceNet™, EtherNet/IP™

### Single-axis robot positioner **TS-S2/TS-SH**

Dedicated compact single-axis... TRANSERVO <sup>Note 1</sup>

**P.490**



Operating method	I/O point tracing/Remote command/ Operation using RS-232C communication
Points	255 points
Input power	Main power supply DC24V +/-10% Control power supply DC24V +/-10%
Origin search method	TS-S2 : Incremental TS-SH : Absolute Incremental
Field networks	CC-Link, DeviceNet™, EtherNet/IP™, PROFINET

Note 1. SG07 is only applicable to TS-SH.

### Single-axis robot positioner **TS-X/TS-P**

Single-axis robot ..... FLIP-X  
Linear motor single-axis ..... PHASER

**P.490**



Operating method	I/O point tracing/Remote command/ Operation using RS-232C communication
Points	255 points
Input power	AC100V/AC200V
Origin search method	TS-X : Absolute Incremental TS-P : Incremental Semi-absolute
Field networks	CC-Link, DeviceNet™, EtherNet/IP™, PROFINET

### Single-axis robot driver **TS-SD**

Dedicated compact single-axis... TRANSERVO

**P.500**



Operating method	Pulse train control
Input power	Main power supply DC24V +/-10% Control power supply DC24V +/-10%
Origin search method	Incremental
Field networks	Not supported

### Single-axis robot driver **RDV-X/RDV-P**

[RDV-X] Single-axis robot..... FLIP-X  
[RDV-P] Linear motor single-axis..... PHASER

**P.504**




Operating method	Pulse train control
Input power	Main power supply Single phase/3-phase 200V to 230V Control power supply Single phase 200V to 230V
Origin search method	Incremental
Field networks	Not supported

### Single-axis robot controller **ERCD**

Single-axis robot..... T4L/T5L  
Clean single-axis ..... C4L/C5L

**P.510**



Operating method	Pulse train control/Programming/ I/O point tracing/Operation using RS-232C communication
Points	1000 points
Input power	DC24V +/-10% maximum
Origin search method	Incremental
Field networks	Not supported

### Single-axis robot controller **SR1-X/SR1-P**

Single-axis robot..... FLIP-X  
Linear motor single-axis ..... PHASER

**P.516**



Operating method	Programming/I/O point tracing/ Remote command/Operation using RS-232C communication
Points	1000 points
Input power	AC100V/AC200V
Origin search method	SR1-X Absolute Incremental SR1-P Incremental Semi-absolute
Field networks	CC-Link, DeviceNet™, PROFINET



## 1 to 2 axis

### Multi-axis robot controller

# RCX221/ RCX221HP

Single-axis robot..... FLIP-X  
 Linear motor single-axis ..... PHASER  
 Cartesian robot ..... XY-X  
 Pick & place..... YP-X

**P.524**



Operating method	Programming/Remote command/ Operation using RS-232C communication
Points	10000 points
Input power	AC200V
Origin search method	Incremental Semi-absolute
Field networks	CC-Link, DeviceNet™, Ethernet, PROFIBUS

### Multi-axis robot controller

# RCX222/ RCX222HP

Single-axis robot..... FLIP-X  
 Cartesian robot ..... XY-X  
 Pick & place..... YP-X

**P.524**



Operating method	Programming/Remote command/ Operation using RS-232C communication
Points	10000 points
Input power	AC200V
Origin search method	Absolute Incremental
Field networks	CC-Link, DeviceNet™, Ethernet, PROFIBUS

## 1 to 4 axis

### Multi-axis robot controller

# RCX240/ RCX240S

Single-axis robot..... FLIP-X  
 Linear motor single-axis ..... PHASER  
 Cartesian robot ..... XY-X  
 SCARA robot..... YK-TW, YK-XG,  
 YK-XGS, YK-XGP  
 Pick & place..... YP-X

**P.532**



Operating method	Programming/Remote command/ Operation using RS-232C communication
Points	10000 points
Input power	Single phase 200 to 230V AC +/-10% maximum (50/60Hz)
Origin search method	Absolute Incremental
Field networks	CC-Link, DeviceNet™, EtherNet/IP™, Ethernet, PROFIBUS

### Multi-axis robot controller

# RCX340

Single-axis robot..... FLIP-X  
 Linear motor single-axis ..... PHASER  
 Cartesian robot ..... XY-X  
 SCARA robot..... YK-TW, YK-XG,  
 YK-XR, YK-XGS,  
 YK-XGP  
 Pick & place..... YP-X











**P.542**



Operating method	Programming/Remote command/ Operation using RS-232C communication
Points	30000 points
Input power	Single phase 200 to 230V AC +/-10% maximum (50/60Hz)
Origin search method	Absolute Incremental
Field networks	CC-Link, DeviceNet™, EtherNet/IP™, Ethernet, PROFIBUS, PROFINET

Articulated robots  
YA  
Linear motor  
modules  
LCM100  
Compact  
single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor  
single-axis robots  
PHASER  
Cartesian  
robots  
XY-X  
SCARA  
robots  
YK-X  
Pick & place  
robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot  
positioner  
Pulse string  
driver  
Robot  
controller  
I/V/V/V2  
Electric  
grripper  
Option

# CONTROLLER SPECIFICATION SHEET

Category		Robot controller	Robot positioner				Robot driver		
Name		LCC140	TS-S2	TS-SH	TS-X	TS-P	TS-SD	RDV-X	RDV-P
External view									
Operating method		Programming/ I/O point tracing/ Remote command/ Operation using RS-232C communication	I/O point tracing/Remote command/ Operation using RS-232C communication				Pulse train control		
Applicable robot	LCM100	●	—	—	—	—	—	—	—
	TRANSERVO	—	● <sup>Note 2</sup>	●	—	—	●	—	—
	FLIP-X	T4L/T5L/C4L/C5L	—	—	—	—	—	—	—
		FLIP-X other than above	—	—	—	●	—	●	—
	PHASER	—	—	—	—	●	—	—	●
	XY-X	—	—	—	—	—	—	—	—
	YK-X	—	—	—	—	—	—	—	—
Input power	Main power supply	Single phase 200 to 230V AC +/-10% maximum (50/60Hz)	DC24V +/-10% maximum			● <b>AC100V specifications</b> <sup>Note 1</sup> (105 / 110 driver) Single phase 100 to 115V AC +/-10% maximum (50/60Hz)  ● <b>AC200V specifications</b> (205 / 210 / 220 driver) Single phase 200 to 230V AC +/-10% maximum (50/60Hz)	DC24V +/-10% maximum	Single phase / 3-phase 200 to 230V +10% to -15% (50/60Hz +/-5%)	
	Control power supply		DC24V +/-10% maximum				DC24V +/-10% maximum	Single phase 200 to 230V AC +10% to -15% (50/60Hz +/-5%)	
Number of controllable axes		Single-axis	Single-axis				Single-axis		
Origin search method		Incremental	Incremental	Absolute/ Incremental	Absolute/ Incremental	Incremental/ Semi-absolute	Incremental		
Maximum number of programs		100	(program not required)				—	—	
Maximum number of steps per program		999 steps	(program not required)				—	—	
Points		10,000 points	255 points				—	—	
Multitasks		4	—	—	—	—	—	—	
I/O points	Dedicated I/O	8 points/4 points	16 points/16 points	16 points/16 points	16 points/16 points	16 points/16 points	—	—	
	General I/O	16 points/16 points	—	—	—	—	—	—	
Field network support	CC-Link	●	●	●	●	●	—	—	—
	DeviceNet	●	●	●	●	●	—	—	—
	EtherNet/IP	●	●	●	●	●	—	—	—
	Ethernet	—	—	—	—	—	—	—	—
		—	—	—	—	—	—	—	—
	—	●	●	●	●	—	—	—	
CE marking		—	●	●	●	●	●	●	●
Programming box		HPB / HPB-D (with enable switch)	HT1 / HT1-D (with enable switch)				—	—	
Support software for PC		POPCOM <sup>+</sup>	TS-Manager				TS-Manager	RDV-Manager	
Detailed info page		<b>P.484</b>	<b>P.490</b>				<b>P.500</b>	<b>P.504</b>	








Note 1. 20A specifications provide only 200V.

Note 2. Exclude SG07

Note 3. Exclude YK400XR

Note 4. Maximum number of general-purpose I/O points when a total of two option boards OP.1 and OP.2 (one each) are installed.

Note 5. Maximum number of general-purpose I/O points when option OP.DIO boards (4 boards) are installed.

Robot controller							
ERCDC	SR1-X	SR1-P	RCX221 RCX221HP	RCX222 RCX222HP	RCX240 RCX240S	RCX340	
							
Pulse train control/ Programming/ I/O point tracing/ Operation using RS-232C communication	Programming/I/O point tracing/ Remote command/ Operation using RS-232C communication		Programming/Remote command/ Operation using RS-232C communication				
—	—	—	—	—	—	—	—
●	—	—	—	—	—	—	—
—	●	—	●	●	●	●	●
—	—	●	●	—	●	●	●
—	—	—	●	●	●	●	●
—	—	—	—	—	● Note 3	●	●
—	—	—	—	●	●	●	●
DC24V +/-10% maximum	<ul style="list-style-type: none"> <li>● <b>05 / 10 driver</b> Single phase 100 to 115V/200 to 230V AC +/-10% maximum (50/60Hz)</li> <li>● <b>20 driver</b> Single phase 200 to 230V AC +/-10% maximum (50/60Hz)</li> </ul>		Single phase 200 to 230V AC +/-10% maximum (50/60Hz)				
Single-axis	Single-axis		2 axes maximum	2 axes maximum	4 axes maximum Max. number of controllable axes 8	Max. number of robots 4 Max. number of controllable axes 16	
Incremental	Absolute/ Incremental	Incremental/ Semi-absolute	Incremental/ Semi-absolute	Absolute/ Incremental	Absolute/ Incremental/ Semi-absolute	Absolute/ Incremental/ Semi-absolute	
100	100		100	100	100	100	
1024 steps	3000 steps		9999 steps	9999 steps	9999 steps	9999 steps	
1000 points	1000 points		10000 points	10000 points	10000 points	30000 points	
4	4		8	8	8	16	
8 points/3 points	8 points/4 points		10 points/12 points	10 points/12 points	10 points/11 points	8 points/9 points	
6 points/6 points	16 points/16 points		40 points/24 points(Max.) <sup>Note 4</sup>	40 points/24 points(Max.) <sup>Note 4</sup>	112 points/72 points (Max.) <sup>Note 5</sup>	96 points/64 points (Max.) <sup>Note 5</sup>	
—	●	●	●	●	●	●	
—	●	●	●	●	●	●	
—	—	—	—	—	●	●	
—	—	—	●	●	●	●	
—	●	●	●	●	●	●	
—	—	—	—	—	—	●	
—	●	●	●	●	●	●	
HPB / HPB-D (with enable switch)			RPB / RPB-E (with enable switch)			PBX / PBX-E (with enable switch)	
POPCOM <sup>+</sup>			VIP <sup>+</sup>			RCX-Studio Pro	
<b>P.510</b>	<b>P.516</b>		<b>P.524</b>		<b>P.532</b>	<b>P.542</b>	

**Controller operating methods**

- Point trace : Host device specifies a binary point number and robot moves to the specified point when a start signal is input. Controller does not need a program and operates just by teaching point data.
- Remote command : Controller issues a wide range of commands and data to the robot via CC-Link or DeviceNet™ word functions. Host device can freely use robot controller functions as needed.
- Pulse train : Controller operates robot by pulse train from positioner unit. Controller needs no programs or point data. Pulse train operation is convenient to allow the host device to concentrate on robot control.
- Online instructions : PC can send various commands and data directly to the robot controller via RS232C or Ethernet and receive status information and data.

# LCC140

## Dedicated controller for LCM100

This is a dedicated controller for the LCM100 linear conveyor module. In addition to controlling movement, positioning, and input/output signals, it can also perform operations related to slider insertion and ejection.



LCC140

## Main functions ▶ P.13



Programming box  
▶ **HPB/HPB-D**  
**P.561**



Support software for PC  
▶ **POPCOM+**  
**P.554**

## Basic specifications

Item	LCC140	
Controllable robot	Linear conveyor module LCM series	
Power supply capacity	1200 VA	
External dimensions	W:402.5 × H:229 × D:106.5 mm	
Weight	4.8 kg	
Control power supply input	Single-phase 200 to 230 V AC +/-10% (50/60 Hz)	
Main power supply input	Single-phase 200 to 230 V AC +/-10% (50/60 Hz)	
Control method	AC fully digital software servo	
Position detection method	Magnetic linear scale	
Emergency stop input	Normal close contact input	
Output signal	Contact output: MPRDY	
Communication	RS-232C 2ch (HPB/COM, RFID)	
Program	Max. 999 steps/single program, Max. 10000 steps/all programs, Max. 100 programs	
Points	10000 points	
System backup	Lithium battery	
Multitasking	Max. 4 tasks	
Usage temperature	0 to 40 °C	
Storage temperature	-10 to 65 °C	
Usage humidity	35 to 85%RH (no dewing)	
Noise resistance	IEC61000-4-4 level 3	
CC-Link unit	CC-Link compatible version	Ver. 1.10
	Remote station type	Remove device station
	Number of occupied stations	Fixed to 2 stations
	Station number	1 to 63 (Set from HPB)
	Communication speed	10M/5M/2.5M/625K/156Kbps (Set using HPB or POPCOM+.)
	Shortest length between stations	0.2 m or more
	Total length	100m/10Mbps, 160m/5Mbps, 4000m/2.5Mbps, 900m/625Kbps, 1200m/156Kbps
	Monitor LED	None
	CC-Link I/O points	General-purpose input 32 points General-purpose output 32 points Dedicated input 16 points Dedicated output 16 points Input register 8 words Output register 8 words

Controllable robot	<b>LCM100</b>	<b>P.120</b>
CE marking	—	Field networks
		CC-Link DeviceNet EtherNet/IP

Model Overview	
Name	LCC140
Controllable robot	Linear conveyor module LCM100
Power	Single-phase AC200 to 230V +/-10% or less (50/60Hz)
Operating method	Programming/I/O point tracing/Remote command/ Operation using RS-232C communication

**Ordering method**

**LCC140 - 10**

Controller	Current sensor	Network option <small>Note</small>
	10:10A	No entry: None CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™

Note. For 2MT, be sure to select an appropriate network option.

Item		LCC140		
DeviceNet™ unit	Applicable DeviceNet™ specifications	Volume 1 Release2.0, Volume 2 Release2.0		
	DeviceNet™ Conformance test	Compliant with CT24		
	Device profile/Device type number	Generic Device (keyable) / 2B Hex		
	Vendor name/Vendor ID	YAMAHA MOTOR CO.,LTD. / 636		
	Product code	21		
	Product revision	1.0		
	EDS file name	Yamaha_LCC1(DEV).eds		
	MAC ID setting	0 to 63 (Set using HPB or POPCOM+.)		
	Communication speed setting	500K/250K/125Kbps (Set using HPB or POPCOM+.)		
	Communication data	Predefined Master/Slave Connection Set: Group 2 only server Dynamic connection support (UCMM): None Support for divided transmission of explicit message: Yes		
	Network length	Total length	100m/500Kbps, 250m/250Kbps, 500m/125Kbps	
		Branch length	6m or less	
Total branch length		39m or less/500Kbps, 78m or less/250Kbps, 156m or less/125Kbps		
Monitor LED	None			
Number of DeviceNet™ I/O points/number of occupied channels	General-purpose input 32 points	Input: 24byte		
	General-purpose output 32 points	Output: 24byte		
EtherNet/IP™ unit	Applicable software version	LCC140: Ver. 64.07 or higher HPB/HPB-D: Ver. 24.06 or higher POPCOM+: Ver. 2.1.0 or higher		
	Applicable EtherNet/IP™ specifications	Volume 1: Common Industrial protocol(CIP™) Edition 3.14 Volume 2: EtherNet/IP™ Adaptation of CIP Edition 1.15		
	EtherNet/IP™ Conformance test	Compliant with CT11		
	Device profile/Device type number	Generic Device (keyable) / 2B Hex		
	Vendor name/Vendor ID	YAMAHA MOTOR CO.,LTD. / 636		
	Product code	23		
	Product revision	1.1		
	EDS file name	Yamaha_LCC1(EIP2).eds		
	Communication speed	10Mbps / 100Mbps		
	Connector specifications	RJ-45 connector (8-pole modular connector), 2 ports		
	Applicable cable specifications	STP cable (double shield) with CAT 5e or higher		
	Maximum cable length	100m		
Monitor LED	Module Status(MS), Network Status(NS), Link/Activity:Port1-2			
Number of EtherNet/IP™ I/O points/number of occupied channels	General-purpose input 32 points	Input: 24byte		
	General-purpose output 32 points	Output: 24byte		
	Dedicated input 16 points			
	Dedicated output 16 points			
	Input register 8 words			
	Output register 8 words			

Articulated robots  
YA

Linear conveyer modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver


Robot controller

INVAZY Electric gripper


Option

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
IV/V/VZ Electric gripper  
Option

## ■ Dimensions




## ■ Part names



## ■ Installation conditions

- Reserve a space for the controller in the vicinity of the module.
- Install the controller perpendicularly to the wall.
- Reserve enough margins around the controller (20 mm or more on each side) and ensure sufficient ventilation. (See fig. at right.)
- Environmental temperature: 0 to 40°C
- Environmental humidity: 35 to 85%RH (no condensation)



## ■ Reference for power supply capacity and heat generation quantity

The power capacity and heat generation quantity required for the linear conveyor may vary depending on the module type or operation duty. Prepare the power supply and investigate the control panel size, controller layout, and cooling method while referring to the table below.

### ● Reference values for actual operation (per LCC140 controller)

Module type	Number of motors	Power supply capacity			Heat generation quantity (during operation)
		Control power supply	During waiting	During slider operation	During slider operation
LCM100-4M	4	35VA	60VA	350VA	20W
LCM100-3M	3	35VA	54VA	271VA	16W
LCM100-2MT	2	35VA	48VA	193VA	11W

The power capacity and heat generation quantity values stated in the table show the maximum values of LCC140 and they do not exceed these values. Since the operation duty of each motor of the linear conveyor is low due to operating characteristics, the power capacity required for actual operation becomes about 1/4 to 1/3 of the maximum capacity value.

### ● Maximum capacity values (per LCC140 controller)

Model	Power supply capacity	Heat generated
LCM100	1200VA	70W

# Option parts


## LCC140



### Options

#### ● Power connector + wiring connection lever

One set of parts per LCC140 is required.



Model	KAS-M5382-00
-------	--------------

LCC140  
 TS-X  
 TS-P  
 SR1-X  
 SR1-P  
 RCX221  
 RCX222  
 RCX240/S  
 RCX340

#### ● HPB dummy connector

When performing the operation with the programming box HPB removed, connect this dummy connector to the HPB connector. One connector per LCC140 is required.




Model	KDK-M5163-00
-------	--------------

LCC140  
 SR1-X  
 SR1-P

#### ● SAFETY connector

One connector per LCC140 is required.



Model	Not wired	KDK-M5370-10
	Wired <sup>Note</sup>	KDK-M5370-00

Note. The wired connector is that the wiring for the emergency stop cancel was performed inside the connector. Select this model when performing the operation check or debugging with single linear conveyor.

LCC140

#### ● LINK cable

[(Number of modules) - 1] cables per line are required.



Model	1m	KDK-M5361-10
	3m	KDK-M5361-30
	5m	KDK-M5361-50

LCC140

#### ● Terminator connector

When connecting modules, two connectors per line are required.



Model	KDK-M5361-00
-------	--------------

LCC140

#### ● Dust cover (for LINK connector)

This dust cover is attached to the insertion port, into which the the LINK cable terminator connector is not inserted. When using only one module without connections, two dust covers are required.



Model	KDK-M658K-00 (for MDR20 pin)
-------	------------------------------

Note. The dust cover is essential for the 2MT.

LCC140

#### ● Programming box HPB/HPB-D

P.561

All operations, such as robot manual operation, program input or edit, teaching, and parameter setting can be performed with this programming box.



	HPB	HPB-D
Model	KBB-M5110-01	KBB-M5110-21
Enable switch	—	3-position
CE marking	Not supported	Applicable

LCC140  
 ERCD  
 SR1-X  
 SR1-P

#### ● Support software for PC POPCOM+

P.554

POPCOM is a simple to use application software that makes tasks such as robot operation, writing-editing programs, and point teaching easy to visually understand.



Model	KBG-M4966-00
-------	--------------

LCC140  
 ERCD  
 SR1-X  
 SR1-P

#### ● POPCOM+ environment

OS	Microsoft Windows XP / Vista (32bit / 64Bit) / 7 (32bit / 64Bit) / 8,8.1 (32bit/64bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	50MB of available space required on installation drive.
Disk operation	RS-232C
Applicable controllers	SRCX/ERCX/DRXC/TRCX/SRCP/SRCD/ERCD/SR1/LCC140 <sup>Note 1</sup>

Note 1. LCC140 is applicable to Ver. 2.1.1 or later.

Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.


Continues on next page

Articulated robots  
 YA  
 Linear conveyor modules  
 LCM100  
 Compact single-axis robots  
 TRANSERVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XX-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER  
 INFORMATION  
 Robot positioner  
 Pulse string driver  
 Robot controller  
 I/V/V/V2 Electric gripper  
 Option

## Options

### Data cables

Communication cable for POPCOM+. Select from USB cable or D-sub cable.



Model	USB type (5m)	KBG-M538F-00
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10

Note. This USB cable supports Windows 2000/XP or later.  
 Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.  
 Note. USB driver for communication cable can also be downloaded from our website.

- LCC140**
- ERCD**
- SR1-X**
- SR1-P**
- RCX221**
- RCX222**
- RCX240/S**
- RCX340**

## RFID

### RFID (manufactured by BALLUFF GmbH)

Reader/writer cable



Model	KDK-M6300-00
-------	--------------

Note. Whether or not the RFID system can be used may vary depending on the destination place (country). Before selecting a RFID system, please contact YAMAHA.

### RFID (manufactured by OMRON)

Antenna amplifier controller cable



Model	KDK-M6300-A0
-------	--------------

Note. Whether or not the RFID system can be used may vary depending on the destination place (country). Before selecting a RFID system, please contact YAMAHA.

### Dust cover (for RFID)

This cover is attached to the insertion port if RFID is not used. (Included as standard)



Model	KDK-M658K-10 (for MDR26 pin)
-------	------------------------------

Note. Whether or not the RFID system can be used may vary depending on the destination place (country). Before selecting a RFID system, please contact YAMAHA.

## Maintenance parts

### Robot cable for LCM100



Model	KDJ-M4751-30 (3m×1 pc.)	<b>LCC140</b>
	KDJ-M4751-50 (5m×1 pc.)	
	KDJ-M4755-30 (Flexible cable 3m×1 pc.)	
	KDJ-M4755-50 (Flexible cable 5m×1 pc.)	

### Lithium battery for system backup



Model	KDK-M4252-00	<b>LCC140</b>
-------	--------------	---------------

### Replacement filter for LCC140 (5 pcs. in package)



Model	KDK-M427G-00	<b>LCC140</b>
-------	--------------	---------------

- Articulated robots  
**YA**
- Linear conveyer modules  
**LCM100**
- Compact single-axis robots  
**TRANSEVO**
- Single-axis robots  
**FLIP-X**
- Linear motor single-axis robots  
**PHASER**
- Cartesian robots  
**XY-X**
- SCARA robots  
**YK-X**
- Pick & place robots  
**YP-X**
- CLEAN**
- CONTROLLER**
- INFORMATION**
- Robot positioner
- Pulse string driver
- Robot controller
- IV1/V1Z Electric gripper
- Option



Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSEKO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller

iVY/iVZ  
Electric  
grripper

Option

# TS-S2/TS-SH/TS-X/TS-P

## CE compliance

**TS series are positioner type controllers that only performs point trace. No program is needed. Operation is simple. After setting point data, specify the point number and enter a START signal from host controller such as a PLC. Positioning or pushing operation then begins.**



TS-S2

TS-SH

TS-X

TS-P

## Main functions ▶ P.58



Handy terminal  
▶ HT1/HT1-D  
P.560



Support software for PC  
▶ TS-Manager  
P.552

## Basic specifications

### TS-S2/TS-SH

Item	Model	TS-S2	TS-SH
Basic specifications	Number of controllable axes	Single-axis	
	Controllable robots	TRANSERVO series	
	Current consumption	2.5A (Rating) 4.5A (Max.)	3.5A (Rating) 6.5A (Max.)
	Dimensions	W30 × H162 × D82mm	W30 × H162 × D123mm
	Weight	Approx. 0.2kg	
	Input power supply	Control power supply Motor power supply	DC24V +/-10% DC24V +/-10%
Axis control	Control method	Closed loop vector control method	
	Operating method	I/O point tracing (Positioning operation by specifying point number) / Remote command	
	Operation types	Positioning, merge-positioning, push, and jog operations	
	Position detection method	Resolver	Resolver with multi-turn absolute function
	Resolution	20480 pulses/rev. or 4096 pulses/rev. depending on the robot	
	Origin search method	Incremental	Absolute / Incremental
Points	Points	255 points	
	Point type setting	(1) Standard setting: Set speed and acceleration in percent of the respective maximum settings. (2) Custom setting: Set speed and acceleration in SI units.	
	Point teaching method	Manual data input (coordinates input), Teaching, Direct teaching	
External input/output	I/O interface	Selectable from the following: NPN, PNP, CC-Link, DeviceNet™, EtherNet/IP™, PROFINET	
	Input	Servo ON (SERVO), reset (RESET), start (START), interlock (/LOCK) origin search (ORG), manual mode (MANUAL), jog motion - (JOG-), jog motion + (JOG+), Point number selection (PIN0 to PIN7)	
	Output	Servo status (SRV-S), alarm (/ALM), operation end (END), operation in-progress (BUSY), control outputs (OUT0 to 3), Point number output 0 to 7 (POUT0 to POUT7)	
	External communications	RS-232C 1CH	
Options	Safety circuit	Emergency stop input, emergency stop contact output (1 system: When the HT1 is used.)	
	Handy terminal	HT1, HT1-D (with enable switch)	
General specifications	Support software for PC	TS-Manager	
	Operating temperature / Operating humidity	0°C to 40°C, 35% to 85%RH (non-condensing)	
	Storage temperature/ Storage humidity	-10°C to 65°C, 10% to 85%RH (non-condensing)	
	Atmosphere	Indoor location not exposed to direct sunlight. No corrosive, flammable gases, oil mist, or dust particles	
	Anti-vibration	All XYZ directions 10 to 57Hz unidirectional amplitude 0.075mm 57 to 150Hz 9.8m/s <sup>2</sup>	
Protective functions	Position detection error, temperature error, overload, overvoltage, low voltage, excessive position deviation, overcurrent, motor current error, motor cable faulty wiring, Excitation power failure error <sup>Note 1</sup>		

Note 1. The excitation power failure error is a protection function that is available only in TS-SH.

Controllable robot	<b>TS-S2/TS-SH ▶ TRANSERVO P.127</b>	<b>TS-X ▶ FLIP-X P.169</b>	<b>TS-P ▶ PHASER P.215</b>
CE marking			
Field networks			

## Model Overview

Name		TS-S2	TS-SH	TS-X/TS-P
Controllable robot		Dedicated compact single-axis TRANSERVO		
Input power	Main power supply	DC24V +/-10%	TS-X: Single-axis robot FLIP-X TS-P: Linear motor single-axis PHASER	
	Control power supply	DC24V +/-10%	● AC100V specifications Main power supply AC100 to 115V+/-10% Control power supply AC100 to 115V+/-10%	● AC200V specifications Main power supply AC200 to 230V+/-10% Control power supply AC200 to 230V+/-10%
Operating method		I/O point tracing / Remote command / Operation using RS-232C communication		
Maximum number of controllable axes		Single-axis		
Origin search method		Incremental	Absolute / Incremental	TS-X: Absolute / Incremental TS-P: Absolute / Semi-absolute

## Ordering method

### TS-S2/TS-SH (TRANSERVO)

Robot positioner	Type	I/O	Battery Note 1
S2: TS-S2	No entry: Standard	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: With no I/O board	B: With battery (Absolute model) N: None (Incremental model)
SH: TS-SH	S: Sensor		

Note 1. Battery can only be selected for TS-SH. (Not provided for TS-S2).

### TS-X/TS-P (FLIP-X/PHASER)

Controller	Driver: Power supply voltage/ Power capacity	Regenerative unit	LCD monitor	Input/Output Selection	Battery Note 2
TSX: TS-X TSP: TS-P	105: 100V / 100W more less 110: 100V / 200W 205: 200V / 100W more less 210: 200V / 200W 220: 200V / 400 to 600W	No entry: None R: With RGT R: With RGU-2	No entry: None L: With LCD	NP: NPN PN: PNP CC: CC-Link DN: DeviceNet™ EP: EtherNet/IP™ PT: PROFINET GW: With no I/O board	B: With battery (Absolute model) N: None (Incremental model)

Note 2. Battery can only be selected for TS-X. (Not provided for TS-P).

## TS-X/TS-P

Item	Model	TS-X / TS-P				
		100V AC input		200V AC input		
Driver model		TS-X105 / TS-P105	TS-X110 / TS-P110	TS-X205 / TS-P205	TS-X210 / TS-P210	TS-X220 / TS-P220
Number of controllable axes		Single-axis				
Controllable robots		TS-X: Single-axis robot FLIP-X series TS-P: Linear motor single-axis robot PHASER series				
Power capacity		400VA	600VA	400VA	600VA	1400VA
Dimensions		W58 × H162 × D131mm				W70 × H162 × D131mm
Weight		Approx. 0.9kg				Approx. 1.1kg
Input power supply	Control power supply	Single phase AC100 to 115V +/-10% 50/60Hz		Single phase AC200 to 230V +/-10% 50/60Hz		
	Motor power supply	Single phase AC100 to 115V +/-10% 50/60Hz		Single phase AC200 to 230V +/-10% 50/60Hz		
Control method		Closed loop vector control method				
Operating method		I/O point tracing (Positioning operation by specifying point number) / Remote command				
Operation types		Positioning, merge-positioning, push, and jog operations				
Position detection method		TS-X: Resolver with multi-rotation absolute function TS-P: Magnetic type linear scale				
Resolution		TS-X: 16384 pulses/rev. or 20480 pulses/rev. depending on the robot TS-P: 1µm				
Origin search method		TS-X: Absolute / Incremental TS-P: Incremental / Semi-absolute				
Number of points		255 points				
Point type setting		(1) Standard setting: Set speed and acceleration in percent of the respective maximum settings. (2) Custom setting: Set speed and acceleration in SI units.				
Point teaching method		Manual data input (coordinates input), Teaching, Direct teaching				
I/O interface		Selectable from the following: NPN, PNP, CC-Link, DeviceNet™, EtherNet/IP™, PROFINET				
Input		Servo ON (SERVO), reset (RESET), start (START), interlock (/LOCK) origin search (ORG), manual mode (MANUAL), jog motion - (JOG-), jog motion + (JOG+), Point number selection (PIN0 to PIN7)				
Output		Servo status (SRV-S), alarm (/ALM), operation end (END), operation in-progress (BUSY), control outputs (OUT0 to 3), Point number output 0 to 7 (POUT0 to POUT7)				
External communications		RS-232C 1CH				
Power supply for brake		DC24V +/-10% 300mA (prepared by the customer)				
Safety circuit		Emergency stop input, main power input ready output, emergency stop contact output (1 system: When the HT1 is used.)				
Handy terminal		HT1, HT1-D (with enable switch)				
Support software for PC		TS-Manager				
Operating temperature / Operating humidity		0°C to 40°C, 35% to 85%RH (non-condensing)				
Storage temperature / Storage humidity		-10°C to 65°C, 10% to 85%RH (non-condensing)				
Atmosphere		Indoor location not exposed to direct sunlight. No corrosive, flammable gases, oil mist, or dust particles				
Anti-vibration		All XYZ directions 10 to 57Hz unidirectional amplitude 0.075mm 57 to 150Hz 9.8m/s <sup>2</sup>				
Protective functions		Position detection error, power module error, temperature error, overload, overvoltage, low voltage, excessive position deviation, overcurrent, motor current error				
Protective structure		IP20				

## TS-X / TS-P specification selection table

Some specifications are automatically determined by the robot model.

### TS-X

		T4LH/ C4LH	T5LH/ C5LH	T6L/ C6L	T9	T9H	F8/ C8	F8L/ C8L	F8LH/ C8LH	F10/ C10	F10H	F14/ C14	F14H/ C14H	GF14XL	F17/ C17	F17L/ C17L	GF17XL	F20/ C20	F20N	N15/ N15D	N18/ N18D	B10	B14	B14H	R5	R10	R20
Power supply voltage / Current sensor	TS-X	105	●	●	●		●	●	●	●		●		●								●	●	●	●	●	
		110				●					●																●
		205	●	●	●	●	●	●	●	●	●		●										●	●	●	●	●
		210				●								●													
	220										●		●	●			●	●	●	●	●						●
Regenerative unit	No entry (None)				(1)	(2)				(1)	(2)	(1)	(2)	●	(3)		(6)	(3)	(4)						(5)		
	R (RGT)				(1)	(2)				(1)	(2)	(1)	(2)	●	(3)	●	(6)	(3)	(4)	●	●				(5)		


- (1) Regenerative unit is needed if using in a perpendicular position and movement stroke is 700mm or more.
- (2) Regenerative unit is needed if using in a perpendicular position.
- (3) Regenerative unit is needed if using in a perpendicular position, using at maximum speeds exceeding 1000mm per second, or if using high leads (40).
- (4) Regenerative unit is needed if using at maximum speeds exceeding 1000mm per second.
- (5) Regenerative unit is needed if using at maximum speeds exceeding 1250mm per second.
- (6) Regenerative unit is needed if using at maximum speeds exceeding 750mm per second.

### TS-P


		MR12/12D	MF7/7D	MF15/15D	MF20/20D	MF30/30D	MF75/75D
Power supply voltage / Current sensor	TS-P	105	●				
		110		●		●	
		205	●				
		210		●		●	
	220					●	
Regenerative unit	No entry (None)	●	●	●			
	R (RGT)				●	●	
	R (RGU-2)						●

## Part names

### TS-S2/TS-SH




### TS-X/TS-P




## ■ Dimensions


### ■ TS-S2




### ■ TS-SH



### ■ TS-X/TS-P (105/110/205/210)




### ■ TS-X/TS-P (220)




## ■ Installation conditions

- Install the TS-S2/TS-SH/TS-X/TS-P inside the control panel.
- Install the TS-S2/TS-SH/TS-X/TS-P on a vertical wall.
- Install the TS-S2/TS-SH/TS-X/TS-P in a well ventilated location, with space on all sides of the TS-S2/TS-SH/TS-X/TS-P (See fig. at right.).
- Ambient temperature : 0 to 40°C
- Ambient humidity : 35 to 85% RH (no condensation)

### ■ TS-S2/TS-SH



### ■ TS-X/TS-P



## ■ Cautions on TS-S2 / TS-SH

For the RF type sensor specifications, the controllers "TS-S2" and "TS-SH" become "TS-S2S" and "TS-SHS", respectively.


### TS-S2 / TS-SH (Standard specifications)

"BK" label is affixed to the front of the controller.





### TS-S2S / TS-SHS (Sensor specifications)

"SENSOR" label is affixed to the front of the controller.  
 (Be aware that "TS-S2S" is affixed to the front of the controller.)



Articulated robots  
 YA  
 Linear CONVEYOR modules  
 LCM100  
 Compact single-axis robots  
 TRANSEVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XY-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER  
 INFORMATION  
 Robot positioner  
 Pulse string driver  
 Robot controller  
 I/V/A/V/Z Electric gripper  
 Option

## Regenerative unit RGT/RGU-2



### Basic specifications

Item	RGT
Model	KCA-M4107-0A
Dimensions	W30 × H142 × D118mm (Not including installation stay)
Weight	470g
Regenerative voltage	Approx. 380V or more
Regenerative stop voltage	Approx. 360V or less
Accessory	Cable for connection with controller (300mm)

Note. Always leave an empty space (gap of about 20mm) between this unit and the adjacent controller.  
Also, always use the dedicated cable when connecting the controller.

### Basic specifications

Item	RGU-2 (TS-P)
Model	KCA-M4107-2A (Including accessory)
Dimensions	W40 × H250 × D157mm
Weight	0.9kg
Regenerative voltage	Approx. 380V or more
Regenerative stop voltage	Approx. 360V or less
Accessory	Cable for connection with controller (300mm)

Note. Always leave an empty space (gap of about 20mm) between this unit and the adjacent controller. Also, always use the dedicated cable when connecting the controller.

## Data overview

Point data and parameter data settings must be specified in order to operate a robot from a TS series controller.


### Point data

The point data used in positioning operations includes items such as the "RUN type", "Position", and "Speed", etc. Up to 255 points (P1 to P255) can be registered. There are two point data setting types: "Standard setting" type that automatically defines optimal positioning simply by specifying the payload and "Custom setting" type that allows setting the speed (mm/s) and acceleration (m/s<sup>2</sup>) in SI units. Select the desired setting type according to the application.

### Parameter data

Parameter data is divided into the following categories: "RUN parameters", "I/O parameters", "option parameters", and "servo parameters".

### Data structure



## Point data

### Point data item list

P1 to P255		
Item		Description
1	RUN type	Specifies the positioning operation pattern.
2	Position	Specifies the positioning target position or movement amount.
3	Speed	Specifies the positioning speed.
4	Accel.	Specifies the positioning acceleration.
5	Decel.	Specifies the positioning deceleration (as a percentage of the acceleration).
6	Push	Specifies the electrical current limit value for "Push" operations.
7	Zone (-)	Specifies the "personal zone" output range.
8	Zone (+)	
9	Near width	Specifies the "near width" zone (distance tolerance relative to target position).
10	Jump	Specifies the next movement destination, or the next merge operation merge destination point No. following positioning completion.
11	Flag	Specifies other information related to the positioning operation.
12	Timer	Specifies the waiting time (delay) after positioning completion.

### "Standard setting" and "custom setting"


There are 2 setting types for point data ("standard setting" or "custom setting"). Select the desired setting type according to the application.

The maximum number of setting points for both setting types is 255 points (P1 to P255).

Setting Type	Description
Standard setting	Optimum positioning is provided simply by specifying the payload. This setting type is well-suited to assembly and transport applications.
Custom setting	Allows changing the speed and acceleration in SI units so the desired positioning operation can be set. This setting type is suited for machining and inspection systems.


## NPN type input / output wiring diagram

### TS-S2/TS-SH




## Emergency stop circuit example

### TS-S2/TS-SH (power connector and host unit connection example)




Note. Always connect a surge absorber unit to the coil on the electromagnetic contactor.

### TS-X




Note. When using a brake-equipped robot.

### TS-X/TS-P (EXT connector and host unit connection example)



Note. Always connect a surge absorber unit to the coil on the electromagnetic contactor.

### TS-P



Installing an external safety circuit will satisfy safety category class 4 standards. See P.613 for more information.

## I/O Specifications

Item	Description
NPN	Input 16 points, 24VDC +/-10%, 5.1mA/point, positive common Output 16 points, 24VDC +/-10%, 50mA/point, sink type
PNP	Input 16 points, 24VDC +/-10%, 5.5mA/point, minus common Output 16 points, 24VDC +/-10%, 50mA/point, source type
CC-Link	CC-Link Ver.1.10 compatible, Remote station device (1 node)
DeviceNet™	DeviceNet™ Slave 1 node
EtherNet/IP™	EtherNet/IP™ adapter (2 ports)
PROFINET	PROFINET Slave 1 node


Articulated robots  
YA  
Linear CONVEYOR modules  
LCM100  
Compact single-axis robots  
TRANSERVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
N/V/N/V2 Electric gripper  
Option

## I/O signals (NPN / PNP)

No.	Signal Name	Description	No.	Signal Name	Description			
A1	+COM	I/O power input, positive common (24VDC +/-10%)	B1	POUT0	Point No. outputs			
A2			B2	POUT1				
A3	NC	No connection	B3	POUT2				
A4			B4	POUT3				
A5	PIN0	Point No. select	B5	POUT4				
A6			B6	POUT5				
A7			B7	POUT6				
A8			B8	POUT7				
A9			B9	OUT0		OUT0 to OUT3 assignments include: • Zone output • Personal zone output • MANUAL mode status • Return-to-origin end status • NEAR output • Movement-in-progress • Push status • Warning output		
A10			B10	OUT1				
A11			B11	OUT2				
A12			B12	OUT3				
A13			JOG+	JOG movement (+ direction)	B13		BUSY	Operation-in-progress
A14			JOG-	JOG movement (- direction)	B14		END	Operation-end
A15			MANUAL	MANUAL mode	B15	/ALM	Alarm	
A16			ORG	Return-to-origin	B16	SRV-S	Servo status	
A17	/LOCK	Interlock	B17	NC	No connection			
A18	START	Start	B18	NC				
A19	RESET	Reset	B19	-COM	I/O power input, negative common (0V)			
A20	SERVO	Servo ON	B20					

### NPN type I/O circuit details

#### Input circuit



**Type : DC input (plus common type)**

Photo-coupler isolation format


**Load : 24VDC +/- 10%, 5.1mA**

OFF voltage : 19.6Vmin (1.0mA)

ON voltage : 4.9Vmax (4.0mA)

### PNP type I/O circuit details

#### Input circuit



**Type : DC input (minus common type)**


Photo-coupler isolation format

**Load : 24VDC +/- 10%, 5.5mA**

ON voltage : 19.6Vmin (4.5mA)

OFF voltage : 4.9Vmax (1.1mA)

#### Output circuit




**Type : NPN open collector output**

(Minus common type)

Photo-coupler isolation format

**Load : 24VDC, 50mA/point**

#### Output circuit



**Type : PNP open collector output**

(Plus common type)

Photo-coupler isolation format

**Load : 24VDC, 50mA/point**



# Accessories and part options

## TS-S2/TS-SH/TS-X/TS-P



### Standard accessories

#### ● Power connector




Model KCC-M4421-00

TS-S2  
TS-SH  
TS-SD

#### ● Power connector (AC100V specifications)

Included when 100V model is purchased




Model KCA-M5382-00

TS-X  
TS-P

#### ● Power connector (AC200V specifications)

Included when 200V model is purchased



Model KAS-M5382-00

LCC140  
TS-X  
TS-P  
SR1-X  
SR1-P  
RCX221  
RCX222  
RCX240/S  
RCX340

#### ● EXT connector

For braking power and safety circuit connections.



Model KCA-M5370-00

TS-X  
TS-P

#### ● Dummy connector



Model KCA-M5163-00

TS-S2  
TS-SH  
TS-X  
TS-P

#### ● I/O cables (2m/20-core×2)




Model KCA-M4421-20

TS-S2  
TS-SH  
TS-X  
TS-P

#### ● Absolute battery

##### ● Absolute battery basic specifications

Item	For TS-X	For TS-SH
Battery type	Lithium metallic battery	
Battery capacity	3.6V / 1,650mAh	3.6V / 2,750mAh
Data holding time	About 1 year (in state with no power applied)	
Dimensions	φ18 × L50mm	φ17 × L53mm
Weight	24g	22g




Model KCA-M53G0-10 (For TS-X)  
KCA-M53G0-01 (For TS-SH)

TS-X  
TS-SH

Note. The absolute battery is subject to wear and requires replacement. If trouble occurs with the memory then remaining battery life is low so replace the absolute battery. The battery replacement period depends on usage conditions. But generally you should replace the battery after about 1 year counting the total time after connecting to the controller and left without turning on the power.

#### ● CC-Link connector (CC-Link specifications)

Included when CC-Link model is purchased



Model Connector<sup>Note</sup> KCA-M4872-00  
Jump socket KCA-M4873-00

TS-S2  
TS-SH  
TS-X  
TS-P

Note. This is a single connector type. (Insert two connectors into a branching socket.)

See next page for optional parts

Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

INVA/NVZ Electric gripper

Option

## Options

### ● Handy terminal HT1/HT1-D

P.560



		HT1	HT1-D
Model	3.5m	KCA-M5110-0J	KCA-M5110-1J
	10m	KCA-M5110-6J	KCA-M5110-7J
Enable switch		–	3-position
CE marking		Not supported	Applicable

TS-S2  
TS-SH  
TS-X  
TS-P

### ● Support software TS-Manager

P.552



Model	
	KCA-M4966-0J (Japanese)
	KCA-M4966-0E (English)

TS-S2  
TS-SH  
TS-X  
TS-P  
TS-SD

### ● TS-Manager environment

OS	Microsoft Windows 2000 / XP / Vista (32bit/64bit) / 7 (32bit/64bit)
CPU	Exceeding the environment recommended by the OS being used
Memory	Exceeding the environment recommended by the OS being used
Hard disk	Vacant capacity of more than 20MB in the installation destination drive
Communication port	Serial (RS-232C), USB
Applicable controllers	TS-S2 / TS-SH / TS-X / TS-P / TS-SD

Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

### ● Data cables

Communication cable for TS-Manager. Select from USB cable or D-sub cable.



Model		
	USB type (5m)	KCA-M538F-A0
	D-Sub type (5m)	KCA-M538F-01

Note. USB driver for communication cable can also be downloaded from our website.

TS-S2  
TS-SH  
TS-X  
TS-P  
TS-SD

### ● Daisy chain and gateway connection cable



Model	
	KCA-M532L-00 (300mm)

TS-S2  
TS-SH  
TS-X  
TS-P  
TS-SD

### ● CC-Link termination connector (CC-Link specifications)



Model	
	KCA-M4874-00

TS-S2  
TS-SH  
TS-X  
TS-P


### ● TS-Monitor (LCD monitor) P.564



Model		
	For TS-X	KCA-M5119-00
	For TS-P	KCA-M5119-10

TS-X  
TS-P

### ● DIN rail mounting bracket (This bracket is provided in TS-SH as standard equipment.)



Model	
	For TS-S2 KCC-M499A-00

TS-S2

Model	
	For TS-X / TS-P KCA-M499A-00

TS-X  
TS-P

Model	
	For TS-X / TS-P with RGT KCA-M499A-10

TS-X  
TS-P

Articulated robots  
YA

Linear CONVEYOR  
modules  
LCM100

Compact  
single-axis robots  
TRANSEKVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller

iVY/iVZ  
Electric  
grripper

Option

# TS-SD

- CE compliance
- Only for pulse train control
- Dedicated for TRANSERVO

The TS-SD is a high-performance robot driver specifically designed for the TRANSERVO series that supports pulse train command input.



TS-SD

## Main functions ▶ P.57



Support software for PC

▶ **TS-Manager**

**P.552**

### Basic specifications


Item	Model	TS-SD	
<b>Basic specifications</b>			
Number of controllable axes		Single-axis	
Controllable robots		TRANSERVO series <sup>Note</sup>	
Current consumption		3A (Rating) 4.5A (Max.)	
Dimensions		W30 × H162 × D82mm	
Weight		Approx. 0.2kg	
Input power supply	Control power supply	DC24V +/-10%	
	Main power supply	DC24V +/-10%	
Operating method		Pulse train control	
Control method		Closed loop vector control method	
Position detection method		Resolver	
Resolution		20480 P/rev, 4096 P/rev	
Origin search method		Incremental	
<b>External input/output</b>	Pulse train command input	Line driver method : 500 kpps or less Open collector method : 100 kpps or less (DC5 to 24V +/-10%)	
	Input	Servo ON (SERVO), reset (RESET) origin search (ORG)	
	Output	Servo status (SRV-S), alarm (/ALM), positioning completion (IN-POS), return-to-origin end status (ORG-S)	
	External communications	RS-232C 1CH	
<b>Options</b>	Support software for PC	TS-Manager	
	Operating temperature	0°C to 40°C	
<b>General specifications</b>	Storage temperature	-10°C to 65°C	
	Operating humidity	35% to 85%RH (non-condensing)	
	Storage humidity	10% to 85%RH (non-condensing)	
	Atmosphere	Indoor location not exposed to direct sunlight. No corrosive, flammable gases, oil mist, or dust particles	
	Anti-vibration	All XYZ directions 10 to 57Hz unidirectional amplitude 0.075mm 57 to 150Hz 9.8m/s <sup>2</sup>	
	Protective functions		Position detection error, overheat, overload, overvoltage, low voltage, position deviation, control power voltage drop, overcurrent, motor current error, CPU error, motor line disconnection, command speed over, pulse frequency over

Note. Except for RF type sensor specifications and STH type vertical specifications.

### I/O signal table

No.	Signal Name	Description
1	+COM	I/O power supply input (DC 24V +/- 10%)
2	OPC	Open collector power supply input
3	PULS1	Command pulse input 1
4	PULS2	Command pulse input 2
5	DIR1	Command direction input 1
6	DIR2	Command direction input 2
7	ORG	Return-to-origin
8	NC	Prohibited to use this signal.
9	RESET	Reset
10	SERVO	Servo ON
11	ORG-S	Return-to-origin end status
12	IN-POS	Positioning completion
13	/ALM	Alarm
14	SRV-S	Servo status
15	-COM	I/O power supply input (0V)
16	FG	Ground

### I/O connector



Controllable robot	<b>TRANSERVO P.127</b>
CE marking	
Field networks	—

**Model Overview**

Name		TS-SD
Controllable robot		Dedicated compact single-axis TRANSERVO
Input power	Main power supply	DC24V +/-10% maximum
	Control power supply	DC24V +/-10% maximum
Operating method		Pulse train control
Maximum number of controllable axes		Single-axis
Origin search method		Incremental

**Ordering method**

**Controller only**      **Robot + Controller**

**TS-SD** Note


Controller      Robot model — Cable length — Controller — I/O cable

TRANSERVO Series      1L: 1 meter  
 3L: 3 meters  
 5L: 5 meters  
 10L: 10 meters  
 (flexible cables)


**SD 1**

Note. I/O cable (1 meter) comes supplied with unit.

**Part names**




**Dimensions**



Articulated robots  
 YA  
 Linear conveyor modules  
 LCM100  
 Compact single-axis robots  
 TRANSERVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XY-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER  
 INFORMATION  
 Robot positioner  
 Pulse string driver  
 Robot controller  
 I/V/I/V2 Electric gripper  
 Option

## Installation conditions

- Install the TS-SD inside the control panel.
- Install the TS-SD on a vertical wall.
- Install the TS-SD in a well ventilated location, with space on all sides of the TS-SD (See fig. at right.).
- Ambient temperature : 0 to 40°C
- Ambient humidity : 35 to 85% RH (no condensation)




## I/O signal list


Type	Signal Name	Open collector	Line driver	Description
Inputs	OPC	Open collector power supply input	(Connection prohibited. <sup>Note 2</sup> )	Input the power supply for the open collector. (DC5 to 24V +/- 10%)
	PULS1	(Connection prohibited. <sup>Note 1</sup> )	Command pulse input (+)	Input terminal for pulse train input commands. Select from 3 command forms by changing parameters.
	DIR1	(Connection prohibited. <sup>Note 1</sup> )	Command direction input (+)	
	PULS2	Command pulse input	Command pulse input (-)	• Phase A/Phase B input • Pulse/Sign input • CW/CCW input
	DIR2	Command direction input	Command direction input (-)	
	ORG	Return-to-origin	←	Starts return-to-origin when ON and stops it when OFF.
Outputs	RESET	Reset	←	Alarm reset
	SREVO	Servo ON	←	ON: servo on; OFF: servo off.
	ORG-S	Return-to-origin end status	←	ON at return-to-origin end.
	IN-POS	Positioning completion	←	ON when accumulated pulse in deviation counter are within specified value range.
	/ALM	Alarm	←	ON when normal. OFF when alarm occurs.
	SRV-S	Servo status	←	ON when servo is on.

Note 1. When using the open collector specifications, do not connect any signal to the PULS1 and DIR1 terminals. Doing so may cause the driver to malfunction or breakdown.  
 Note 2. When using the line driver specifications, do not connect any signal to the OPC terminal. Doing so may cause the driver to malfunction or breakdown.

### Input / output signal connection diagram [open collector]




### Input / output signal connection diagram [line driver]



## Daisy chain function

Connecting two or more TS series controllers and drivers in a daisy chain allows editing data on any one unit from a PC.

- Up to 16 units connectable
- Requires daisy chain coupler cables.





# Accessories and part options

## TS-SD

### Standard accessories

#### ● Power connector



Model KCC-M4421-00

TS-S2  
TS-SH  
TS-SD

#### ● I/O cables (1m)



Model KCC-M5362-00

TS-SD

### Options

#### ● Support software TS-Manager

P.552



Model KCA-M4966-0J (Japanese)  
KCA-M4966-0E (English)

TS-S2  
TS-SH  
TS-X  
TS-P  
TS-SD

#### ● TS-Manager environment

OS	Microsoft Windows 2000 / XP / Vista (32bit/64bit) / 7 (32bit/64bit)
CPU	Exceeding the environment recommended by the OS being used
Memory	Exceeding the environment recommended by the OS being used
Hard disk	Vacant capacity of more than 20MB in the installation destination drive
Communication port	Serial (RS-232C), USB
Applicable controllers	TS-S2 / TS-SH / TS-X / TS-P / TS-SD

Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

#### ● Data cables

Communication cable for TS-Manager. Select from USB cable or D-sub cable.



Model USB type (5m) KCA-M538F-A0  
D-Sub type (5m) KCA-M538F-01

Note. USB driver for communication cable can also be downloaded from our website.

TS-S2  
TS-SH  
TS-X  
TS-P  
TS-SD

#### ● Daisy chain and gateway connection cable



Model KCA-M532L-00 (300mm)

TS-S2  
TS-SH  
TS-X  
TS-P  
TS-SD

# RDV-X/RDV-P

● Only for pulse train control

These are high-performance robot drivers for the FLIP-X series and PHASER series which support pulse train command input.



RDV-X

RDV-P

Main functions ▶ P.56



Support software for PC

▶ RDV-Manager

P.558

## Basic specifications

Item		RDV-X			RDV-P			
Driver model		RDV-X205	RDV-X210	RDV-X220	RDV-P205	RDV-P210	RDV-P220	RDV-P225
Number of controllable axes		Single-axis						
Controllable robots		Single-axis robot FLIP-X			Linear motor single-axis robot PHASER			
Basic specifications	Capacity of the connected motor	200V 100W or less	200V 200W or less	200V 600W or less	200V 100W or less	200V 200W or less	200V 400W or less	200V 750W or less
	Maximum power consumption	0.3kVA	0.5kVA	0.9kVA	0.3kVA	0.5kVA	0.9kVA	1.3kVA
	Dimensions	W40×H160×D140mm			W40×H160×D170mm	W40×H160×D140mm		W40×H160×D170mm
	Weight	0.7kg			1.1kg	0.7kg		1.2kg
	Input power supply	Single phase 200 to 230V +10%, -15%, 50/60Hz +/-5%						
	Control power supply	Single phase / 3-phase 200 to 230V +10%, -15%, 50/60Hz +/-5%						
Axis control	Position detection method	Resolver			Magnetic linear scale			
	Control system	Sine-wave PWM (pulse width modulation)						
	Control mode	Position control						
	Maximum speed <sup>Note 1</sup>	5000rpm			3.0m/s			
Input/output related function	Position command input	Line driver signal (2M pps or less) (1) Forward pulse + reverse pulse (2) Sign pulse + Command pulse (3) 90-degree phase difference 2-phase pulse command One of (1) to (3) is selectable.						
	Input signal	24V DC contact point signal input (usable for sink/source) (24V DC power supply incorporated) (1) Servo ON (2) Alarm reset (3) Torque limit (4) Forward overtravel (5) Reverse overtravel (6) Origin sensor <sup>Note 3</sup> (7) Return-to-origin (8) Pulse train input enable (9) Deviation counter clear						
	Output signal	Open collector signal output (usable for sink/source) (1) Servo ready (2) Alarm (3) Positioning completed (4) Return-to-origin complete						
	Relay output signal	Braking cancel signal (24V 375mA)			-			
	Position output	Phase A, B signal output: Line driver signal output Phase Z signal output: Line driver signal output / open collector signal output N/8192 (N=1 to 8191), 1/N (N=1 to 64) or 2/N (N=3 to 64)						
	Monitor output	Selectable items: 2ch, 0 to +/-5V voltage output, speed detection value, torque command, etc.						
Internal function	Display	5-digit number indicator, Control power LED						
	External operator	PC software "RDV-Manager" monitoring function, parameter setting function, operation tracing function, trial operation function, etc. USB2.0 is used. Windows Vista / 7 / 8 / 8.1 personal computer can be connected.						
	Regenerative braking circuit	Included (but without braking resistor)						
	Dynamic brake <sup>Note 4</sup>	Included (Operation conditions can be set.) (No DB resistor, connection: 2-phase short circuit)						Included (Operation conditions can be set.) (with DB resistor, connection: 2-phase short circuit)
	Protective function <sup>Note 2</sup>	Semi-enclosure type (IP20)						
Protective functions	Over-current, overload, braking resistor overload, main circuit overvoltage, memory error, etc.							



Controllable robot	<b>RDV-X ▶ FLIP-X<sup>Note 1</sup></b> <b>P.169</b>	<b>RDV-P ▶ PHASER</b> <b>P.215</b>
CE marking		Field networks

Note 1. Exclude T4 / T5 / C4 / C5 / YMS

## Model Overview

Name		RDV-X	RDV-P
Controllable robot		Single-axis robot FLIP-X <sup>Note 1</sup>	Linear motor single-axis robot PHASER
Input power	Main power supply	Single phase / 3-phase 200 to 230V +10% to -15% (50/60Hz +/-5%)	
	Control power supply	Single phase 200 to 230V +10% to -15% (50/60Hz +/-5%)	
Operating method		Pulse train control	
Maximum number of controllable axes		Single-axis	
Origin search method		Incremental	

## Ordering method

### RDV-X

Note. Driver selection and regenerative unit selection depend on the robot type. See the selection table on the next page for selecting the driver/regenerative circuit.


### RDV-P

Note. Driver selection and regenerative unit selection depend on the robot type. See the selection table on the next page for selecting the driver/regenerative circuit.

Item	RDV-X			RDV-P			
	RDV-X205	RDV-X210	RDV-X220	RDV-P205	RDV-P210	RDV-P220	RDV-P225
Driver model	RDV-X205	RDV-X210	RDV-X220	RDV-P205	RDV-P210	RDV-P220	RDV-P225
Options	Support software for PC RDV-Manager						
General specifications	Operating temperature 0°C to +55°C						
	Storage temperature <sup>Note 5</sup> -10°C to +70°C						
	Operating humidity 20% to 90%RH (non-condensing)						
	Vibration <sup>Note 6</sup> 5.9m/s <sup>2</sup> (0.6G) 10 to 55Hz						

Note 1. These data are parameters and calculation range in controlling the robot driver and do not indicate the capacity of the robot at the maximum speed.  
 Note 2. JIS C 0920 (IEC60529) is used as the base for the protection method.  
 Note 3. GXL-8FB (made by SUNX) or FL7M-1P5B6-Z (made by YAMATAKE) is used for the origin sensor. The power consumption of the origin sensor is 15mA or less (at open output) and only 1 unit of the origin sensor is connected to each robot driver. (future specification)  
 Note 4. Use the dynamic brake for emergency stop. Note that the braking may be less effective depending on the robot model.  
 Note 5. The storage temperature is the temperature in the non-energized state including transportation.  
 Note 6. The JIS C 60068-2-6:2010 (IEC 60068-2-6:2007) test method is uses as the base.

## Part names



Articulated robots  
YA

Linear motor  
modules  
LCM100

Compact  
single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver


Robot  
controller

IN/VN/VZ  
Electric  
gripper


Option

## ■ Dimensions


### RDV-X205/210 RDV-P205/210



### RDV-X220 RDV-P220



### RDV-P225



## ■ Driver / regenerative unit selection table

### RDV-X

		FLIP-X																												
		T4LH/C4LH	T5LH/C5LH	T6L/C6L	T9	T9H	F8/C8	F8L/C8L	F8LH/C8LH	F10/C10	F10H	F14/C14	F14H/C14H	GF14XL	F17/C17	F17L/C17L	GF17XL	F20/C20	F20N	N15	N18	N15D	N18D	B10	B14	B14H	R5	R10	R20	
Driver selection	RDV-X 05	●	●	●	●	●	●	●	●	●	●	●	●																	
	RDV-X 10					●							●												●	●		●	●	
	RDV-X 20										●			●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	
Regenerative unit	No entry (None)	●	●																											
	RBR1			●	●	●	●	●	●	●	●	●	●	●	①	①		①	●	●	●	●	●	●	●	●	●	●	●	
	RBR2														①	①		①												

① If placed horizontally the RBR1 is required, if placed vertically then RBR2 is required.



### RDV-P

		PHASER					
		MR12/MR12D	MF7/MF7D	MF15/MF15D	MF20/MF20D	MF30/MF30D	MF75/MF75D
Driver selection	RDV-P 05	●					
	RDV-P 10		●	●	●		
	RDV-P 20					●	
	RDV-P 25						●
Regenerative unit	No entry (None)	●					
	RBR1		●	●	●	●	
	RBR2						●

## ■ Regenerative unit RBR1 / RBR2 dimensions

The regenerative unit is a device that converts the braking current generated when the motor decelerates into heat.

Regenerative unit is required for specified Yamaha models and for operation with loads having large inertia.





### ● Regenerative unit RBR1 / RBR2 basic specifications

Item	RBR1	RBR2
Model	KBH-M5850-00	KBH-M5850-10
Capacity type	120W	200W
Resistance value	100Ω	100Ω
Permissible braking frequency	2.5%	7.5%
Permissible continuous braking time	12 sec.	30 sec.
Weight	0.27kg	0.97kg


Note. The internal thermal contact point capacity is AC250V, 2A max. ON (b contact point) in the normal state.  
 Note. The built-in thermal fuse prevents abnormal heat generation which occurs by an erroneous use. (not resettable)  
 Note. When the thermal relay has worked, reduce the regeneration energy by either stopping the servo amplifier or making the deceleration time longer.  
 Note. With the regenerative unit, specifications and whether or not required may vary depending on each robot and its operation conditions.

## Installation conditions

- Install the RDV-X/RDV-P on a vertical metal wall.
- Install the RDV-X/RDV-P in a well ventilated location, with space on all sides of the RDV-X/RDV-P.
- Ambient temperature: 0 to 55°C
- Ambient humidity: 20 to 90% RH (no condensation)
- When placing two or more robot drivers in one operating panel, install them as shown in the figure below.



## Input / output signal connection diagram



## List of RDV-P / RDV-X terminal functions

Type	Terminal symbol	Terminal name	Description
Input signal	P24	Interface power	Supplies 24V DC for contact inputs. Connecting this signal to the PLC terminal allows using the internal power supply. Use this terminal only for contact input. Do not use for controlling external equipment connected to the driver, such as brakes.
	CM1	Interface power common	This is a ground signal for the power supply connected to P24. If using the internal power supply then input a contact signal between this signal and the contact-point signal.
	PLC	Intelligent input common	Connect this signal to the power supply common contact input. Connect an external supply or internal power supply (P24).
	SON	Servo ON	Setting this signal to ON turns the servo on (supplies power to motor to control it). Additionally, this signal is also used for estimating magnetic pole position when FA-90 is set to oFF4, oFF5.
	RS	Alarm reset	After an alarm has tripped, inputting this signal cancels the alarm. But before inputting this reset signal, first set the SON terminal to OFF and eliminate the cause of the trouble.
	TL	Torque limit	When this signal is ON, the torque limit is enabled.
	FOT	Forward overtravel	When this signal is OFF, the robot will not run in forward direction. (Forward direction limit signal)
	ROT	Reverse overtravel	When this signal is OFF, the robot will not run in reverse direction. (Reverse direction limit signal)
	ORL	Origin sensor	Input an origin limit switch signal showing the origin area.
	ORG	Return-to-origin	Inputting this signal starts return-to-origin operation.
Output signal	PEN	Pulse train input enable	When this signal is turned on, the pulse train position command input is enabled.
	CER	Position error counter clear	Inputting this signal clears the position deviation (position error) counter. (Position command value is viewed as current position.)
	SRD	Servo ready	This signal is output when the servo is ready to turn on (with main power supply turned on and no alarms tripped)
	SRDE	Servo ready	This signal is output when an alarm has tripped. (This signal is ON in normal state and OFF when an alarm has tripped.)
	ALM	Alarm	This signal is output when the deviation between the command position and current position is within the preset positioning range.
	ALME	Alarm	This signal is output when the deviation between the command position and current position is within the preset positioning range.
	INP	Positioning complete	This signal is output when the deviation between the command position and current position is within the preset positioning range.
	INPE	Positioning complete	This signal is output when the deviation between the command position and current position is within the preset positioning range.
	ORG-S	Return-to-origin complete	This signal is output when the return-to-origin is completed successfully.
	ORG-SE	Return-to-origin complete	This signal is output when the return-to-origin is completed successfully.
Relay output	BK (B24) <sup>Note 1</sup>	Brake release relay output	When the servo is ON, this terminal outputs a signal to allow releasing the brake. (FLIP-X series only)
Monitor output	AO1	Monitor output 1	Outputs speed detection values, torque commands, etc. as analog signal voltages for monitoring. Signals to output are selected by setting parameters. These signals are only for monitoring. Do not use for control.
	AO2	Monitor output 2	Outputs speed detection values, torque commands, etc. as analog signal voltages for monitoring. Signals to output are selected by setting parameters. These signals are only for monitoring. Do not use for control.
	L	Monitor output common	This is the ground for the monitor signal.
Position command	PLSP	Position command pulse (pulse signal)	Select one of the following signal forms as the pulse-train position command input. 1. Command pulse + direction signal 2. Forward direction pulse train + reverse direction pulse train 3. Phase difference 2-phase pulse
	PLSN	Position command pulse (pulse signal)	
	SIGP	Position command pulse (pulse signal)	
	SIGN	Position command pulse (sign signal)	Select one of the following signal forms as the pulse-train position command input. 1. Command pulse + direction signal 2. Forward direction pulse train + reverse direction pulse train 3. Phase difference 2-phase pulse
	SIGN	Position command pulse (sign signal)	
	SIGN	Position command pulse (sign signal)	
Position sensor monitor	OAP	Position sensor Phase A signal	Outputs monitor signal obtained by dividing "phase A" signal of position sensor.
	OAN	Position sensor Phase A signal	
	OBP	Position sensor Phase B signal	Outputs monitor signal obtained by dividing "phase B" signal of position sensor.
	OBN	Position sensor Phase B signal	
	OZP	Position sensor Phase Z signal	Outputs monitor signal for position sensor "phase Z" signal.
	OZN	Position sensor Phase Z signal	
	OZ	Phase Z detection	Outputs monitor signal for position sensor "phase Z" signal.
L	Phase Z detection common		
Braking power input	B24 <sup>Note 1</sup>	Brake power input	Input 24V DC brake power to this terminal.
	B0 <sup>Note 1</sup>	Brake power common	Common terminal input for brake power.

Note 1. B24, B0 and BK are available only with RDV-X, and not with RDV-P.

## Accessories and part options

### RDV-X/RDV-P



#### Standard accessories

- I/O connector (no brake wiring)



Model KBH-M4420-00

RDV-X  
RDV-P

- I/O connector (with brake wiring)



Model KBH-M4421-00

RDV-X  
RDV-P

- Power supply connector



Model KEF-M4422-00

RDV-X  
RDV-P

#### Options

- Support software RDV-Manager

P.558



Model KEF-M4966-00

RDV-X  
RDV-P

#### Environment

OS	Microsoft Windows Vista (32bit) <sup>Note 1</sup> / 7 (32bit/64bit) / 8, 8.1 (32bit/64bit)
CPU	Pentium4 1.8GHz or more (Recommend)
Memory	1GB or more
Hard disk	1GB of available space required on installation drive.
Disk operation	USB
Applicable controllers	RDV-X / RDV-P

Note 1. SP1 (service pack 1) or higher.

Note. Windows Vista, Windows 7, and Windows 8 / Windows 8.1 are trademarks of Microsoft Corporation registered in U.S.A. and other countries.

- Communication cable

Communication cable to connect PC and a controller.



Model KEF-M538F-00

RDV-X  
RDV-P

Articulated robots  
YA

Linear CONVEYOR  
modules  
LCM100

Compact  
single-axis robots  
TRANSEKVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller

iV1/V1Z  
Electric  
grripper

Option

# ERCD

● Dedicated for T4L / T5L / C4L / C5L

Low price and compact in size.

In addition to the conventional functions, a pulse train function is added for a wider application range.

This is a dedicated controller for the FLIP-X series models T4L, T5L, C4L, and C5L.


Main functions ▶ P.62



Programming box  
▶ HPB/HPB-D  
P.561



Support software for PC  
▶ POPCOM+  
P.554



ERCD

## Basic specifications

Item	Model	ERCD	
Number of controllable axes		Single-axis	
Controllable robots		Single-axis robot FLIP-X series T4L / T5L / C4L / C5L	
Capacity of the connected motor		DC24V 30W or less	
Dimensions		W44 × H166 × D117mm	
Weight		0.45kg	
Input power supply		DC24V +/-10% maximum 3A to 4.5A (Variable depending on robots in use.)	
Drive method		AC full-digital software servo	
Position detection method		Resolver	
Operating method		Normal mode: point trace movement, program operation, operation using RS-232C communication Pulse Train mode: operation by pulse train input	
Position indication units		mm (millimeters)	
Speed setting		1% to 100% (Setting by 1% unit)	
Acceleration setting		1. Automatic speed setting per robot No. and payload 2. Setting based on acceleration and deceleration parameter 1% to 100% (Setting by 1% unit)	
Resolution		16384 P/rev	
Origin search method		Incremental	
Program language		YAMAHA SRC	
Multitasks		4 tasks	
Point-data input method		Manual data input (coordinates input), Direct teaching, Remote teaching	
RAM		32 Kbytes with lithium battery backup (5-year life) Retains programs, point data, parameters and alarm history	
Programs		100 programs (Maximum program number) 255 steps per program 1024 steps / total or less	
Points		1000 points (256 when point tracing)	
External input/output	Normal mode <sup>Note 1</sup>	Sequence input	Dedicated input 8 points, General input 6 points
		Sequence output	Dedicated input 3 points, General input 6 points, Open collector output
	Pulse train mode <sup>Note 1</sup>	Sequence input	Dedicated input 5 points, General input 6 points
		Sequence output	Dedicated input 3 points, General input 6 points, Open collector output
		Command pulse input	Type 1.Phase A / phase B, 2.Pulse / code, 3.CW / CCW Mode Line driver (+5V) Frequency Maximum 2 Mpps
	Feedback pulse output	Terminal name	PA+, PA-, PB+, PB-, PZ+, PZ-
		Type	Phase A / phase B / phase Z
		Mode	Line driver (+5V)
		Number of pulse	16 to 4096 P/rev
	Power supply for sequence I/O		External DC +24V input
Emergency stop input		Normal close contact point input	
Brake output		Relay output (for 24V/300mA brake) 1CH	
External communications		RS-232C 1CH (For communication with HPB or PC)	

Controllable robot	<b>FLIP-X Dedicated for T4L/T5L P.174</b>	<b>Dedicated for C4L/C5L P.442</b>
CE marking	—	Field networks —

**Model Overview**

Name	ERCD
Controllable robot	Dedicated for T4L / T5L / C4L / C5L
Input power	DC24V +/-10% maximum 3A to 4.5A (Variable depending on robots in use.)
Operating method	Pulse train control / Programming / I/O point tracing / Operation using RS-232C communication
Maximum number of controllable axes	Single-axis
Origin search method	Incremental


**Ordering method**

<b>ERCD</b>	Controller	I/O connector specification
		CN1: I/O flat cable 1m (Standard)
		CN2: Twisted-pair cable 2m (pulse train function)


Item	Model	ERCD
Options	Programming box	HPB, HPB-D (with enable switch)
	Support software for PC	POPCOM+
General specifications	Operating temperature	0°C to 40°C
	Storage temperature	-10°C to 65°C
	Operating humidity	35% to 85%RH (non-condensing)
	Noise resistance capacity	IEC61000-4-4 Level 2
	Protective functions	Overload, overvoltage, voltage drop, resolver wire breakage, runaway detection, etc.

Note 1. Switching between the normal mode and pulse train mode is done by use of the parameter.

**Part names**




**Dimensions**



**Installation conditions**

- Install the ERCD inside the control panel.
- Install the ERCD on a vertical wall.
- Install the ERCD in a well ventilated location, with space on all sides of the ERCD (See fig. below).
- Ambient temperature : 0 to 40°C
- Ambient humidity : 35 to 85% RH (no condensation)



Articulated robots  
YA  
Linear CONVEYOR modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
I/V/I/V2 Electric gripper  
Option

## Connector I/O signals

Terminal number	Signal name	Function
A-1	ABS-PT	Move the point from the origin position
B-1	INC-PT	Move the point from the current position
A-2	AUTO-R	Start automatic operation
B-2	STEP-R	Start step operation
A-3	ORG-S	Return to the origin
B-3	RESET	Reset
A-4	SERVO	Return to servo on
B-4	LOCK	Interlock
A-5	DI 0	General input 0
B-5	DI 1	General input 1
A-6	DI 2	General input 2
B-6	DI 3	General input 3
A-7	DI 4	General input 4
B-7	DI 5	General input 5
A-8	(SVCE)	Service mode input
B-8	DO 5	General output 5
A-9	DO 0	General output 0
B-9	DO 1	General output 1
A-10	DO 2	General output 2
B-10	DO 3	General output 3
A-11	DO 4	General output 4
B-11	END	End normal execution
A-12	BUSY	Executing the command
B-12	READY	Ready for operation
A-13	FG	Frame ground
B-13	FG	Frame ground
A-14	GND	Signal ground
B-14	GND	Signal ground
A-15	NC	Reserved (use inhibited)
B-15	NC	Reserved (use inhibited)
A-16	NC	Reserved (use inhibited)
B-16	NC	Reserved (use inhibited)
A-17	PA+	Feedback pulse output
B-17	PA-	Feedback pulse output
A-18	PB+	Feedback pulse output
B-18	PB-	Feedback pulse output
A-19	PZ+	Feedback pulse output
B-19	PZ-	Feedback pulse output
A-20	NC	Reserved (use inhibited)
B-20	NC	Reserved (use inhibited)

## Pulse train I/O connector signals

Terminal number	Signal name	Function
A-1	NC	Reserved (use inhibited)
B-1	NC	Reserved (use inhibited)
A-2	NC	Reserved (use inhibited)
B-2	PCLR	Differential clear input
A-3	ORG-S	Return to the origin input
B-3	RESET	Alarm reset input
A-4	SERVO	Servo-ON input
B-4	INH	Command pulse inhibition input
A-5	DI 0	General input 0
B-5	DI 1	General input 1
A-6	DI 2	General input 2
B-6	DI 3	General input 3
A-7	DI 4	General input 4
B-7	DI 5	General input 5
A-8	NC	Reserved (use inhibited)
B-8	DO 5	General output 5
A-9	DO 0	General output 0
B-9	DO 1	General output 1
A-10	DO 2	General output 2
B-10	DO 3	General output 3
A-11	DO 4	General output 4
B-11	IN-POS	In-position output
A-12	SRDY	Servo ready output
B-12	ALM	Alarm output
A-13	FG	Frame ground
B-13	FG	Frame ground
A-14	GND	Signal ground
B-14	GND	Signal ground
A-15	PULS+	Command pulse input
B-15	PULS-	Command pulse input
A-16	DIR+	Command direction input
B-16	DIR-	Command direction input
A-17	PA+	Feedback pulse output
B-17	PA-	Feedback pulse output
A-18	PB+	Feedback pulse output
B-18	PB-	Feedback pulse output
A-19	PZ+	Feedback pulse output
B-19	PZ-	Feedback pulse output
A-20	NC	Reserved (use inhibited)
B-20	NC	Reserved (use inhibited)


## Robot Language Table

Command	Description
MOVA	Moves to a point data position.
MOVI	Moves from current position by amount of point data.
MOVF	Moves until a specified DI input is received.
JMP	Jumps to a specified label in the specified program.
JMPF	Jumps to a specified label in a specified program according to the input condition.
JMPB	Jumps to a specified label when general-purpose input or memory input is in the specified state.
L	Defines the jump destination for a JMP or JMPF statement, etc.
CALL	Runs another program.
DO	Turns general-purpose output or memory output on or off.
WAIT	Waits until general-purpose input or memory input is in the specified state.
TIMR	Waits the specified amount of time before advancing to the next step.
P	Defines point variable.
P+	Adds 1 to point variable.
P-	Subtracts 1 from point variable.
SRVO	Turns servo on or off.
STOP	Temporarily stops program execution.
ORGN	Performs return-to-origin.
TON	Runs a specified task.
TOFF	Stops a specified task.


Command	Description
JMPP	Jumps to a specified label when the axis position condition meets the specified conditions.
MAT	Defines a matrix.
MSEL	Specifies a matrix to move.
MOVm	Moves to a specified pallet work position on matrix.
JMPC	Jumps to a specified label when the counter array variable C equals the specified value.
JMPD	Jumps to a specified label when the counter variable D equals the specified value.
CSEL	Specifies an array element for counter array variable C.
C	Defines counter array variable C.
C+	Adds a specified value to counter array variable C.
C-	Subtracts a specified value from counter array variable C.
D	Defines counter variable D.
D+	Adds a specified value to counter variable D.
D-	Subtracts a specified value from counter variable D.
SHFT	Shifts the coordinate position by amount of specified point data.
IN	Stores bit information on specified general-purpose input or memory input into counter variable D.
OUT	Outputs the value of counter variable D to specified generalpurpose output or memory output.
LET	Assigns the value of a specified variable to another variable.
TORQ	Defines the maximum torque command value.



**Input / output wiring diagram**



**Pulse train input / output wiring diagram**



**Pulse train input form**

Logic	Command pulse form	CW direction	CCW direction
Positive logic	Phase A / phase B		
	Pulse / code		
	CW / CCW		

Logic	Command pulse form	CW direction	CCW direction
Positive logic	Phase A / phase B		
Negative logic	Pulse / code		
	CW / CCW		

Articulated robots  
 YA  
 Linear CONVEYOR modules  
 LCM100  
 Compact single-axis robots  
 TRANSERVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XY-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER  
 INFORMATION  
 Robot positioner  
 Pulse string driver  
 Robot controller  
 I/V/I/V2 Electric gripper  
 Option

# Accessories and part options



## ERCD

### Standard accessories

- **24V power connector (for EXT. CN)**



Model	KAU-M4422-00	ERCD
-------	--------------	------

- **I/O flat cable (CN1): 1m**

Connects the standard parallel I/O to an external device. The end of the cable is cut and left as it is.



Model	KAU-M4421-00	ERCD
-------	--------------	------

- **I/O twisted-pair cable (CN2): 2m**

Connects the parallel I/O to an external device. The end of the cable is cut and left as it is.



Note. Select CN2 when using the pulse train input equipment.

Model	KAU-M4421-10	ERCD
-------	--------------	------

### Options

- **Support software for PC P.554**  
**POPCOM+**

POPCOM+ is a simple to use application software that makes tasks such as robot operation, writing-editing programs, and point teaching easy to visually understand.



Model	KBG-M4966-00	LCC140
		ERCD
		SR1-X
		SR1-P


#### Environment

OS	Microsoft Windows XP / Vista (32bit / 64Bit) / 7 (32bit / 64Bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	50MB of available space required on installation drive.
Disk operation	RS-232C
Applicable controllers	SRCX/ERCX/DRCX/TRCX/SRCP/SRCD/ERCD/SR1/LCC140

Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

- **Data cables**

Communication cable for POPCOM+. Select from USB cable or D-sub cable.



Model	USB type (5m)	KBG-M538F-00	LCC140
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10	ERCD
			SR1-X
			SR1-P
			RCX221
			RCX222
			RCX240/S
			RCX340

Note. This USB cable supports Windows 2000/XP or later.  
Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.  
Note. USB driver for communication cable can also be downloaded from our website.

- **Programming box P.561**  
**HPB/HPB-D**

This device can perform all operations such as manual robot operation, program entry and edit, teaching and parameter settings.



	HPB	HPB-D	LCC140
Model	KBB-M5110-01	KBB-M5110-21	ERCD
Enable switch	—	3-position	SR1-X
CE marking	Not supported	Applicable	SR1-P

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSEKVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller

iV/iV2  
Electric  
gripper

Option

# SR1-X/SR1-P

● Robot controller with advanced functions

**Compact design with high performance.**  
**Although with one axis, functions of upper class controllers.**



## Main functions ▶ P.62

Programming box  
 ▶ **HPB/HPB-D**  
**P.561**

Support software for PC  
 ▶ **POPCOM+**  
**P.554**

## Basic specifications

Item	Model	SR1-X			SR1-P		
Driver model		SR1-X05	SR1-X10	SR1-X20	SR1-P05	SR1-P10	SR1-P20
Applicable motor output		200V 100W or less	200V 200W or less	200V 600W or less	200V 100W or less	200V 200W or less	200V 600W or less
Number of controllable axes		Single-axis					
Controllable robots		Single-axis robot FLIP-X (exclude T4L, T5L)			Linear motor single-axis robot PHASER		
Maximum power consumption		400VA	600VA	1400VA	400VA	600VA	1400VA
Capacity of the connected motor		100W	200W	600W	100W	200W	600W
Dimensions		W74 × H210 × D146mm			W74 × H210 × D146mm		W99 × H210 × D146mm
Weight		1.54kg			1.92kg		1.92kg
Input power supply	Control power supply	Single phase AC100 to 115/200 to 230V +/-10% maximum 50/60Hz					
	Motor power supply	Single phase AC100 to 115/200 to 230V +/-10% maximum 50/60Hz		Single phase AC200 to 230V +/-10% maximum 50/60Hz	Single phase AC100 to 115/200 to 230V +/-10% maximum 50/60Hz		Single phase AC200 to 230V +/-10% maximum 50/60Hz
Drive method		AC full-digital software servo					
Position detection method		Multi-turn resolver with data backup function				Magnetic linear scale	
Operating method		Programming, I/O point tracing, Remote command, Operation using RS-232C communication					
Position indication units		mm (millimeters), deg (degrees)					
Speed setting		1% to 100% (Setting by 1% unit)					
Acceleration setting		1. Automatic speed setting per robot No. and payload 2. Setting based on acceleration and deceleration parameter (Setting by 1% unit)					
Resolution		16384 P/rev				1μm	
Origin search method		Absolute, Incremental				Incremental, Semi-absolute	
Program language		YAMAHA SRC					
Multitasks		4 tasks maximum					
Point-data input method		Manual data input (coordinate value input), Direct teaching, Teaching playback					
Programs		100 programs					
		255 steps / 1 programs 3000 steps / total					
Points		1000 points					
STD.DIO	I/O input	Dedicated input 8 points, General input 16 points					
	I/O output	Dedicated Output 4 points, General output 16 points					
SAFETY		Emergency stop input (Normal close contact point input), service mode input					
Brake output		Relay contact				-	
Origin sensor input		Connectable to DC 24V normally-closed contact sensor					
External communications		RS-232C: 1CH (For communication with HPB / HPB-D or PC)					
Analog input/output		Input 1ch (0 to +10V) Output 2ch (0 to +10V)					
	Slots	1					
Options	Type	NPN/PNP: Dedicated input 8 points, Dedicated Output 4 points, General input 16 points, General output 16 points					
		CC-Link: Dedicated input 16 points, Dedicated Output 16 points, General input 32 points, General output 32 points					
		DeviceNet™: Dedicated input 16 points, Dedicated Output 16 points, General input 32 points, General output 32 points					
		PROFIBUS: Dedicated input 16 points, Dedicated Output 16 points, General input 32 points, General output 32 points					

Controllable robot	<b>SR1-X ▶ FLIP-X P.169</b>	<b>SR1-P ▶ PHASER P.215</b>
CE marking		Field networks 

■ Model Overview		
Name	SR1-X	SR1-P
Controllable robot	Single-axis robot FLIP-X	Linear motor single-axis robot PHASER
Input power	05 / 10 driver Single phase 100 to 115V/200 to 230V +/-10% maximum (50/60Hz)	20 driver Single phase 200 to 230V +/-10% maximum (50/60Hz)
Operating method	Programming / I/O point tracing / Remote command / Operation using RS-232C communication	
Maximum number of controllable axes	Single-axis	
Origin search method	Absolute/Incremental	Incremental/Semi-absolute

## ■ Ordering method

### SR1-X

**Controller**

**Driver**  
 05: 100W or less  
 10: 200W  
 20: 400 to 600W

**Usable for CE**  
 No entry: Standard  
 E: CE marking

**Regenerative unit<sup>Note1</sup>**  
 No entry: None  
 R: RG1

**Input/Output Selection**  
 N: NPN  
 P: PNP  
 CC: CC-Link  
 DN: DeviceNet™  
 PB: PROFIBUS  
 YC: YC-Link<sup>Note2</sup>

**Battery**  
 No entry: None (Incremental specification)  
 B: Battery (Absolute specification)

Note 1. Driver selection and regenerative unit selection depends on the robot type. See the selection table on the next page for selecting the driver/regenerative circuit.  
 Note 2. Available only for the slave.

### SR1-P

**Controller**

**Driver**  
 05: 100W or less  
 10: 200W  
 20: 400 to 600W

**Usable for CE**  
 No entry: Standard  
 E: CE marking


**Regenerative unit<sup>Note1</sup>**  
 No entry: None  
 R: RG1

**Input/Output Selection**  
 N: NPN  
 P: PNP  
 CC: CC-Link  
 DN: DeviceNet™  
 PB: PROFIBUS  
 YC: YC-Link<sup>Note2</sup>

Note 1. Driver selection and regenerative unit selection depends on the robot type. See the selection table on the next page for selecting the driver/regenerative circuit.  
 Note 2. Available only for the slave.

Item	Model	SR1-X	SR1-P
Options	Programming box	HPB, HPB-D (with enable switch)	
	Support software for PC	POPCOM+	
	Operating temperature	0°C to 40°C	
	Storage temperature	-10°C to 65°C	
	Operating humidity	35% to 85%RH (non-condensing)	
General Specifications	Absolute backup battery	Lithium metallic battery	
	Absolute data backup period	1 year (in state with no power applied)	
	Noise immunity	IEC61000-4-4 Level 3	

## ■ Part names



Note. Cable for monitor I/O (option) is required when using this connector.

Articulated robots  
YA

Linear motor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

IN/VI/VZ Electric gripper

Option

## Driver / regenerative unit selection table

### SR1-X

		FLIP-X																										
		T4LH/C4LH	T5LH/C5LH	T6L/C6L	T9	T9H	F8/C8	F8L/C8L	F8LH/C8LH	F10/C10	F10H	F14/C14	F14H/C14H	GF14XL	F17/C17	F17L/C17L	GF17XL	F20/C20	F20N	N15/N15D	N18/N18D	B10	B14	B14H	R5	R10	R20	
Driver selection	SR1-X 05	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	SR1-X 10					●					●		●	●														●
	SR1-X 20																											
Regenerative unit	No entry (None)	●	●	●	①	②	●	●	●	①	②	①	②	●	③		⑥	③	④				●	●		⑤	●	●
	R (RG1)				①	②				①	②	①	②		③	●	⑥	③	④		●	●		⑤				

- ① Regenerative unit is needed if using in a perpendicular position and movement stroke is 700mm or more.
- ② Regenerative unit is needed if using in a perpendicular position.
- ③ Regenerative unit is needed if using in a perpendicular position, using at maximum speeds exceeding 1000mm per second, or if using high leads (40).


- ④ Regenerative unit is needed if using at maximum speeds exceeding 1000mm per second.
- ⑤ Regenerative unit is needed if using at maximum speeds exceeding 1250mm per second.
- ⑥ Regenerative unit is needed if using at maximum speeds exceeding 750mm per second.

### SR1-P


		PHASER									
		MR12/MR12D	MR16/MR16D	MR16H/MR16HD	MR20/MR20D	MR25/MR25D	MF7/MF7D	MF15/MF15D	MF20/MF20D	MF30/MF30D	MF75/MF75D
Driver selection	SR1-P 05	●	●				●	●	●	●	
	SR1-P 10			●							
	SR1-P 20				●					●	●
Regenerative unit	No entry (None)	●	●	●	●	●	●				
	R (RG1)							●	●		
	R (RGU-2)										●

## Dimensions



### SR1-X/SR1-P 05 - 10



### SR1-X/SR1-P 20



## Regenerative unit RG1 / RGU-2



### Basic specifications

Item	RG1
Model	KBG-M4107-0A (Including accessory)
Dimensions	W40 × H210 × D146mm
Weight	0.8kg
Regenerative voltage	Approx. 380V or more
Regenerative stop voltage	Approx. 360V or less
Accessory	Cable for connection with controller (300mm)

Note. Always leave an empty space (gap of about 20mm) between this unit and the adjacent controller. Also, always use the dedicated cable when connecting the controller.


### Basic specifications

Item	RGU-2
Model	KS5-M4107-0A (Including accessory)
Dimensions	W40 × H250 × D157mm
Weight	0.9kg
Regenerative voltage	Approx. 380V or more
Regenerative stop voltage	Approx. 360V or less
Accessory	Cable for connection with controller (300mm)

Note. Always leave an empty space (gap of about 20mm) between this unit and the adjacent controller. Also, always use the dedicated cable when connecting the controller.

## Installation conditions

- Install the SR1-X/SR1-P inside the control panel.
- Install the SR1-X/SR1-P on a vertical wall.
- Install the SR1-X/SR1-P in a well ventilated location, with space on all sides of the SR1-X/SR1-P (See fig. at right.).
- Ambient temperature : 0 to 40°C
- Ambient humidity : 35 to 85% RH (no condensation)



## [NPN, PNP type] Input/Output list


Terminal number	Signal name	Function
1	DI.+COM	Input supply+common
2	SERVO	Return to servo on
3	INC-PT	Relative point transfer
4	ABS-PT	Absolute point transfer
5	STEP-R	Step run
6	DI 0	General input 0
7	DI 1	General input 1
8	DI 2	General input 2
9	DI 3	General input 3
10	DI 4	General input 4
11	DI 5	General input 5
12	DI 6	General input 6
13	DI 7	General input 7
14	DO.+COM	Output supply+common
15	DO.+COM	Output supply+common
16	END	Execution result (Execution complete)
17	BUSY	Executing the command
18	DO 0	General output 0
19	DO 1	General output 1
20	DO 2	General output 2
21	DO 3	General output 3
22	DO 4	General output 4
23	DO 5	General output 5
24	DO 6	General output 6
25	DO 7	General output 7

Terminal number	Signal name	Function
26	DI.-COM	Input supply-common
27	AUTO-R	Auto run
28	RESET	Reset
29	ORG-S	Return to the origin
30	ALMRST	Alarm reset
31	DI 8	General input 8
32	DI 9	General input 9
33	DI 10	General input 10
34	DI 11	General input 11
35	DI 12	General input 12
36	DI 13	General input 13
37	DI 14	General input 14
38	DI 15	General input 15
39	DO.-COM	Output supply-common
40	DO.-COM	Output supply-common
41	READY	Available to operate (Ready for operation)
42	UTL	Utility output
43	DO 8	General output 8
44	DO 9	General output 9
45	DO 10	General output 10
46	DO 11	General output 11
47	DO 12	General output 12
48	DO 13	General output 13
49	DO 14	General output 14
50	DO 15	General output 15

## NPN type input/output circuit


### Input circuit

- Form : DC input (positive common type)  
Photo coupler insulation type
- Input power supply : 5mA/point
- Answering time : 30ms or less



### Output circuit


- Form : NPN open collector output (negative common type)  
Photo coupler insulation type
- Load : 50mA/point
- Answering time : 1ms or less



## PNP type input/output circuit


### Input circuit

- Form : DC input (negative common type)  
Photo coupler insulation type
- Input power supply : 5mA/point
- Answering time : 30ms or less



### Output circuit

- Form : PNP open collector output (positive common type)  
Photo coupler insulation type
- Load : 50mA/point
- Answering time : 1ms or less



Articulated robots  
YA  
Linear CONVEYor  
modules  
LCM100  
Compact  
single-axis robots  
TRANSEURO  
Single-axis robots  
FLIP-X  
Linear motor  
single-axis robots  
PHASER  
Cartesian  
robots  
XX-X  
SCARA  
robots  
YK-X  
Pick & place  
robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot  
positioner  
Pulse string  
driver  
Robot  
controller  
I/V/I/V2  
Electric  
gripper  
Option

Articulated robots  
YA

Linear conveyer modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

IV/V/VZ Electric gripper

Option

## SAFETY connector signals

Terminal number	Signal name	Meaning
1	DI.COM	Input supply common
2	LOCK	Interlock
3	SVCE	SERVICE mode
4	DO.COM	Output supply common
5	MPRDY	Main power ready
6	NC	NC
7	NC	NC
8	NC	NC
9	NC	NC
10	NC	NC
11	EMG1	Emergency stop 1
12	EMG2	Emergency stop 2
13	NC	NC
14	NC	NC

## Robot Language Table

Command	Description
MOVA	Moves to a point data position.
MOVI	Moves from current position by amount of point data.
MOVF	Moves until a specified DI input is received.
JMP	Jumps to a specified label in the specified program.
JMPF	Jumps to a specified label in a specified program according to the input condition.
JMPB	Jumps to a specified label in a specified program when general-purpose input or memory input is in the specified state.
L	Defines the jump destination for a JMP or JMPF statement.
CALL	Runs another program.
DO	Turns general-purpose output or memory output on or off.
WAIT	Waits until general-purpose input or memory input is in the specified state.
TIMR	Waits the specified amount of time before advancing to the next step.
P	Defines point variable.
P+	Adds 1 to point variable.
P-	Subtracts 1 from point variable.
SRVO	Turns servo on or off.
STOP	Temporarily stops program execution.
ORGN	Performs return-to-origin.
TON	Runs a specified task.
TOFF	Stops a specified task.
JMPP	Jumps to a specified label when the axis position condition meets the specified conditions.
MAT	Defines a matrix.
MSEL	Specifies a matrix to move.
MOVm	Moves to a specified pallet work position on matrix.
JMPC	Jumps to a specified label when the counter array variable C equals the specified value.
JMPD	Jumps to a specified label when the counter variable D equals the specified value.
CSEL	Specifies an array element for counter array variable C.
C	Defines counter array variable C.
C+	Adds a specified value to counter array variable C.
C-	Subtracts a specified value from counter array variable C.
D	Defines counter variable D.
D+	Adds a specified value to counter variable D.
D-	Subtracts a specified value from counter variable D.
SHFT	Shifts the coordinate position by amount of specified point data.
IN	Stores bit information on specified general-purpose input or memory input into counter variable D.
OUT	Outputs the value of counter variable D to specified general-purpose output or memory output.
LET	Shifts the coordinate position by amount of specified point data.



# Accessories and part options

## SR1-X/SR1-P



### Standard accessories

#### ● Power connector + wiring connection lever



Model KAS-M5382-00

- LCC140
- TS-X
- TS-P
- SR1-X
- SR1-P
- RCX221
- RCX222
- RCX240/S
- RCX340

#### ● Safety connector



Connector plug model KBG-M4424-00  
 Connector cover model KBG-M4425-00

- SR1-X
- SR1-P

#### ● HPB dummy connector

Attach this to the HPB connector during operation with the programming box HPB removed.



Model KDK-M5163-00

- LCC140
- SR1-X
- SR1-P

#### ● NPN / PNP connector



Connector plug model KBH-M4424-00  
 Connector cover model KBH-M4425-00

- SR1-X
- SR1-P
- RCX340

#### ● L type stay

Use to install the controller.



Model KBG-M410H-00

Note. Model No. is for a single bracket (L type stay).

- SR1-X
- SR1-P

#### ● Absolute battery

Battery for absolute data back-up.  
 (Not included with the SR1-P)

##### ● Basic specifications

Item	Absolute battery
Battery type	Lithium metallic battery
Battery capacity	3.6V/2,750mAh
Data holding time	About 1 year (in state with no power applied)
Dimensions	φ17 × L53mm
Weight <sup>Note1</sup>	22g



Model KAS-M53G0-11

Note 1. Weight of battery itself.

Note. The absolute battery is subject to wear and requires replacement.

If trouble occurs with the memory then remaining battery life is low so replace the absolute battery. The battery replacement period depends on usage conditions. But generally you should replace the battery after about 1 year counting the total time after connecting to the controller and left without turning on the power.

- SR1-X
- RCX222
- RCX240/S

#### ● Battery case

This is the absolute battery holder.



Model KBG-M5395-00

- SR1-X
- RCX222
- RCX240/S

See next page for optional parts

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

IN/VI/VZ  
Electric gripper

Option

## Options

### ● Cable for monitor I/O

Cable to connect I/O connector of SR1 monitor. The cable is 1.5m long with its end cut and left as it is. Required when using analog input / output and feedback pulse output.



Model KBG-M4421-00

SR1-X  
SR1-P

### ● Support software for PC **P.554** **POPCOM+**

POPCOM+ is a simple to use application software that makes tasks such as robot operation, writing-editing programs, and point teaching easy to visually understand.



Model KBG-M4966-00

LCC140  
ERCD  
SR1-X  
SR1-P

### ● Environment

OS	Microsoft Windows XP / Vista (32bit/64bit) / 7 (32bit/64bit) 8.1 (32bit/64bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	50MB of available space required on installation drive.
Disk operation	RS-232C
Applicable controllers	SRCX/ERCX/DRCX/TRCX/SRCP/SRCD/ERCD/SR1/LCC140 <sup>Note 1</sup>

Note 1. LCC140 is applicable to Ver. 2.1.1 or later.

Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

### ● Data cables

Communication cable for POPCOM+. Select from USB cable or D-sub cable.



Model	USB type (5m)	KBG-M538F-00
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10

Note. This USB cable supports Windows 2000/XP or later. Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.

Note. USB driver for communication cable can also be downloaded from our website.

LCC140  
ERCD  
SR1-X  
SR1-P  
RCX221  
RCX222  
RCX240/S  
RCX340

### ● Programming box **P.561** **HPB/HPB-D**

This device can perform all operations such as manual robot operation, program entry and edit, teaching and parameter settings.



	HPB	HPB-D
Model	KBB-M5110-01	KBB-M5110-21
Enable switch	-	3-position
CE marking	Not supported	Applicable

LCC140  
ERCD  
SR1-X  
SR1-P

### ● Y-Link board (with connection cable)

Model KBG-M4400-60

SR1-X  
SR1-P

Note. Use the converter cable if changing to the SR1-X, SR1-P from a system using SRCX, SRCP. (See P.603).

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSEKO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller


iV/iV2  
Electric  
grripper

Option

# RCX221/RCX222

## Robot controller with advanced functions

A 2-axis robot controller with a full range of advanced functions in a compact, space-saving size. Very easy to use.



RCX221

RCX222

### Main functions ▶ P.64



Programming box  
▶ RPB/RPB-E  
P.562



Support software for PC  
▶ VIP+  
P.556

### Basic specifications

Item	Model	RCX221	RCX221HP	RCX222	RCX222HP
Basic specifications	Number of controllable axes	2 axes maximum			
	Controllable robots	Single-axis robot FLIP-X, Linear motor single-axis robot PHASER, Cartesian robot XY-X, Pick & place robot YP-X		Single-axis robot FLIP-X, Cartesian robot XY-X, Pick & place robot YP-X	
	Connected motor capacity	2 axes total: 800W or less	2 axes total: 900W to 1200W	2 axes total: 800W or less	2 axes total: 900W to 1200W
	Maximum power consumption	1700VA	2400VA	1700VA	2400VA
	Dimensions	W130 × H210 × D158mm			
Weight	Approx. 2.9kg		Approx. 3.1kg	Approx. 2.9kg	Approx. 3.1kg
Input power supply	Control power supply	Single phase AC200 to 230V +/-10% maximum (50/60Hz)			
	Motor power	Single phase AC200 to 230V +/-10% maximum (50/60Hz)			
Axis control	Drive method	AC full-digital software servo			
	Position detection method	Resolver, Magnetic linear scale		Multi-turn resolver with data backup function	
	Operating method	PTP (Point to Point), Linear interpolation, Circular interpolation, Arch motion			
	Coordinate system	Joint coordinates, Cartesian coordinates			
	Position indication units	Pulses, mm (millimeters), deg (degrees)			
	Speed setting	1% to 100% (In units of 1%. However speed is in units of 0.01% during single-axis operation by DRIVE statement.)			
	Acceleration setting	1. Automatic acceleration setting based on robot model type and end mass parameter 2. Setting based on acceleration and deceleration parameter (Setting by 1% unit)			
	Resolution	1μm		16384 P/rev	
Program	Origin search method	Incremental / Semi-absolute		Absolute / Incremental	
	Program language	YAMAHA BASIC (Conforming to JIS B8439 SLIM Language)			
	Multitasks	8 tasks maximum			
	Sequence program	1 program			
Memory	Point-data input method	Manual data input (coordinate value input), Direct teaching, Teaching playback			
	Memory capacity	364KB (total capacity of program and points) (available program capacity during use of maximum number of points is 84KB)			
	Programs	100 program 9,999: maximum lines per program		98KB: maximum capacity per program	
	Points	10,000 points : maximum numbers of points			
	Memory Backup battery	Lithium metallic battery (service life 4 years at 0°C to 40°C)			
Internal flash memory	512KB (ALL data only)				
External memory backup	SD memory card				

Controllable robot	<b>RCX221 ▶ XY-X <span style="border: 1px solid red; border-radius: 50%; padding: 2px;">P.239</span>, FLIP-X <span style="border: 1px solid red; border-radius: 50%; padding: 2px;">P.169</span>, PHASER <span style="border: 1px solid red; border-radius: 50%; padding: 2px;">P.215</span>, YP-X <span style="border: 1px solid red; border-radius: 50%; padding: 2px;">P.427</span></b>
	<b>RCX222 ▶ XY-X <span style="border: 1px solid red; border-radius: 50%; padding: 2px;">P.239</span>, FLIP-X <span style="border: 1px solid red; border-radius: 50%; padding: 2px;">P.169</span>, YP-X <span style="border: 1px solid red; border-radius: 50%; padding: 2px;">P.427</span></b>

CE marking Field networks **CC-Link DeviceNet Ethernet**

Model Overview		
Name	RCX221/RCX221HP	RCX222/RCX222HP
Controllable robot	Cartesian robot XY-X / Single-axis robot FLIP-X / Linear motor single-axis robot PHASER/ Pick & place robot YP-X	Cartesian robot XY-X / Single-axis robot FLIP-X / Pick & place robot YP-X
Power	Single phase: AC200V to 230V +/-10% maximum (50/60Hz)	
Operating method	Programming / Remote command / Operation using RS-232C communication	
Maximum number of controllable axes	2 axes maximum	
Origin search method	Incremental/Semi-absolute	Absolute/Incremental

### RCX221/RCX221HP

Controller <sup>Note1</sup>	Usable for CE	Regenerative unit <sup>Note2</sup>	Input/Output Selection 1	Input/Output Selection 2
RCX221	No entry: Standard E: CE marking	No entry: None R: RG2	N: NPN P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note3</sup>	No entry: None N1: OP.DIO24/16 (NPN) P1: OP.DIO24/16 (PNP) EN: Ethernet <sup>Note4</sup>
RCX221HP	No entry: Standard E: CE marking	No entry: None R: RG2	N: NPN P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note3</sup>	No entry: None N1: OP.DIO24/16 (NPN) P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note4</sup>

Note 1. Driver selection and regenerative unit selection depends on the robot type. See Specification selection table on following page.  
 Note 2. The regenerative unit (option) is required when operating a model designated by YAMAHA or a load with a large inertia.  
 Note 3. Available only for the master.  
 Note 4. Only when you have selected CC, DN or PB for Input/Output selection 1, you can select EN for Input/Output selection 2.

### RCX222/RCX222HP

Controller <sup>Note1</sup>	Usable for CE	Regenerative unit <sup>Note2</sup>	Input/Output Selection 1	Input/Output Selection 2
RCX222	No entry: Standard E: CE marking	No entry: None R: RG2	N: NPN P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note3</sup>	No entry: None N1: OP.DIO24/16 (NPN) P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note4</sup>
RCX222HP	No entry: Standard E: CE marking	No entry: None R: RG2	N: NPN P: PNP CC: CC-Link DN: DeviceNet <sup>TM</sup> PB: PROFIBUS EN: Ethernet YC: YC-Link <sup>Note3</sup>	No entry: None N1: OP.DIO24/16 (NPN) P1: OP.DIO24/17 (PNP) EN: Ethernet <sup>Note4</sup>


Note 1. Driver selection and regenerative unit selection depends on the robot type. See Specification selection table on following page.  
 Note 2. The regenerative unit (option) is required when operating a model designated by YAMAHA or a load with a large inertia.  
 Note 3. Available only for the master.  
 Note 4. Only when you have selected CC, DN or PB for Input/Output selection 1, you can select EN for Input/Output selection 2.

Item	Model	RCX221	RCX221HP	RCX222	RCX222HP	
External input/output	STD.DIO	I/O input	Dedicated input 10 points, General input 16 points			
		I/O output	Dedicated Output12 points, General output 8 points			
	SAFETY	Emergency stop input (Relay contact), Service mode input (NPN/PNP specification is set according to STD. DIO setting)				
	Brake output	Relay contact				
	Origin sensor input	Connectable to DC 24V normally-closed contact sensor				
	External communications	RS232C: 1CH D-SUB9 (female) RS422 : 1CH (RPB)				
	Options	Slots	2 (inc.STD.DIO)			
		Type	STD.DIO (NPN/PNP): Dedicated input 10 points, Dedicated output 12 points, General input 16 points, General output 8 points Optional input/output (NPN/PNP): General input 24 points / General output 16 points			
			CC-Link: Dedicated input 16 points, Dedicated output 16 points, General input 96 points, General output 96 points (4 nodes occupied)			
			DeviceNet <sup>TM</sup> : Dedicated input 16 points, Dedicated output 16 points, General input 96 points, General output 96 points			
PROFIBUS: Dedicated input 16 points, Dedicated output16 points, General input 96 points, General output 96 points Ethernet: IEEE802.3 10Mbps (10BASE-T)						
Options	Programming box	RPB, RPB-E (with enable switch)				
	Support software for PC	VIP+ / VIP				
General specifications	Operating temperature	0°C to 40°C				
	Storage temperature	-10°C to 65°C				
	Operating humidity	35% to 85%RH (non-condensing)				
	Absolute backup battery	-			Lithium metallic battery 3.6V 5400mAH (2700nAH × 2)	
	Absolute data backup period	-			1 year (in state with no power applied)	
	Noise immunity	IEC61000-4-4 Level3				
Protecting structure	IP10					


Articulated robots YA  
 Linear motor modules LCM100  
 Compact single-axis robots TRANSERVO  
 Single-axis robots FLIP-X  
 Linear motor single-axis robots PHASER  
 Cartesian robots XY-X  
 SCARA robots YK-X  
 Pick & place robots YP-X  
 CLEAN  
 CONTROLLER INFORMATION  
 Robot positioner  
 Pulse string driver  
 Robot controller  
 I/V/M/VZ Electric gripper  
 Option

## Dimensions


### RCX221




### RCX221HP




### RCX222



### RCX222HP




## Part names



Note. Photograph shows RCX222. The component names on the RCX221 are the same but it does not come with an absolute backup battery.

## Regenerative unit RG2



Note. Depth (D) is 158mm. Installs on the right side of the RCX221 (HP), RCX222 (HP). Cannot be installed as a separate unit.

## Basic specifications

Item	RG2
Model	KAS-M4130-00 (including cable supplied with unit)
Dimensions	W35 × H210 × D158mm
Weight	0.8kg
Regenerative voltage	Approx. 380V or more
Regenerative stop voltage	Approx. 360V or less
Accessory	Cable for connection with controller (300mm)

Note. Installs on the right side of the RCX221 (HP), RCX222 (HP). Cannot be installed as a separate unit.

## Specification selection table

The robot type automatically determines the normal specifications or HP specifications.

### RCX221/RCX221HP

	PHASER						
	MR12D	MF7D	MF15D	MF20D	MF30D	MF50D	MF75D
RCX221	●	●	●	●	●	●	●
RCX221HP	●	●	●	●	●	●	●
Regenerative unit R (RG2)	No entry (None)	●	●	●	●	●	●

● : Applicable

### RCX222/RCX222HP

	FLIP-X	XY-X										YP-X	Clean								
		Arm type, Gantry type, Moving arm type, Pole type					XZ type														
	N15D	N18D	PXYx	FXYx	FXBYx	SXYx	SXYBx	NXY	MXYx	HXYx	HXYLx	SXYx (ZF)	SXYx (ZFL20)	SXYBx (ZF)	SXYBx (ZFL20)	MXYx	HXYx	YP220BX	YP320X	SXYx-C	
RCX222	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
RCX222HP	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
Regenerative unit R (RG2)	No entry (None)	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●
	●	●	●	●	●	●	○	●	●	●	●	●	●	●	●	●	●	●	●	●	●

● : Applicable ○ : Select per conditions

## Power capacity

Required power supply capacity varies according to the robot type and number of axes. Prepare a power supply using the following table as a general guide.

### When connected to 2 axes (Cartesian robot or multi-axis robot)

Axial current sensor value		Power capacity (VA)
X axis	Y axis	
05	05	500
10	05	700
10	10	900
20	05	1500
20	10	1700
20	20	2000
20	20	2400 (HP)

Note. Even if axial current sensor values for each axis are interchanged no problem will occur.

### Motor capacity vs. current sensor table

Connected motor capacity	Current sensor
100W or less	05
200W	10
400W or more	20


Note. Motor output of the B14H is 200W but the current sensor is 05.

## Conditions where regenerative unit is needed on multi robots

- Motor capacity exceeds a total of 450W.
- Motor capacity for perpendicular axis exceeds a total of 240W.
- The following conditions apply when perpendicular axis capacity is 240W or less.
  - perpendicular axis is 200W.
  - perpendicular axis is 100W and stroke is 700mm or more.
  - there are 2 perpendicular axes at 100W, and includes leads of 5mm.
- B14H which maximum speed exceeds 1250mm per second.


## Installation conditions

- Install the RCX221/RCX222 inside the control panel.
- Install the RCX221/RCX222 on a flat, level surface.
- Install the RCX221/RCX222 in a well ventilated location, with space on all sides of the RCX221/RCX222 (See fig. at right.).
- Do not block the heat-sink on the side panel.
- Do not block the fan on the bottom of the controller.
- Ambient temperature : 0 to 40°C
- Ambient humidity : 35 to 85% RH (no condensation)




\*Provide the same space dimensions for RCX222.



## Example of input signal connection



## Example of output signal connection



## Emergency input signal connections



## SAFETY connector signals

Terminal number	I/O No.	Name
1	DI.COM	Dedicated input common
2	INTERLOCK	Interlock signal
3	SERVICE	SERVICE mode input
4	DO.COM	Dedicated output common
5	MPRDY	Main power supply ready
6	SERVO OUT	Servo-on state output
7	NC	No connection
8	KEY1	RPB key switch contact
9	KEY2	RPB key switch contact
10	24VGND	EMG 24V, GND

Terminal number	I/O No.	Name
11	EMG24V	Power supply for emergency stop input
12	EMGRDY	Emergency stop ready signal
13	EMGIN1	Emergency stop input 1
14	EMGIN2	Emergency stop input 2
15	EMGIN3	Emergency stop input 3
16	EMGIN4	Emergency stop input 4
17	LCKIN1	Enable switch input 1
18	LCKIN2	Enable switch input 2
19	LCKIN3	Enable switch input 3
20	LCKIN4	Enable switch input 4

Articulated robots  
YA  
Linear robot modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
I/V/V/V2 Electric gripper  
Option

Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Robot positioner

Pulse string driver

Robot controller

IV/V/VZ Electric gripper

Option

## Standard I/O [connector name: STD. DIO] signal table

Terminal number	Signal name	Name	
		RCX221	RCX222
1	DI01	Servo ON	
2	DI10	Sequence program control	
3	DI03	Step run	
4	CHK1	Check input 1	
5	DI05	I/O command run	
6	DI06	Spare <sup>Note 1</sup>	
7	DI07	Spare <sup>Note 1</sup>	
8	DI20	General input 20	
9	DI21	General input 21	
10	DI22	General input 22	
11	DI23	General input 23	
12	DI24	General input 24	
13	DI25	General input 25	
14	DI26	General input 26	
15	DI27	General input 27	
16	DO00	EMG monitor (emergency stop monitor)	
17	DO01	CPU OK	
18	DO10	AUTO mode	
19	DO11	Return-to-origin complete	
20	DO12	Sequence program in progress	
21	DO13	Auto operation in progress	
22	DO14	Program reset output	
23	DO15	Battery alarm output <sup>Note 2</sup>	
24	DO16	END	
25	DO17	BUSY	
26	DI12	Auto operation start	
27	DI13	AUTO mode switching	
28	DI14	ABS reset (Not in use normally)	Return-to-origin <sup>Note 3</sup>
29	DI15	Program reset	
30	DI16	MANUAL mode	
31	DI17	Return-to-origin (In use normally)	ABS reset <sup>Note 4</sup>
32	DI30	General input 30	
33	DI31	General input 31	
34	DI32	General input 32	
35	DI33	General input 33	
36	DI34	General input 34	
37	DI35	General input 35	
38	DI36	General input 36	
39	DI37	General input 37	
40	CHK2	Check input 2	
41	DO02	Servo-on state	
42	DO03	Alarm	
43	DO20	General output 20	
44	DO21	General output 21	
45	DO22	General output 22	
46	DO23	General output 23	
47	DO24	General output 24	
48	DO25	General output 25	
49	DO26	General output 26	
50	DO27	General output 27	

Note 1. Use of DI06, DI07 is prohibited.

Note 2. DO15 is a memory backup battery voltage drop alarm output.

Note 3. Set origin return for axes using incremental specifications and axes using semi-absolute specifications.

Note 4. Set origin return on axes using absolute specifications.

Area check output can be assigned to DO20 to DO157.

(Area check output assignment differs depending on the controller software version. See the user's manual for details.)

## Option I/O [connector name: OP. DIO] signal table

Terminal number	Signal name	Name
1	–	Spare
2	DI40	General input
3	–	Spare
4	DI41	General input
5	–	Spare
6	–	Spare
7	–	Spare
8	DI50	General input
9	DI51	General input
10	DI52	General input
11	DI53	General input
12	DI54	General input
13	DI55	General input
14	DI56	General input
15	DI57	General input
16	–	Spare
17	–	Spare
18	DO30	General output
19	DO31	General output
20	DO32	General output
21	DO33	General output
22	DO34	General output
23	DO35	General output
24	DO36	General output
25	DO37	General output
26	DI42	General input
27	DI43	General input
28	DI44	General input
29	DI45	General input
30	DI46	General input
31	DI47	General input
32	DI60	General input
33	DI61	General input
34	DI62	General input
35	DI63	General input
36	DI64	General input
37	DI65	General input
38	DI66	General input
39	DI67	General input
40	–	Spare
41	–	Spare
42	–	Spare
43	DO40	General output
44	DO41	General output
45	DO42	General output
46	DO43	General output
47	DO44	General output
48	DO45	General output
49	DO46	General output
50	DO47	General output



## Robot Language Table

### General commands

Language	Function
DECLARE	Declares that a label or sub-procedure is in an external program.
DEF FN	Defines a function that is available to the user.
DIM	Declares the name of an array variable and the number of elements.
EXIT FOR	Terminates a FOR statement to NEXT statement loop.
FOR to NEXT	Controls repetitive operations
GOSUB to RETURN	Jumps to a subroutine with the label specified by a GOSUB statement and executes the subroutine.
GOTO	Unconditionally jumps to the line specified by a label.
HALT	Stops a program and resets it.
HOLD	Pauses a program.
IF	Allows control flow to branch according to conditions.
LET	Executes a specified assignment statement.
ON to GOSU	Jumps to a subroutine with each label specified by a GOSUB statement according to conditions and executes the subroutine.
ON to GOTO	Jumps to each line specified by a label according to conditions.
REM	All characters that follow REM or an apostrophe (') are viewed as comments.
SELECT CASE to END SELECT	Allows control flow to branch according to conditions.
SWI	Switches the currently executed program to a specified program, and executes from the first line after compiling.
WHILE to WEND	Controls repetitive operations.
Label statement	Defines "labels" in program lines.

### Robot operation

Language	Function
ABSRST	Performs return-to-origin along robot absolute motor axes.
DRIVE	Performs an absolute movement of each axis in the main group.
DRIVEI	Performs a relative movement of each axis in the main group.
MOVE	Performs an absolute movement of the main robot axes.
MOVEI	Performs a relative movement of the main robot axes.
ORIGIN	Performs return-to-origin on an incremental mode axis or absolute search on a semi-absolute mode axis.
PMOVE	Performs a pallet movement of the main robot axes.
SERVO	Controls the servo ON/OFF of the specified axes in the main group or all axes (in main group and sub group).

### I/O control

Language	Function
DELAY	Waits for the specified length of time (ms).
DO	Outputs the specified value to the DO ports.
LO	Outputs the specified value to the LO port to prohibit axis movement or permit axis movement.
MO	Outputs the specified value to the MO ports.
OUT	Turns ON the bits of the specified output ports and the command statement ends.
RESET	Turns OFF the bits of the specified output ports.
SET	Turns ON the bits of the specified output ports
SO	Outputs the specified value to the SO port.
TO	Outputs the specified value to the TO port.
WAIT	1. Waits until the condition in DI/DO conditional expression are met. 2. Waits until positioning on the robot axes is complete (within the tolerance range).

### Coordinate control

Language	Function
CHANGE	Switches the hand of the main robot.
HAND	Defines the hand of the main robot.
RIGHTY / LEFTY	Selects whether the main robot will be "right-handed" or "left-handed" when moving to a point specified on a Cartesian coordinate system.
SHIFT	Sets the shift coordinates for the main robot by using the shift data specified by a shift variable.

### Condition change

Language	Function
ACCEL	Changes the acceleration coefficient parameter of the main group.
ARCH	Changes the arch position parameter of the main group.
ASPEED	Changes the automatic movement speed of the main group.
AXWGHT	Changes the axis tip weight parameter of the main group.
DECEL	Changes the deceleration rate parameter of the main group.
ORGORD	Sets the axis sequence parameter to perform return-to-origin and absolute search in the main group.
OUTPOS	Changes the OUT position parameter of the main group.
PDEF	Defines the pallet used to execute a pallet movement command.
SPEED	Changes the program speed for the main group.
TOLE	Changes the tolerance parameter of the main group.
WEIGHT	Changes the tip weight parameter of the main robot.

### Communication control

Language	Function
ONLINE / OFFLINE	Changes communication mode and initialize the communication port.
SEND	Sends the read file data into a write file.

### Screen control

Language	Function
PRINT	Displays the value of specified variable on the MPB/RPB screen.

### Key control

Language	Function
INPUT	Assigns a value to the variable specified from the MPB/RPB.

### Procedure

Language	Function
CALL	Calls up sub-procedures defined by the SUB and END SUB statements.
EXIT SUB	Terminates the sub-procedure defined by the SUB and END SUB statements.
SHARED	Does not permit variables declared with a program written outside a subprocedure (SUB to END SUB) to be passed on as dummy arguments, but allows them to be referred to with a sub-procedure.
SUB to END SUB	Defines a sub-procedure.

### Task control

Language	Function
CHGPRI	Changes the priority of the specified task.
CUT	Terminates a task currently being executed or temporarily stopped.
EXIT TASK	Terminates its own task currently being executed.
RESTART	Restarts a task that is temporarily stopped.
START	Sets the task number and priority of the specified task and starts that task.
SUSPEND	Temporarily stops another task being executed.

### Error control

Language	Function
ON ERROR GOTO	If an error occurs during program execution, this command allows the program to jump to the error processing routine specified by the label without stopping the program, or stops the program and displays the error message.
RESUME	Resumes the program execution after recovery from an error. This command is used in the error processing routine.
ERL	Gives the line number where an error occurred.
ERR	Gives the error code number when an error occurred.

### PATH control

Language	Function
PATH	Sets the PATH motion on the main robot axis.
PATH END	Terminates the path setting for PATH motion.
PATH SET	Starts the path setting for PATH motion.
PATH START	Starts the PATH motion.

### Torque control

Language	Function
DRIVE (with torque limit option)	Executes an absolute movement command on each axis in the main group.
TORQUE	Changes the maximum torque instruction for the specified main group axis.
TRQTIME	Sets the current limit time-out period on the specified main group axis when using a torque limit setting option in the DRIVE statement.
TRQTIME	Sets the current limit time-out period on the specified main group axis when using a torque limit setting option in the DRIVE statement.

Articulated robots  
YA

Linear coordinate robots  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

INVA/NV2 Electric gripper

Option

## Accessories and part options

### RCX221/RCX222



#### Standard accessories

- LCC140
- TS-X
- TS-P
- SR1-X
- SR1-P
- RCX221
- RCX222
- RCX240/S
- RCX340

● **Power connector + wiring connection lever**



Model KAS-M5382-00

● **Safety connector**



Model KAS-M5370-00

- RCX221
- RCX222

● **RPB terminator (dummy connector)**

Attach this to the RPB connector during operation with the programming box RPB removed.



Model KAS-M5163-30

- RCX221
- RCX222
- RCX240/S

● **Standard I/O (STD.DIO) connector**



Model KAS-M533G-00

- RCX221
- RCX222

● **Option I/O (OP.DIO) connector**



Model KAS-M533G-10

- RCX221
- RCX222

● **L type stay (for installing front side, rear side.)**

Use to install the controller.



Model KAS-M410H-00

Note. Model No. is for a single bracket (L type stay).  
(Two are required to install one controller.)

- RCX221
- RCX222

● **Absolute battery**

Battery for absolute data back-up.  
(Not included with the RCX221)

● **Basic specifications**

Item	Absolute battery
Battery type	Lithium metallic battery
Battery capacity	3.6V/2,750mAh
Data holding time	About 1 year <sup>Note1</sup> (in state with no power applied)
Dimensions	φ17 × L53mm
Weight <sup>Note2</sup>	22g



Model KAS-M53G0-11

Note 1. When using 2 batteries.

Note 2. Weight of battery itself.

Note. The absolute battery is subject to wear and requires replacement.

If trouble occurs with the memory then remaining battery life is low so replace the absolute battery. The battery replacement period depends on usage conditions. But generally you should replace the battery after about 1 year counting the total time after connecting to the controller and left without turning on the power.

- SR1-X
- RCX222
- RCX240/S

**Important**

**Absolute battery installation conditions**

- 1 to 2 batteries are required for each 2 axes.
- 1 battery.....Data storage time of approximately 6 months (with no power applied)
- 2 batteries....Data storage time of approximately 1 year (with no power applied)

Note. Absolute battery is not required for either of the 2 axes if using incremental or semi-absolute specifications.

● **Battery case**

This is the absolute battery holder.



Model KBG-M5395-00

- SR1-X
- RCX222
- RCX240/S

## Options

### ● Programming box RPB/RPB-E

**P.562**

This device can perform all operations such as manual robot operation, program entry and edit, teaching and parameter settings.



	RPB	RPB-E
Model	KBK-M5110-10	KBK-M5110-00
Enable switch	—	3-position
CE marking	Not supported	Applicable

**RCX221**  
**RCX222**  
**RCX240/S**

### ● Support software for PC VIP+

**P.556**

VIP+ is a simple to use application software that makes tasks such as robot operation, writing-editing programs, and point teaching easy to visually understand.



VIP+ software model	KX0-M4966-00
---------------------	--------------

**RCX221**  
**RCX222**  
**RCX240/S**


### ● Environment

OS	Microsoft Windows 2000 / XP / Vista (32bit / 64Bit) / 7 (32bit / 64Bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	40MB of available space required on installation drive.
Communication method	RS-232C, Ethernet Note. For Ethernet communication, Ethernet unit for RCX series controller is required.
Applicable robot controllers	RCX221 / RCX222 / RCX141 / RCX142 / RCX240 / RCX240S

Note. Microsoft and Windows are registered trademarks of Microsoft Corporation.  
 Note. ADOBE and ADOBE READER are registered trademarks of Adobe Systems Incorporated.  
 Note. Ethernet is a registered trademark of Xerox Corporation.

### ● Data cables

Communication cable for VIP+.  
 Select from USB cable or D-sub cable.



Model	USB type (5m)	KBG-M538F-00
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10

Note. This USB cable supports Windows 2000/XP or later.  
 Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.  
 Note. USB driver for communication cable can also be downloaded from our website.

**LCC140**  
**ERCD**  
**SR1-X**  
**SR1-P**  
**RCX221**  
**RCX222**  
**RCX240/S**  
**RCX340**

Articulated robots  
 YA  
 Linear controller modules  
 LCM100  
 Compact single-axis robots  
 TRANSERVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XX-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER  
 INFORMATION  
 Robot positioner  
 Pulse string driver  
 Robot controller  
 I/V/V/V2 Electric gripper  
 Option

# RCX240/RCX240S

## Robot controller with advanced functions

An advanced multi-axial controller newly developed based on long years of actual results! Along with a full range of functions, great engineering also makes it extremely easy to use.



RCX240



RCX240S

## Main functions ▶ P.64




Programming box  
▶ RPB/RPB-E  
P.562



Support software for PC  
▶ VIP+  
P.556

## Basic specifications

Item	Model	RCX240 / RCX240S
Basic specifications	Number of controllable axes	4 axes maximum (Control simultaneously: 4 axes)
	Controllable robots	Single-axis robot FLIP-X, Linear motor single-axis robot PHASER, Cartesian robot XY-X, SCARA robot YK-XG, Pick & place robot YP-X
	Maximum power consumption	2500VA (RCX240) / 1500VA (RCX240S)
	Capacity of the connected motor	1600W (RCX240) / 800W (RCX240S)
	Dimensions	W180 × H250 × D235mm
Weight		6.5kg
	Input power supply	Control power supply: Single phase AC200 to 230V +/-10% maximum (50/60Hz) Motor power supply: Single phase AC200 to 230V +/-10% maximum (50/60Hz)
Axis control	Drive method	AC full-digital software servo
	Position detection method	Multi-turn resolver with data backup function, Magnetic linear scale
	Operating method	PTP (Point to Point), Linear interpolation, Circular interpolation, ARCH
	Coordinate system	Joint coordinates, Cartesian coordinates
	Position indication units	Pulses, mm (millimeters), deg (degrees)
	Speed setting	1% to 100% (In units of 1%. However speed is in units of 0.01% during single-axis operation by DRIVE statement.)
	Acceleration setting	1. Automatic acceleration setting based on robot model type and end mass parameter 2. Setting based on acceleration and deceleration parameter (Setting by 1% unit)
Program	Origin search method	Incremental, Absolute, Semi-absolute
	Program language	YAMAHA BASIC (Conforming to JIS B8439 SLIM Language)
	Multitasks	8 tasks maximum
	Sequence program	1 program
Memory	Point-data input method	Manual data input (coordinate value input), Direct teaching, Teaching playback
	Memory capacity	364KB (total capacity of program and points) (available program capacity during use of maximum number of points is 84KB)
	Programs	100 program (Max.) 9,999: maximum lines per program 98KB: maximum capacity per program
	Points	10,000 points: maximum numbers of points
	Memory Backup battery	Lithium metallic battery (service life 4 years at 0°C to 40°C)
	Internal flash memory	512KB (ALL data only)

Controllable robot	<b>XY-X P.239</b>	<b>YK-X P.367</b>	<b>FLIP-X P.169</b>	<b>PHASER P.215</b>	<b>YP-X P.427</b>
CE marking	Field networks <b>CC-Link DeviceNet EtherNet/IP Ethernet</b> 				

## Model Overview

Name	RCX240/RCX240S
Controllable robot <sup>Note</sup>	Cartesian robot XY-X / SCARA robot YK-X / Single-axis robot FLIP-X / Linear motor single-axis robot PHASER / Pick & place robot YP-X
Input power	Single phase : AC200V to 230V +/-10% maximum (50/60Hz)
Operating method	Programming / Remote command / Operation using RS-232C communication
Maximum number of controllable axes	4 axes maximum
Origin search method	Incremental/Absolute

Note. For details, please refer to the controller model selection table on the next page.

## Ordering method

### RCX240 RCX240S

Controller <sup>Note1</sup>	Usable for CE	Regenerative unit <sup>Note2</sup>	Option I/O	Network Option	iVY System Option board	Light/Tracking	Gripper	Battery
RCX240: Standard model RCX240S: Low capacity model	No entry: Standard E: CE marking K: KCs	No entry: None R: RGU-2 R3: RGU-3 <sup>Note3</sup>	N, P: Standard I/O 16/8 N1, P1: 40/24 points N2, P2: 64/40 points N3, P3: 88/56 points N4, P4: 112/72 points	No entry: None CC: CC-Link DN: DeviceNet™ PB: PROFIBUS EN: Ethernet EP: EtherNet/IP™ YC: YC-Link <sup>Note5</sup>	No entry: None VY: iVY (VISION)	No entry: None TR: Light+Tracking LC: Light	No entry: None GR: Gripper	No entry: None <sup>Note6</sup> B: 2pcs <sup>Note7</sup> BB: 4pcs <sup>Note8</sup>

**Note 1.** The RCX240S controller is limited to use with robots that handles 200W or lower on each axis. Check the following controller selection table to find the matching model.

**Note 2.** The regenerative unit (option) is required when operating a model designated by YAMAHA or a load with a large inertia. Please refer to the following regenerative unit selection table.

**Note 3.** YK500XG to YK1000XG are for RGU-3.

**Note 4.** Use N to N4 when NPN is selected on the I/O board, and P to P4 when PNP is selected.

**Note 5.** Available only for the master. (The YC-Link system controls an SR1 series single-axis controller in accordance with communications received from an RCX series multi-axis controller. Using the YC-Link system allows control of up to 8 axes (or up to 6 axes with synchronous control)).

**Note 6.** Use battery-less model if connecting to all-axis linear motor, or to incremental models.

**Note 7.** If any or Single-axis among the XY axes are absolute specifications then 2 batteries are required.

**Note 8.** If any or Single-axis among the ZR axes are absolute specifications then 2 batteries are required.

**☆ Please note that:**


The current sensor on the RCX240S cannot be set to 20A.  
 As a controller stocked for maintenance, please order an RCX240 that can be set to any of 05A, 10A and 20A.

Item	Model	RCX240 / RCX240S		
External input/output	STD.DIO	I/O input	Dedicated input 10 points, General input 16 points (NPN / PNP specifications selectable)	
		I/O output	Dedicated output 11 points, General output 8 points	
	SAFETY		Emergency stop input (Relay contact), Service mode input (NPN/PNP specification is set according to STD. DIO setting), Enabling switch input (Enabled only when the RPB-E is used.)	
	Brake output		Relay contact	
	Origin sensor input		Connectable to DC 24V normally-closed contact sensor	
	External communications		RS-232C: 1CH D-SUB9 (female) RS-422: 1CH (Dedicated RPB)	
	Regenerative unit connection		RGEN connector	
	Options	Type	Slots	4
			Optional input/output (NPN/PNP)	General input 24 points, General output 16 points
			CC-Link	Dedicated input 16 points, Dedicated Output 16 points, General input 96 points, General output 96 points (4 nodes occupied)
			DeviceNet™	Dedicated input 16 points, Dedicated Output 16 points, General input 96 points, General output 96 points
			PROFIBUS	Dedicated input 16 points, Dedicated Output 16 points, General input 96 points, General output 96 points
			Ethernet	IEEE802.3 10Mbps (10BASE-T)
			EtherNet/IP™	Dedicated input 16 points, dedicated output 16 points, General-purpose input 96 points, general-purpose output 96 points Conforms to Ethernet (IEEE 802.3) 10Mbps/100Mbps.
			iVY	Camera input (2ch), camera trigger input, PC connection input
Tracking			AB phase input, lighting trigger input, lighting power supply input/output	
Lighting control			Lighting trigger input, lighting power supply input/output	
Gripper control	No. of axes: 1 axis, Position detection method: Optical rotary encoder, Min. setting distance: 0.01mm			
General specifications	Programming box		RPB, RPB-E (with enable switch)	
	Support software for PC		VIP+	
	Regenerative unit		RGU-2, RGU-3	
	Operating temperature		0°C to 40°C	
	Storage temperature		-10°C to 65°C	
	Operating humidity		35% to 85%RH (non-condensing)	
	Absolute backup battery		Lithium metallic battery 3.6V 5400mAH (2700mAH × 2)	
	Absolute data backup period		1 year (in state with no power applied)	
	Noise immunity		IEC61000-4-4 Level 3	
Protective structure		IP10		

Articulated robots  
YA  
 Linear motor modules  
LCM100  
 Compact single-axis robots  
TRANSEVO  
 Single-axis robots  
FLIP-X  
 Linear motor single-axis robots  
PHASER  
 Cartesian robots  
XY-X  
 SCARA robots  
YK-X  
 Pick & place robots  
YP-X  
 CLEAN  
 CONTROLLER INFORMATION  
 Robot positioner  
Pulse string driver  
Robot controller  
iVY/iVY2 Electric gripper  
 Option



## ■ Dimensions



## ■ Power supply capacity and heat emission

The required power supply capacity and heat emission will vary depending on the robot type and number of axes.

Using the following table as a general guide consider the required power supply preparation and control panel size, controller installation, and cooling method.

### (1) When connected to SCARA robot

Robot type					Power capacity (VA)	Generated heat amount (W)
Standard type	Clean type	Dust-proof & drip-proof type	Wall-mount / Ceiling-mount / inverse type	Orbit type		
YK180X, 220X	-	-	-	-	500	63
YK250XG, 350XG, 400XG, 500XGL, 600XGL	YK250XGC, 350XGC, 400XGC, 500XGLC, 600XGLC	YK250XGP, 350XGP, 400XGP, 500XGLP, 600XGLP	YK300XGS, 400XGS	-	1000	75
-	YK500XC, 600XC	-	-	-	1500	88
YK550X, 500XG, 600XG	-	YK500XGP, 600XGP	YK500XGS, 600XGS	-	1700	93
-	YK700XC, 800XC, 1000XC	-	-	-	2000	100
YK600XGH, 700XG, 800XG, 900XG, 1000XG, 1200X	-	YK600XGHP, 700XGP, 800XGP, 900XGP, 1000XGP	YK700XGS, 800XGS, 900XGS, 1000XGS	YK350TW, YK500TW	2500	113

### (2) When connected to 2 axis (Cartesian robot and/or multi-axis robot)

Axial current sensor value <sup>Note</sup>		Power capacity (VA)	Generated heat amount (W)
X axis	Y axis		
05	05	600	65
10	05	800	70
10	10	1000	75
20	05	1100	78
20	10	1300	83
20	20	1700	93

### (3) When connected to 3 axis (Cartesian robot and/or multi-axis robot)

Axial current sensor value <sup>Note</sup>			Power capacity (VA)	Generated heat amount (W)
X axis	Y axis	Z axis		
05	05	05	700	68
10	05	05	900	73
10	10	05	1000	75
10	10	10	1200	80
20	05	05	1200	80
20	10	05	1300	83
20	10	10	1500	88
20	20	05	1600	90
20	20	10	1800	95
20	20	20	2000	95

### (4) When connected to 4 axis (Cartesian robot and/or multi-axis robot)

Axial current sensor value <sup>Note</sup>				Power capacity (VA)	Generated heat amount (W)
X axis	Y axis	Z axis	R axis		
05	05	05	05	800	70
10	05	05	05	1000	75
10	10	05	05	1100	78
10	10	10	05	1300	83
10	10	10	10	1400	85
20	05	05	05	1200	80
20	10	05	05	1400	85
20	10	10	05	1500	88
20	10	10	10	1700	93
20	20	05	05	1600	90
20	20	10	05	1800	95
20	20	10	10	2000	100
20	20	20	05	2100	103
20	20	20	10	2200	105
20	20	20	20	2500	113


Note. Even if axial current sensor values for each axis are interchanged no problem will occur.

Note. Motor capacity vs. current sensor table

Connected motor capacity	Current sensor
100W or less	05
200W	10
400W or more	20

Note. Motor output of the B14H is 200W but the current sensor is 05.

## Regenerative unit



## RGU-2 basic specifications



Item	RGU-2
Model	KX0-M4107-20 (including cable supplied with unit)
Dimensions	W40 × H250 × D157mm
Weight	0.9kg
Regenerative voltage	Approx. 380V or more
Regenerative stop voltage	Approx. 360V or less
Accessory	Cable for connection with controller (300mm)

Note. Always leave an empty space (gap of about 20mm) between this unit and the adjacent controller. Also, always use the dedicated cable when connecting the controller.


## RGU-3 basic specifications




Item	RGU-3
Model	KX0-M4107-30 (including cable supplied with unit)
Dimensions	W62 × H250 × D242.5mm
Weight	3.7kg
Regenerative voltage	Approx. 380V or more
Regenerative stop voltage	Approx. 360V or less
Accessory	Cable for connection with controller (300mm)

Note. Cannot be installed as a separate unit.



## Example of input signal connection



## Example of output signal connection



## Emergency input signal connections



Installing an external safety circuit will satisfy safety category class 4 standards. See P.615 for more information.



## ■ Connector input / output signals

PIN	I/O No.	Name	Note	PIN	I/O No.	Name	Note
1	DI05	I/O command execution trigger input		27	COMMON	Relay common	
2	DI01	Servo ON input		28	DO01b	CPU_OK (B contact)	
3	DI10	Sequence control		29	DO01a	CPU_OK (A contact)	
4	DI11	Interlock		30	DO02b	Servo ON output (B contact)	(Relay output) Maximum capacity of each terminal (resistance load) : DC 24V 0.5A Common terminal : COMMON
5	DI12	Program start		31	DO02a	Servo ON output (A contact)	
6	DI13	AUTO mode input		32	DO03b	Alarm (B contact)	
7	DI14	Return-to-origin		33	DO03a	Alarm (A contact)	
8	DI15	Program reset		34	DO10	AUTO mode output	
9	DI16	MANUAL mode input		35	DO11	Return-to-origin complete	
10	DI17	Absolute reset / Return-to-origin	Common terminal : P.COMDI N.COMDI	36	DO12	Sequence program in-progress	
11	DI20	General input 20					
12	DI21	General input 21	(Photo-coupler input) NPN specification	37	DO13	Robot program in-progress	
13	DI22	General input 22					
14	DI23	General input 23	: Source type PNP specification	38	DO14	Program reset	
15	DI24	General input 24					
16	DI25	General input 25	: Sink type	39	DO20	General output 20	
17	DI26	General input 26					
18	DI27	General input 27		40	DO21	General output 21	
19	DI30	General input 30		41	DO22	General output 22	
20	DI31	General input 31		42	DO23	General output 23	
21	DI32	General input 32		43	DO24	General output 24	
22	DI33	General input 33		44	DO25	General output 25	
23	DI34	General input 34		45	DO26	General output 26	
24	DI35	General input 35		46	DO27	General output 27	
25	DI36	General input 36		47	DC24V	DC+24V (P.COMDI)	External power supply input
26	DI37	General input 37		48	GND	GND (N.COMDI)	
				49			
				50			

Note. When using the CC-Link, DeviceNet™, EtherNet/IP™, or PROFIBUS, the dedicated inputs other than the interlock signal (DI11) of the STD.DIO that are provided on the RCX240 controller are disabled.  
 Additionally, when the external 24V monitor control of the system parameters is set disabled, the interlock signal (D11) becomes disabled.

## ■ SAFETY connector signals

Terminal number	RPB connected		RPB-E connected	
	I/O No.	Name	I/O No.	Name
1	DI02	SERVICE mode	DI02	SERVICE mode
2	MP READY	Motor power ready signal	MP READY	Motor power ready signal
3	E-STOPIN 1	Emergency stop input 1	E-STOPIN 1	Emergency stop input 1
4	E-STOPIN 2	Emergency stop input 2	E-STOPIN 2	Emergency stop input 2
5	NC	NC	E-STOPIN 3	Emergency stop input 3
6	NC	NC	E-STOPIN 4	Emergency stop input 4
7	NC	NC	LCKIN 1	Enabling switch input 1
8	NC	NC	LCKIN 2	Enabling switch input 2
9	NC	NC	LCKIN 3	Enabling switch input 3
10	NC	NC	LCKIN 4	Enabling switch input 4
11	P.COM	DC+24V (P.COM DI)	P.COM	DC+24V (P.COM DI)
12	N.COM	GND (N.COM DI)	N.COM	GND (N.COM DI)
13	E-STOP 24V	Emergency stop input supply	E-STOP 24V	Emergency stop input supply
14	E-STOPRDY	Emergency stop READY signal	E-STOPRDY	Emergency stop READY signal
15	NC	NC	NC	NC

## ■ Standard functions of the controller

Function	Description
<b>Operation mode</b>	Automatic mode (main task: execution of program, execution of step), Program mode (main task: creation of program), Manual mode (main task: jog movement, point teaching), System mode (main task: parameter editing, data initialization), Utility mode (main task: operation of motor power source)
<b>Command</b>	Array declarator command (DIM statement), Assignment command (numeric value assignment statement, character string assignment statement, point definition statement), Movement related command (MOVE statement, DRIVE statement, PMOVE statement), Condition branching command (IF statement, FOR statement, WHILE statement), External output command (DO statement, MO statement, LO statement, TO statement, SO statement), Parameter command (ACCEL statement, OUTPOS statement, TOLE statement), Task related command (START statement, SUSPEND statement, CUT statement), Condition wait command (WAIT statement), etc.
<b>Function</b>	Arithmetic function (SIN function, COS function, TAN function), Character string function (STR\$ function, LEFT\$ function, MID\$ function, RIGHT\$ function), Point function (WHERE function, JTOXY function, XYTOJ function), Parameter function (ACCEL statement, OUTPOS statement, TOLE statement), etc.
<b>Variable</b>	Simple variable (integer type variable, real number type variable, character string type variable), Array variable (integer type variable, real number type variable, character string type variable), Point variable, Shift variable, Element variable (point element variable, shift element variable), Input/output variable, etc.
<b>Operator</b>	Arithmetic operator (+, -, *, /, MOD), Logical operator (AND, OR, XOR), Comparison operator (=, <, >, <>, <=, >=)
<b>Monitor</b>	Monitor of input/output (200ms interval)
<b>On-line command</b>	Key operation command (AUTO, RUN, RESET, STEP), Data handling command (READ, WRITE, ?VER, ?CONFIG), Utility command (COPY, ERA, INIT), Robot language command (independently executable command)
<b>Data file</b>	Program, Point, Parameter, Shift, Hand, All, Error history, etc.
<b>Internal timer</b>	10ms interval
<b>Program break point</b>	4 points at maximum

Articulated robots  
YA  
Linear conveyer modules  
LCM100  
Compact single-axis robots  
TRANSERVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
N/V/N/V2 Electric gripper  
Option

## Robot Language Table

### General commands

Language	Function
DECLARE	Declares that a label or sub-procedure is in an external program.
DEF FN	Defines a function that is available to the user.
DIM	Declares the name of an array variable and the number of elements.
EXIT FOR	Terminates a FOR statement to NEXT statement loop.
FOR to NEXT	Controls repetitive operations
GOSUB to RETURN	Jumps to a subroutine with the label specified by a GOSUB statement and executes the subroutine.
GOTO	Unconditionally jumps to the line specified by a label.
HALT	Stops a program and resets it.
HOLD	Pauses a program.
IF	Allows control flow to branch according to conditions.
LET	Executes a specified assignment statement.
ON to GOSU	Jumps to a subroutine with each label specified by a GOSUB statement according to conditions and executes the subroutine.
ON to GOTO	Jumps to each line specified by a label according to conditions.
REM	All characters that follow REM or an apostrophe (') are viewed as comments.
SELECT CASE to END SELECT	Allows control flow to branch according to conditions.
SWI	Switches the currently executed program to a specified program, and executes from the first line after compiling.
WHILE to WEND	Controls repetitive operations.
Label statement	Defines "labels" in program lines.

### Robot operation

Language	Function
ABSRST	Performs return-to-origin along robot absolute motor axes.
DRIVE	Performs an absolute movement of each axis in the main group.
DRIVEI	Performs a relative movement of each axis in the main group.
MOVE	Performs an absolute movement of the main robot axes.
MOVEI	Performs a relative movement of the main robot axes.
ORIGIN	Performs return-to-origin on an incremental mode axis or absolute search on a semi-absolute mode axis.
PMOVE	Performs a pallet movement of the main robot axes.
SERVO	Controls the servo ON/OFF of the specified axes in the main group or all axes (in main group and sub group).

### I/O control

Language	Function
DELAY	Waits for the specified length of time (ms).
DO	Outputs the specified value to the DO ports.
LO	Outputs the specified value to the LO port to prohibit axis movement or permit axis movement.
MO	Outputs the specified value to the MO ports.
OUT	Turns ON the bits of the specified output ports and the command statement ends.
RESET	Turns OFF the bits of the specified output ports.
SET	Turns ON the bits of the specified output ports
SO	Outputs the specified value to the SO port.
TO	Outputs the specified value to the TO port.
WAIT	1. Waits until the condition in DI/DO conditional expression are met. 2. Waits until positioning on the robot axes is complete (within the tolerance range).

### Coordinate control

Language	Function
CHANGE	Switches the hand of the main robot.
HAND	Defines the hand of the main robot.
RIGHTY / LEFTY	Selects whether the main robot will be "right-handed" or "left-handed" when moving to a point specified on a Cartesian coordinate system.
SHIFT	Sets the shift coordinates for the main robot by using the shift data specified by a shift variable.

### Condition change

Language	Function
ACCEL	Changes the acceleration coefficient parameter of the main group.
ARCH	Changes the arch position parameter of the main group.
ASPEED	Changes the automatic movement speed of the main group.
AXWGHT	Changes the axis tip weight parameter of the main group.
DECEL	Changes the deceleration rate parameter of the main group.
ORGORD	Sets the axis sequence parameter to perform return-to-origin and absolute search in the main group.
OUTPOS	Changes the OUT position parameter of the main group.
PDEF	Defines the pallet used to execute a pallet movement command.
SPEED	Changes the program speed for the main group.
TOLE	Changes the tolerance parameter of the main group.
WEIGHT	Changes the tip weight parameter of the main robot.

### Communication control

Language	Function
ONLINE / OFFLINE	Changes communication mode and initialize the communication port.
SEND	Sends the read file data into a write file.

### Screen control

Language	Function
PRINT	Displays the value of specified variable on the MPB/RPB screen.

### Key control

Language	Function
INPUT	Assigns a value to the variable specified from the MPB/RPB.

### Procedure

Language	Function
CALL	Calls up sub-procedures defined by the SUB and END SUB statements.
EXIT SUB	Terminates the sub-procedure defined by the SUB and END SUB statements.
SHARED	Does not permit variables declared with a program written outside a subprocedure (SUB to END SUB) to be passed on as dummy arguments, but allows them to be referred to with a sub-procedure.
SUB to END SUB	Defines a sub-procedure.

### Task control

Language	Function
CHGPRI	Changes the priority of the specified task.
CUT	Terminates a task currently being executed or temporarily stopped.
EXIT TASK	Terminates its own task currently being executed.
RESTART	Restarts a task that is temporarily stopped.
START	Sets the task number and priority of the specified task and starts that task.
SUSPEND	Temporarily stops another task being executed.

### Error control

Language	Function
ON ERROR GOTO	If an error occurs during program execution, this command allows the program to jump to the error processing routine specified by the label without stopping the program, or stops the program and displays the error message.
RESUME	Resumes the program execution after recovery from an error. This command is used in the error processing routine.
ERL	Gives the line number where an error occurred.
ERR	Gives the error code number when an error occurred.

### PATH control

Language	Function
PATH	Sets the PATH motion on the main robot axis.
PATH END	Terminates the path setting for PATH motion.
PATH SET	Starts the path setting for PATH motion.
PATH START	Starts the PATH motion.

### Torque control

Language	Function
DRIVE (with torque limit option)	Executes an absolute movement command on each axis in the main group.
TORQUE	Changes the maximum torque instruction for the specified main group axis.
TRQTIME	Sets the current limit time-out period on the specified main group axis when using a torque limit setting option in the DRIVE statement.
TRQTIME	Sets the current limit time-out period on the specified main group axis when using a torque limit setting option in the DRIVE statement.

## Accessories and part options

### RCX240/RCX240S



#### Standard accessories

##### ● Power connector + wiring connection lever



Model KAS-M5382-00

LCC140  
 TS-X  
 TS-P  
 SR1-X  
 SR1-P  
 RCX221  
 RCX222  
 RCX240/S  
 RCX340

##### ● Safety connector



Model KX0-M5163-00

RCX240/S

##### ● RPB terminator (dummy connector)

Attach this to the RPB connector during operation with the programming box RPB removed.



Model KAS-M5163-30

RCX221  
 RCX222  
 RCX240/S

##### ● Standard I/O (STD.DIO) connector



Model KX0-M533G-00

RCX240/S

##### ● L type stay (for installing front side, rear side.)

Use to install the controller.



Model KX0-M410H-00

Note. Model No. is for a single bracket (L type stay).  
 (Two are required to install one controller.)

RCX240/S

##### ● Absolute battery

Battery for absolute data back-up.

###### ● Basic specifications

Item	Absolute battery
Battery type	Lithium metallic battery
Battery capacity	3.6V/2,750mAh
Data holding time	About 1 year <sup>Note1</sup> (in state with no power applied)
Dimensions	φ17 × L53mm
Weight <sup>Note2</sup>	22g



Model KAS-M53G0-11

Note 1. When using two batteries for each two axes.  
 Note 2. Weight of battery itself.

Note. The absolute battery is subject to wear and requires replacement.  
 If trouble occurs with the memory then remaining battery life is low so replace the absolute battery. The battery replacement period depends on usage conditions. But generally you should replace the battery after about 1 year counting the total time after connecting to the controller and left without turning on the power.

SR1-X  
 RCX222  
 RCX240/S

#### Important Absolute battery installation conditions

- 1 to 2 batteries are required for each 2 axes.
  - 1 battery.....Data storage time of approximately 6 months (with no power applied)
  - 2 batteries...Data storage time of approximately 1 year (with no power applied)
- Note. Absolute battery is not required for either of the 2 axes if using incremental or semi-absolute specifications.

##### ● Battery case

This is the absolute battery holder.



Model KBG-M5395-00

SR1-X  
 RCX222  
 RCX240/S

See next page for optional parts

Articulated robots  
 YA  
 Linear conveyor modules  
 LCM100  
 Compact single-axis robots  
 TRANSEVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XY-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER  
 INFORMATION  
 Robot positioner  
 Pulse string driver  
 Robot controller  
 I/V/V/VZ Electric gripper  
 Option

## Options

### L type stay (for side surface installation)

Use to install the controller.



Model	KX0-M410H-10	RCX240/S
-------	--------------	----------

Note. Model No. is for a single bracket (L type stay).

### Programming box RPB/RPB-E

P.562

This device can perform all operations such as manual robot operation, program entry and edit, teaching and parameter settings.



	RPB	RPB-E	
Model	KBK-M5110-10	KBK-M5110-00	RCX221
Enable switch	-	3-position	RCX222
CE marking	Not supported	Applicable	RCX240/S

### Support software for PC VIP+

P.556

VIP+ is a simple to use application software that makes tasks such as robot operation, writing-editing programs, and point teaching easy to visually understand.



VIP+ software model	KX0-M4966-00	RCX221
---------------------	--------------	--------

RCX222  
RCX240/S

### Environment

OS	Microsoft Windows 2000 / XP / Vista (32bit / 64Bit) / 7 (32bit / 64Bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	40MB of available space required on installation drive.
Communication method	RS-232C, Ethernet Note. For Ethernet communication, Ethernet unit for RCX series controller is required.
Applicable robot controllers	RCX221 / RCX222 / RCX141 / RCX142 / RCX240 / RCX240S

Note. Microsoft and Windows are registered trademarks of Microsoft Corporation.  
Note. ADOBE and ADOBE READER are registered trademarks of Adobe Systems Incorporated.  
Note. Ethernet is a registered trademark of Xerox Corporation.

### Data cables

Communication cable for VIP+.  
Select from USB cable or D-sub cable.



Model	USB type (5m)	KBG-M538F-00	LCC140
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10	ERCD

Note. This USB cable supports Windows 2000/XP or later.  
Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.

Note. USB driver for communication cable can also be downloaded from our website.

SR1-X  
SR1-P  
RCX221  
RCX222  
RCX240/S  
RCX340

### YC-Link board

Model	KX0-M4400-A1	RCX240/S
-------	--------------	----------

Articulated robots  
YA

Linear CONVEYOR  
modules  
LCM100

Compact  
single-axis robots  
TRANSEKVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller

iV1/V1Z  
Electric  
grripper

Option

# RCX340

## Robot controller with advanced functions

Next generation controller, all functions of which were reviewed to further improve the functions of conventional controllers.

This controller provides the features to achieve the high functionalities that can construct the equipment at high level.



RCX340

### Main functions ▶ P.67



Programming box  
▶ **PBX/PBX-E**  
**P.563**



Support software for PC  
▶ **RCX-Studio Pro**  
**P.559**

### Basic specifications

Item		RCX340	
Basic specifications	Applicable robots	YAMAHA single-axis robots, linear single-axis robots, Cartesian robots, SCARA robots (except for YK120X and YK150X), P&P robots	
	Connected motor capacity	1600W or less (in total for 4 axes)	
	Power capacity	2500VA	
	Dimensions	W355 × H195 × D130mm (main unit only)	
	Weight	6.2kg (main unit only)	
	Power supply voltage	Single-phase 200 to 230V AC +/-10% maximum, 50/60Hz	
Axis control	No. of controllable axes	Max. 4 axes (simultaneous control: 6 axes) Expandable to a maximum of 16 axes (four robots) via controller link	
	Drive method	AC full digital servo	
	Position detection method	Resolver or magnetic linear scale	
	Control method	PTP motion (point to point), ARCH motion, linear interpolation, circular interpolation	
	Coordinate systems	Joint coordinates, Cartesian coordinates	
	Position display units	Pulses, mm (1/1000 steps), degree (1/1000 steps)	
	Speed setting	0.01 to 100% (below 1% can be changed by programming)	
	Acceleration/deceleration setting	Optimized by robot model and tip weight parameter Setting by acceleration coefficient and deceleration rate parameters (1% steps) * Can be changed by programming. Zone control (For SCARA robots only, optimized according to arm posture)	
Programming	Program language	YAMAHA BASIC II conforming to JIS B8439 (SLIM language)	
	Multi-task	Max. 16 tasks	
	Sequence program	1 program	
	Memory capacity	2.1MB (Total of program and point data) (Available capacity for program when the maximum number of points is used: 300KB)	
	Program	100 programs (maximum number of programs) 9999 lines (maximum number of lines per program)	
	Point	30000 points (maximum number of points)	
	Point teaching method	MDI (coordinate data input), direct teaching, teaching playback, offline teaching (data input from external unit)	
	System backup (Internal memory backup)	Lithium battery (service life about 4 years at 0 to 40°C)	
	Internal flash memory	512 KB	
External I/O	SAFETY	Input	Emergency stop ready input, 2 systems Auto mode input, 2 systems (Enabled only when the global specifications are used.)
		Output	Emergency stop contact output, 2 systems Enable contact output, 2 systems (Enabled only when the PBX-E is used.) Motor power ready output, 2 systems
	Brake output	Transistor output (PNP open collector)	
	Origin sensor input	Connectable to 24V DC B-contact (normally closed) sensor	
	External communications	RS-232C: 1CH (D-SUB 9-pin (female)) Ethernet: 1CH (In conformity with IEEE802.3u/IEEE802.3) 100Mbps/10Mbps (100BASE-TX/10BASE-T) Applicable to Auto Negotiation RS-422: 1CH (Dedicated to PBX)	


Controllable robot	<b>XY-X P.239</b>	<b>YK-X P.367</b>	<b>FLIP-X P.169</b>	<b>PHASER P.215</b>	<b>YP-X P.427</b>
CE marking					
Field networks					

## Ordering method

<b>RCX340</b>							
<b>Controller</b>	<b>No. of control-able axes</b>	<b>Safety standards</b>	<b>Controller option A (OP.A)</b>	<b>Controller option B (OP.B)</b>	<b>Controller option C (OP.C)</b>	<b>Controller option D (OP.D)</b>	<b>Controller option E (OP.E)</b>
	4: 4 axes 3: 3 axes 2: 2 axes	N: Normal E: CE	No entry: Non-selection NS: STD.DIO(NPN) Note 1 Note 4 NE: EXP.DIO(NPN) Note 2 Note 4 PS: STD.DIO(PNP) Note 1 Note 4 PE: EXP.DIO(PNP) Note 2 Note 4 GR: Gripper TR: Tracking Note 5 YM1: YC-Link/E master Note 6 YS2 to 4: YC-Link/E slave Note 6 EP: EtherNet/IP™ Note 7 PB: PROFIBUS Note 7 CC: CC-Link Note 7 DN: DeviceNet™ Note 7 PT: PROFINET Note 7	No entry: Non-selection --- Note 3 NE: EXP.DIO(NPN) Note 2 Note 4 --- Note 3 PE: EXP.DIO(PNP) Note 2 Note 4 GR: Gripper TR: Tracking Note 5 YM1: YC-Link/E master Note 6 YS2 to 4: YC-Link/E slave Note 6 EP: EtherNet/IP™ Note 7 PB: PROFIBUS Note 7 CC: CC-Link Note 7 DN: DeviceNet™ Note 7 PT: PROFINET Note 7	No entry: Non-selection --- Note 3 NE: EXP.DIO(NPN) Note 2 Note 4 --- Note 3 PE: EXP.DIO(PNP) Note 2 Note 4 GR: Gripper TR: Tracking Note 5 YM1: YC-Link/E master Note 6 YS2 to 4: YC-Link/E slave Note 6 EP: EtherNet/IP™ Note 7 PB: PROFIBUS Note 7 CC: CC-Link Note 7 DN: DeviceNet™ Note 7 PT: PROFINET Note 7	No entry: Non-selection --- Note 3 NE: EXP.DIO(NPN) Note 2 Note 4 --- Note 3 PE: EXP.DIO(PNP) Note 2 Note 4 GR: Gripper TR: Tracking Note 5 YM1: YC-Link/E master Note 6 YS2 to 4: YC-Link/E slave Note 6 EP: EtherNet/IP™ Note 7 PB: PROFIBUS Note 7 CC: CC-Link Note 7 DN: DeviceNet™ Note 7 PT: PROFINET Note 7	No entry: Non-selection VY: iVY2 without light VL: iVY2 with light
							4: 4 pcs. 3: 3 pcs. 2: 2 pcs. 1: 1 pc. 0: 0 pc.

Please select desired selection items from the upper portion of the controller option A in order.


- Note 1. [STD.DIO] Parallel I/O board standard specifications  
Dedicated input 8 points, dedicated output 9 points, general-purpose input 16 points, general-purpose output 8 points  
Do not mix with field bus (CC/DN/PB/EP/PT).
- Note 2. [EXP.DIO] Parallel I/O board expansion specifications  
General-purpose input 24 points, general-purpose output 16 points
- Note 3. Only one DIO STD specification board can be selected. Therefore, this board cannot be selected in OP.B to OP.D.
- Note 4. Be careful not to mix NPN and PNP of DIO.
- Note 5. Only one tracking board can be selected.
- Note 6. Select only one master or slave board for YC-Link/E.  
For details, refer to "YC-Link/E ordering explanation" below.  
Additionally, when ordering YC-Link/E, please specify what robot is connected to what number controller.
- Note 7. Be careful not to mix field networks (CC/DN/PB/EP/PT).



Item		RCX340	
General specifications	Operating temperature	0 to 40°C	
	Storage temperature	-10 to 65°C	
	Operating humidity	35 to 85% RH (no condensation)	
	Noise immunity	Conforms to IEC61000-4-4 Level 3	
	Protective structure	IP20	
	Appliance classes	Class I	
Options	Parallel I/O board	Standard specifications	Dedicated input 8 points, dedicated output 9 points General-purpose input 16 points, general-purpose output 8 points NPN/PNP specifications are selected. (maximum 1 board)
		Expansion specifications	General-purpose input 24 points, general-purpose output 16 points NPN/PNP specifications are selected. (maximum 4 boards)
	Option board	CC-Link board Ver1.1/2.0	Remote I/O
		DeviceNet™ board	Dedicated input/output: 16 points each
		EtherNet/IP™ board	General-purpose input/output: 96 points each
		PROFIBUS board	Remote register
		PROFINET board	Input/output: 16 words each
	YC-Link/E board (master/slave)	Communication cycle: 1 ms, control cycle: minimum 1 ms / maximum 8 ms, maximum number of robot units: four units Maximum number of control axes: total 16 axes (including four master controller axes), maximum 12 axes for slaves only	
	YRG (gripper) board	Position detection method: optical rotary encoder, minimum setting distance: 0.01 mm Speed setting: 20 to 100% relative to the maximum parameter speed, number of connected gripper units: maximum four units Drive power: DC 24V +/-10%, 1.0A Max	
	Tracking board	Number of connected encoders: maximum two units, supported encoders: 26LS31/26C31 equivalent line driver (RS422 compliant) Encoder power supply: DC5V (2 counter (ch) total 500 mA or less) (supplied from controller)	
iVY2 unit	Camera pixels: maximum 2 million pixels, number of registered models: 254 models, number of connected cameras: maximum two units Power supply: DC24V +/-10% 1.5A Max		
Programming box	PBX, PBX-E		
Absolute battery	3.6V 2750mAh / axis Backup retention time: About 1 year		
Support software for personal computer	RCX-Studio Pro		

Note. There are four slots in which option boards can be installed.

## YC-Link/E ordering explanation



Articulated robots  
YA

Linear conveyer modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner


Pulse string driver

Robot controller

NV/NV2 Electric gripper

Option

## ■ Dimensions



## ■ Power supply capacity and heat emission

The required power supply capacity and heat emission will vary depending on the robot type and number of axes.

Using the following table as a general guide consider the required power supply preparation and control panel size, controller installation, and cooling method.

### (1) When connected to SCARA robot

Robot type					Power capacity (VA)	Generated heat amount (W)
Standard type	Clean type	Dust-proof & drip-proof type	Ceiling-mount	Wall-mount / Inverse type		
YK120XG, YK150XG	-	-	-	-	300	58
YK180XG, YK180X YK220X	YK180XC, YK220XC	-	-	-	500	63
YK250XG, YK350XG YK400XG, YK500XGL YK600XGL, YK400XR	YK250XCH, YK350XCH YK400XCH, YK250XGC YK350XGC, YK400XGC YK500XGLC, YK600XGLC	YK250XGP, YK350XGP YK400XGP, YK500XGLP YK600XGLP	-	YK300XGS, YK400XGS	1000	75
-	YK500XC, YK600XC	-	-	-	1500	88
YK500XG, YK600XG YK700XGL	-	YK500XGP, YK600XGP	-	YK500XGS, YK600XGS	1700	93
-	YK700XC, YK800XC YK1000XC	-	-	-	2000	100
YK600XGH, YK700XG YK800XG, YK900XG YK1000XG, YK1200X	-	YK600XGHP, YK700XGP YK800XGP, YK900XGP YK1000XGP	YK350TW YK500TW	YK700XGS, YK800XGS YK900XGS, YK1000XGS	2500	113

### (2) When connected to 2 axis (Cartesian robot and/or multi-axis robot)

Axial current sensor value <sup>Note</sup>		Power capacity (VA)	Generated heat amount (W)
X axis	Y axis		
05	05	600	65
10	05	800	70
20	05	1100	78
10	10	1000	75
20	10	1300	83
20	20	1700	93

### (3) When connected to 3 axis (Cartesian robot and/or multi-axis robot)

Axial current sensor value <sup>Note</sup>			Power capacity (VA)	Generated heat amount (W)
X axis	Y axis	Z axis		
05	05	05	700	68
10	05	05	900	73
20	05	05	1200	80
10	10	05	1000	75
20	10	05	1300	83
20	20	05	1600	90
10	10	10	1200	80
20	10	10	1500	88
20	20	10	1800	95
20	20	20	2000	100

### (4) When connected to 4 axis (Cartesian robot and/or multi-axis robot)


Axial current sensor value <sup>Note</sup>				Power capacity (VA)	Generated heat amount (W)
X axis	Y axis	Z axis	R axis		
05	05	05	05	800	70
10	05	05	05	1000	75
20	05	05	05	1200	80
10	10	05	05	1100	78
20	10	05	05	1400	85
20	20	05	05	1600	90
10	10	10	05	1300	83
20	10	10	05	1500	88
20	20	10	05	1800	95
20	20	20	05	2100	103
10	10	10	10	1400	85
20	10	10	10	1700	93
20	20	10	10	2000	100
20	20	20	10	2200	105
20	20	20	20	2500	113

Note. Even if axial current sensor values for each axis are interchanged no problem will occur.



## ■ Installation conditions

- Use the screws to secure the controller to the installation plate inside the control panel so that it is in a horizontal position. Be sure to use the metallic installation plate.
- Install the RCX340 in a well ventilated location, with space on all sides of the RCX340 (See fig. at right.).
- Ambient temperature : 0 to 40°C
- Ambient humidity : 35 to 85% RH (no condensation)



## ■ Standard specification I/O connector signal list

Pin	I/O No.	Signal name	Remarks
1	DI 01	Dedicated input: Servo ON input	
2	DI 10	Dedicated input: Sequence control	
3	DI 03	Spare	Do not use.
4	CHK 1	Check signal 1	Short-circuit with CHK2.
5	DI 05	Spare	Do not use.
6	DI 06	Dedicated input: Stop	
7	DI 07	Spare	Do not use.
8	DI 20	General-purpose input 20	
9	DI 21	General-purpose input 21	
10	DI 22	General-purpose input 22	
11	DI 23	General-purpose input 23	
12	DI 24	General-purpose input 24	
13	DI 25	General-purpose input 25	
14	DI 26	General-purpose input 26	
15	DI 27	General-purpose input 27	
16	DO 00	Spare	Do not use.
17	DO 01	Dedicated output CPU OK	
18	DO 10	Dedicated output AUTO mode output	
19	DO 11	Dedicated output Return-to-origin complete	
20	DO 12	Dedicated output Sequence program-in-progress	
21	DO 13	Dedicated output Robot program-in-progress	
22	DO 14	Dedicated output Program reset status output	
23	DO 15	Dedicated output Warning output	
24	DO 16	Spare	Do not use.
25	DO 17	Spare	Do not use.
26	DI 12	Dedicated input: Automatic operation start	
27	DI 13	Spare	Do not use.
28	DI 14	Dedicated input: Return-to-origin (for INC axis)	
29	DI 15	Dedicated input: Program reset input	
30	DI 16	Dedicated input: Alarm reset input	
31	DI 17	Dedicated input: Return-to-origin (for ABS axis)	
32	DI 30	General-purpose input 30	
33	DI 31	General-purpose input 31	
34	DI 32	General-purpose input 32	
35	DI 33	General-purpose input 33	
36	DI 34	General-purpose input 34	
37	DI 35	General-purpose input 35	
38	DI 36	General-purpose input 36	
39	DI 37	General-purpose input 37	
40	CHK 2	Check signal 2	Short-circuit with CHK1.
41	DO 02	Dedicated output: Servo ON output	
42	DO 03	Dedicated output: Alarm output	
43	DO 20	General-purpose output 20	
44	DO 21	General-purpose output 21	
45	DO 22	General-purpose output 22	
46	DO 23	General-purpose output 23	
47	DO 24	General-purpose output 24	
48	DO 25	General-purpose output 25	
49	DO 26	General-purpose output 26	
50	DO 27	General-purpose output 27	

## ■ Expanded specification I/O connector signal list

Pin	I/O No. (ID=1)	I/O No. (ID=2)	I/O No. (ID=3)	I/O No. (ID=4)	Signal name
1	---	---	---	---	Reserved
2	DI 10	DI 40	DI 70	DI 120	General-purpose input 10,40,70,120
3	---	---	---	---	Reserved
4	DI 11	DI 41	DI 71	DI 121	General-purpose input 11,41,71,121
5	---	---	---	---	Reserved
6	---	---	---	---	Reserved
7	---	---	---	---	Reserved
8	DI 20	DI 50	DI 100	DI 130	General-purpose input 20,50,100,130
9	DI 21	DI 51	DI 101	DI 131	General-purpose input 21,51,101,131
10	DI 22	DI 52	DI 102	DI 132	General-purpose input 22,52,102,132
11	DI 23	DI 53	DI 103	DI 133	General-purpose input 23,53,103,133
12	DI 24	DI 54	DI 104	DI 134	General-purpose input 24,54,104,134
13	DI 25	DI 55	DI 105	DI 135	General-purpose input 25,55,105,135
14	DI 26	DI 56	DI 106	DI 136	General-purpose input 26,56,106,136
15	DI 27	DI 57	DI 107	DI 137	General-purpose input 27,57,107,137
16	---	---	---	---	Reserved
17	---	---	---	---	Reserved
18	DO 10	DO 30	DO 50	DO 70	General-purpose output 10,30,50,70
19	DO 11	DO 31	DO 51	DO 71	General-purpose output 11,31,51,71
20	DO 12	DO 32	DO 52	DO 72	General-purpose output 12,32,52,72
21	DO 13	DO 33	DO 53	DO 73	General-purpose output 13,33,53,73
22	DO 14	DO 34	DO 54	DO 74	General-purpose output 14,34,54,74
23	DO 15	DO 35	DO 55	DO 75	General-purpose output 15,35,55,75
24	DO 16	DO 36	DO 56	DO 76	General-purpose output 16,36,56,76
25	DO 17	DO 37	DO 57	DO 77	General-purpose output 17,37,57,77
26	DI 12	DI 42	DI 72	DI 122	General-purpose input 12,42,72,122
27	DI 13	DI 43	DI 73	DI 123	General-purpose input 13,43,73,123
28	DI 14	DI 44	DI 74	DI 124	General-purpose input 14,44,74,124
29	DI 15	DI 45	DI 75	DI 125	General-purpose input 15,45,75,125
30	DI 16	DI 46	DI 76	DI 126	General-purpose input 16,46,76,126
31	DI 17	DI 47	DI 77	DI 127	General-purpose input 17,47,77,127
32	DI 30	DI 60	DI 110	DI 140	General-purpose input 30,60,110,140
33	DI 31	DI 61	DI 111	DI 141	General-purpose input 31,61,111,141
34	DI 32	DI 62	DI 112	DI 142	General-purpose input 32,62,112,142
35	DI 33	DI 63	DI 113	DI 143	General-purpose input 33,63,113,143
36	DI 34	DI 64	DI 114	DI 144	General-purpose input 34,64,114,144
37	DI 35	DI 65	DI 115	DI 145	General-purpose input 35,65,115,145
38	DI 36	DI 66	DI 116	DI 146	General-purpose input 36,66,116,146
39	DI 37	DI 67	DI 117	DI 147	General-purpose input 37,67,117,147
40	---	---	---	---	Reserved
41	---	---	---	---	Reserved
42	---	---	---	---	Reserved
43	DO 20	DO 40	DO 60	DO 100	General-purpose output 20,40,60,100
44	DO 21	DO 41	DO 61	DO 101	General-purpose output 21,41,61,101
45	DO 22	DO 42	DO 62	DO 102	General-purpose output 22,42,62,102
46	DO 23	DO 43	DO 63	DO 103	General-purpose output 23,43,63,103
47	DO 24	DO 44	DO 64	DO 104	General-purpose output 24,44,64,104
48	DO 25	DO 45	DO 65	DO 105	General-purpose output 25,45,65,105
49	DO 26	DO 46	DO 66	DO 106	General-purpose output 26,46,66,106
50	DO 27	DO 47	DO 67	DO 107	General-purpose output 27,47,67,107

Note. The IDs are set using the parameter.


Articulated robots  
YA  
Linear conveyer modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
I/V/N/V2 Electric gripper  
Option

## Standard specification I/O connector pin assignment lists


Pin	I/O No.	Name
1	DI01	Servo ON
2	DI10	SEQ enable
3	DI03	(Spare)
4	CHK1	Check input 1
5	DI05	(Spare)
6	DI06	STOP
7	DI07	(Spare)
8	DI20	General-purpose input
9	DI21	General-purpose input
10	DI22	General-purpose input
11	DI23	General-purpose input
12	DI24	General-purpose input
13	DI25	General-purpose input
14	DI26	General-purpose input
15	DI27	General-purpose input
16	DO00	(Spare)
17	DO01	CPUOK
18	DO10	AUTO
19	DO11	ORGOK
20	DO12	SEQRUN
21	DO13	RUN
22	DO14	RESET
23	DO15	WARNING
24	DO16	(Spare)
25	DO17	(Spare)
26	DI12	RUN
27	DI13	(Spare)
28	DI14	ORIGIN (for INC axis)
29	DI15	RESET
30	DI16	ALMRST
31	DI17	ORIGIN(for ABS axis)
32	DI30	General-purpose input
33	DI31	General-purpose input
34	DI32	General-purpose input
35	DI33	General-purpose input
36	DI34	General-purpose input
37	DI35	General-purpose input
38	DI36	General-purpose input
39	DI37	General-purpose input
40	CHK2	Check input 2
41	DO02	SERVO
42	DO03	ALARM
43	DO20	General-purpose output
44	DO21	General-purpose output
45	DO22	General-purpose output
46	DO23	General-purpose output
47	DO24	General-purpose output
48	DO25	General-purpose output
49	DO26	General-purpose output
50	DO27	General-purpose output

## Typical input signal connection

### NPN specifications




### PNP specifications




## Typical output signal connection

### NPN specifications



### PNP specifications



## Basic functions

Function	Description
<b>Operation modes</b>	AUTO mode (Major functions: program creation, program execution, step execution, etc.) MANUAL mode (Major functions: jog movement, point data teaching, parameter editing, etc.)
<b>Commands</b>	Array declaration commands (DIM statement) Assignment commands (Numeric assignment, character string assignment, point definition statements, etc.) Movement commands (MOVE, DRIVE, PMOVE statements, etc.) Conditional branching commands (IF, FOR, WHILE statements, etc.) External output commands (DO, MO, LO, TO, SO statements) Parameter commands (ACCEL, OUTPOS, TOLE statements, etc.) Condition wait command (WAIT statement) Task related commands (START, SUSPEND, CUT statements, etc.) etc.
<b>Functions</b>	Arithmetic functions (SIN, COS, TAN functions, etc.) Character string functions (STR\$, LEFT\$, MID\$, RIGHT\$ functions, etc.) Point functions (WHERE, JTOXY, XYTOJ functions, etc.) Parameter functions (ACCEL, OUTPOS, TOLE statements, etc.) etc.
<b>Variables</b>	Simple variables (integer variables, real variables, character variables) Array variables (integer variables, real variables, character variables) Point variables Shift variables I/O variables etc.
<b>Arithmetic operation</b>	Arithmetic operators (+, -, *, /, MOD) Logic operators (AND, OR, XOR) Relational operators (=, <, >, <=>, >=)
<b>Monitor</b>	I/O status monitor (200 ms intervals)
<b>Online commands</b>	Program operation commands (RUN, STOP, RESET, STEP, etc.) Utility commands (COPY, ERA, INIT, etc.) Data handling commands (READ, WRITE, etc.) Robot language commands (independent-executable commands)
<b>Data files</b>	Program, point, parameter, shift, hand, all, error history etc.
<b>Internal timer</b>	Timer count variable (TCOUNTER), 1 ms interval
<b>Program break points</b>	Max. 32 points

**Emergency input signal connections**

Articulated robots  
YA

Linear conveyer modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

**CONTROLLER INFORMATION**

Robot positioner


Pulse string driver

Robot controller


IN/VI/VZ Electric gripper

Option

● Connection example of controller with normal specifications and PBX



● Connection example of controller with CE specifications and PBX-E



## Robot Language Table

### General commands

Command	Description
DIM	Declares the array variable name and the number of elements.
LET	Executes a specified assignment statement.
REM	Expresses a comment statement.

### Arithmetic commands

Command	Description
ABS	Acquires the absolute value of a specified value.
ATN	Acquires the arctangent of the specified value.
ATN2	Acquires the arctangent of the specified X-Y coordinates.
COS	Acquires the cosine value of a specified value.
DEGRAD	Converts a specified value to radians (↔RADDEG).
DIST	Acquires the distance between 2 specified points.
INT	Acquires an integer for a specified value by truncating all decimal fractions.
LSHIFT	Shifts a value to the left by the specified bit count. (↔RSHIFT)
RADDEG	Converts a specified value to degrees. (↔DEGRAD)
RSHIFT	Shifts a value to the right by the specified bit count. (↔LSHIFT)
SIN	Acquires the sine value for a specified value.
SQR	Acquires the square root of a specified value.
TAN	Acquires the tangent value for a specified value.

### Date / time

Command	Description
DATE \$	Acquires the date as a "yy/mm/dd" format character string.
TCOUNTER	Outputs count-up values at 1ms intervals starting from the point when the TCOUNTER variable is reset.
TIME \$	Acquires the current time as an "hh:mm:ss" format character string.
TIMER	Acquires the current time in seconds, counting from midnight.

### Character string operation

Command	Description
CHR \$	Acquires a character with the specified character code.
LEFT \$	Extracts a character string comprising a specified number of digits from the left end of a specified character string.
LEN	Acquires the length (byte count) of a specified character string.
MID \$	Extracts a character string of a desired length from a specified character string.
ORD	Acquires the character code of the first character in a specified character string.
RIGHT \$	Extracts a character string comprising a specified number of digits from the right end of a specified character string.
STR \$	Converts a specified value to a character string (↔VAL).
VAL	Converts the numeric value of a specified character string to an actual numeric value. (↔STR\$)

### Point, coordinates, shift coordinates

Command	Description
CHANGE	Switches the hand of a specified robot.
HAND	Defines the hand of a specified robot.
JTOXY	Converts joint coordinate data to Cartesian coordinate data of a specified robot. (↔XYTOJ)
LEFTY	Sets the hand system of a specified robot to the left-handed system.
LOCx	Specifies/acquires point data for a specified axis or shift data for a specified element.
PATH	Sets the movement path.
Pn	Defines points within a program.
PPNT	Creates point data specified by a pallet definition number and pallet position number.
RIGHTY	Sets the hand system of a specified robot to the right-handed system.
Sn	Defines the shift coordinates within the program.
SHIFT	Sets the shift coordinate for a specified robot by using the shift data specified by a shift variable.
XYTOJ	Converts the point variable Cartesian coordinate data to the joint coordinate data of a specified robot. (↔JTOXY).

### Branching commands

Command	Description
EXIT FOR	Terminates the FOR to NEXT statement loop.
FOR to NEXT	Executes the FOR to NEXT statement repeatedly until a specified value is exceeded.
GOSUB to RETURN	Jumps to a subroutine with the label specified by GOSUB statement, and executes that subroutine.
GOTO	Unconditionally jumps to the line specified by a label.
IF	Allows control flow to branch according to conditions.
ON to GOSUB	Jumps to a subroutine with labels specified by a GOSUB statement in accordance with the conditions, and executes that subroutine.
ON to GOTO	Jumps to label-specified lines in accordance with the conditions.
SELECT CASE to END SELECT	Allows control flow to branch according to conditions.
WHILE to WEND	Controls repeated operations.

### Error control

Command	Description
ERR / ERL	Acquires the error code number of an error which has occurred / the line number where an error occurred.
ON ERROR GOTO	This command allows the program to jump to the error processing routine specified by the label without stopping the program, or it stops the program and displays the error message.
RESUME	Resumes program execution after error recovery processing.

### Program control

Command	Description
CALL	Calls a sub-procedure.
HALT	Stops the program and performs a reset.
HALTALL	Stops and resets all programs.
HOLD	Temporarily stops the program.
HOLDALL	Temporarily stops all programs.
PGMTSK	Acquires the task number in which a specified program is registered.
PGN	Acquires the program number from a specified program name.
SGI	Assigns/acquires the value to a specified integer type static variable.
SGR	Assigns/acquires the value to a specified real type static variable.
SWI	Switches the program being executed, then begins execution from the first line.
TSKPGM	Acquires the program number which is registered in a specified task.

### Task control

Command	Description
CHGPRI	Changes the priority ranking of a specified task.
CUT	Terminates another task currently being executed or temporarily stopped.
EXIT TASK	Terminates its own task which is in progress.
RESTART	Restarts another task during a temporary stop.
START	Specifies the task number and priority ranking of a specified program, and starts that program.
SUSPEND	Temporarily stops another task which is being executed.

### Robot operations

Command	Description
DRIVE	Moves a specified axis of a specified robot to an absolute position.
DRIVEI	Moves a specified axis of a specified robot to a relative position.
MOTOR	Controls the motor power status.
MOVE	Performs absolute movement of all axes of a specified robot.
MOVEI	Performs relative movement of all axes of a specified robot.
MOVET	Performs relative movement of all axes of a specified robot when the tool coordinate is selected.
ORIGIN	Performs return-to-origin.
PMOVE	Executes the pallet movement command of a specified robot.
PUSH	Executes a pushing operation in the axis unit.
SERVO	Controls the servo ON/OFF of a specified axis or all axes of a specified robot.

## ● Status acquisition

Command	Description
ABSRPOS	Acquires the machine reference value for specified robot axes. (Valid only for axes whose return-to-origin method is set as "mark".)
ARMCND	Acquires the current arm status of a specified robot.
ARMSEL	Specifies/acquires the current "hand system" setting of a specified robot.
ARMTYP	Specifies/acquires the "hand system" setting of a specified robot.
CURTQST	Acquires the current torque value ratio of a specified axis to the rated torque.
MCHREF	Acquires the return-to-origin or absolute-search machine reference value for specified robot axes. (Valid only for axes whose return-to-origin method is set as "sensor" or "stroke-end".)
MTRDUTY	Acquires the motor load factor of the specified axis.
PSHRSLT	Acquires the status at the end of the PUSH statement.
PSHSPD	Specifies/acquires the push speed parameter.
PSHTIME	Specifies/acquires the push time parameter.
WAIT ARM	Waits until the axis operation of a specified robot is completed.
WHERE	Reads out the current position of the arm of a specified robot in joint coordinates (pulse).
WHRXY	Reads out the current position of the arm of a specified robot as Cartesian coordinates (mm, degrees).

## ● Status change

Command	Description
ACCEL	Specifies/acquires the acceleration coefficient parameter of a specified robot.
ARCHP1	Specifies/acquires the arch position 1 parameter of a specified robot.
ARCHP2	Specifies/acquires the arch position 2 parameter of a specified robot.
ASPEED	Specifies/acquires the AUTO movement speed of a specified robot.
AXWGHT	Specifies/acquires the axis tip weight parameter of a specified robot.
CHANGE	Switches the hand of a specified robot.
DECEL	Specifies/acquires the deceleration rate parameter of a specified robot.
HAND	Defines the hand of a specified robot.
LEFTY	Sets the hand system of a specified robot to the left-handed system.
ORGORD	Specifies/acquires the axis sequence parameter for performing return-to-origin and an absolute search operation in a specified robot.
OUTPOS	Specifies/acquires the "OUT position" parameter of a specified robot.
PDEF	Defines the pallet used to execute pallet movement commands.
PSHFRC	Specifies/acquires the "Push force" parameter.
PSHJGSP	Specifies/acquires the push judge speed threshold parameter.
PSHMTD	Specifies/acquires the push method parameter.
RIGHTY	Sets the hand system of a specified robot to the right-handed system.
SETGEP	Sets the General Ethernet Port.
SPEED	Changes the program movement speed of a specified robot.
TOLE	Specifies/acquires the tolerance parameter of a specified robot.
WEIGHT	Specifies/acquires the tip weight parameter of a specified robot.

## ● PATH control

Command	Description
PATH	Specifies the PATH motion path.
PATH END	Ends the path setting for PATH motion.
PATH SET	Starts the path setting for PATH motion.
PATH START	Starts the PATH motion.

## ● Torque control

Command	Description
CURTQST	Acquires the current torque value ratio of a specified axis to the rated torque.
CURTRQ	Acquires the current torque value of the specified axis of a specified robot.
PUSH	Executes a pushing operation in the axis unit.
TORQUE	Specifies/acquires the maximum torque command value which can be set for a specified axis of a specified robot.

## ● Input/output control

Command	Description
DELAY	Waits for the specified period (units: ms).
DO	Outputs a specified value to the DO port or acquires the DO status.
LO	Outputs a specified value to the LO port to enable/disable axis movement or acquires the LO status.
MO	Outputs a specified value to the MO port or acquires the MO status.
OUT	Turns ON the bits of the specified output ports and terminates the command statement.
RESET	Turns the bit of a specified output port OFF.
SET	Turns the bit at the specified output port ON.
SI	Acquires a specified SI status.
SID	Acquires a specified serial input's double-word information status.
SIW	Acquires a specified serial input's word information status.
SO	Outputs a specified value to the SO port or acquires the SO status.
SOD	Outputs a specified serial output's double-word information or acquires the output status.
SOW	Outputs a specified serial output's word information or acquires the output status.
TO	Outputs a specified value to the TO port or acquires the TO status.
WAIT	Waits until the conditions of the DI/DO conditional expression are met (with time-out).

## ● Communication control

Command	Description
CLOSE	Close the specified General Ethernet Port.
ETHSTS	Acquires the Ethernet port status.
GEPSTS	Acquires the General Ethernet Port status.
OFFLINE	Sets a specified communication port to the "offline" mode.
ONLINE	Sets the specified communication port to the "online" mode.
OPEN	Opens the specified General Ethernet Port.
SEND	Sends a file.

Articulated robots  
YA

Linear COORVEXor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

IN/VA/VZ Electric gripper

Option

## Accessories and part options


### RCX340



#### Standard accessories

- LCC140
- TS-X
- TS-P
- SR1-X
- SR1-P
- RCX221
- RCX222
- RCX240/S
- RCX340

#### ● Power connector + wiring connection lever



Model KAS-M5382-00

#### ● Safety connector



Model KCX-M5370-00

RCX340

#### ● PBX terminator (dummy connector)

Attach this to the PBX connector during operation with the programming box PBX removed.



Model KAS-M5163-30

- RCX221
- RCX222
- RCX240/S
- RCX340

#### ● NPN / PNP connector



Connector plug model KBH-M4424-00  
Connector cover model KBH-M4425-00

- SR1-X
- SR1-P
- RCX340

#### ● Absolute battery

Battery for absolute data back-up.

##### ● Basic specifications

Item	Absolute battery
Battery type	Lithium metallic battery
Battery capacity	3.6V/2,750mAh
Data holding time	About 1 year <sup>Note1</sup> (in state with no power applied)
Dimensions	φ17 × L53mm
Weight <sup>Note2</sup>	22g



Model KCA-M53G0-01

Note 1. When using two batteries for each two axes.  
Note 2. Weight of battery itself.

Note. The absolute battery is subject to wear and requires replacement.  
If trouble occurs with the memory then remaining battery life is low so replace the absolute battery. The battery replacement period depends on usage conditions. But generally you should replace the battery after about 1 year counting the total time after connecting to the controller and left without turning on the power.

RCX340

#### Important Absolute battery installation conditions

- 1 to 2 batteries are required for each 2 axes.
- 1 battery.....Data storage time of approximately 6 months (with no power applied)
- 2 batteries.....Data storage time of approximately 1 year (with no power applied)

Note. Absolute battery is not required for either of the 2 axes if using incremental or semi-absolute specifications.

#### ● Dust cover for COM connector

Model KR7-M5395-10

RCX340

#### ● Dust cover for LAN connector

Model KCX-M658K-00

RCX340

#### ● Dust cover for USB connector

Model KCX-M658K-00

RCX340

## Options

- External 24V power supply connector for brake + wiring lever



Model	KCX-M6500-10	<b>RCX340</b>
-------	--------------	---------------

- Programming box PBX/PBX-E

**P.563**

This device can perform all operations such as manual robot operation, program entry and edit, teaching and parameter settings.



Type	Language	Cable length	Model	<b>RCX340</b>
PBX	Japanese	5m	KCX-M5110-1J	<b>RCX340</b>
		12m	KCX-M5110-3J	
	English	5m	KCX-M5110-1E	
		12m	KCX-M5110-3E	
Chinese	5m	KCX-M5110-1C		
	12m	KCX-M5110-3C		
PBX-E (with enable switch)	Japanese	5m	KCX-M5110-0J	
		12m	KCX-M5110-2J	
	English	5m	KCX-M5110-0E	
		12m	KCX-M5110-2E	
	Chinese	5m	KCX-M5110-0C	
		12m	KCX-M5110-2C	
Display language switching USB for PBX			Model KCX-M6498-00	
USB cable			Model KCX-M657E-00	

- Support software for PC RCX-Studio Pro

**P.559**

This is support software for operating the RCX340 controller. A USB key is supplied to the RCX-Studio Pro to prevent robot operation mistakes.



Model	RCX-Studio Pro (USB key included)	KCX-M4990-10	<b>RCX340</b>
-------	-----------------------------------	--------------	---------------

Note. Although it is possible to install this software on multiple PCs, the functionality is limited if there is no USB key (see table below). Additional USB keys (additional licenses) are available at a special price. Please contact Yamaha for details.

- Environment

OS	Microsoft Windows XP / Vista (32/64bit) / 7 (32/64bit) / 8 (32/64bit) / 8.1 (32/64bit)
CPU	Intel® Core™ 2 Duo 2 GHz or higher is recommended
Memory	1 GB or more is recommended
Hard disk	80MB or more free space in the RCX-Studio Pro installation destination
Communication port	Communication cable: serial communication port, Ethernet, or USB port USB key: USB port (one port)
Display	1024×768 or higher resolution, 256 colors or higher
Other	CD-ROM drive Dedicated communication cable (for D-Sub or for USB) Ethernet cable (category 5 or higher)
Applicable robot controllers	RCX340


Note. Microsoft, Windows, Windows XP, Windows Vista, Windows 7, Windows 8 and Windows 8.1 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other company names and product names listed in this manual may be the trademarks or registered trademarks of their respective companies.

### Functional limitations depending on USB key presence

Function	USB key present	USB key absent
Connecting to the controller	○	×
Saving the file data	○	×
Emulator function	○	○
Real Time Trace	○	△ Emulator only
Cycletime Calculator	○	×
iVY2 editor	○	×
Data Difference	○	△ Except data saving

- Data cables

Communication cable for RCX-Studio Pro. Select from USB cable or D-sub cable.



Model	USB type (5m)	KBG-M538F-00	<b>LCC140</b>
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10	<b>ERCD</b>
			<b>SR1-X</b>
			<b>SR1-P</b>
			<b>RCX221</b>
			<b>RCX222</b>
			<b>RCX240/S</b>
			<b>RCX340</b>

Note. This USB cable supports Windows 2000/XP or later.  
 Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.  
 Note. USB driver for communication cable can also be downloaded from our website.

- YC-Link/E master board

Model	KCX-M4410-M0	<b>RCX340</b>
-------	--------------	---------------

- YC-Link/E slave board

Model	KCX-M4410-S0	<b>RCX340</b>
-------	--------------	---------------

- YC-Link/E cable (1m)

Model	KCX-M6479-10	<b>RCX340</b>
-------	--------------	---------------

Articulated robots  
YA

Linear conveyer modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner  
LCC140

Pulse string driver  
ERCD

Robot controller  
SR1-X

SR1-P

RCX221

RCX222

RCX240/S

RCX340

INVA/VAZ Electric gripper

Option

Support software for PC

# TS-Manager

Besides basic functions, such as point data edit and backup, this support software TS-Manager incorporates various convenient functions to efficiently process the system debugging and analysis. The TS-Manager helps you in every scene from the system setup to the maintenance.



▼Applicable controllers

- TS-S2
- TS-SH **P490**
- TS-X
- TS-P
- TS-SD **P500**

■ Features

1 Basic functions

Detailed settings by point, such as the position information, operation pattern, speed, acceleration, and deceleration settings, and robot parameter settings can be set, edited, and backed up. Additionally, the basic operation of the robot, such as JOG movement or inching operation can also be controlled through the TS-Manager.

- Only clicking relevant icon will show the operation panel or I/O monitor.
- JOG movement, inching operation, and current position acquisition buttons.
- Turns ON or OFF the operation point monitoring.
- Shows the data in easy-to-read tabular format. Exchanging data with a spreadsheet application, such as Excel is also easy.
- Operation panel for servo status, brake ON/OFF, and stop.
- Shows the servo or emergency stop status, and operation mode.
- Shows the current position at real-time.

Note. Excel is a registered trademark of Microsoft Corporation in the United States and/or other countries.

2 Real-time trace

This function traces the current position, speed, load factor, current value, and voltage value at real-time. Additionally, as trigger conditions are set, data can be automatically obtained when these conditions are satisfied. Furthermore, as a zone is specified from the monitor results, the maximum value, minimum value, and average value can be calculated. These values are useful for the analysis if a trouble occurs.

Real-time traceable items (up to four items)		
• Voltage value	• Commanded position	• Current position
• Command speed	• Current speed	• Internal temperature
• Command current value	• Present current value	• Motor load factor
• Input/output I/O status	• Input pulse count *1	• Movement pulse count *1
• Word input/output status*2		

\*1: Only on TS-SD \*2: Only on TS controllers

- Specify a zone for calculation.
- Calculates the maximum value, minimum value, average value, and root mean square value in a specified zone.
- Traces data at real-time.

3 Various monitor functions and detailed error logs

The robot operation status (operation mode or servo status) and I/O status can be monitored.

Additionally, the Alarm Log screen also displays the input/output I/O status in addition to the carrier position, speed, operation status, current value, and voltage value in case of an alarm. This greatly contributes to the status analysis.

- I/O status monitor panel
- Detailed status monitor panel

4 Operation simulation

As the operation condition data or point data is input, a period of time necessary for operation is simulated.

Use of this function makes it possible to select an optimal model before purchase and simulate the speed and acceleration/deceleration settings without use of actual machine. It is also possible to link this operation simulation function with the TS-Manager main software. This easily affects the point data you have edited in the actual machine.

- Point data list
- Operation setting list
- Result display list
- Displays the detailed simulation results graphically.



## ■ TS-Manager



Model	KCA-M4966-0J (Japanese)
	KCA-M4966-0E (English)

## ■ TS-Manager environment

OS	Microsoft Windows 2000/XP/Vista (32bit/64bit)/7 (32bit/64bit)
CPU	Exceeding the environment recommended by the OS being used
Memory	Exceeding the environment recommended by the OS being used
Hard disk	Vacant capacity of more than 20MB in the installation destination drive
Communication port	Serial (RS-232C), USB
Applicable controllers	TS-S2/TS-SH/TS-X/TS-P/TS-SD

Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

## ■ Data cables (5m)

Communication cable for TS-Manager.  
Select from USB cable or D-sub cable.



- TS-S2
- TS-SH
- TS-X
- TS-P
- TS-SD

Model	USB type (5m)	KCA-M538F-A0
	D-Sub type (5m)	KCA-M538F-01

Note. USB driver for communication cable can also be downloaded from our website.

Articulated robots  
YA

Linear robot  
modules  
LCM100

Compact  
single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller

INVERTER  
Electric  
grripper

Option

Option details

Support software for PC

# POPCOM+

POPCOM+ is an easy to operate application software that makes tasks such as robot operation, writing-editing programs, and point teaching easy to visually understand.



▼Applicable controllers

LCC-140 P484


ERC-D P510

SR1-X P516  
SR1-P

■ Features


1 Easy to use

All items necessary for robot operation are displayed on single screen. There is no need to remember the menu structure so that it can be easily operated with mouse control by anybody.




2 Program editing

Edit amendment, cut, copy, paste, syntax check and program entry can be performed efficiently with function keys.



3 Point editing

Edit amendment, cut, copy, paste, syntax check, teach and trace functions are provided.



4 Help function

If you need some detailed information, robot language etc. during operation, operate [F1] key or [HELP] key to recall useful information on the screen.



5 Robot operation

By connecting between a computer and the controller with a communication cable, the controller can control the robot in the same way as a HPB / HPB-D (programming box).




6 Creating point data

There are three methods available for creating the point data.

● MDI (Manual Data Input) teaching

The numeric keyboard is used to enter position coordinate data directly.




● Remote teaching

The robot arm is actually moved to the target position using the keys for point data registration.



● Direct teaching

The robot arm is manually moved to the target position with the servo motors off for point data registration.



PC supporting software POPCOM+



POPCOM+ software model | KBG-M4966-00

POPCOM+ environment

OS	Microsoft Windows XP / Vista (32bit/64bit) / 7 (32bit/64bit) / 8,8.1 (32bit/64bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	50MB of available space required on installation drive.
Disk operation	RS-232C
Applicable controllers	SRCX/ERCX/DRCX/TRCX/SRCP/SRCD/ERCD/SR1/LCC140 <sup>Note 1</sup>

Note 1. LCC140 is applicable to Ver. 2.1.1 or later.  
 Note. Windows is the registered trademark of US Microsoft Corporation in U.S.A. and other countries.

Data cables (5m)

Communication cable for POPCOM+.  
 Select from USB cable or D-sub cable.



	USB	D-Sub
Model	USB type (5m) D-Sub type 9pin-9pin (5m)	KBG-M538F-00 KAS-M538F-10

LCC140	ERCD
SR1-X	SR1-P
RCX221	RCX222
RCX240/S	RCX340

Note. This USB cable supports Windows 2000/XP or later.  
 Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.  
 Note. USB driver for communication cable can also be downloaded from our website.

9Pin-25Pin converter adapter

This is an adapter for converting the female D-sub25Pin to a female D-sub9Pin.  
 This adapter is needed if using the ERCX and DRCX.




Model | KBB-M657E-01

Note. It is unnecessary when using ERCD or SR1-X, SR1-P.

Controller & data cable / converter adapter matchup table

Controller	ERCD SR1-X/SR1-P LCC140 (9Pin)	ERCX DRCX (25Pin)
Data cables		
[9Pin-9Pin cable] • KAS-M538F-10 (SSC-2-5L)	Needs no converter adapter	9Pin-25Pin converter adapter KBB-M657E-01

Controller and data cable connection diagrams



Articulated robots  
YA

Linear conveyer modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

IN/VI/VZ Electric gripper

Option

Support software for PC

# VIP+ Windows

Visual Integrated Programming

VIP+ is an easy to operate application software that makes tasks such as robot operation, writing-editing programs, and point teaching easy to visually understand.




▼Applicable controllers

- RCX221 P.524
- RCX222
- RCX240 P.532
- RCX240S

■ Features

**1 GUI updated for enhanced usability**

The user interface has been improved with the VIP Windows function kept as it is so as to achieve more ease of use.



**2 Data displayed in the tree view form**

The data included in the controller is displayed legibly.




**3 Fully equipped tool bar**

Each of various functions can be executed by simple one click on the tool bar.



**4 Expanded monitor function**

The I/O conditions and variables in the controller can be monitored at real time. In the advanced mode, it is also possible to attach any label (Note) to general purpose input/output and others.



Note. The label is stored in PC.

**5 Data operation using the new drag & drop function**

The data can be stored easily by using the drag & drop function. Likewise, the stored data can be restored to the controller by operating the mouse only.



Select the data to be stored.

Drag the selected data to the document window and drop it there.

Specify the file name and this completes the storage procedure.

**6 Input the data in the work sheet form (Parameter, Point data)**

It is also possible to copy and paste the data from the other spread sheet (chart calculation software).



**7 Syntax coloring when editing the program**

When reserved words (character string reserved as the robot language) are inputted, they are colored automatically, making them noted at one glance for easier program editing.




**8 Program execution monitor**

The step being performed during the program execution can be monitored. Thus, it is possible to check which step is performed without stopping the program, thereby debugging of the program is made much easier.



**9 List appointing (point where the system is restored)**


It is possible to create the system restoration point at any timing. By doing so at important points in the system constructing process when, for example, something faulty is found after the system was changed, the system can be returned to the state before such change easily.



VIP PLUS function

1 Easy to use

With a number of robot operation items provided on one screen, any operator can operate easily without memorizing the menu construction.



2 Programming editing

The program, point, parameter, shift, and hand can be edited on the PC alone. Equipped with the function selector having the command searching function which enables to input the robot language with ease.




3 Data check function

Provided with the equivalent data check function to that of a robot controller, it is possible to correct data errors before operation.



4 Help function

When more information is needed during operation, press the [F1] or [HELP] key, and the help screen will appear.




5 Robot operation

By connecting PC and controller with communication cable, robot operation will be available by the on-line command.




6 On-line editing

Connecting a PC and the controller with a communication cable enable to edit data from robot controllers just as with RPB / RPB-E.



7 Creating point data There are three methods available for creating the point data.

● MDI (Manual Data Input) teaching  
The numeric keyboard is used to enter position coordinate data directly.



● Remote teaching  
The robot arm is actually moved to the target position using the keys for point data registration.



● Direct teaching  
The robot arm is manually moved to the target position with the servo motors off for point data registration.


Support software for PC VIP+



Model	KX0-M4966-00
-------	--------------

Data cables (5m)

Communication cable for VIP+. Select from USB cable or D-sub cable.



Model	USB type (5m)	D-Sub type 9pin-9pin (5m)
	KBG-M538F-00	KAS-M538F-10


Note. This USB cable supports Windows 2000/XP or later.  
Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.  
Note. USB driver for communication cable can also be downloaded from our website.

Environment

OS	Microsoft Windows 2000 / XP / Vista (32bit / 64Bit) / 7 (32bit / 64Bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk	40MB of available space required on installation drive.
Communication method	RS-232C, Ethernet Note. For Ethernet communication, Ethernet unit for RCX series controller is required.
Applicable robot controllers	RCX221 / RCX222 / RCX141 / RCX142 / RCX240 / RCX240S

Note. Microsoft and Windows are registered trademarks of Microsoft Corporation.  
Note. ADOBE and ADOBE READER are registered trademarks of Adobe Systems Incorporated.  
Note. Ethernet is a registered trademark of Xerox Corporation.

Controller and data cable connection diagrams



Articulated robots  
YA  
Linear CONVEYOR modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
I/V/N/V2 Electric gripper

Option

## Option details

### Support software for PC

# RDV-Manager

▼Applicable controllers

RDV-X  
RDV-P

P.504


RDV-Manager is software for RDV-X/RDV-P. Using the Windows operating computer, it is possible to set parameters, to monitor the position, speed and torque and to have graphics displayed, assuring pleasant and easy operation in the Windows Vista, Windows 7 or Windows 8 / Windows 8.1 environment.



## Features


### 1 Monitoring function

It is possible to monitor the operation condition and output state in real time. Additionally, the terminal can be operated forcibly to check the operation.




### 2 Setting parameters

It is possible to set, change, print and store the parameters.




### 3 Operation tracing function

It is possible to have the servo motor speed and electric current displayed in the form of graphics.



### 4 Offline auto tuning function

The load moment of inertia can be estimated and the automatic servo gain can be adjusted.



## Support software RDV-Manager

RDV-Manager is RDV-X / RDV-P dedicated software.



Model KEF-M4966-00

## Environment

OS	Microsoft Windows Vista(32bit) Note 1 / 7(32bit/64bit) / 8, 8.1(32bit/64bit)
CPU	Pentium4 1.8GHz or more (Recommend)
Memory	1GB or more
Hard disk	1GB of available space required on installation drive.
Disk operation	USB
Applicable controllers	RDV-X / RDV-P

Note 1. SP1 (service pack 1) or higher.  
Note. Windows Vista, Windows 7, and Windows 8 / Windows 8.1 are trademarks of Microsoft Corporation registered in U.S.A. and other countries.

## Communication cable for PC supporting software RDV-Manager (3m)

Communication cable to connect PC and a controller.



Model KEF-M538F-00

## Support software for PC

# RCX-Studio Pro

▼Applicable controllers

RCX340

P.542

This is dedicated support software for the RCX340 controller. It is a further advance in ease-of-use over the previous RCX-Studio. Emulator functionality is also provided, contributing to full-scale system startup.



## ■ Features

### 1 Evaluation

#### ● Emulator function provided

By operating the controller on a PC, programs can be created and debugged even without a controller. Cycle time can also be calculated, greatly reducing the time for software design.

#### ● Cycle time calculator

Cycle time between two points can be easily calculated in two steps. Choosing a model is easily done; simply select a model and enter the position.



### 2 Design

#### ● Easy-to-use operation allows speedy setup

Program entry support functionality is provided. Program editing and data editing.


#### ● Inter-operation with other manufacturer's line simulators

Software made by other companies can be connected to the emulator of the RCX-Studio Pro, allowing checking for interference between robots in the facility.

Note. Software made by other companies is provided by the customer.

#### ● iVY2 editor provided

Integration of iVY2 Studio makes it unnecessary to switch between software; this improves productivity.



### 3 After installation


#### ● Realtime trace

Continuous output of the controller's internal data allows the status to be checked at any time. Even if no measuring device is present, the current waveform can be obtained for peace of mind.



#### ● Application debugging function

Debugging information for multiple tasks can be displayed simultaneously.




Debug information on multi tasks is displayed at the same time.

### 4 Maintenance

#### ● Data comparison tool

Two specified data items can be compared, and the difference shown. Comparison of entire ALL files and comparison of individual programs is also possible. Direct comparison with online data is also possible, greatly shortening the time required for maintenance tasks.



Select and compare two data items

## ■ RCX-Studio Pro software



USB key (Dongle)

Model	RCX-Studio Pro (USB key included)	KCX-M4990-10
-------	-----------------------------------	--------------

Note. Although it is possible to install this software on multiple PCs, the functionality is limited if there is no USB key (see P.551). Additional USB keys (additional licenses) are available at a special price. Please contact Yamaha for details.

## ■ Environment

OS	Microsoft Windows XP / Vista (32/64bit) / 7 (32/64bit) / 8 (32/64bit) / 8.1 (32/64bit)
CPU	Intel® Core™ 2 Duo 2 GHz or higher is recommended
Memory	1 GB or more is recommended
Hard disk	80MB or more free space in the RCX-Studio Pro installation destination
Communication port	Communication cable: serial communication port, Ethernet, or USB port USB key: USB port (one port)
Display	1024×768 or higher resolution, 256 colors or higher
Other	CD-ROM drive Dedicated communication cable (for D-Sub or for USB) Ethernet cable (category 5 or higher)
Applicable robot controllers	RCX340

Note. Microsoft, Windows, Windows XP, Windows Vista, Windows 7, Windows 8 and Windows 8.1 are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries. Other company names and product names listed in this manual may be the trademarks or registered trademarks of their respective companies.

## ■ Data cables (5m)

Communication cable for RCX-Studio Pro. Select from USB cable or D-sub cable.



USB



D-Sub

Model	USB type (5m)	KBG-M538F-00
	D-Sub type 9pin-9pin (5m)	KAS-M538F-10

Note. This USB cable supports Windows 2000/XP or later. Note. Data cable jointly used for POPCOM+, VIP+, RCX-Studio Pro.

Note. USB driver for communication cable can also be downloaded from our website.

LCC140	ERCD
SR1-X	SR1-P
RCX221	RCX222
RCX240/S	RCX340

## Handy terminal

# HT1/HT1-D



### ▼Applicable controllers

TS-S2  
TS-SH  
TS-X  
TS-P


P490

This Handy Terminal is a device that can perform any operation such as robot manual operation, point data edit, teaching, and parameter setting, etc. Has graphic LCD display with backlight for easy viewing.


### ■ HT1 / HT1-D basic specifications

Name		HT1	HT1-D
External view			
Applicable controllers		TS-S2 / TS-SH / TS-X / TS-P	
Model	Japanese specifications	KCA-M5110-0J(3.5m) KCA-M5110-6J(10m)	KCA-M5110-1J(3.5m) KCA-M5110-7J(10m)
	English specifications	KCA-M5110-0E(3.5m) KCA-M5110-6E(10m)	KCA-M5110-1E(3.5m) KCA-M5110-7E(10m)
Display		Dot matrix monochrome display (with backlighting) 32 characters × 10 lines	
Operation keys		Mechanical switch	
Emergency stop button		Normally closed contact point (with lock function)	
Enable switch		-	3-position
Safety connector		-	15 pin D-sub connector (male)
CE marking		Not supported	Applicable
Operating temperature		0°C to 40°C	
Operating humidity		35% to 85%RH (non-condensing)	
Dimensions		W88 × H191 × D45mm (Emergency stop button not included.)	
Weight		260g (not including cable)	300g (not including cable)
Cable length		3.5m / 10m	

### ■ Part names and function



### ■ HT1-D rear side







**Programming box**

# HPB/HPB-D


▼Applicable controllers	
<b>LCC140</b>	<b>P.484</b>
<b>ERCD</b>	<b>P.510</b>
<b>SR1-X</b> <b>SR1-P</b>	<b>P.516</b>

All operations can be performed from this device including manual robot operation, programming entry and editing, teaching and setting parameters. The display works interactively with the operator so even an absolute beginner can easily learn how to use programming box.

■ **HPB / HPB-D basic specifications**

Name	HPB	HPB-D
External view		
Model	Using with ERCD, SR1-X, SR1-P Using with ERCX, SRCP30, DRCX	KBB-M5110-01 (without a conversion adaptor) KBB-M5110-0A (with a conversion adaptor) KBB-M5110-21 (without a conversion adaptor) KBB-M5110-2A (with a conversion adaptor)
Display	LCD (20characters × 4 lines)	
Emergency stop button	Normally closed contact point (with lock function)	
Enable switch	-	3-position
CE marking	Not supported	Applicable
Memory back-up device	SD Memory card	
Operating temperature	0°C to 40°C	
Operating humidity	35% to 85%RH (non-condensing)	
Dimensions	W107 × H230 × D53mm (Strap holder, emergency stop button not included.)	
Weight	650g	
Cable length	3.5m	

■ **Part names and function**



**Emergency stop button**  
Performs a robot emergency stop when pressed during robot operation. Release the button lock (locks when pressed) by turning the button in the CW direction. After releasing the button, a servo recovery must be performed from the HPB (or by I/O operation) in order to recover from the emergency stop status.


**Strap hole**  
Attaching a short strap or necklace strap here prevents dropping the HPB while operating it or installing it onto equipment.

**SD memory card connector**  
An SD memory card can be inserted here. SD memory cards are provided by the customer.

**Operation keys**  
These keys are used to operate the robot and to enter programs and data, etc. The keys are divided into 2 main groups: function keys and data entry/operation keys. (For operation key details, see Chapter 3, "Basic operations".)

**Connector cable**  
Connects the HPB to the controller. A D-Sub 9-pin connector (male) is provided at one end of the cable.

■ **HPB-D rear side**



**Safety connector (HPB-D only)**  
Use this connector with the emergency stop or enable switch to configure an external safety circuit. Attaching the supplied 15-pin D-sub connector (female) directly to this safety connector enables the emergency stop button only.

**3-position enable switch (HPB-D only)**  
This switch is effective for use with an external safety circuit. This switch opens (cuts off) the circuit when pressed or released. Pressing it to mid-position connects the circuit. Use this switch as the enable switch in Service mode, so that the external safety circuit triggers emergency stop on the robot when this switch is pressed or released.

■ **A conversion adapter for HPB**

The adapter converts from 25 pins to 9 pins. If the HPB was ordered along with a converter adapter then this adapter comes packed along with the unit.



Model	KBB-M657E-01
Note. It is unnecessary when using ERCD or SR1-X, SR1-P.	

Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

I/V/I/V/Z Electric gripper

Option

**Programming box**

# RPB/RPB-E

▼Applicable controllers



**RCX221**  
**RCX222** **P.524**

**RCX240**  
**RCX240S** **P.532**


Customers using the RCX141 / RCX142 controllers should use the connector converter cable (See P.603.)

All operations can be performed from this device including manual robot operation, programming entry and editing, teaching and setting parameters. The display works interactively with the operator so even an absolute beginner can easily learn how to use programming box.


■ RPB / RPB-E basic specifications

Name	RPB	RPB-E
External view		
Applicable controllers	RCX221 / RCX222 / RCX240 / RCX240S	
Model	KBK-M5110-10	KBK-M5110-00
Display	LCD (40characters 8 lines)	
Emergency stop button	Normally closed contact point (with lock function)	
Enable switch	–	3-position
CE marking	Not supported	Applicable
Operating temperature	0°C to 40°C	
Operating humidity	35% to 85%RH (non-condensing)	
Dimensions	W180 × H250 × D50mm (Strap holder, emergency stop button not included.)	
Weight	600g	
Cable length	5m (Standard), 12m (Options)	

■ Part names and function



■ RPB-E rear side



## Programming box

## PBX/PBX-E

▼Applicable controllers



RCX340

P.542


This programming box is applicable to three languages, “Japanese”, “English”, and “Chinese”. Use of a color display makes it possible to improve the visibility. Work to add or edit functions becomes easy, allowing even personnel without programming skill to operate this programming box.

A function to save the controller data into the USB memory is incorporated.


## ■ PBX/PBX-E basic specifications

Name	PBX	PBX-E
External view		
Applicable controllers	RCX340	
Model	Japanese language model	KCX-M5110-1J (5m) KCX-M5110-3J (12m)
	English language model	KCX-M5110-1E (5m) KCX-M5110-3E (12m)
	Chinese language model	KCX-M5110-1C (5m) KCX-M5110-3C (12m)
Display screen	Color LCD (320 × 240 dot)	
Emergency stop button	Normally-closed contact (with lock function)	
Enable switch	Not provided	3-position type
Manual lock selector switch	90°, 2-notch	
Power	+12 V DC	
Operating environment	Ambient temperature for use: 0 to 40 °C, Ambient temperature for storage: -10 to 60 °C Humidity: 35 to 80% (no condensation)	
Dimensions (mm)	W141 × H245 × D45 (excluding projecting parts)	
Cable length	5 m or 12 m (Select either)	
Weight	440 g (excluding the cable)	460 g (excluding the cable)

## ■ Part names and function



## ■ PBX-E rear side



## ■ Display language switching USB for PBX

	Model
Display language switching USB for PBX	KCX-M6498-00
USB cable	KCX-M657E-00

## Option details

### LCD Monitor option

# TS-Monitor

#### ▼Applicable controllers

TS-X  
TS-P

P490



Integrated into the controller unit, the TS-monitor needs no connections to the handy terminal or PC and checks operation status, current position, error information, etc. The TS-monitor even allows the operator on the scene or service personnel to easily check the controller status.

Total operating time is also displayed which is convenient to schedule maintenance periods.

Note. The TS-Monitor cannot be installed on the controller when using a daisy-chain connection or when using a gateway connection.


### The TS Monitor Advantage

#### Before installing TS Monitor



Without a handy terminal "HT1" and PC software "TS-Manager", the operator does not know what caused the alarm and it takes a time to find out the cause.

#### After installing TS-Monitor



- Operator instantly knows various information without hooking to a handy terminal or PC.
- During errors the backlit display turns red and operator can see what error occurred on what controller at a glance.
- Display shows total operating time, so scheduling maintenance periods is easy.
- Backlit display is bright and easy to read even on dark panels.

### Features

#### MAIN screen

**Shows basic info**  
Displays optional name or character string.

**Error**

Desired character string specified by the user.

Simple status display  
■ ON / □ OFF

Run mode

Current position

#### MAIN screen

**Easy to see error messages**  
Red backlit display appears during alarms.

**Alarm occurs.**

Error or warning alarm number

Alarm name

**Simple status display**

Display	Meaning
S	Servo status
E	Emergency stop
P	Main power failure
O	Return-to-origin completion status
L	Interlock status
A	Alarm

**Run mode**

Display	Meaning
NRM	Normal mode
MON	Monitor mode
DBG	Debug mode

#### I/O screen

**Shows I/O status**  
Displays input/output bit states.

Input signal status  
\* Displays the status of input bit 0 to 15.

Output signal status  
\* Displays the status of output bit 0 to 15.

**Bit signal correspondence table**

	F	E	D	C	B	A	9	8
IN	SERVO	RESET	START	LOCK	ORG	MANUAL	JOG	JOG+
	7	6	5	4	3	2	1	0
	F	E	D	C	B	A	9	8
OUT	SRV-S	ALM	END	BUSY	OUT3	OUT2	OUT1	OUT0
	7	6	5	4	3	2	1	0
	POU17	POU16	POU15	POU14	POU13	POU12	POU11	POU10

#### INFORMATION screen

**Shows machine info**  
Displays the connected robot and version.

Controller name

Controller software version

Robot name

Point type

#### STATUS screen

**Shows status info**  
Info such as error status or movement status is all at a glance.

Status display  
■ ON, □ OFF

**Status display**

Display	Meaning
SRV-S	Servo status
ORGSEN	Origin sensor
TLM-S	Push status
MOVE	Move status
E-STOP	Emergency stop
P-BLK	Main power failure
ORG-S	Return-to-origin completion status
WARN	Warning output

#### CHECK screen

**Shows operating status**  
Displays total drive distance (helpful for preventive maintenance).

Internal voltage of controller

Temperature inside controller

Total startup time of controller (Day : Hour : Minute)

Total movement distance of robot

#### RUN screen

**Shows operation status and data**  
Info includes position, speed, load factors and run type.

Run type

Robot current position

Run point

Robot operation speed


Load rate

**Run type**


Display	Meaning
HOLD	Servo is off or robot is stopping
ABS	ABS
INC	INC
ABS MERGE	ABS merge operation
INC MERGE	INC merge operation
ABS PUSH	ABS push operation
INC PUSH	INC push operation
ABS->PUSH	ABS deceleration push operation
P-BLK	Main power failure
INC->PUSH	INC deceleration push operation
ORG	Return-to-origin

### TS-X/TS-P dimensions (with TS-Monitor)

#### ● TS-X/TS-P (105/110/205/210) with TS-Monitor



#### ● TS-X/TS-P (220) with TS-Monitor



### TS-Monitor basic specifications

Model	TS-X	KCA-M5119-00
	TS-P	KCA-M5119-10
Effective display size	W40.546 × H25.63mm	
Screen display	Graphic monochrome LCD	

Backlight	Blue and red, 2-color LCD
Contrast adjustment	5 steps
Number of display dots	128 × 64 dots

Touch operator interface

# Pro-face GP4000 series

▼Applicable controllers

**TS-S2**  
**TS-SH**  
**TS-X**  
**TS-P**

**P490**

Connecting GP4000 Series made by Pro-face to Robot Positioner, TS-S2, TS-SH, TS-X, TS-P enables you to use a lot of functions as well as basic operations on Touch Operator Interface.

Free download of the program file from the Pro-face home page  
<http://www.proface.com>

■ Features


## 1 Can easily check a state and change settings.

- Check the status (the current position, speed etc)
- Basic operations such as Jog operation, inching operation, return to origin, error reset etc.
- Set, edit, or back up point data and parameters
- Check triggered alarms and detailed descriptions of alarm history

## 2 Supports 3 languages

- Supports Japanese, English, and Chinese (simplified, traditional)

Without opening the control panel, you can check the status and change the settings on Touch Operator Interface alone.



■ Screen details

### Diagnostic Screen

When a problem occurs, you can check the detailed descriptions of the alarm history, so you can understand easily what the cause is.




### I/O Monitor Screen

Displays both general I/O and dedicated I/O together. You can quickly check the I/O status.




### Information Monitor Screen

The screen can display the robot status and the operation status. You can check immediately the robot condition.




### Position Data Editing Screen

You can edit and back up point data (255 points).  
Note. Settings for it and a USB storage required.




### Parameter Editing Screen

While checking parameters of robot positioners in the list, you can set them with the pull-down menu.



### Connecting Selection Screen

You can connect up to 16 robot positioners simultaneously with GP-Pro EX Ver.3.0 multi-axis feature.



Contact; Pro-face TEL:06-6613-1101 FAX:06-6613-5888

Articulated robots  
YA

Linear motor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Robot positioner

Pulse string driver

Robot controller

IN/VA/VZ Electric gripper

Option

Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION

Robot positioner

Pulse string driver

Robot controller

IV/V/VZ Electric gripper

Option

Option details

Field network system with minimal wiring

NETWORK  
LCC140

P.484

CC-Link Basic specifications for network modules

Item	Network modules CC-Link
Applicable controllers	LCC140
CC-Link compatible version	Ver. 1.10
Remote station type	Remove device station
Number of occupied stations	Fixed to 2 stations
Station number	1 to 63 (Set from HPB)
Communication speed	10M/5M/2.5M/625K/156Kbps (Set using HPB or POPCOM+.)
Shortest length between stations	0.2 m or more
Total length	100m/10Mbps, 160m/5Mbps, 4000m/2.5Mbps, 900m/625Kbps, 1200m/156Kbps
Monitor LED	None
CC-Link I/O points	General-purpose input 32 points, General-purpose output 32 points Dedicated input 16 points, Dedicated output 16 points Input register 8 words Output register 8 words

DeviceNet Basic specifications for network modules

Item	Network modules DeviceNet™
Applicable controllers	LCC140
Applicable DeviceNet™ specifications	Volume 1 Release2.0 Volume 2 Release2.0
DeviceNet™ Conformance test	Compliant with CT24
Device profile / Device type number	Generic Device (keyable) / 2B Hex
Vendor name/Vendor ID	YAMAHA MOTOR CO.,LTD. / 636
Product code	21
Product revision	1.0
EDS file name	Yamaha_LCC1(DEV).eds
MAC ID setting	0 to 63 (Set using HPB or POPCOM+.)
Communication speed setting	500K/250K/125Kbps (Set using HPB or POPCOM+.)
Communication data	Predefined Master/Slave Connection Set: Group 2 only server Dynamic connection support (UCMM): None Support for divided transmission of explicit message: Yes
Network length	Total length 100m/500Kbps, 250m/250Kbps, 500m/125Kbps Branch length/Total branch length 6m or less/39m or less, 6m or less/78m or less, 6m or less/156m or less
Monitor LED	None
Number of DeviceNet™ I/O points/ number of occupied channels	General-purpose input 32 points, General-purpose output 32 points Dedicated input 16 points, Dedicated output 16 points Input register 8 words Output register 8 words
	Input: 24byte Output: 24byte

EtherNet/IP Basic specifications for network modules

Item	Network modules EtherNet/IP™
Applicable controllers	LCC140
Applicable software version	LCC140: Ver. 64.07 or higher HPB/HPB-D: Ver. 24.06 or higher POPCOM+: Ver. 2.1.0 or higher
Applicable EtherNet/IP™ specifications	Volume 1: Common Industrial protocol(CIP™) Edition 3.14 Volume 2: EtherNet/IP™ Adaptation of CIP Edition 1.15
EtherNet/IP™ Conformance test	Compliant with CT11
Device profile/Device type number	Generic Device (keyable) / 2B Hex
Vendor name/Vendor ID	YAMAHA MOTOR CO.,LTD. / 636
Product code	23
Product revision	1.1
EDS file name	Yamaha_LCC1(EIP2).eds
Communication speed	10Mbps / 100Mbps
Connector specifications	RJ-45 connector (8-pole modular connector), 2 ports
Applicable cable specifications	STP cable (double shield) with CAT 5e or higher
Maximum cable length	100m
Monitor LED	Module Status(MS), Network Status(NS), Link/Activity: Port1-2
Number of EtherNet/IP™ I/O points/ number of occupied channels	General-purpose input 32 points, General-purpose output 32 points Dedicated input 16 points, Dedicated output 16 points Input register 8 words Output register 8 words
	Input: 24byte Output: 24byte

## Field network system with minimal wiring

## NETWORK

## TS-S2/TS-SH/TS-X/TS-P

P.490

 **Basic specifications for network modules**

Item	Network modules CC-Link
Applicable controllers	TS-S2 / TS-SH / TS-X / TS-P
Version supporting CC-Link	Ver. 1.10
Remote node type	Remote device node
Number of occupied nodes	1 node
Node number setting	1 to 64
Communication speed setting	10Mbps, 5Mbps, 2.5Mbps, 625Kbps, 156Kbps
No. of CC-Link inputs/outputs	Input 16 points, Output 16 points
Shortest distance between nodes <sup>Note1</sup>	0.2m or more
Overall extension distance <sup>Note1</sup>	100m/10Mbps, 160m/5Mbps, 400m/2.5Mbps, 900m/625Kbps, 1200m/156Kbps
Monitor LED	L RUN, L ERR, SD, RD

Note 1. These values apply when a cable that supports CC-Link Ver.1.10 is used.

 **Basic specifications for network modules**

Item	Network modules DeviceNet™	
Applicable controllers	TS-S2 / TS-SH / TS-X / TS-P	
Applicable DeviceNet™ specifications	Volume 1 Release2.0/Volume 2 Release2.0	
Device type	Generic Device (device number 0)	
Number of occupied CH	Input 6ch, Output 6ch	
MAC ID setting	0 to 63	
Communication speed setting	500Kbps, 250Kbps, 125Kbps	
DeviceNet™ inputs/outputs	Input 16 points, Output 16 points	
Network length	Overall extension distance	100m/500Kbps, 250m/250Kbps, 500m/125Kbps
	Branch length	6m or less
	Overall branch length	39m or less/500Kbps, 78m or less/250Kbps, 156m or less/125Kbps
Monitor LED	Module, Network	

 **Basic specifications for network modules**

Item	Network modules EtherNet/IP™
Applicable controllers	TS-S2 / TS-SH / TS-SH / TS-X / TS-P <sup>Note</sup>
Applicable EtherNet/IP™ specifications	Volume1: Common Industrial Protocol (CIP™) Edition 3.8 Volume2: EtherNet/IP™ Adaptation Edition 1.9
Device type	Generic Device (device number 43)
Number of occupied CH	Input 6ch, Output 6ch
Ethernet interface	10BASE-T/100BASE-TX
Network length	100m
Monitor LED	MS, NS, Activity, Link

Note. Supported by controller software version V1.10.121 or later. Necessary parameters can be set with the support tool, HT-1 (V1.13 or later) and TS-Manager (V1.3.3 or later).

 **Basic specifications for network modules**

Item	Network modules PROFINET
Applicable controllers	TS-S2/TS-SH/TS-X/TS-P <sup>Note</sup>
Network specification conformance	PROFINET IO V2.2
Conformance class	Conformance Class B / IO Device
Input/output data size	Input 6 words, output 6 words
Transmission speed	100Mbps(Auto-negotiation)
Network length	100m
Monitor LED	MS, NS, Activity, Link

Note. Supported by controller software version V1.14.136 or later. Necessary parameters can be set with the support tool, HT-1 (V1.16 or later) and TS-Manager (V1.4.4 or later).

## Field network system with minimal wiring

## NETWORK

## SR1-X/SR1-P

P.516

 **Basic specifications for network modules**

Item	Network modules CC-Link
Applicable controllers	ERCX / SR1-P / SR1-X / SRCP30 / DRCX
Version supporting CC-Link	Ver. 1.10
Remote node type	Remote device node
Number of occupied nodes	Two nodes fixed
Node number setting	1 to 63
Communication speed setting	10Mbps, 5Mbps, 2.5Mbps, 625Kbps, 156Kbps
No. of CC-Link I/O <sup>Note1</sup>	General input 32 points, General output 32 points, Dedicated input 16 points, Dedicated Output 16 points
Parallel external I/O (ERCX, SRCP30, DRCX only)	All points usable as parallel external I/O for controller. Each point controllable from master station sequencer (PLC) by emulated serialization, regardless of robot program.
Shortest distance between nodes <sup>Note2</sup>	0.2m or more
Overall length <sup>Note2</sup>	100m/10Mbps, 160m/5Mbps, 400m/2.5Mbps, 900m/625Kbps, 1200m/156Kbps
Monitor LED	RUN, ERR, SD, RD

Note 1. Controller I/Os are updated every 10ms.

Note 2. These values apply when a cable that supports CC-Link Ver 1.10 is used.

 **Basic specifications for network modules**

Item	Network modules DeviceNet™
Applicable controllers	ERCX / SR1-P / SR1-X / SRCP30 / DRCX
Applicable DeviceNet™ specifications	Volume 1 Release2.0/Volume 2 Release2.0
Device type	Generic Device (device number 0)
Number of occupied CH	Input 2ch <sup>Note1</sup> , Output 2ch <sup>Note1</sup>
MAC ID setting	0 to 63
Communication speed setting	500Kbps, 250Kbps, 125Kbps
DeviceNet™ I/O <sup>Note2</sup>	General input 16 points <sup>Note3</sup> , General output 16 points <sup>Note3</sup> , Dedicated input 16 points, Dedicated Output 16 points
Parallel external I/O (ERCX, SRCP30, DRCX only)	All points usable as parallel external I/O for controller. Each point controllable from master station sequencer (PLC) by emulated serialization, regardless of robot program.
Network length	Overall length <sup>Note4</sup> 100m/500Kbps, 250m/250Kbps, 500m/125Kbps
Branch length/Overall branch length	6m or less/39m or less, 6m or less/78m or less, 6m or less/156m or less
Monitor LED	Module, Network

Note 1. Inputs / Outputs are 12ch each when using SR1-P / SR1-X with extension model.

Note 2. Controller I/Os are updated every 10ms.

Note 3. General Inputs / Outputs are 32 each when using SR1-P / SR1-X with extension model.

Note 4. These values apply when a thick cable is used. The distance is less when a fine cable is used or when thick and fine cables are mixed in use.

 **Basic specifications for network modules**

Item	Network modules PROFIBUS
Applicable controllers	ERCX / SR1-P / SR1-X / SRCP30 / DRCX
Communication profile	PROFIBUS-DP slave
Number of occupied nodes	1 node
Setting of station address	0 to 126
Communication speed setting	9.6Kbps, 19.2Kbps, 93.75Kbps, 187.5Kbps, 500Kbps, 1.5Mbps, 3Mbps, 6Mbps, 12Mbps (automatic recognition)
PROFIBUS I/O <sup>Note</sup>	General input 32 points, General output 32 points, Dedicated input 16 points, Dedicated Output 16 points
Parallel external I/O (ERCX / DRCX only)	All points usable as parallel external I/O for controller. Each point controllable from master station sequencer (PLC) by emulated serialization, regardless of robot program.
Overall length	100m/12Mbps, 200m/1.5Mbps, 400m/500Kbps, 1000m/187.5Kbps, 1200m/9.6K · 19.2K · 93.75Kbps

Note. The shortest I/O update interval of the controller is 10ms but the actual I/O update time varies depending on the update time with the master station.

 **Basic specifications for network modules**

Item	Network modules Ethernet
Applicable controllers	ERCX / SRCP30 / DRCX
Network specification	As specified for Ethernet (IEEE802.3)
Connector specification	RJ-45 connector (8-pole modular connector) 1 port
Baud rate / Communication mode	10Mbps (10BASE-T) / Half Duplex (Half-duplex)
Network protocol	Application layer: TELNET / Transport layer: TCP / Network layer: IP, ICMP, ARP / Data link layer: CSMA/CD / Physical layer: 10BASE-T
Number of simultaneous log inputs	1
Setting of IP address, etc.	Set from HPB / HPB-D
Monitor LED	Run, Collision, Link, Transmit, Receive



## Field network system with minimal wiring

## NETWORK

# RCX221/RCX222 P.524 RCX240/RCX240S P.532 RCX340 P.542

## CC-Link Basic specifications for network modules

Item	Network modules CC-Link
Applicable controllers	RCX221 / RCX222 / RCX240 / RCX240S / RCX340
Version supporting CC-Link	Ver. 1.10
Remote station type	Remote device node
Number of occupied stations	Fixed to 4 stations
Station number setting	1 to 61 (set from the Rotary switch on board)
Communication speed setting	10Mbps, 5Mbps, 2.5Mbps, 625Kbps, 156Kbps (set from the Rotary switch on board)
No. of CC-Link I/O <small>Note1</small>	General input 96 points, General output 96 points, Dedicated input 16 points, Dedicated output 16 points
Parallel external I/O <small>Note2</small>	A function that simulates serial communication enables individual control of the various points from a master sequencer, regardless of the robot program.
Shortest distance between nodes <small>Note3</small>	0.2 m or more
Overall length <small>Note3</small>	100m/10Mbps, 150m/5Mbps, 200m/2.5Mbps, 600m/625Kbps, 1200m/156Kbps
Monitor LED	RUN, ERR, SD, RD

Note 1. Controller I/Os are updated every 10ms.

Note 2. With RCX 141/142, the exclusive input of the parallel I/O cannot be used other than the interlock input. With RCX221 / 222, the exclusive input of the parallel I/O cannot be used. (The interlock input terminal is located on the SAFETY connector side.)

Note 3. These values apply when a cable that supports CC-Link Ver.1.10 is used.

## DeviceNet Basic specifications for network modules

Item	Network modules DeviceNet™
Applicable controllers	RCX221 / RCX222 / RCX240 / RCX240S / RCX340
Applicable DeviceNet™ specifications	Volume 1 Release2.0 / Volume 2 Release2.0
Device Profile Name	Generic Device (device number 0)
Number of occupied CH <small>Note1</small>	Normal: Input/output 24ch each, Compact: Input/output 2ch each
MAC ID setting	0 to 63
Transmission speed setting	500Kbps, 250Kbps, 125Kbps (set using DIP switch on board)
DeviceNet™ I/O <small>Note2</small>	Normal General input 96 points, General output 96 points, Dedicated input 16 points, Dedicated output 16 points Compact General input 16 points, General output 16 points, Dedicated input 16 points, Dedicated output 16 points
Parallel external I/O <small>Note3</small>	The master module and up to four ports can be controlled regardless of the robot program by using the pseudoserialization function.
Network length	Overall length <small>Note4</small> 100m/500Kbps, 250m/250Kbps, 500m/125Kbps Branch length / Overall branch length 6m max./39m max., 6m max./78m max., 6m max./156m max.
Monitor LED	MS (Module Status), NS (Network Status)

Note 1. Use the robot parameter to select Normal or Compact. However, with the controllers earlier than Ver.9.08 of RCX221 / 222, this selection is not available and the setting remains the same as Normal.

Note 2. Controller I/Os are updated every 10ms.

Note 3. With RCX221 / 222, the exclusive input of the parallel I/O cannot be used. (The interlock input terminal is located on the SAFETY connector side.)

Note 4. These values apply when a thick cable is used. The distance is less when a fine cable is used or when thick and fine cables are mixed in use.

## PROFIBUS Basic specifications for network modules

Item	Network modules PROFIBUS
Applicable controllers	RCX221 / RCX222 / RCX240 / RCX240S / RCX340
Communication profile	PROFIBUS-DP slave
Number of occupied nodes	1 node
Setting of station address	1 to 99 (set using Rotary switch on board)
Setting of communication speed	9.6Kbps, 19.2Kbps, 93.75Kbps, 187.5Kbps, 500Kbps, 1.5Mbps, 3Mbps, 6Mbps, 12Mbps (automatic recognition)
PROFIBUS I/O <small>Note1</small>	General input 96 points, General output 96 points, Dedicated input 16 points, Dedicated output 16 points
Parallel external I/O <small>Note2</small>	The master module and up to four ports can be controlled regardless of the robot program by using the pseudoserialization function.
Overall length	100m/3M-6M-12Mbps, 200m/1.5Mbps, 400m/500Kbps, 1000m/187.5Kbps, 1200m/9.6K-19.2K-93.75Kbps
Monitor LED	RUN, ERR, SD, RD, DATA-EX

Note 1. The shortest I/O update interval of the controller is 10ms but the actual I/O update time varies depending on the update time with the master station.

Note 2. With RCX221 / 222, the exclusive input of the parallel I/O cannot be used. (The interlock input terminal is located on the SAFETY connector side.)

## Ethernet Basic specifications for network modules

Item	Network modules Ethernet
Applicable controllers	RCX221 / RCX222 / RCX240 / RCX240S / RCX340
Network specification	As specified for Ethernet (IEEE802.3)
Connector specification	RJ-45 connector (8-pole modular connector) 1 port
Baud rate	10Mbps (10BASE-T)
Communication mode	Half Duplex (Half-duplex)
Network protocol	Application layer: TELNET / Transport layer: TCP / IP Network layer: IP, ICMP, ARP / Data link layer: CSMA/CD / Physical layer: 10BASE-T
Number of simultaneous log inputs	1
Setting of IP address, etc.	Set from RPB
Monitor LED	Run, Collision, Link, Transmit, Receive

Option details

Field network system with minimal wiring

NETWORK

RCX240/RCX240S **P.532** RCX340 **P.542**

**EtherNet/IP™** Basic specifications for network modules

Item	Network modules EtherNet/IP™		
Controller model	RCX240 / RCX240S / RCX340		
Software version	HOST : Ver.10.64 or higher VIP+ : Ver.2.5.0 or higher		
Network specifications	Conforms to Ethernet (IEEE 802.3).		
Applicable EtherNet/IP™ specifications	Volume 1 : Common Industrial protocol (CIP™) Edition 3.8 Volume 2 : EtherNet/IP™ Adaptation Edition 1.9		
Device type	Generic Device (Device No. 43)		
Data size	48 bytes each for input/output		
Transmission speed	10 Mbps/100 Mbps		
Connector specifications	RJ-45 connector (8-pole modular connector) 1 port		
Cable specifications	Refer to "4.1. LAN cable" in Chapter 2 of this user's manual.		
Max. cable length	100 m		
EtherNet/IP™ input/output points <sup>Note</sup>	Input (48 bytes in total)	byte 0-3	Dedicated word input : 2 words
		byte 4-31	General purpose word input : 14 words
	Output (48 bytes in total)	byte 0-3	Dedicated bit input : 16 points
		byte 4-31	General-purpose bit input : 96 points
	Output (48 bytes in total)	byte 0-3	Dedicated word output : 2 words
		byte 4-31	General-purpose word output : 14 words
		byte 32-33	Dedicated bit output : 16 points
		byte 34-47	General-purpose bit output : 96 points
Parallel external input	Regardless of the robot program, the master module and up to four ports can be controlled using the emulated serialization function.		
Settings, such as IP address	The settings are made with the programming box (RPB) or VIP+ (via a COM port or telnet).		
Monitor LEDs	Activity, Network Status, Link, Module Status		
CPU BOARD ASSY	KX0-M4210-2XX (Refer to "3. Installing into the robot controller" in Chapter 1 of this user's manual.)		

Note. Controller's I/O update intervals are 10 ms at shortest, but actual I/O update intervals may vary depending on the update time for the master station.

Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

IV/V/VZ Electric gripper

Option

## NETWORK

## RCX340

P.542



## Basic specifications for network modules

Item	Network modules PROFINET	
Applicable controllers	RCX340	
Supported software versions	RCX340 : V1.21 or later PBX/PBX-E : V1.08 or later RCX-Studio : V1.0.1 or later	
Network specification conformance	PROFINET IO V2.2	
Conformance class	Conformance Class B / IO Device	
Vendor Name / Vendor_ID	YAMAHA MOTOR CO.,LTD. / 0x02D5	
Station Type / Device_ID	YAMAHA RCX3 PROFINET / 0x0001	
Product revision	1.00	
GSD file name	GSDML-V2.3-YMC-RCX3-20150203.xml	
Transmission speed	100Mbps (Auto-negotiation)	
Connector specifications	RJ-45 connector (8-pole modular connector) 2 ports	
Conforming cable specifications	CAT 5e or higher STP cable (double shield)	
Max. cable length	100m	
Monitor LEDs	Module Status(MS), Network Status(NS), Link/Activity:Port1-2	
Input/output data size	Input : 48bytes	Dedicated word input 2 words (4 bytes)
		General-purpose word input 14 words (28 bytes)
		Dedicated bit input 16 bits (2 bytes)
		General-purpose bit input 96 bits (12 bytes)
		Reserved area 2 bytes
	Output : 48bytes	Dedicated word output 2 words (4 bytes)
		General-purpose word output 14 words (28 bytes)
		Dedicated bit output 16 bits (2 bytes)
		General-purpose bit output 96 bits (12 bytes)
		Reserved area 2 bytes

Articulated robots  
YALinear conveyor  
modules  
LCM100Compact  
single-axis robots  
TRANSEVOSingle-axis robots  
FLIP-XLinear motor  
single-axis robots  
PHASERCartesian  
robots  
XY-XSCARA  
robots  
YK-XPick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positionerPulse string  
driverRobot  
controllerI/V/I/V2  
Electric  
grripper

Option

# iVY System

Applicable controllers ▶ RCX240/RCX240S


● Robot with image processing functions

“SEARCH and TAKE” “CHECK POSITION and ASSEMBLE”  
**YAMAHA offers a whole new production line concept that eliminates time-consuming teaching and positioning tasks with “iVY-system”.**



Main functions ▶ P.72

■ Ordering method



Note. For details on the various selection items, refer to P.533

■ Basic specifications

● iVY board

Item	iVY board	
Basic specifications	Applicable controllers	RCX240 / RCX240S
	Pixels	640 (H) × 480 (V) (300,000 pixels, VGA)
	Settable part types	40 part types
	Connectable cameras	Maximum 2 units Note. Note. If connecting 2 units, then must be the same model
	Camera types	Double speed compatible analog camera
	Memory	128MB SDRAM, 256MB miniSD card
	External I/F	Ethernet (100BASE-TX)
Search method	Edge search (Correlative edge filter, Sobel filter)	
Image input	Trigger	S/W trigger, H/W trigger, Camera internal synch
	External trigger input	2 points
Functions	Search function	Position offset, Auto registry of point data
	ID recognition (usage planned)	QR-Code [Model2], DataMatrix
Setup support functions	Calibration, image save function, model registration <sup>Note</sup> , fiducial mark registration <sup>Note</sup> , monitor function <sup>Note</sup>	

Note. Requires Windows PC.

● Lighting control board (option)

Item	Lighting control board (option)	
Basic specifications	Applicable controllers	RCX240 / RCX240S
	Number of lighting connected units	Up to 2 units
	Light adjusting system	PWM control (0 to 100%) (Cycle 60kHz) Stroboscopic light (10 to 33000us)
	Trigger	S/W trigger, H/W trigger
	External trigger input	2 points
	Lighting power input	12VDC or 24VDC (Supplied from outside commonly to 2 channels)
	Lighting output	When DC12V is supplied: Less than 30W with 2 channels totaled When DC24V is supplied: Less than 60W with 2 channels totaled


● Tracking board (Options)

Item	Tracking board (option)		
Basic specifications	Applicable controllers	RCX240 / RCX240S	
	Lighting control section	Light adjusting system	Up to 2 units
		Light adjusting system	PWM control (0 to 100%) (Cycle 60kHz) Stroboscopic light (10 to 33000us)
		Trigger	S/W trigger, H/W trigger
		External trigger input	2 points
	Pulse input section	Lighting power input	12VDC or 24VDC (Supplied from outside commonly to 2 channels)
		Lighting output	When DC12V is supplied: Less than 30W with 2 channels totaled When DC24V is supplied: Less than 60W with 2 channels totaled
		Number of encoder connected units	Up to 2 units
		Encoder power source	DC5V (Less than 500mA with 2 channels totaled) (Supplied from controller)
		Applicable encoder	Line driver equivalent to 26LS31 / 26C31 (Conforming to RS-422)
Input phase		A, $\bar{A}$ , B, $\bar{B}$ , Z, $\bar{Z}$	
Maximum response frequency	2MHz		
Counter / Step-up multiplication	0 to 65535 / Double, quadruple		
Other	Provided with broken wire detect function		

Note. The tracking board is required when using the tracking function.


Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
iVY  
Option

**System configuration illustration**



**Dimensional outlines CCD camera**

**CCD camera dimensions  
 (Model No. : KX0-M7913-00)**



Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver


Robot controller

ivY


Option

## Lenses


- **8mm lens [ML-0813]**  
(Model No. : KM7-M7214-60)




- **12mm lens [ML-1214]**  
(Model No. : KM7-M7214-40)



- **16mm lens [ML-1614]**  
(Model No. : KM7-M7214-30)



- **25mm lens [ML-2514]**  
(Model No. : KM7-M7214-20)



## Standard lens angle-of-view table

	Focal length (mm)	Aperture value (F No.)	Angle-of-view (degrees)		Closest approach distance (m)
			Vertical	Horizontal	
8mm lens [ML-0813]	8	F1.3-CLOSE	45.0	57.8	0.2
12mm lens [ML-1214]	12	F1.4-CLOSE	21.9	29.0	0.3
16mm lens [ML-1614]	16	F1.4-CLOSE	23.0	30.4	0.4
25mm lens [ML-2514]	25	F1.4-CLOSE	21.6	28.5	0.5

Note. Field-of-view table for our standard lenses. As the field-of-view widens, distortion on image edges may increase.

## Viewing angle, WD, and magnification when using close-up ring

Close-up ring (mm)	8mm lens [ML-0813]				12mm lens [ML-1214]			
	Viewing angle (mm×mm)		WD (mm)	Magnification	Viewing angle (mm×mm)		WD (mm)	Magnification
	Vertical	Horizontal			Vertical	Horizontal		
None	72	96	148	0.05	77	103	248	0.05
0.5	32	43	59	0.11	41	55	125	0.09
	57	77	115	0.06	89	119	289	0.04
1	21	27	34	0.18	28	38	80	0.13
	29	38	52	0.13	45	59	136	0.08
1.5	26	34	22	0.24	21	29	57	0.17
	19	26	31	0.19	30	40	85	0.12
2	-	-	-	-	17	23	42	0.21
	-	-	-	-	22	30	59	0.16
5	-	-	-	-	-	-	-	-
	-	-	-	-	-	-	-	-

Close-up ring (mm)	16mm lens [ML-1614]				25mm lens [ML-2514]			
	Viewing angle (mm×mm)		WD (mm)	Magnification	Viewing angle (mm×mm)		WD (mm)	Magnification
	Vertical	Horizontal			Vertical	Horizontal		
None	82	109	358	0.04	65	87	458	0.06
0.5	48	64	206	0.07	48	64	338	0.08
	117	156	515	0.03	181	242	1270	0.02
1	34	45	143	0.11	38	50	269	0.10
	58	78	252	0.06	91	121	637	0.12
1.5	26	35	108	0.14	31	42	223	0.12
	39	52	164	0.09	60	81	425	0.06
2	22	29	86	0.17	27	36	191	0.13
	29	39	120	0.12	45	60	320	0.08
5	10	14	35	0.35	14	19	103	0.25
	12	16	42	0.31	18	24	130	0.20

### Notes

- This table shows viewing angles when using the standard lens and close-up ring. (If no close-up ring this is closest approach.)
- If not using a close-up ring, then a WD smaller than the value in this table cannot be used.
- If using a close-up ring, then only a WD close to this value can be used.
- The values in this table are at most only a reference and do not signify an absolute index.
- To find viewing angle and WD other than for our standard lens, visit our website at: <http://www.moritex.co.jp/products/>.

# Accessories and part options

## iVY System

### Standard accessories



Model	Without power supply harness	KX0-M4402-10
	With power supply harness	KX0-M4402-00

Note. If newly adding an iVY, choose the model with harness.

- **iVY board**

- **iVY board accessories**

Name	Single unit model	Set Model
Camera trigger input cable connector	KX0-M657L-00	KX0-M657K-00
Custom tool	KX0-M657M-00	

- **Support software for PC**  
**iVY Studio**

iVY Studio is support software for the iVY system that allows registering part types and reference marks as well as monitoring the work search status during automatic robot operation by connecting to the robot controller.



- **Environment**

Software model	KX0-M4988-00
OS	Microsoft Windows 2000 / XP / Vista Note. The 64 bit version is not subject to the operation warranty.
CPU	Exceeding the environment recommended by the OS being used
Memory	64MB or more (Recommend)
Hard disk	Vacant capacity of more than 40MB in the installation destination drive Note. Besides the above, also requires memory space for storing images and data.
Display	800 × 600 dots or more, 32768 colors (16bit High Color) or more (recommended)
Network	TCP/IP Ethernet port × 1

**Options**

● **Lighting control board**

Model	KX0-M4400-G0
-------	--------------

● **Required options for the lighting control board**

Name	Single unit model	Set Model
Lighting power cable connector	KX0-M657L-10	KX0-M657K-10
Wiring lever	KX0-M657M-10	
Lighting input trigger cable connector	KX0-M657L-00	KX0-M657K-00
Custom tool	KX0-M657M-00	

● **Tracking board**

Model	KX0-M4400-E0
-------	--------------

● **Required options for the tracking board**

Name	Single unit model	Set Model
Lighting power cable connector	KX0-M657L-10	KX0-M657K-10
Wiring lever	KX0-M657M-10	
Lighting input trigger cable connector	KX0-M657L-00	KX0-M657K-00
Custom tool	KX0-M657M-00	
AB phase input cable connector	KX0-M657L-20	KX0-M657K-20
AB phase input cable connector case	KX0-M657M-20	

● **Camera cable**

Cable for connecting the camera to the iVY board.



Model	3.5m	KX0-M66F3-00
	6m	KX0-M66F3-10
	9.5m (relay 3.5m+6m)	KX0-M66F0-20
	Relay cable 3.5m	KX0-M66F4-00
	7m (relay 1m+6m)	KX0-M66F0-30
	Relay cable 1m	KX0-M66F4-10

Note. When installing a camera cable in a moving section, use a relay cable so that it can be easily replaced if needed.

● **CCD camera**



Model	KX0-M7913-00
-------	--------------

● **Lens**



Model	8mm	KM7-M7214-60 (ML-0813)
	12mm	KM7-M7214-40 (ML-1214)
	16mm	KM7-M7214-30 (ML-1614)
	25mm	KM7-M7214-20 (ML-2514)

● **Close-up ring**



Model	0.5mm	KX0-M7215-00
	1.0mm	KX0-M7215-10
	2.0mm	KX0-M7215-20
	5.0mm	KX0-M7215-30

● **LAN cable with shield cloth (5m)**



Model	KX0-M55G0-00
-------	--------------

● **Tracking encoder cable (10m)**



Model	KX0-M66AF-00
-------	--------------


# iVY2 System

Applicable controllers ▶ RCX340

● Robot with image processing functions

Integrated Robot Vision System with “plug-and-play” simplicity.

Basic specifications have been dramatically enhanced while retaining the current iVY system’s ease of use.



Main functions ▶ P.78

■ Ordering method

<b>RCX340</b>					
Controller	No. of controllable axes	Safety standards	Controller option A to D (OP.A to D) <small>TR: Tracking</small>	Controller option E (OP.E) <small>No entry: Non-selection VY: iVY2 without light VL: iVY2 with light</small>	Absolute battery

Note. For details on the various selection items, refer to P.543


■ Basic specifications

● Robot vision basic specifications

Item		iVY2 unit
Basic specifications	Applicable controllers	RCX340
	Number of screen pixels	648(H) × 494(V) (300,000 pixels, VGA) 1280(H) × 966(V) (1,300,000 pixels, SXGA) 1624(H) × 1236(V) (2,000,000 pixels, UXGA)
	Model setting capacity	254 models
	Number of connectable cameras	Max. 2 cameras
	Connectable camera	GigE camera (VGA, SXGA, UXGA) PoE: IEEE802.3af 1 ch up to 7W
	External interface	Ethernet (1000BASE-T) Note. For setting and monitor operations
	External monitor output	DVI-I Note. Also usable with an analog monitor by using a conversion adaptor. Monitor resolution: 1024 × 768
	Power supply	DC24V +/-10% 1.5A Max.
	Dimensions	W45 × H195 × D130 (iVY2 unit only)
	Weight	0.8kg (iVY2 unit only, when the lighting control board option is selected)
Search method		Edge search (correlated edge filter, Sobel filter)
Image capturing	Trigger mode	S/W trigger, H/W trigger
	External trigger input	2 points
Function		Position detection, automatic point data generation
Camera installation position		Fixed to the fixed camera (up, down) or robot (Y-axis, Z-axis). Perpendicular to the workpiece to be captured.
Setting support function		Calibration, image save function, model registration <sup>Note</sup> , fiducial mark registration <sup>Note</sup> , monitor function <sup>Note</sup> Note. iVY2 Studio function (requires a Windows PC)
Lighting control options	Number of connectable lighting units	Max. 2 lighting units
	Modulated light format	PWM modulated light control (0 to 100%), PWM frequency switchable 62.5 kHz/125 kHz
		Continuous light, strobe light (follows camera exposure)
	Lighting power input	12VDC or 24VDC (external supply shared by both channels)
Lighting output	For 12VDC supply: Total of less than 40W for both channels. For 24VDC supply: Total of less than 80W for both channels.	




## System configuration illustration



## Tracking board basic Specifications

Item		Tracking board
Basic specifications	Applicable controllers	RCX340
	Number of connected encoders	Up to 2 units.
	Encoder power supply	5VDC (2 counters total 500 mA or less) (Supplied from controller)
	Applicable encoder	26LS31/26C31 or equivalent line driver (RS-422 compliance).
	Input phase	A, $\bar{A}$ , B, $\bar{B}$ , Z, $\bar{Z}$
	Max. response frequency	2MHz or less
	Counter	0 to 65535
	Multiplier	4x
	Other	With disconnection detection function

## Dimensional outlines



Articulated robots  
YA

Linear CONVEYOR modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver


Robot controller

iVY2

Option

## Dimensional outlines


### ● CCD camera



## Lenses


### ● 8mm lens

(Model No. : KCX-M7214-00)




### ● 8mm lens (megapixel support)

(Model No. : KCX-M7214-40)




### ● 12mm lens

(Model No. : KCX-M7214-10)




### ● 12mm lens (megapixel support)

(Model No. : KCX-M7214-50)




### ● 16mm lens

(Model No. : KCX-M7214-20)




### ● 16mm lens (megapixel support)

(Model No. : KCX-M7214-60)




### ● 25mm lens

(Model No. : KCX-M7214-30)



### ● 25mm lens (megapixel support)

(Model No. : KCX-M7214-70)





## Accessories and part options

### iVY2 System

#### Standard accessories

##### ● iVY2 unit

The iVY2 unit adds robot vision to the RCX340 robot controller.



Model	No lighting	KCX-M4400-V0
	With lighting	KCX-M4400-L0

##### ● iVY2 unit accessories

Name	Individual model
Camera trigger input cable connector	KX0-M657K-00
24V power supply connector	KCF-M5382-00

##### ● Support software for PC iVY2 Studio

iVY2 Studio is support software for the iVY2 system that allows registering part types and reference marks as well as monitoring the work search status during automatic robot operation by connecting to the robot controller.



##### ● Environment

Software model	KCX-M4988-00
OS	Microsoft Windows XP / Vista (32bit/64bit) / 7 (32bit/64bit) / 8, 8.1 (32bit/64bit)
CPU	Processor that meets or exceeds the suggested requirements for the OS being used.
Memory	Suggested amount of memory or more for the OS being used.
Hard disk capacity	16MB of available space required on installation drive.
Display	800 x 600 dot, or higher, 32768 colors (16bit High Color) or higher (recommended)
Communication Port	Ethernet Port of TCP/IP

Note. Microsoft, Windows XP, Windows Vista, Windows 7, Windows 8, 8.1 are registered trademarks of the Microsoft Corporation, USA.

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XY-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot positioner

Pulse string driver

Robot controller

iVY2

Option

## Options

### ● CCD camera



Model	300,000 pixel	648×494 (VGA)	KCX-M6541-00
	1,300,000 pixel	1280×966 (SXGA)	KCX-M6541-10
	2,000,000 pixel	1624×1236 (UXGA)	KCX-M6541-20

### ● Lens



Model	8mm	KCX-M7214-00
	12mm	KCX-M7214-10
	16mm	KCX-M7214-20
	25mm	KCX-M7214-30
	8mm (megapixel support)	KCX-M7214-40
	12mm (megapixel support)	KCX-M7214-50
	16mm (megapixel support)	KCX-M7214-60
	25mm (megapixel support)	KCX-M7214-70

### ● Close-up ring



Model	0.5mm	KX0-M7215-00
	1.0mm	KX0-M7215-10
	2.0mm	KX0-M7215-20
	5.0mm	KX0-M7215-30

### ● Lighting control board

This board adds lighting control functionality to the iVY2 system. (Installed in the iVY2 unit when shipped)

Model	KCX-M4403-L0
-------	--------------

#### ● Lighting control board accessories

Name	Model
Lighting power cable connector	KX0-M657K-10

### ● Tracking board

This board adds conveyor tracking functionality to the RCX340 controller.

Model	KCX-M4400-T0
-------	--------------

#### ● Tracking board accessories

Name	Single unit model
AB phase input cable connector	KX0-M657K-20

#### ● Recommended option cable <sup>Note</sup>


Name	Single unit model
AB phase input cable (10 m, only for counter 1)	KX0-M66AF-00

Note. Not included.

We can provide an option that is pre-wired to the AB phase input cable connector.

### ● Camera cable

Cable for connecting the camera to the iVY2 board.



Model	5m	KCX-M66F0-00
	10m	KCX-M66F0-10
	15m	KCX-M66F0-20

### ● LAN cable with shield cloth (5 m)




Model	KX0-M55G0-00
-------	--------------

Articulated robots  
VA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
iVY2  
Option

# YRG Series

Simple gripper operation and control via the YAMAHA robot language. Just install a gripper control board into the controller and set the electrical gripper as an additional robot axis.

Main functions ▶ P.86




## Structure

- Single cam structure
- Double cam structure
- Ball screw structure
- Compact ball guide structure



Unique cam structure is simple and compact. The fingers work due to external force since no self-locking is used.



Unique double cam structure with gear. Simple design gives high gripping power yet body is compact.





Belt-driven ground ball screw delivers a long stroke with high efficiency and high precision.



Use of special cams provides light weight and compactness. Ideal for grasping and moving a round workpiece made of glass or similar material.

## System configuration illustration



Compact single cam type

# YRG-2005SS



## Basic specifications


Model name		YRG-2005SS
Model number		KCF-M2010-A0
Holding power	Max. continuous rating (N)	5
	Min. setting (% (N))	30 (1.5)
	Resolution (% (N))	1 (0.05)
Open/close stroke (mm)		3.2
Speed	Max. rating (mm/sec)	100
	Min. setting (% (mm/sec))	20 (20)
	Resolution (% (mm/sec))	1 (1)
	Holding speed (Max.) (%)	50
Repetitive positioning accuracy (mm)		+/-0.02
Guide mechanism		Linear guide
Max. holding weight <sup>Note 1</sup> (kg)		0.05
Weight (g)		90

- Holding power control: 30 to 100% (1% steps)
- Speed control: 20 to 100% (1% steps)
- Acceleration control: 1 to 100% (1% steps)
- Multipoint position control: 10,000 max.

Note. Design the finger as short and lightweight as possible.  
 Note. Set the parameters and holding power (%) of the holding movement command so that any excessive shock is not applied to the finger during operation.  
 Note. When installing or uninstalling the finger, tighten the bolts while the finger is being held securely so that any excessive force or shock is not applied to the guide block.  
 Note. Workpiece weight that is able to be held may greatly vary depending on the material, shape, and/or holding surface conditions of the finger.

Note 1. Design the weight of a workpiece to be held so that it is approximately 1/10 to 1/20 of the holding power. (Consider further allowance when moving and swinging the gripper that keeps holding a workpiece.)

## Gripping power vs. gripping power setting (%)




- Graph shows a general guide to gripping power versus gripping power setting (%). Variations will appear in the actual gripping power.


## Allowable load and load moment

		YRG-2005SS		
Guide	Allowable load	F	N	12
	Allowable pitching moment	Mp	N•m	0.04
	Allowable yawing moment	My	N•m	0.04
	Allowable rolling moment	Mr	N•m	0.08
Finger	Max. weight (1 pair)		g	10
	Max. holding position	L	mm	20
	Max. overhang	H	mm	20

- Mount the finger so that the allowable load and load moment of the guide do not exceed the values stated in the table above.
- Make the adjustment so that the finger weight, holding length (L) from the installation surface to the holding point, and overhang (H) do not exceed the values stated in the table above.
- Please contact your YAMAHA sales dealer for further information on combination of L and H.



### YRG-2005SS



Note. Avoid extreme winding of the cable and fix the cable securely so that it does not move. Take appropriate measures so that any excessive force is not applied to the root of the cable.

- Articulated robots  
YA
- Linear conveyer modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER
- INFORMATION
- Robot positioner
- Pulse string driver
- Robot controller
- Electric gripper
- Option

# YRG Series

Single cam type

# YRG-2010S/2815S/4225S



## Basic specifications

Model name	YRG-2010S	YRG-2815S	YRG-4225S	
Model number	KCF-M2011-A0	KCF-M2011-B0	KCF-M2011-C0	
Holding power	Max. continuous rating (N)	6	22	40
	Min. setting (% (N))	30 (1.8)	30 (6.6)	30 (12)
	Resolution (% (N))	1 (0.06)	1 (0.22)	1 (0.4)
Open/close stroke (mm)		7.6	14.3	23.5
	Max. rating (mm/sec)	100		
	Min. setting (% (mm/sec))	20 (20)		
	Resolution (% (mm/sec))	1 (1)		
Speed		50		
	Holding speed (Max.) (%)	50		
Repetitive positioning accuracy (mm)	+/-0.02			
Guide mechanism	Linear guide			
Max. holding weight <sup>Note 1</sup> (kg)	0.06	0.22	0.4	
Weight (g)	160	300	580	

• Holding power control: 30 to 100% (1% steps) • Speed control: 20 to 100% (1% steps)  
 • Acceleration control : 1 to 100% (1% steps) • Multipoint position control: 10,000 max.

Note. Design the finger as short and lightweight as possible.


Note. Set the parameters and holding power (%) of the holding movement command so that any excessive shock is not applied to the finger during operation.

Note. When installing or uninstalling the finger, tighten the bolts while the finger is being held securely so that any excessive force or shock is not applied to the guide block.

Note. Workpiece weight that is able to be held may greatly vary depending on the material, shape, and/or holding surface conditions of the finger.

Note 1. Design the weight of a workpiece to be held so that it is approximately 1/10 to 1/20 of the holding power. (Consider further allowance when moving and swinging the gripper that keeps holding a workpiece.)

## Gripping power vs. gripping power setting (%)



• Graph shows a general guide to gripping power versus gripping power setting (%). Variations will appear in the actual gripping power.


## Allowable load and load moment

			YRG-2010S	YRG-2815S	YRG-4225S
Guide	Allowable load	F N	450	350	600
	Allowable pitching moment	Mp N•m	0.7	0.5	1.1
	Allowable yawing moment	My N•m	0.8	0.6	1.3
	Allowable rolling moment	Mr N•m	2.3	2.8	8.6
Finger	Max. weight (1 pair)	g	15	30	50
	Max. holding position	L mm	20	20	25
	Max. overhang	H mm	20	25	30


• Mount the finger so that the allowable load and load moment of the guide do not exceed the values stated in the table above.

• Make the adjustment so that the finger weight, holding length (L) from the installation surface to the holding point, and overhang (H) do not exceed the values stated in the table above.

• Please contact your YAMAHA sales dealer for further information on combination of L and H.



## YRG-2010S/2815S/4225S



	A	AA	AB	B	CB	D	E	ED	F	G	H	J	L
YRG-2010S	17	17	17	12	27	2	9 <sup>0</sup> <sub>-0.05</sub>	20	71	8.4 to 16	φ3 <sup>0</sup> <sub>-0.01</sub>	5	3.5
YRG-2815S	24	24	14	15	38	2	14 <sup>0</sup> <sub>-0.05</sub>	25	78	9.6 to 23.9	φ3 <sup>0</sup> <sub>-0.01</sub>	6	4.3
YRG-4225S	36	25	13	20	50	3	24 <sup>0</sup> <sub>-0.05</sub>	40	86	12 to 35.5	φ4 <sup>0</sup> <sub>-0.012</sub>	6.5	5.5

	M	N	P	Q	R	RA	SA	SB	SC	TE	U	V	VA	VB	W	Z
YRG-2010S	12.1	M3	5	24	34	165+/-10	13	17	8.3	5	M3	5	6	6	61	2.2
YRG-2815S	15	M4	5	32	46	140+/-10	16	21	9.3	6	M4	6	8	8	69	2
YRG-4225S	17.4	M5	8	46	60	235+/-10	18	24	10.8	7.5	M5	7.5	8	10	72	3



Double cam type

# YRG-2005W/2810W/4220W



## Basic specifications


Model name	YRG-2005W	YRG-2810W	YRG-4220W	
Model number	KCF-M2012-A0	KCF-M2012-B0	KCF-M2012-C0	
Holding power	Max. continuous rating (N)	50	150	250
	Min. setting (% (N))	30 (15)	30 (45)	30 (75)
	Resolution (% (N))	1 (0.5)	1 (1.5)	1 (2.5)
Open/close stroke (mm)	5	10	19.3	
Speed	Max. rating (mm/sec)	60	60	45
	Min. setting (% (mm/sec))	20 (12)	20 (12)	20 (9)
	Resolution (% (mm/sec))	1 (0.6)	1 (0.7)	1 (0.45)
	Holding speed (Max.) (%)	50		
Repetitive positioning accuracy (mm)	±0.03			
Guide mechanism	Linear guide			
Max. holding weight <sup>Note 1</sup> (kg)	0.5	1.5	2.5	
Weight (g)	200	350	800	

- Holding power control: 30 to 100% (1% steps)
- Speed control: 20 to 100% (1% steps)
- Acceleration control: 1 to 100% (1% steps)
- Multipoint position control: 10,000 max.

Note. Design the finger as short and lightweight as possible.  
 Note. Set the parameters and holding power (%) of the holding movement command so that any excessive shock is not applied to the finger during operation.  
 Note. When installing or uninstalling the finger, tighten the bolts while the finger is being held securely so that any excessive force or shock is not applied to the guide block.  
 Note. Workpiece weight that is able to be held may greatly vary depending on the material, shape, and/or holding surface conditions of the finger.

Note 1. Design the weight of a workpiece to be held so that it is approximately 1/10 to 1/20 of the holding power. (Consider further allowance when moving and swinging the gripper that keeps holding a workpiece.)

## Gripping power vs. gripping power setting (%)




• Graph shows a general guide to gripping power versus gripping power setting (%). Variations will appear in the actual gripping power.


## Allowable load and load moment

				YRG-2005W	YRG-2810W	YRG-4220W
Guide	Allowable load	F	N	1000	1000	2000
	Allowable pitching moment	Mp	N·m	6.7	8.1	20.1
	Allowable yawing moment	My	N·m	4	4.8	12
	Allowable rolling moment	Mr	N·m	5.1	7.8	25.9
Finger	Max. weight (1 pair)		g	40	80	200
	Max. holding position	L	mm	30	30	50
	Max. overhang	H	mm	20	20	30

- Mount the finger so that the allowable load and load moment of the guide do not exceed the values stated in the table above.
- Make the adjustment so that the finger weight, holding length (L) from the installation surface to the holding point, and overhang (H) do not exceed the values stated in the table above.
- Please contact your YAMAHA sales dealer for further information on combination of L and H.



## YRG-2005W/2810W/4220W



	A	AA	AB	B	CB	D	E	ED	F	G	H	J	K	L
YRG-2005W	17	17	17	12	27	2	9 <sup>0</sup> / <sub>-0.05</sub>	20	74	10.6 to 15.6	φ4 <sup>0</sup> / <sub>-0.012</sub>	6	8	4.6
YRG-2810W	24	24	14	15	38	2	14 <sup>0</sup> / <sub>-0.05</sub>	25	80	12.6 to 22.6	φ5 <sup>0</sup> / <sub>-0.012</sub>	7	10	5.65
YRG-4220W	36	25	13	20	50	3	24 <sup>0</sup> / <sub>-0.05</sub>	40	90	17.0 to 36.3	φ6 <sup>0</sup> / <sub>-0.012</sub>	8	15	7.5

	M	N	P	Q	R	RA	SA	SB	SC	TE	U	V	VA	VB	W	X	X1	Z
YRG-2005W	22.5	M3	5	24	34	165±/10	13	17	8.3	5	M3	5	6	6	64	52	54	2.2
YRG-2810W	27.5	M4	5	32	46	140±/10	16	21	9.3	6	M4	6	8	8	71	67	61	2
YRG-4220W	37	M5	8	46	60	235±/10	18	24	10.8	7.5	M5	7.5	8	10	76	96	63	3

Articulated robots  
YA  
Linear CONVEYOR modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
Electric gripper  
Option

# YRG Series

Screw type straight style

# YRG-2020FS/2840FS



## Basic specifications

Model name	YRG-2020FS	YRG-2840FS
Model number	KCF-M2013-A0	KCF-M2013-B0
Holding power	Max. continuous rating (N)	50
	Min. setting (% (N))	30 (15)
	Resolution (% (N))	1 (0.5)
Speed	Open/close stroke (mm)	19
	Max. rating (mm/sec)	50
	Min. setting (% (mm/sec))	20 (10)
	Resolution (% (mm/sec))	1 (0.5)
	Holding speed (Max.) (%)	50
Repetitive positioning accuracy (mm)	+/-0.01	+/-0.01
Guide mechanism	Linear guide	
Max. holding weight <sup>Note 1</sup> (kg)	0.5	1.5
Weight (g)	420	880


- Holding power control : 30 to 100% (1% steps)
- Speed control : 20 to 100% (1% steps)
- Acceleration control : 1 to 100% (1% steps)
- Multipoint position control : 10,000 max.

Note. Design the finger as short and lightweight as possible. Set the parameters and holding power (%) of the holding movement command so that any excessive shock is not applied to the finger during operation.

Note. When installing or uninstalling the finger, tighten the bolts while the finger is being held securely so that any excessive force or shock is not applied to the guide block. Workpiece weight that is able to be held may greatly vary depending on the material, shape, and/or holding surface conditions of the finger.

Note 1. Design the weight of a workpiece to be held so that it is approximately 1/10 to 1/20 of the holding power. (Consider further allowance when moving and swinging the gripper that keeps holding a workpiece.)

## Gripping power vs. gripping power setting (%)




- Graph shows a general guide to gripping power versus gripping power setting (%). Variations will appear in the actual gripping power.


## Allowable load and load moment

			YRG-2020FS	YRG-2840FS
Guide	Allowable load	F N	1000	1300
	Allowable pitching moment	Mp N•m	3.5	5
	Allowable yawing moment	My N•m	4.2	6
	Allowable rolling moment	Mr N•m	7.3	12.7
Finger	Max. weight (1 pair)	g	40	80
	Max. holding position	L mm	30	30
	Max. overhang	H mm	20	20

- Mount the finger so that the allowable load and load moment of the guide do not exceed the values stated in the table above.
- Make the adjustment so that the finger weight, holding length (L) from the installation surface to the holding point, and overhang (H) do not exceed the values stated in the table above.
- Please contact your YAMAHA sales dealer for further information on combination of L and H.



## YRG-2020FS/2840FS



Note. Avoid extreme winding of the cable and fix the cable securely so that it does not move. Take appropriate measures so that any excessive force is not applied to the root of the cable.

	A	B	BD	C	D	E	ED	F	G	H	J	K	L	M	N
YRG-2020FS	22	12	15	12	2	14 <sup>0</sup> <sub>-0.05</sub>	25	69	10.5 to 29.5	φ3 <sup>0</sup> <sub>-0.01</sub>	6	12	4.5	27.5	M3
YRG-2840FS	30	15	20	16	2	18 <sup>0</sup> <sub>-0.05</sub>	30	84	13 to 51	φ4 <sup>0</sup> <sub>-0.012</sub>	8	14	5.5	34.5	M4

	P	Q	R	RA	S	SA	SB	T	TA	TB	TC	TD	U	V	W	WA	Y	Z
YRG-2020FS	5	30	76	175+/-10	27	27	4	9	24	24	30	12.5	M4	6	60	9	38	2
YRG-2840FS	7.5	40	110	135+/-10	40	40	5	12	28	28	36	14	M5	7.5	72	12	55	3

Screw type "T" style

# YRG-2020FT/2840FT



## Basic specifications

Model name	YRG-2020FT	YRG-2840FT
Model number	KCF-M2013-A0	KCF-M2013-B0
Holding power	Max. continuous rating (N)	50
	Min. setting (% (N))	30 (15)
	Resolution (% (N))	1 (0.5)
Open/close stroke (mm)		19
		38
Speed	Max. rating (mm/sec)	50
	Min. setting (% (mm/sec))	20 (10)
	Resolution (% (mm/sec))	1 (0.5)
	Holding speed (Max.) (%)	50
Repetitive positioning accuracy (mm)	+/-0.01	+/-0.01
Guide mechanism	Linear guide	
Max. holding weight <sup>Note 1</sup> (kg)	0.5	1.5
Weight (g)	420	890

• Holding power control: 30 to 100% (1% steps) • Speed control: 20 to 100% (1% steps)  
 • Acceleration control : 1 to 100% (1% steps) • Multipoint position control: 10,000 max.

Note. Design the finger as short and lightweight as possible.  
 Note. Set the parameters and holding power (%) of the holding movement command so that any excessive shock is not applied to the finger during operation.  
 Note. When installing or uninstalling the finger, tighten the bolts while the finger is being held securely so that any excessive force or shock is not applied to the guide block.  
 Note. Workpiece weight that is able to be held may greatly vary depending on the material, shape, and/or holding surface conditions of the finger.


Note 1. Design the weight of a workpiece to be held so that it is approximately 1/10 to 1/20 of the holding power. (Consider further allowance when moving and swinging the gripper that keeps holding a workpiece.)

## Allowable load and load moment


Guide		YRG-2020FT		YRG-2840FT	
		F	N		
Guide	Allowable load			1000	1300
	Allowable pitching moment	Mp	N·m	3.5	5
	Allowable yawing moment	My	N·m	4.2	6
	Allowable rolling moment	Mr	N·m	7.3	12.7
Finger	Max. weight (1 pair)		g	40	80
	Max. holding position	L	mm	30	30
	Max. overhang	H	mm	20	20

• Mount the finger so that the allowable load and load moment of the guide do not exceed the values stated in the table above.  
 • Make the adjustment so that the finger weight, holding length (L) from the installation surface to the holding point, and overhang (H) do not exceed the values stated in the table above.  
 • Please contact your YAMAHA sales dealer for further information on combination of L and H.


## Gripping power vs. gripping power setting (%)



• Graph shows a general guide to gripping power versus gripping power setting (%). Variations will appear in the actual gripping power.



## YRG-2020FT/2840FT




Note. Avoid extreme winding of the cable and fix the cable securely so that it does not move.  
 Take appropriate measures so that any excessive force is not applied to the root of the cable.

	A	B	C	D	E	ED	F	G	H	J	JA	K	L	M	N	P		
YRG-2020FT	22	12	12	2	14 <sub>0-0.05</sub>	25	39	10.5 to 29.5	φ3 <sub>0-0.01</sub>	6	12	12	4.5	27.5	M3	5		
YRG-2840FT	30	15	16	2	18 <sub>0-0.05</sub>	30	52	13 to 51	φ4 <sub>0-0.012</sub>	8	14	14	5.5	34.5	M4	7.5		
	Q	R	RA	S	SA	SB	T	TA	TB	TC	TD	TE	U	V	W	Y	Z	ZA
YRG-2020FT	30	76	175+/-10	27	27	4	24	9	24	30	12.5	12.5	M4	6	60	38	2	9
YRG-2840FT	40	110	135+/-10	40	40	5	28	12	28	36	14	14	M5	7.5	72	55	3	12

# YRG Series

Three fingers type

# YRG-2004T



## Basic specifications

Model name	YRG-2004T	
Model number	KCF-M2015-A0	
Holding power	Max. continuous rating (N)	2.5
	Min. setting (% (N))	30 (0.75)
	Resolution (% (N))	1 (0.025)
Open/close stroke (mm)	3.5	
Speed	Max. rating (mm/sec)	100
	Min. setting (% (mm/sec))	20 (20)
	Resolution (% (mm/sec))	1 (1)
	Holding speed (Max.) (%)	50
Repetitive positioning accuracy (mm)	+/-0.03	
Guide mechanism	Linear guide	
Max. holding weight <sup>Note 1</sup> (kg)	0.02	
Weight (g)	90	


• Holding power control : 30 to 100% (1% steps) • Speed control : 20 to 100% (1% steps)  
 • Acceleration control : 1 to 100% (1% steps) • Multipoint position control : 10,000 max.

Note. Design the finger as short and lightweight as possible.  
 Note. Set the parameters and holding power (%) of the holding movement command so that any excessive shock is not applied to the finger during operation.

Note. When installing or uninstalling the finger, tighten the bolts while the finger is being held securely so that any excessive force or shock is not applied to the guide block.  
 Note. Workpiece weight that is able to be held may greatly vary depending on the material, shape, and/or holding surface conditions of the finger.

Note 1. Design the weight of a workpiece to be held so that it is approximately 1/10 to 1/20 of the holding power. (Consider further allowance when moving and swinging the gripper that keeps holding a workpiece.)

## Gripping power vs. gripping power setting (%)



• Graph shows a general guide to gripping power versus gripping power setting (%). Variations will appear in the actual gripping power.

## Allowable load and load moment

		YRG-2004T	
Finger	Allowable load	N	6
	Allowable pitching moment	N·m	0.02
	Max. weight (1 pair)	g	10
	Max. holding position	L mm	15


• When the external forces  $F_a$  and  $F_b$  are applied to a portion the distance (L) apart from the finger installation surface, the load (F) and moment (M) are calculated from the formulas shown below.

$$F = F_a + W \times g$$


$$M = F_b \times L$$

$F_a$  : External force [N]  
 $F_b$  : External force [N]  
 $W$  : Workpiece weight [Kg]  
 $g$  : Gravity acceleration [m/s<sup>2</sup>]  
 $L$  : Distance of holding point [m]

$F$  : Load [N]  
 $M$  : Moment [N·m]  
 $L$  : Distance of point of external force application [m]



## YRG-2004T



Note. Avoid extreme winding of the cable and fix the cable securely so that it does not move. Take appropriate measures so that any excessive force is not applied to the root of the cable.

Three fingers type

# YRG-2013T/2820T/4230T



## Basic specifications

Model name	YRG-2013T	YRG-2820T	YRG-4230T	
Model number	KCF-M2015-B0	KCF-M2015-C0	KCF-M2015-D0	
Holding power	Max. continuous rating (N)	2	10	20
	Min. setting (% (N))	30 (0.6)	30 (3)	30 (6)
	Resolution (% (N))	1 (0.02)	1 (0.1)	1 (0.2)
Open/close stroke (mm)	13	20	30	
Speed	Max. rating (mm/sec)	100		
	Min. setting (% (mm/sec))	20 (20)		
	Resolution (% (mm/sec))	1 (1)	1 (1)	1 (1)
	Holding speed (Max.) (%)	50	50	50
Repetitive positioning accuracy (mm)	±0.03			
Guide mechanism	Linear guide			
Max. holding weight <sup>Note 1</sup> (kg)	0.02	0.1	0.2	
Weight (g)	190	340	640	

- Holding power control: 30 to 100% (1% steps) • Speed control: 20 to 100% (1% steps)
- Acceleration control: 1 to 100% (1% steps) • Multipoint position control: 10,000 max.

Note. Design the finger as short and lightweight as possible.  
 Note. Set the parameters and holding power (%) of the holding movement command so that any excessive shock is not applied to the finger during operation.  
 Note. When installing or uninstalling the finger, tighten the bolts while the finger is being held securely so that any excessive force or shock is not applied to the guide block.  
 Note. Workpiece weight that is able to be held may greatly vary depending on the material, shape, and/or holding surface conditions of the finger.

Note 1. Design the weight of a workpiece to be held so that it is approximately 1/10 to 1/20 of the holding power. (Consider further allowance when moving and swinging the gripper that keeps holding a workpiece.)

## Allowable load and load moment

		YRG-2013T	YRG-2820T	YRG-4230T	
Finger	Allowable load	N	20	30	50
	Allowable pitching moment	N·m	0.1	0.2	0.4
	Max. weight (1 pair)	g	20	30	50
	Max. holding position	L mm	20	30	40


• When the external forces Fa and Fb are applied to a portion the distance (L) apart from the finger installation surface, the load (F) and moment (M) are calculated from the formulas shown below.

$$F = Fa + W \times g$$


$$M = Fb \times L$$

Fa : External force [N]  
 Fb : External force [N]  
 W : Workpiece weight [Kg]  
 g : Gravity acceleration [m/s<sup>2</sup>]  
 L : Distance of holding point [m]

## Gripping power vs. gripping power setting (%)



• Graph shows a general guide to gripping power versus gripping power setting (%). Variations will appear in the actual gripping power.



## YRG-2013T/2820T/4230T

Note. Avoid extreme winding of the cable and fix the cable securely so that it does not move. Take appropriate measures so that any excessive force is not applied to the root of the cable.

	A	B	C	D	E	F	G	H	HA	HB	J	K	L	N
YRG-2013T	50	19	34	24	50	19	42	17	13	13	17	M3	6	17
YRG-2820T	58	19	46	32	66	25	40	24	16	16	24	M4	8	14
YRG-4230T	59	25	60	46	86	34	45	25	18	18	36	M5	8	13

	NA	NB	P	Q	R	S	T	U	V	W	WA	AA	BA
YRG-2013T	17	72	27	M3	6	17	17	M3	5	11.4 to 4.6	6.8st	12	10 <sup>0</sup> <sub>-0.02</sub>
YRG-2820T	21	80	38	M4	8	24	24	M4	6	15.9 to 5.6	10.3st	15	10 <sup>0</sup> <sub>-0.02</sub>
YRG-4230T	24	88	50	M5	10	36	36	M5	7.5	21.9 to 6.6	15.3st	20	14 <sup>0</sup> <sub>-0.02</sub>

	BB	BC	BD	BE	BF	BG	BH	BJ	BK	BL
YRG-2013T	16	2.5	10	***	3x1-M3	8	2	φ3 <sup>0</sup> <sub>-0.01</sub>	165±/10	8.3
YRG-2820T	19.5	2.5	6	8	3x2-M3	6	2	φ3 <sup>0</sup> <sub>-0.01</sub>	140±/10	9.3
YRG-4230T	22.5	2.5	6	10	3x2-M4	8	3	φ4 <sup>0</sup> <sub>-0.012</sub>	235±/10	10.8

Articulated robots  
YA  
Linear COMEYO robot modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XY-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER  
INFORMATION  
Robot positioner  
Pulse string driver  
Robot controller  
Electric gripper  
Option

## Electric gripper basic specifications

Item		Specifications	
Basic specifications	Applicable controller	RCX240/RCX240S	RCX340
	Number of connection grippers	Max. 2 units (One unit per slot, max. 2 slots)	Max. 4 units
Axis control	Control method	PTP motion	
	Min. setting unit	0.01mm	
	Position indication unit	Pulses, mm (millimeters)	
	Speed setting	20 to 100% (in 1% steps, Changeable by the program.)	
Programming	Acceleration setting	1 to 100% (in 1% steps, Setting by the acceleration parameter)	
	Teaching	MDI (coordinate data input), direct teaching, teaching playback, offline teaching (data input from external unit)	

## Gripper control board specifications

Item		Specifications	
Axis control	No. of axes	1 axis	
	Position detection method	Optical rotary encoder	
	Min. setting distance	0.01mm	
	Speed setting	Set in the range of 20 to 100% to the max. parameter speed.	
Protective alarm		Overcurrent, overload, voltage failure, system failure, position deviation over, feedback error, etc.	
LED status indication		POWER (Green), RUN (Green), READY (Yellow), ALARM (Red)	
Power supply	Drive power	DC 24V +/-10% 1.0A Max.	

## Part names and functions

### RCX240





Figure when viewed from the front of the controller



### RCX340





Figure when viewed from the front of the controller



# Accessories and part options

## YRG Series



### Standard accessories

● **Gripper control board**

Model	For RCX240/RCX240S	KX0-M4400-F1	<b>RCX240/S</b>
	For RCX340	KCX-M4400-G0	<b>RCX340</b>

Note. This board includes a 24V supply connector.

● **Robot (for gripper) cable**



Model	3.5m	KCF-M4751-31	<b>RCX240/S</b> <b>RCX340</b>
	5m	KCF-M4751-51	
	10m	KCF-M4751-A1	

Note. Be sure to adjust the total length of the robot (for gripper) cable and relay cable to 14m or less.

● **Relay cable**



Model	0.5m	KCF-M4811-11	<b>RCX240/S</b> <b>RCX340</b>
	1m	KCF-M4811-21	
	1.5m	KCF-M4811-31	
	2m	KCF-M4811-41	
	2.5m	KCF-M4811-51	
	3m	KCF-M4811-61	
	3.5m	KCF-M4811-71	
	4m	KCF-M4811-81	

● **Connector for 24V power supply**



Model	KCF-M5382-00	<b>RCX240/S</b> <b>RCX340</b>
-------	--------------	----------------------------------

● **Connector for gripper emergency stop**



Model	KCF-M5370-00	<b>RCX240/S</b>
-------	--------------	-----------------

Note. Not included with the RCX340.

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XX-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER
- INFORMATION
- Robot positioner
- Pulse string driver
- Robot controller
- Electric gripper
- Option

# MEMO

---

---

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

Robot  
positioner

Pulse string  
driver

Robot  
controller

IVY/IVZ  
Electric  
gripper

Option



# ALL TYPES OF INFORMATION

# INFORMATION

## CONTENTS

### CABLE

Robot cable table	594
Single-axis robot cable	594
Multi-robot cable	598
Cartesian robot cable	600
SCARA robot cable	601
Gripper cable	601
Cable terminal table	602
PHASER relay cable	602
Connector converter cable	603
Programming box converter cable	603
I/O control converter cable	603

### TECHNICAL

TRANSERVO RF type model selection	604
Selecting a model	604
List of moment of inertia calculation formulas (Calculation of moment of inertia I)	605
Kinds of loads	605
R-axis tolerable moment of inertia and acceleration coefficient	606
Acceleration coefficients for inertia moment in each SCARA robot YK-X series model	606
How to find the inertia moment	611
Example of moment of inertia calculation	612
External safety circuit examples	613
Circuit configuration examples (TS-X/TS-P)	613

Circuit configuration examples (SR1)	614
Circuit configuration examples (RCX240)	615

### INFORMATION

Cautions regarding CE specifications	616
CE marking	616
Cautions regarding compliance with EC Directives	616
Applicable directives and their related standards	616
Installation of external safety circuits	616
Compliance with EMC Directives	616
Cautions regarding official language of EU countries	616
Cautions on KCs (Korean Certificate Safety) specifications	617
About KCs	617
About measures for KCs	617
List of robots subject to KCs	617
Cautions on Korean EMC specifications	619
About Korean KC	619
About Korean KC compliance	619
List of KC compliant robots	619
About non-compliant models	619
Warranty	620
This warranty does not cover any failure caused by:	620
The following cases are not covered under the warranty:	620

Repeatability positioning accuracy	621
Factors involving absolute accuracy	621
Operating pattern factors	621
Temperature factors	621
Fluctuating load factors	621

# Robot cable table

The robot cable is a cable joining the robot to the controller.

## Single-axis robot cable

### TS-S/TS-S2/TS-SD cable


#### [Flexible cable]

Connected robot ▷ **TRANSERVO**

Set	Single item	
-	Composite wire	KCK-M4751-□ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
1	1m
3	3m
5	5m
A	10m



### TS-S2S cable


#### [Flexible cable]

Connected robot ▷ **TRANSERVO**  
(RF Type Sensor specification)

Set	Single item	
-	Composite wire	KCK-M4752-□ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
1	1m
3	3m
5	5m
A	10m



### TS-X cable



#### [Standard cable]

Connected robot ▷ **FLIP-X**

Set	Single item	
KBY-M4710-□ 0	Signal wire	KBY-M4751-□ 0
	Motor wire	KX7-M4752-□ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m





#### [Flexible cable]

Connected robot ▷ **FLIP-X**

Set	Single item	
KBY-M4720-□ 0	Signal wire	KBY-M4755-□ 0
	Motor wire	KX7-M4752-□ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



**TS-P cable**

**[Standard cable]**


Connected robot ▷ PHASER

Set	Single item	
KBS-M4710-□ 0	Signal wire	KBS-M4751-□ 1
	Motor wire	KAU-M4752-□ 1

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m

**[Signal wire]**




**[Flexible cable]**

Connected robot ▷ PHASER


Set	Single item	
KBS-M4720-□ 0	Signal wire	KBS-M4755-□ 1
	Motor wire	KAU-M4752-□ 1

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



**[Motor wire]**



**RDV-X cable (No-brake specifications)**

**[Standard cable]**


Connected robot ▷ FLIP-X

Set	Single item	
KEF-M4710-□ 0	Signal wire	KBH-M4751-□ 0
	Motor wire	KEF-M4752-□ 0
	I/O connector	KBH-M4420-00

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m

**[Signal wire]**




**[Flexible cable]**

Connected robot ▷ FLIP-X


Set	Single item	
KEF-M4730-□ 0	Signal wire	KBH-M4756-□ 0
	Motor wire	KEF-M4752-□ 0
	I/O connector	KBH-M4420-00

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



**[Motor wire]**



# Robot cable table

## RDV-X cable (models with brake and sensor)

### [Standard cable]


Connected robot ▷ FLIP-X

Set	Single item
KEF-M4720-□ 0	Signal wire KBH-M4753-□ 0
	Motor wire KEF-M4752-□ 0
	ORG, BK wires KBH-M4421-00

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m

### [Signal wire]




### [Flexible cable]

Connected robot ▷ FLIP-X


Set	Single item
KEF-M4740-□ 0	Signal wire KBH-M4757-□ 0
	Motor wire KEF-M4752-□ 0
	ORG, BK wires KBH-M4421-00

Note. Notation within slot in model types is as shown at right.


Within □	Cable length
3	3.5m
5	5m
A	10m



### [ORG, BK wires]



### [Motor wire]



## RDV-P cable

### [Standard cable]


Connected robot ▷ PHASER

Set	Single item
KEF-M4711-□ 0	Signal wire KBH-M4754-□ 1
	Motor wire KEF-M4755-□ 0
	I/O connector KBH-M4420-00

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m

### [Signal wire]




### [Flexible cable]

Connected robot ▷ PHASER


Set	Single item
KEF-M4712-□ 0	Signal wire KBH-M4758-□ 0
	Motor wire KEF-M4755-□ 0
	I/O connector KBH-M4420-00

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



### [Motor wire]



**SR1-X cable**

**[Standard cable]**


Connected robot ▷ **FLIP-X**

Set	Single item	
KX7-M4710-□ 0	Signal wire	KX7-M4751-□ 1
	Motor wire	KX7-M4752-□ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m

**[Signal wire]**




**[Flexible cable]**

Connected robot ▷ **FLIP-X**


Set	Single item	
KX7-M4720-□ 0	Signal wire	KX7-M4755-□ 0
	Motor wire	KX7-M4752-□ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



**[Motor wire]**



**SR1-P cable**

**[Standard cable]**



Connected robot ▷ **PHASER**

Set	Single item	
KAU-M4710-□ 0	Signal wire	KAU-M4751-□ 4
	Motor wire	KAU-M4752-□ 1

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m

**[Signal wire]**



**[Flexible cable]**


Connected robot ▷ **PHASER**

Set	Single item	
KAU-M4720-□ 0	Signal wire	KAU-M4755-□ 0
	Motor wire	KAU-M4752-□ 1

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m

**[Motor wire]**



# Robot cable table

## ERCD / ERCX cable


### [Standard cable]

Connected robot ▷ **FLIP-X**

Set	Single item
-	Composite wire KX1-M4751- □ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
1	1m
3	3.5m
5	5m
A	10m




### [Flexible cable]

Connected robot ▷ **FLIP-X**

Set	Single item
-	Composite wire KX1-M4752- □ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
1	1m
3	3.5m
5	5m
A	10m



## Multi-robot cable

### Single axis multi-robot cable



### [Flexible cable]

Connected controller ▷ **RCX240**

Robot	Cable type
FLIP-X	KX7-M4754- □ 0
PHASER	KAU-M4757- □ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



2-axes multi-robot cable


[Flexible cable]

Connected controller ▷ • RCX221/RCX222  
• RCX240/RCX340  
• DRCX

Robot combinations		Cable type
First axis	Second axis	
FLIP-X	FLIP-X	KX7-M4753-□ 1

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m




[Flexible cable]

Connected controller ▷ RCX221 / RCX240

Robot combinations		Cable type
First axis	Second axis	
PHASER	PHASER	KAU-M4753-□ 2

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m




[Flexible cable]

Connected controller ▷ RCX221 / RCX240

Robot combinations		Cable type
First axis	Second axis	
PHASER	FLIP-X	KAU-M4754-□ 2

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m




[Flexible cable]

Connected controller ▷ RCX221 / RCX240

Robot combinations		Cable type
First axis	Second axis	
FLIP-X	PHASER	KAU-M4756-□ 2

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



# Cartesian robot cable

## Cartesian 2-axes cable


**[Standard cable]**

Connected controller ▷ **DRCX / RCX222 / RCX340**

**Type** KT6-M4751-□ 1

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



## Cartesian 3-axes cable


**[Standard cable]**

Connected controller ▷ **RCX142 / RCX240 / RCX340**

**Type** KT6-M4755-□ 0

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m



## Cartesian 4-axes cable


**[Standard cable]**

Connected controller ▷ **RCX142 / RCX240 / RCX340**

**Type** KT6-M4752-□ 1

Note. Notation within slot in model types is as shown at right.

Within □	Cable length
3	3.5m
5	5m
A	10m





# SCARA robot cable

Note. SCARA robot cables all use the same size connectors but different models use different cables.

## [Standard cable]

Connected robot ▷ • **YK-XG (No including YK120XG / YK150XG / YK180XG)**

- YK-XGS
- YK-TW
- YK400XR

Cable length	Type
3.5m	KBF-M6211-00
5m	KBF-M6211-10
10m	KBF-M6211-20

Connected robot ▷ • **YK120XG**  
• **YK150XG**  
• **YK180XG**

Cable length	Type
2m	KCB-M6211-31
3.5m	KCB-M6211-01
5m	KCB-M6211-11
10m	KCB-M6211-21

Connected robot ▷ • **YK-XGP**  
• **YK-XGC**

Cable length	Type
3.5m	KDP-M6211-00
5m	KDP-M6211-10
10m	KDP-M6211-20

Connected robot ▷ • **YK-XC (Large type)**  
• **YK-XS**  
• **YK-XP**


Cable length	Type
3.5m	KN3-M6211-00
5m	KN3-M6211-10
10m	KN3-M6211-20

Connected robot ▷ • **YK1200X**

Cable length	Type
3.5m	KN6-M6211-00
5m	KN6-M6211-10
10m	KN6-M6211-20

Connected robot ▷ • **YK180X**  
• **YK220X**  
• **YK180XC**  
• **YK220XC**

Cable length	Type
3.5m	KBE-M6211-00
5m	KBE-M6211-10
10m	KBE-M6211-20



# Gripper cable

Note. Be sure to adjust the total length of the robot (for gripper) cable and relay cable to 14m or less.

## ● Robot cable

[Flexible cable]



Cable length	Type
3.5m	KCF-M4751-31
5m	KCF-M4751-51
10m	KCF-M4751-A1

## ● Relay cable

[Flexible cable]

Type	KCF-M4811-□ 1
------	---------------

Within □	1	2	3	4	5	6	7	8
Length (mm)	0.5	1	1.5	2	2.5	3	3.5	4



Articulated robots  
YA  
Linear conveyor modules  
LCM100  
Compact single-axis robots  
TRANSEVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
CABLE  
TECHNICAL INFORMATION

# Cable terminal table


This is a relay cable used between the robot body and the robot cable such cable carrier wiring, etc.

## PHASER relay cable

Motor wire (350mm to 1450mm) Note. Common to MR types and MF types

Type	KAU-M4813-□ 0
------	---------------


Within □	1	2	3	4	5	6	7	8	9	A	B	C
Length (mm)	350	450	550	650	750	850	950	1050	1150	1250	1350	1450



Motor wire (1500mm to 2600mm) Note. Not usable on MR type

Type	KBD-M4813-□ 0
------	---------------


Within □	6	7	8	9	A	B	C	D	E	F	G	M
Length (mm)	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600



Signal cable (350mm to 1450mm) Note. Common to MR types and MF types

Type	KAU-M4812-□ 1
------	---------------


Within □	1	2	3	4	5	6	7	8	9	A	B	C
Length (mm)	350	450	550	650	750	850	950	1050	1150	1250	1350	1450



Signal cable (1500mm to 2600mm) Note. Common to MR types and MF types


Type	KBD-M4812-□ 1
------	---------------

Within □	6	7	8	9	A	B	C	D	E	F	G	J
Length (mm)	1500	1600	1700	1800	1900	2000	2100	2200	2300	2400	2500	2600




# Connector converter cable

## Programming box converter cable




Converter cable for operating the RCX40, RCX141, RCX142 by RPB.

Type	KAS-M5151-10
------	--------------




## I/O control converter cable




Converter cable allows connecting to the SRCX connector when system using the SRCX was changed to the SR1-X.

External power supply is used for the I/O power supply.




Type	KBG-M533G-B0
------	--------------

Internal power supply of the SRCX is used for the I/O power supply.




Note. It is necessary to input the 24V-power supply from the outside.

Type	KBG-M533G-C0
------	--------------



Converter cable allows connecting to the SRCP connector when system using the SRCP was changed to the SR1-P.



Type	KBG-M533G-A0
------	--------------

Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN

CONTROLLER INFORMATION


CABLE

TECHNICAL INFORMATION

# TRANSERVO RF type model selection

## Selecting a model

### Operating conditions



Rotary type: RF03  
 Installation posture: Horizontal  
 Kind of load: Inertial load  $T_a$   
 Shape of load: 150 mm x 80 mm  
 (rectangular plate)  
 Oscillating angle  $\theta$ : 180°

Acceleration/deceleration  $\dot{\omega}$ : 1,000 °/sec<sup>2</sup>  
 Speed  $\omega$ : 420 °/sec  
 Load mass  $m$ : 2.0 kg  
 Distance between shaft and center of gravity  $H$ : 40 mm

### Step 1 Moment of inertia Acceleration/deceleration

- Calculating the moment of inertia.
- Checking the moment of inertia vs. acceleration/deceleration. Select an appropriate model from the moment of inertia vs. acceleration/deceleration while referring to the moment of inertia vs. acceleration/deceleration graph.


#### Calculation formula

$$I = m \times (a^2 + b^2) / 12 + m \times H^2$$

#### Selection example

$$I = 2.0 \times (0.15^2 + 0.08^2) / 12 + 2.0 \times 0.04^2 = 0.00802 \text{ kg} \cdot \text{m}^2$$

#### RF03



### Step 2 Selecting a torque

- Kinds of loads
  - Static load:  $T_s$
  - Resistance load:  $T_f$
  - Inertial load:  $T_a$
- Checking the effective torque  
 Check that the speed can be controlled by the effective torque by the speed while referring to the effective torque vs. speed graph.


#### Calculation formula

$$\begin{aligned} \text{Effective torque} &\geq T_s \\ \text{Effective torque} &\geq T_f \times 1.5 \\ \text{Effective torque} &\geq T_a \times 1.5 \end{aligned}$$

#### Selection example

$$\begin{aligned} \text{Inertial load: } T_a \\ T_a \times 1.5 &= I \times \dot{\omega} \times 2\pi / 360 \times 1.5 \\ &= 0.00802 \times 1,000 \times 0.0175 \times 1.5 \\ &= 0.21 \text{ N} \cdot \text{m} \end{aligned}$$

#### RF03



### Step 3 Allowable load

- Checking the allowable load
  - Radial load
  - Thrust load
  - Moment

#### Calculation formula

$$\begin{aligned} \text{Allowable thrust load} &\geq m \times 9.8 \\ \text{Allowable moment} &\geq m \times 9.8 \times H \end{aligned}$$

#### Selection example


$$\begin{aligned} \text{Thrust load} \\ 2.0 \times 9.8 &= 19.6 \text{ N} < \text{Allowable load OK} \\ \text{Allowable moment} \\ 2.0 \times 9.8 \times 0.04 \\ &= 0.784 \text{ N} \cdot \text{m} < \text{Allowable moment OK} \end{aligned}$$

List of moment of inertia calculation formulas (Calculation of moment of inertia I)

I: Moment of inertia m: Load mass


1 Thin rod

Position of rotation axis:  
Passes through one end perpendicularly to the rod.




2 Thin rod

Position of rotation axis:  
Passes through the center of gravity of the rod.




3 Thin rectangular plate (rectangular parallelepiped)

Position of rotation axis:  
Passes through the center of gravity of the rod.




4 Thin rectangular plate (rectangular parallelepiped)

Position of rotation axis:  
Passes through one end perpendicularly to the plate.  
(Same position for the rectangular parallelepiped with the plate thickened.)




5 Thin rectangular plate (rectangular parallelepiped)

Position of rotation axis:  
Passes through one end perpendicularly to the plate.  
(Same position for the rectangular parallelepiped with the plate thickened.)




6 Cylinder (including thin disc)

Position of rotation axis:  
Central axis




7 Solid ball

Position of rotation axis:  
Diameter




8 Thin disc

Position of rotation axis:  
Diameter




9 Load at lever tip



$I = m_1 \cdot \frac{a_1^2}{3} + m_2 \cdot a_2^2 + K$   
(Example)  
When the shape of  $m_2$  is a ball, refer to [7] to obtain the following.  
 $K = m_2 \cdot \frac{2r^2}{5}$

10 Gear transmission



1. Calculate the moment of inertia  $I_B$  around the (B) axis.
2. Next, substitute  $I_B$  for the moment of inertia around the (A) axis to calculate  $I_A$  as follows.

$I_A = (\frac{a}{b})^2 \cdot I_B$

Kinds of loads

Kinds of loads		
Static load: Ts	Resistance load: Tf	Inertial load: Ta
Only push force is needed (clamp, etc.).	Gravity or friction force applies in the rotation direction.	Load with inertia needs to be rotated.
	<Gravity applies.> 	<Rotation center matches to the gravity of the load.> 
$T_s = F \cdot L$ Ts : Static load (N·m) F : Clamp force (N) L : Distance from oscillating center to clamp position (m)	<Friction force applies.> 	<Rotation axis is in the vertical direction.> 
Gravity applies in the rotation direction. $T_f = m \cdot g \cdot L$ Tf : Resistance load (N·m) m : Mass of load (kg) g : Gravity acceleration 9.8 (m/s <sup>2</sup> ) L : Distance from oscillating center to gravity or friction force action point (m) μ : Friction coefficient	Friction force applies in the rotation direction. $T_f = \mu \cdot m \cdot g \cdot L$	$T_a = I \cdot \dot{\omega} \cdot 2\pi / 360$ ( $T_a = I \cdot \dot{\omega} \cdot 0.0175$ ) Ta : Inertial load (N·m) I : Moment of inertia (kg·m <sup>2</sup> ) ω̇ : Acceleration/deceleration (°/sec <sup>2</sup> ) ω : Speed (°/sec)
Required torque T = Ts	Required torque T = Tf × 1.5 (Note 1)	Required torque T = Ta × 1.5 (Note 1)
<p>• Load becomes the resistance load. Gravity or friction force applies in the rotation direction.</p> <p>Example 1) The rotation center of the rotation axis does not match to the center of gravity of the load in the horizontal direction.</p> <p>Example 2) The load slips on the floor to move it. The required torque is the total of the resistance load and inertial load. <math>T = (T_f + T_a) \times 1.5</math></p>		<p>• Load does not become the resistance load. Gravity or friction force does not apply in the rotation direction.</p> <p>Example 1) The rotation axis is vertical.</p> <p>Example 2) The rotation center of the rotation axis does not match to the center of gravity of the load in the horizontal direction. The required torque is only the inertial load. <math>T = T_a \times 1.5</math></p> <p>Note 1) An allowance is required for Tf and Ta to make the speed adjustment.</p>

Articulated robots  
YA  
Linear conveyor modules  
LCM100  
compact single-axis robots  
TRANSERVO  
Single-axis robots  
FLIP-X  
Linear motor single-axis robots  
PHASER  
Cartesian robots  
XX-X  
SCARA robots  
YK-X  
Pick & place robots  
YP-X  
CLEAN  
CONTROLLER INFORMATION  
CABLE  
TECHNICAL INFORMATION

# R-axis tolerable moment of inertia and acceleration coefficient

The RCX340 automatically specifies the acceleration coefficient according to the parameter settings.

The moment of inertia of a load (end effector and workpiece) that can be attached to the R-axis is limited by the strength of the robot drive unit and residual vibration during positioning. It is therefore necessary to reduce the acceleration coefficient in accordance with the moment of inertia.

**[Example: YK500XG]**

If there is a payload of 1.5kg installed on the R axis then the inertia moment in the R axis vicinity is 0.1kgm<sup>2</sup> (1.0kgfcmsec<sup>2</sup>). The tip payload set at this time is 2kg. As shown on the graph, the robot can be operated with the X axis, Y axis and R axis acceleration coefficients reduced to 62%. Always select a tip payload and acceleration coefficient parameter that matches the payload and inertia moment before operating the robot. See your "YAMAHA Robot Controller Instruction Manual" when setting the tip payload and acceleration coefficient.


Note. The method for calculating the inertia moment load is shown on P.611. However, making an accurate calculation is difficult. If the actual inertia moment is larger than the calculated value and the robot is set for that calculated value then residual vibrations might occur. If this happens, reduce the acceleration coefficient parameter more.

**CAUTION**


- The robot must be operated with correct tolerable moment of inertia and acceleration coefficients according to the manipulator tip mass and moment of inertia. If this is not observed, premature end to the life of the drive units, damage to the robot parts or residual vibration during positioning may result.
- Depending on the Z-axis position, vibration may occur when the X, Y or R-axis moves. If this happens, reduce the X, Y or R-axis acceleration to an appropriate level.
- If the moment of inertia is too large, vibration may occur on the Z-axis depending on its operation position. If this happens, reduce the Z-axis acceleration to an appropriate level.

## Acceleration coefficients for inertia moment in each SCARA robot YK-X series model


**YK350TW**





**YK500TW**






**YK120XG**



**YK150XG**




**YK180XG**




Graph notation description  
 Ax, Ay, AR ⇒ Acceleration coefficient for X axis, Y axis, R axis  
 Ir, Jr ⇒ Inertia moment in R axis load vicinity  
 m ⇒ Tip payload

# R-axis tolerable moment of inertia and acceleration coefficient


## YK180X / YK220X




## YK250XG/YK250XGP/YK250XGC




## YK250XH



## YK350XG/YK350XGP/YK350XGC/YK300XGS



## YK350XH




### Graph notation description

Ax, Ay, AR  $\Rightarrow$  Acceleration coefficient for X axis, Y axis, R axis  
 Ir, Jr  $\Rightarrow$  Inertia moment in R axis load vicinity  
 m  $\Rightarrow$  Tip payload


Articulated robots  
 YA  
 Linear conveyor modules  
 LCM100  
 Compact single-axis robots  
 TRANSERVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XX-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER INFORMATION  
 CABLE  
 TECHNICAL INFORMATION

# R-axis tolerable moment of inertia and acceleration coefficient


## YK400XG/YK400XGP/YK400XGC/YK400XGS




## YK400XH



## YK500XGL/YK500XGLP/YK500XGLC



## YK600XGL/YK600XGLP/YK600XGLC




**Graph notation description**  
 Ax, Ay, AR → Acceleration coefficient for X axis, Y axis, R axis  
 Ir, Jr → Inertia moment in R axis load vicinity  
 m → Tip payload




# R-axis tolerable moment of inertia and acceleration coefficient

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XX-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- CABLE
- TECHNICAL INFORMATION
- INFORMATION


## YK500XG/YK500XGS/YK500XGP




## YK600XG/YK600XGS/YK600XGP




## YK600XGH/YK600XGHP



## YK700XG/YK700XGS/YK700XGP/YK800XG/YK800XGS/YK800XGP



## YK900XG/YK900XGS/YK900XGP/YK1000XG/YK1000XGS/YK1000XGP












### Graph notation description

- Ax, Ay, AR → Acceleration coefficient for X axis, Y axis, R axis
- Ir, Jr → Inertia moment in R axis load vicinity
- m → Tip payload

# R-axis tolerable moment of inertia and acceleration coefficient

## YK1200X

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- CABLE
- TECHNICAL INFORMATION
- INFORMATION



**Graph notation description**

Ax, Ay, AR → Acceleration coefficient for X axis, Y axis, R axis  
 Ir, Jr → Inertia moment in R axis load vicinity  
 m → Tip payload

## How to find the inertia moment

The tool and work are not usually a simple shape so calculating the inertia moment is not easy.

As a method, the load is replaced with several factors that resemble a simple form for which the moment of inertia can be calculated. The total of the moment of inertia for these factors is then obtained. The objects and equations often used for the calculation of the moment of inertia are shown below. Incidentally, there is the following relation:  $J \text{ (kgfcmsec}^2\text{)} = I \text{ (kgm}^2\text{)} \times 10.2$

### [1] Moment of inertia for material particle

The equation for the moment of inertia for a material particle that has a rotation center such as shown in Fig. ①

① is as follows: This is used as an approximate equation when  $x$  is larger than the object size.

$$I = mx^2 \text{ (kgm}^2\text{)}$$

$$J = \frac{Wx^2}{g} \text{ (kgfcmsec}^2\text{)} \quad \dots (3.1)$$

$g$  : Gravitational acceleration (cm/sec<sup>2</sup>)  
 $m$  : Mass of material particle (kg)  
 $W$  : Weight of material particle (kgf)




Fig.①

### [2] Moment of inertia for cylinder (part 1)

The equation for the moment of inertia for a cylinder that has a rotation center such as shown in Fig. ② is given below.

$$I = \frac{\rho \pi D^2 h}{32} = \frac{mD^2}{8} \text{ (kgm}^2\text{)}$$

$$J = \frac{\rho \pi D^2 h}{32g} = \frac{WD^2}{8g} \text{ (kgfcmsec}^2\text{)} \quad \dots (3.2)$$

$\rho$  : Density (kg/m<sup>3</sup>, kg/cm<sup>3</sup>)  
 $g$  : Gravitational acceleration (cm/sec<sup>2</sup>)  
 $m$  : Mass of cylinder (kg)  
 $W$  : Weight of cylinder (kgf)




Fig.②

### [3] Moment of inertia for cylinder (part 2)

The equation for the moment of inertia for a cylinder that has a rotation center such as shown in Fig. ③ is given below.

$$I = \frac{\rho \pi D^2 h}{16} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) = \frac{m}{4} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) \text{ (kgm}^2\text{)}$$

$$J = \frac{\rho \pi D^2 h}{16g} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) = \frac{W}{4g} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) \text{ (kgfcmsec}^2\text{)} \quad \dots (3.3)$$

$\rho$  : Density (kg/m<sup>3</sup>, kg/cm<sup>3</sup>)  
 $g$  : Gravitational acceleration (cm/sec<sup>2</sup>)  
 $m$  : Mass of cylinder (kg)  
 $W$  : Weight of cylinder (kgf)




Fig.③

### [4] Moment of inertia for prism

The equation for the moment of inertia for a prism that has a rotation center as shown in Fig. ④ is given as follows.

$$I = \frac{\rho abc (a^2 + b^2)}{12} = \frac{m (a^2 + b^2)}{12} \text{ (kgm}^2\text{)}$$

$$J = \frac{\rho abc (a^2 + b^2)}{12g} = \frac{W (a^2 + b^2)}{12g} \text{ (kgfcmsec}^2\text{)} \quad \dots (3.4)$$

$\rho$  : Density (kg/m<sup>3</sup>, kg/cm<sup>3</sup>)  
 $g$  : Gravitational acceleration (cm/sec<sup>2</sup>)  
 $m$  : Mass of prism (kg)  
 $W$  : Weight of prism (kgf)




Fig.④

### [5] When the object's center line is offset from the rotation center

The equation for the moment of inertia, when the center of the cylinder is offset by the distance "x" from the rotation center as shown in Fig. ⑤, is given as follows.

$$I = \frac{\rho \pi D^2 h}{32} + \frac{\rho \pi D^2 hx^2}{4} = \frac{mD^2}{8} + mx^2 \text{ (kgm}^2\text{)}$$

$$J = \frac{\rho \pi D^2 h}{32g} + \frac{\rho \pi D^2 hx^2}{4g}$$

$$= \frac{WD^2}{8g} + \frac{Wx^2}{g} \text{ (kgfcmsec}^2\text{)} \quad \dots (3.5)$$

$\rho$  : Density (kg/m<sup>3</sup>, kg/cm<sup>3</sup>)  
 $g$  : Gravitational acceleration (cm/sec<sup>2</sup>)  
 $m$  : Mass of cylinder (kg)  
 $W$  : Weight of cylinder (kgf)




Fig.⑤

In the same manner, the moment of inertia of a cylinder as shown in Fig. ⑥ is given by

$$I = \frac{\rho \pi D^2 h}{16} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) + \frac{\rho \pi D^2 hx^2}{4} = \frac{m}{4} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) + mx^2 \text{ (kgm}^2\text{)}$$

$$J = \frac{\rho \pi D^2 h}{16g} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) + \frac{\rho \pi D^2 hx^2}{4g}$$

$$= \frac{W}{4g} \left( \frac{D^2}{4} + \frac{h^2}{3} \right) + \frac{Wx^2}{g} \text{ (kgfcmsec}^2\text{)} \quad \dots (3.6)$$




Fig.⑥

In the same manner, the moment of inertia of a prism as shown in Fig. ⑦ is given by

$$I = \frac{\rho abc (a^2 + b^2)}{12} + \rho abc x^2 = \frac{m (a^2 + b^2)}{12} + mx^2 \text{ (kgm}^2\text{)}$$

$$J = \frac{\rho abc (a^2 + b^2)}{12g} + \frac{\rho abc x^2}{g}$$

$$= \frac{W (a^2 + b^2)}{12g} + \frac{Wx^2}{g} \text{ (kgfcmsec}^2\text{)} \quad \dots (3.7)$$

$m$  : Mass of prism (kg)  
 $W$  : Weight of prism (kgf)




Fig.⑦

Articulated robots  
 YA  
 Linear conveyor modules  
 LCM100  
 Compact single-axis robots  
 TRANSERVO  
 Single-axis robots  
 FLIP-X  
 Linear motor single-axis robots  
 PHASER  
 Cartesian robots  
 XX-X  
 SCARA robots  
 YK-X  
 Pick & place robots  
 YP-X  
 CLEAN  
 CONTROLLER INFORMATION  
 INFORMATION  
 CABLE  
 TECHNICAL INFORMATION  
 INFORMATION

## Example of moment of inertia calculation

Let's discuss an example in which the chuck and workpiece are at a position offset by 10cm from the R-axis by a stay, as shown in Fig. ⑧. The moment of inertia is calculated with the following three factors, assuming that the load material is steel and its density  $\rho$  is  $0.0078\text{kg/cm}^3$ .




Fig. ⑧

### [1] Moment of inertia of the stay

From Fig. ⑧, the weight of the stay ( $W_s$ ) is given as follows :

$$W_s = \rho abc = 0.0078 \times 12 \times 2 \times 2 = 0.37 \text{ (kgf)}$$

The moment of inertia of the stay ( $J_s$ ) is then calculated from Eq. 3-7.

$$J_s = \frac{0.37 \times (12^2 + 2^2)}{12 \times 980} + \frac{0.37 \times 5^2}{980} = 0.014 \text{ (kgfcmsec}^2\text{)}$$




Fig. ⑨

### [4] Total weight

$$W = W_s + W_c + W_w = 0.84 \text{ (kgf)}$$

### [5] Total moment of inertia

$$J = J_s + J_c + J_w = 0.062 \text{ (kgfcmsec}^2\text{)}$$

### [2] Moment of inertia of the chuck

When the chuck form resembles that shown in Fig. ⑩, the weight of the chuck ( $W_c$ ) is

$$W_c = 0.0078 \times 2 \times 4 \times 6 = 0.37 \text{ (kgf)}$$

The moment of inertia of the chuck ( $J_c$ ) is then calculated from Eq. 3-7.

$$J_c = \frac{0.37 \times (2^2 + 4^2)}{12 \times 980} + \frac{0.37 \times 10^2}{980} = 0.038 \text{ (kgfcmsec}^2\text{)}$$




Fig. ⑩

### [3] Moment of inertia of workpiece

When the workpiece form resembles that shown in Fig. ⑪, the weight of the workpiece ( $W_w$ ) is

$$W_w = \frac{\rho \pi D^2 h}{4} = \frac{0.0078 \pi \times 2^2 \times 4}{4} = 0.098 \text{ (kgf)}$$

The moment of inertia of the workpiece ( $J_w$ ) is then calculated from Eq. 3-5.

$$J_w = \frac{0.097 \times 2^2}{8 \times 980} + \frac{0.097 \times 10^2}{980} = 0.010 \text{ (kgfcmsec}^2\text{)}$$




Fig. ⑪

# External safety circuit examples


To ensure safe use of the robot, we request the customers make a risk assessment of their end equipment to decide what performance level is needed from safety circuits at the point. Customer should then install a safety circuit at the required performance level.

Here we show examples of category 4 circuits for the TS-X/TS-P, SR1 and RCX240 controllers using a programming box with an enable switch.


Safety circuits for other categories are described in the user's manuals, so download them from our website if needed.

## ■ Circuit configuration examples (TS-X/TS-P)

### General connection diagram



### Category 4



Articulated robots  
YA

Linear conveyor modules  
LCM100

Compact single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor single-axis robots  
PHASER

Cartesian robots  
XX-X

SCARA robots  
YK-X

Pick & place robots  
YP-X

CLEAN


CONTROLLER INFORMATION

CABLE


TECHNICAL INFORMATION

# Circuit configuration examples (SR1)

## General connection diagram




## Category 4




\*1: Wiring to check whether the controller is normal when using an alarm to shut off the main power

# Circuit configuration examples (RCX240)

## General connection diagram



## Category 4



### Parts Table

Circuit No.	Part Name	Circuit No.	Part Name
S1	Reset switch	KM1, 2	Contactor (mirror contact)
S2	Key-selector switch	KA1 to 5 <sup>*1</sup>	Safety relay
S3	Safety door switch	SRL1 to 4	Safety relay unit
S4	Emergency stop switch	SRL5, 6 <sup>*2</sup>	Safety relay unit

\*1. TS-X and TS-P are KA1 to 2.  
\*2. Only TS-X and TS-P.

# Cautions regarding CE specifications

## ■ CE marking

The YAMAHA robot (robot and controller) is one component that is incorporated into the customer's system (built-in equipment), and we declare that the YAMAHA robots conform to the EC Directives only within the scope of built-in equipment (semi-finished product). So, no CE marks are affixed to the YAMAHA robot products.

## ■ Cautions regarding compliance with EC Directives

The YAMAHA robot (robot and controller) is not, in itself, a robot system. The YAMAHA robot-series product is one component that is incorporated into the customer's system (built-in equipment), and we declare that the YAMAHA robots conform to the EC Directives only within the scope of built-in equipment. This does not therefore guarantee that the YAMAHA robot-series product conforms to the EC Directives if only the robot is used independently. The customer who incorporates YAMAHA robot products into the customer's final system, which will be shipped to or used in the European region, should verify that the overall system conforms to the EC Directives.

## ■ Applicable directives and their related standards

Directives applicable to YAMAHA robots and related standards are shown below.

TS-S2 / TS-X / TS-P / SR1-X / SR1-P / RCX221 / RCX222 / RDV-X / RDV-P

EC Directives	Related Standards
Machinery Directive 2006/42/EC	EN ISO12100 EN 60204-1
EMC Directive 2004/108/EC	EN 55011 EN 61000-6-2

RCX240 / RCX340

EC Directives	Related Standards
Machinery Directive 2006/42/EC	EN ISO12100 EN ISO10218-1 EN 60204-1
EMC Directive 2004/108/EC	EN 55011 EN 61000-6-2

## ■ Installation of external safety circuits

To comply with EC directives, customers using YAMAHA robots must always build and install their own external safety circuits after selecting product components (safety relays, etc.) according to performance levels and safety categories required by the customer equipment.

For details about examples of external safety circuits, the user's manual should be referred to.

## ■ Compliance with EMC Directives

In order to conform to the EMC Directives, the customer should evaluate the final system (overall system) and take necessary countermeasures. As examples of EMC countermeasures for single YAMAHA robot product are described in the user's manual, these descriptions should be referred to.

## ■ Cautions regarding official language of EU countries

Only English which is the official language of the EU is utilized in the manuals, warning labels, operating screens, and the Declaration of Incorporation for this product.

If warning text appears on the warning label, then Japanese may also sometimes be listed along with the English.



# Cautions on KCs (Korean Certificate Safety) specifications

## About KCs

KCs is a system that conforms to Korean Industrial Safety and Health Act and self-regulatory safety confirmation declaration of hazardous machines and devices. For machines specified in this system, the KCs mark needs to be indicated after conducting the forced certification or self-regulatory safety confirmation declaration. Industrial robots that have manipulators with 3 or more axes are specified as machines needing the self-regulatory safety confirmation declaration in South Korea's Ministry of Employment and Labor Notification No. 1201-46. Its safety standards are defined in separate table 2 of this notification.

## About measures for KCs

For some YAMAHA robot models, this self-regulatory safety confirmation declaration is conducted to register these models. Additionally, the KCs mark is indicated on the robots that have been declared. When you investigate to purchase a robot to be used in South Korea, check whether or not this robot conforms to KCs and order it with the KCs specifications specified.

The YAMAHA robot is a unit that is incorporated into the customer's system. Therefore, when the customer incorporates the robot into the customer's system, additional safety measures need to be taken. For details, see "Safety standards application guide reference manual".

## List of robots subject to KCs

Robot products may not be applicable to KCs depending on the customer's applications, operating conditions, or environments. Consult YAMAHA before purchasing a product.

Since a self-regulatory safety declaration has not been made for inapplicable models, these models cannot be used in Korea. Special-order robots are also unavailable. For details, please contact YAMAHA.

As of October, 2015  
 ○ : subject to KCs  
 - : not subject to KCs

Product	Type	Model name	KCs registration	
			RCX240 (S)	RCX340
Cartesian robot	FXYx	3 axes	○	○
		4 axes	○	○
	SXYx	3 axes	○	○
		4 axes	○	○
	SXYBx	3 axes	○	○
		4 axes	○	○
	MXYx	3 axes	○	○
		4 axes	○	○
	HXYx	3 axes	○	○
		4 axes	○	○
	NXY	3 axes	-	-
		4 axes	-	-
6 axes		-	-	
SXYxC	3 axes	-	-	
	4 axes	-	-	
Pick & place robot	YP Series	3 axes	-	-
		4 axes	-	-
SCARA robot	YK180X		-	-
	YK220X		-	-
	YK120XG		-	-
	YK150XG		-	-
	YK180XG		-	-
	YK250XG		-	-
	YK350XG		○	-
	YK400XG		-	-
	YK400XR		-	○
	YK500XGL		○	-
	YK600XGL		-	-
	YK700XGL		-	-
	YK500XG		-	-
	YK600XG		-	-
	YK600XGH		-	-
	YK700XG		○	-
	YK800XG		-	-
	YK900XG		-	-
	YK1000XG		-	-
	YK1200X		-	-
YK180XC		-	-	
YK220XC		-	-	

▶ Continues to the next page.



# Cautions on KCs (Korean Certificate Safety) specifications

Product	Type	Model name	KCs registration	
			RCX240 (S)	RCX340
SCARA robot		YK250XGC	○	-
		YK350XGC		
		YK400XGC		
		YK500XGLC		
		YK600XGLC		
		YK300XGS		
		YK400XGS		
		YK500XGS		
		YK600XGS	○	-
		YK700XGS		
		YK800XGS		
		YK900XGS		
		YK1000XGS		
		YK250XGP	○	-
		YK350XGP		
		YK400XGP		
		YK500XGLP		
		YK600XGLP		
		YK500XGP		
		YK600XGP		
		YK600XGHP		
		YK700XGP		
		YK800XGP		
		YK900XGP	-	-
		YK1000XGP		
		YK350TW		
	YK500TW	○	-	

- Articulated robots  
YA
- Linear conveyor modules  
LCM100
- Compact single-axis robots  
TRANSEVO
- Single-axis robots  
FLIP-X
- Linear motor single-axis robots  
PHASER
- Cartesian robots  
XY-X
- SCARA robots  
YK-X
- Pick & place robots  
YP-X
- CLEAN
- CONTROLLER INFORMATION
- CABLE
- TECHNICAL INFORMATION

# Cautions on Korean EMC specifications

## About Korean KC

KC is a system based on the radio regulations of Korea. Devices specified by this system must certify compliance or register compliance, and indicate compliance. Applicable devices are defined by public announcement from the Korean National Radio Research Agency (NRRRA).

## About Korean KC compliance

Some models of YAMAHA robot (robots and controllers) are registered with the Korean National Radio Research Agency (NRRRA) by self-test compliance registration. YAMAHA robots that have already been registered display the KC mark.

If you are considering the purchase of robots to be used in Korea, please check the table below for compliance before ordering the applicable product.

YAMAHA robots are devices for inclusion in a system; therefore, if you, the customer, build a complete system that includes robots, and ship that system as a final product to Korea or use it within Korea, you yourself must verify EMC compliance.

For TS series and TS-SD units, check "Examples of EMC countermeasures" within the user's manual; for other controllers, check this section within the "Safety standards application guide reference manual".

## List of KC compliant robots

- \* Please consult with YAMAHA before purchase, since compliance might not be possible depending on your application, conditions of use, and environment.
- \* In the case of 3-axis or greater Cartesian robots and SCARA robots, the robot must be compliant with both KC and KCs. In conjunction with this table, refer also to the list of KCs compliant robots.

As of January 2016

Product	Model name	Registration number
Controller	ERCD	MSIP-REM-Y3M-ERCD
	TS-S2	MSIP-REM-Y3M-TSS
	TS-SD	MSIP-REM-Y3M-TSSD
	TS-SH	MSIP-REM-Y3M-TSSH
	TS-X	MSIP-REM-Y3M-TSX
	TS-P	MSIP-REM-Y3M-TSP
	RDV-X	MSIP-REM-Y3M-RDVX
	RDV-P	MSIP-REM-Y3M-RDVP
	SR1-X	MSIP-REM-Y3M-SR1X
	SR1-P	MSIP-REM-Y3M-SR1P
	RCX221	MSIP-REM-Y3M-X221
	RCX222	MSIP-REM-Y3M-X222
	RCX240(S)	MSIP-REM-Y3M-X240
	RCX340	MSIP-REM-Y3M-X340
LCC140	MSIP-REM-Y3M-C140	
Robot	TRANSERVO series	MSIP-REM-Y3M-TR
	FLIP-X series	MSIP-REM-Y3M-FXL
		MSIP-REM-Y3M-FX
	PHASER series	MSIP-REM-Y3M-PH
	XY-X series	MSIP-REM-Y3M-XY
	YK series	MSIP-REM-Y3M-YK
Linear conveyor	Linear Conveyor Module	MSIP-REM-Y3M-M100

## About non-compliant models

The following robots are subject to the KC system; however, since self-test compliance registration has not been done at the present time, they cannot be used in Korea. Additionally, special-order robots are also not compliant with the KC system.

Even for the various series listed in the table, some new models might not have been registered.

(Contact YAMAHA for details.)

Pick and place robots: YP-X series

General-purpose assembly base machines: YSC series

For information on the warranty period and terms, please contact our distributor where you purchased the product.

## ■ This warranty does not cover any failure caused by:

1. Installation, wiring, connection to other control devices, operating methods, inspection or maintenance that does not comply with industry standards or instructions specified in the YAMAHA manual;
2. Usage that exceeded the specifications or standard performance shown in the YAMAHA manual;
3. Product usage other than intended by YAMAHA;
4. Storage, operating conditions and utilities that are outside the range specified in the manual;
5. Damage due to improper shipping or shipping methods;
6. Accident or collision damage;
7. Installation of other than genuine YAMAHA parts and/or accessories;
8. Modification to original parts or modifications not conforming to standard specifications designated by YAMAHA, including customizing performed by YAMAHA in compliance with distributor or customer requests;
9. Pollution, salt damage, condensation;
10. Fires or natural disasters such as earthquakes, tsunamis, lightning strikes, wind and flood damage, etc;
11. Breakdown due to causes other than the above that are not the fault or responsibility of YAMAHA;

## ■ The following cases are not covered under the warranty:

1. Products whose serial number or production date (month & year) cannot be verified.
2. Changes in software or internal data such as programs or points that were created or changed by the customer.
3. Products whose trouble cannot be reproduced or identified by YAMAHA.
4. Products utilized, for example, in radiological equipment, biological test equipment applications or for other purposes whose warranty repairs are judged as hazardous by YAMAHA.

THE WARRANTY STATED HEREIN PROVIDED BY YAMAHA ONLY COVERS DEFECTS IN PRODUCTS AND PARTS SOLD BY YAMAHA TO DISTRIBUTORS UNDER THIS AGREEMENT. ANY AND ALL OTHER WARRANTIES OR LIABILITIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY EXPRESSLY DISCLAIMED BY YAMAHA. MOREOVER, YAMAHA SHALL NOT BE HELD RESPONSIBLE FOR CONSEQUENTIAL OR INDIRECT DAMAGES IN ANY MANNER RELATING TO THE PRODUCT.

This manual does not serve as a guarantee of any industrial property rights or any other rights and does not grant a license in any form. Please acknowledge that we bear no liability whatsoever for any problems involving industrial property rights which may arise from the contents of this manual.

# Repeatability positioning accuracy

The “repeatability positioning accuracy” cannot be guaranteed for the accuracy conditions listed below.

## (1) Factors involving absolute accuracy

- Under conditions requiring accuracy between the robot controller internal coordinate position (command position) and real space position (movement position).

## (2) Operating pattern factors

- Under conditions including a motion approaching close to a teaching point (position) from different directions during repeating operation.
- Under conditions where power was turned off or operation was stopped, even when approaching a teaching position from same direction.
- Under conditions where movement to a teaching position uses a hand system (left-handed or right-handed system) different from that during teaching. (SCARA robots)

## (3) Temperature factors

- Under conditions subject to drastic changes in ambient temperature.
- Under conditions where temperature of robot unit fluctuates.

## (4) Fluctuating load factors

- Under conditions where load conditions fluctuate during operation (load fluctuates due to workpiece or no workpiece).

# MEMO

---

---

Articulated robots  
YA

Linear conveyor  
modules  
LCM100

Compact  
single-axis robots  
TRANSEVO

Single-axis robots  
FLIP-X

Linear motor  
single-axis robots  
PHASER

Cartesian  
robots  
XY-X

SCARA  
robots  
YK-X

Pick & place  
robots  
YP-X

CLEAN

CONTROLLER

INFORMATION

CABLE

TECHNICAL

INFORMATION



**2016 Robotics Partner**



**A.T.T.I. Srl**

Via F.lli Cervi,3 - 20063 Cernusco S/N (MI)

Tel. 0292106954 | Fax 0292107261

Email: [info@atti.it](mailto:info@atti.it)

Web: [www.atti.it](http://www.atti.it)