


Ordering method



	X-axis	Y-axis			
Axis construction Note 1	F14H	F14			
AC servo motor output (W)	200	100			
Repeatability Note 2 (mm)	+/-0.01	+/-0.01			
Drive system	Ball screw (Class C7)	Ball screw (Class C7)			
Ball screw lead (Deceleration ratio) (mm)	20	20			
Maximum speed Note 3 (mm/sec)	1200	1200			
Moving range (mm)	150 to 850	150 to 350			
Robot cable length (m)	Standard: 3.5 Option: 5,10				

Maximum payload (kg) Y stroke (mm) XY 2 axes 150 15 14 250 350 13


Note 1. Use caution that the flame machining (installation holes, tap holes) differs from single-axis robots'.

Note 2. Positioning repeatability in one direction.

Note 3. The total of the X and Y strokes should be 1000mm or less.

Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table below.

Controller							
Controller	Operation method						
RCX222	Programming / /O point trace / Remote command / Operation using						
DRCX1005	RS-232C communication						



X stroke No	ite 3	150	250	350	450	550	650	750	850	١
L		470	570	670	770	870	970	1070	1170	١.
К		200	100	200	100	200	100	200	100	
D		240	240	420	420	600	600	780	960	
М		0	1	1	2	2	3	3	4	
N		4	6	6	8	8	10	10	12	
Y stroke No	te 3	150	250	350						N
Maximum speed for each	X-axis			12	00			960	780	. V
stroke (mm/sec) Note 4	Cunned antition							0.00/	650/	


Speed setting

- stopper.

 Note 2. The shaded position indicates an user cable extraction port.
- Note 3. The total of the X and Y strokes should be 1000mm or less.

 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.





960 780 80% 65%

X stroke Note 3	150	250	350	450	550	650	750	850
L	470	570	670	770	870	970	1070	1170
K	200	100	200	100	200	100	200	100
D	240	240	420	420	600	600	780	960
M	0	1	1	2	2	3	3	4
N	4	6	6	8	8	10	10	12
Y stroke Note3	150	250	350					

1200

Maximum speed for each stroke (mm/sec) Note 4 Speed setti

- Note 1. The moving range when returning to origin and the stop position when stopping by the mechanical
- stopper. Note 2. The shaded position indicates an user cable extraction port.
- Note 3. The total of the X and Y strokes should be 1000mm or less.

 Note 4. When the X-axis stroke is longer than 750mm, resonance of the ball screw may occur depending on the operation conditions (critical speed). In this case, reduce the speed setting on the program by referring to the maximum speeds shown in the table at the left.